

**iPECS**

**CLI User Manual**

**ES-4028G / ES-4052G**  
Managed Layer 2 GE Switch

## **ES-4028G MANAGED 24-PORT GE SWITCH**

*Layer 2 Gigabit Ethernet Switch  
with 24 10/100/1000BASE-T (RJ-45) Ports  
and 4 SFP+ 10-Gigabit Slots*

## **ES-4052G MANAGED 24-PORT GE SWITCH**

*Layer 2 Gigabit Ethernet Switch  
with 44 10/100/1000BASE-T (RJ-45) Ports  
and 4 SFP+ 10-Gigabit Slots*

# Table of Contents

<b>1</b>	<b>Preface .....</b>	<b>15</b>
<b>2</b>	<b>User Interface Commands .....</b>	<b>21</b>
	enable .....	21
	disable .....	21
	login .....	22
	configure .....	22
	exit (Configuration) .....	23
	exit (EXEC) .....	23
	end .....	24
	help .....	24
	history .....	25
	history size .....	25
	terminal history .....	26
	terminal history size .....	27
	terminal datadump .....	27
	terminal width .....	28
	terminal prompt .....	28
	debug-mode .....	29
	show history .....	29
	show privilege .....	30
	do .....	30
	banner exec .....	31
	banner login .....	32
	banner motd .....	33
	exec-banner .....	35
	login-banner .....	35
	motd-banner .....	36
	show banner .....	37
<b>3</b>	<b>System Management Commands .....</b>	<b>39</b>
	ping .....	39
	traceroute .....	41
	telnet .....	43
	resume .....	45
	hostname .....	45
	reload .....	46
	service cpu-utilization .....	46
	show cpu utilization .....	47
	clear cpu counters .....	48
	service cpu-counters .....	48
	show cpu counters .....	49
	show users .....	49
	show sessions .....	50
	show system .....	51
	show version .....	51
	system resources routing .....	52

## TABLE OF CONTENTS

iPECS ES-4000G Series

	show system resources .....	53
	show system defaults .....	53
	show services tcp-udp .....	53
	show tech-support .....	54
	show system id .....	56
<b>4</b>	<b>Clock Commands .....</b>	<b>57</b>
	clock set .....	57
	clock source .....	57
	clock timezone .....	58
	clock summer-time .....	58
	sntp authentication-key .....	60
	sntp authenticate .....	60
	sntp trusted-key .....	61
	sntp client poll timer .....	61
	sntp broadcast client enable .....	62
	sntp anycast client enable .....	62
	sntp client enable .....	63
	sntp client enable (Interface) .....	63
	sntp unicast client enable .....	64
	sntp unicast client poll .....	65
	sntp server .....	65
	sntp port .....	66
	show clock .....	66
	show sntp configuration .....	67
	show sntp status .....	68
<b>5</b>	<b>Configuration and Image File Commands .....</b>	<b>71</b>
	copy .....	71
	write memory .....	74
	write .....	74
	delete .....	75
	dir .....	76
	more .....	76
	rename .....	77
	boot system .....	78
	show running-config .....	79
	show startup-config .....	79
	show bootvar .....	80
<b>6</b>	<b>Auto-Update and Auto-Configuration .....</b>	<b>81</b>
	boot host auto-config .....	81
	boot host dhcp .....	81
	show boot .....	82
	ip dhcp tftp-server ip address .....	84
	ip dhcp tftp-server file .....	85
	show ip dhcp tftp-server .....	85
<b>7</b>	<b>Management ACL Commands .....</b>	<b>87</b>
	management access-list .....	87
	permit (Management) .....	88
	deny (Management) .....	89
	management access-class .....	89
	show management access-list .....	90
	show management access-class .....	91

<b>8</b>	<b>Network Management Protocol (SNMP) Commands .....</b>	<b>93</b>
	snmp-server server .....	93
	snmp-server community .....	93
	snmp-server community-group .....	94
	snmp-server view .....	95
	show snmp views .....	96
	snmp-server group .....	97
	show snmp groups .....	98
	snmp-server user .....	99
	show snmp users .....	100
	snmp-server filter .....	101
	show snmp filters .....	102
	snmp-server host .....	103
	snmp-server engineID local .....	104
	snmp-server engineID remote .....	105
	show snmp engineID .....	105
	snmp-server enable traps .....	106
	snmp-server trap authentication .....	106
	snmp-server contact .....	107
	snmp-server location .....	108
	snmp-server set .....	108
	show snmp .....	109
<b>9</b>	<b>RSA and Certificate Commands .....</b>	<b>111</b>
	crypto key generate dsa .....	111
	crypto key generate rsa .....	111
	crypto certificate generate .....	112
	crypto certificate request .....	113
	crypto certificate import .....	114
	crypto certificate export pkcs12 .....	116
	crypto certificate import pkcs12 .....	117
	show crypto certificate .....	118
<b>10</b>	<b>Web Server Commands .....</b>	<b>121</b>
	ip http server .....	121
	ip http port .....	121
	ip http timeout-policy .....	122
	ip http secure-server .....	122
	ip http secure-port .....	123
	ip https certificate .....	123
	show ip http .....	124
	show ip https .....	124
	ssl versions .....	125
	show ssl versions .....	125
<b>11</b>	<b>Teletype Network (Telnet), Secure Shell (SSH) and Secure Login (Slogin) Commands .....</b>	<b>127</b>
	ip telnet server .....	127
	ip ssh server .....	127
	ip ssh port .....	128
	ip ssh password-auth .....	128
	ip ssh pubkey-auth .....	129
	crypto key pubkey-chain ssh .....	130
	user-key .....	131
	key-string .....	131
	show ip ssh .....	132

## TABLE OF CONTENTS

iPECS ES-4000G Series

	show crypto key pubkey-chain ssh .....	133
<b>12</b>	<b>Line Commands .....</b>	<b>135</b>
	line .....	135
	speed .....	135
	autobaud .....	136
	exec-timeout .....	136
	show line .....	137
<b>13</b>	<b>Authentication, Authorization and Accounting (AAA) Commands .....</b>	<b>139</b>
	aaa authentication login .....	139
	aaa authentication enable .....	140
	login authentication .....	141
	enable authentication .....	142
	ip http authentication .....	142
	show authentication methods .....	143
	password .....	144
	enable password .....	145
	username .....	146
	show users accounts .....	146
	aaa accounting login .....	147
	aaa accounting dot1x .....	148
	show accounting .....	149
<b>14</b>	<b>Remote Authentication Dial-In User Service (RADIUS) Commands .....</b>	<b>151</b>
	radius-server host .....	151
	radius-server key .....	152
	radius-server retransmit .....	153
	radius-server source-ip .....	153
	radius-server source-ipv6 .....	154
	radius-server timeout .....	154
	radius-server deadtime .....	155
	show radius-servers .....	155
<b>15</b>	<b>Terminal Access Controller Access-Control System Plus (TACACS+) Commands .....</b>	<b>157</b>
	tacacs-server host .....	157
	tacacs-server key .....	158
	tacacs-server timeout .....	158
	tacacs-server source-ip .....	159
	show tacacs .....	159
<b>16</b>	<b>Syslog Commands .....</b>	<b>161</b>
	logging on .....	161
	logging host .....	161
	logging console .....	162
	logging buffered .....	163
	clear logging .....	163
	logging file .....	164
	clear logging file .....	164
	aaa logging .....	165
	file-system logging .....	165
	management logging .....	166
	show logging .....	166
	show logging file .....	167
	show syslog-servers .....	168

<b>17</b>	<b>Remote Network Monitoring (RMON) Commands .....</b>	<b>171</b>
	show rmon statistics .....	171
	rmon collection stats .....	172
	show rmon collection stats .....	173
	show rmon history .....	173
	rmon alarm .....	175
	show rmon alarm-table .....	176
	show rmon alarm .....	177
	rmon event .....	178
	show rmon events .....	179
	show rmon log .....	180
	rmon table-size .....	180
<b>18</b>	<b>802.1x Commands .....</b>	<b>183</b>
	aaa authentication dot1x .....	183
	dot1x system-auth-control .....	183
	dot1x port-control .....	184
	dot1x reauthentication .....	185
	dot1x timeout reauth-period .....	185
	dot1x re-authenticate .....	186
	dot1x timeout quiet-period .....	186
	dot1x timeout tx-period .....	187
	dot1x max-req .....	187
	dot1x timeout supp-timeout .....	188
	dot1x timeout server-timeout .....	189
	show dot1x .....	189
	show dot1x users .....	191
	show dot1x statistics .....	192
	clear dot1x statistics .....	193
	dot1x auth-not-req .....	194
	dot1x host-mode .....	194
	dot1x violation-mode .....	195
	dot1x guest-vlan .....	196
	dot1x guest-vlan timeout .....	196
	dot1x guest-vlan enable .....	197
	dot1x mac-authentication .....	198
	dot1x radius-attributes vlan .....	198
	show dot1x advanced .....	199
<b>19</b>	<b>Ethernet Configuration Commands .....</b>	<b>201</b>
	interface .....	201
	interface range .....	201
	shutdown .....	202
	description .....	203
	speed .....	203
	duplex .....	204
	negotiation .....	204
	flowcontrol .....	205
	mdix .....	206
	back-pressure .....	206
	port jumbo-frame .....	207
	clear counters .....	207
	set interface active .....	208
	errdisable recovery cause .....	208
	errdisable recovery interval .....	209
	show interfaces configuration .....	209

## TABLE OF CONTENTS

iPECS ES-4000G Series

	show interfaces status .....	210
	show interfaces advertise .....	211
	show interfaces description .....	212
	show interfaces counters .....	212
	show ports jumbo-frame .....	214
	show errdisable recovery .....	214
	show errdisable interfaces .....	215
	storm-control broadcast enable .....	216
	storm-control broadcast level kbps .....	216
	storm-control include-multicast .....	217
	show storm-control .....	217
<b>20</b>	<b>PHY Diagnostics Commands .....</b>	<b>219</b>
	test cable-diagnostics tdr .....	219
	show cable-diagnostics tdr .....	219
	show cable-diagnostics cable-length .....	220
	show fiber-ports optical-transceiver .....	221
<b>21</b>	<b>Port Channel Commands .....</b>	<b>223</b>
	channel-group .....	223
	port-channel load-balance .....	223
	show interfaces port-channel .....	224
<b>22</b>	<b>Address Table Commands .....</b>	<b>227</b>
	bridge multicast filtering .....	227
	bridge multicast mode .....	227
	bridge multicast address .....	229
	bridge multicast forbidden address .....	230
	bridge multicast ip-address .....	230
	bridge multicast forbidden ip-address .....	231
	bridge multicast source group .....	232
	bridge multicast forbidden source group .....	233
	bridge multicast ipv6 mode .....	234
	bridge multicast ipv6 ip-address .....	235
	bridge multicast ipv6 forbidden ip-address .....	236
	bridge multicast ipv6 source group .....	237
	bridge multicast ipv6 forbidden source group .....	237
	bridge multicast unregistered .....	238
	bridge multicast forward-all .....	239
	bridge multicast forbidden forward-all .....	239
	bridge unicast unknown .....	240
	mac address-table static .....	241
	clear mac address-table .....	242
	mac address-table aging-time .....	243
	port security .....	243
	port security mode .....	244
	port security max .....	245
	port security routed secure-address .....	246
	show mac address-table .....	246
	show mac address-table count .....	247
	show bridge multicast mode .....	248
	show bridge multicast address-table .....	248
	show bridge multicast address-table static .....	250
	show bridge multicast filtering .....	252
	show bridge multicast unregistered .....	253
	show ports security .....	253



	show ports security addresses .....	254
<b>23</b>	<b>Port Monitor Commands .....</b>	<b>257</b>
	port monitor .....	257
	show ports monitor .....	258
	port monitor mode .....	258
<b>24</b>	<b>sFlow Commands .....</b>	<b>261</b>
	sflow receiver .....	261
	sflow flow-sampling .....	261
	sflow counters-sampling .....	262
	clear sflow statistics .....	262
	show sflow configuration .....	263
	show sflow statistics .....	263
<b>25</b>	<b>Link Layer Discovery Protocol (LLDP) Commands .....</b>	<b>265</b>
	lldp run .....	265
	lldp transmit .....	265
	lldp receive .....	266
	lldp timer .....	266
	lldp hold-multiplier .....	267
	lldp reinit .....	268
	lldp tx-delay .....	268
	lldp optional-tlv .....	269
	lldp optional-tlv 802.1 .....	269
	lldp management-address .....	270
	lldp notifications .....	271
	lldp notifications interval .....	271
	lldp med .....	272
	lldp med notifications topology-change .....	272
	lldp med fast-start repeat-count .....	273
	lldp med network-policy (global) .....	273
	lldp med network-policy (interface) .....	274
	clear lldp table .....	275
	lldp med location .....	275
	show lldp configuration .....	276
	show lldp med configuration .....	278
	show lldp local tlvs-overloading .....	279
	show lldp local .....	279
	show lldp neighbors .....	281
	show lldp statistics .....	284
<b>26</b>	<b>Spanning-Tree Commands .....</b>	<b>287</b>
	spanning-tree .....	287
	spanning-tree mode .....	287
	spanning-tree forward-time .....	288
	spanning-tree hello-time .....	289
	spanning-tree max-age .....	289
	spanning-tree priority .....	290
	spanning-tree disable .....	290
	spanning-tree cost .....	291
	spanning-tree port-priority .....	292
	spanning-tree portfast .....	292
	spanning-tree link-type .....	293
	spanning-tree pathcost method .....	293

spanning-tree bpdu (Global) .....	294
spanning-tree bpdu (Interface) .....	295
spanning-tree guard root .....	295
spanning-tree bpduguard .....	296
clear spanning-tree detected-protocols .....	296
spanning-tree mst priority .....	297
spanning-tree mst max-hops .....	297
spanning-tree mst port-priority .....	298
spanning-tree mst cost .....	299
spanning-tree mst configuration .....	299
instance (MST) .....	300
name (MST) .....	301
revision (MST) .....	301
show (MST) .....	302
exit (MST) .....	302
abort (MST) .....	303
show spanning-tree .....	303
show spanning-tree bpdu .....	312
spanning-tree loopback-guard .....	313
<b>27 Virtual Local Area Network (VLAN) Commands .....</b>	<b>315</b>
vlan database .....	315
vlan .....	315
show vlan .....	316
interface vlan .....	317
interface range vlan .....	318
name .....	319
switchport .....	319
switchport mode .....	320
switchport access vlan .....	321
switchport trunk allowed vlan .....	322
switchport trunk native vlan .....	322
switchport general allowed vlan .....	324
switchport general pvid .....	324
switchport general ingress-filtering disable .....	326
switchport general acceptable-frame-type .....	326
map protocol protocols-group .....	327
switchport general map protocols-group vlan .....	328
show vlan protocols-groups .....	328
map mac macs-group .....	329
switchport general map macs-group vlan .....	330
show vlan macs-groups .....	331
map subnet subnets-group .....	331
switchport general map subnets-group vlan .....	332
show vlan subnets-groups .....	332
switchport forbidden default-vlan .....	333
switchport forbidden vlan .....	334
switchport default-vlan tagged .....	334
show interfaces switchport .....	335
ip internal-usage-vlan .....	336
<b>28 Internet Group Management Protocol (IGMP) Snooping Commands .....</b>	<b>339</b>
ip igmp snooping (Global) .....	339
ip igmp snooping vlan .....	339
ip igmp snooping vlan mrouter .....	340
ip igmp snooping vlan mrouter interface .....	341

	ip igmp snooping vlan forbidden mrouter .....	341
	ip igmp snooping vlan static .....	342
	ip igmp snooping vlan querier .....	343
	ip igmp snooping vlan querier address .....	343
	ip igmp snooping vlan querier version .....	344
	ip igmp robustness .....	344
	ip igmp query-interval .....	345
	ip igmp query-max-response-time .....	345
	ip igmp last-member-query-count .....	346
	ip igmp last-member-query-interval .....	346
	ip igmp snooping vlan immediate-leave .....	347
	show ip igmp snooping mrouter .....	347
	show ip igmp snooping interface .....	348
	show ip igmp snooping groups .....	349
<b>29</b>	<b>IPv6 MLD Snooping Commands .....</b>	<b>351</b>
	ipv6 mld snooping (Global) .....	351
	ipv6 mld snooping vlan .....	351
	ipv6 mld robustness .....	352
	ipv6 mld snooping vlan mrouter .....	352
	ipv6 mld snooping vlan mrouter .....	353
	ipv6 mld snooping vlan forbidden mrouter .....	354
	ipv6 mld snooping vlan static .....	354
	ipv6 mld query-interval .....	355
	ipv6 mld query-max-response-time .....	356
	ipv6 mld last-member-query-count .....	356
	ipv6 mld last-member-query-interval .....	357
	ipv6 mld snooping vlan immediate-leave .....	357
	show ipv6 mld snooping mrouter .....	358
	show ipv6 mld snooping interface .....	359
	show ipv6 mld snooping groups .....	359
<b>30</b>	<b>Link Aggregation Control Protocol (LACP) Commands .....</b>	<b>361</b>
	lACP system-priority .....	361
	lACP port-priority .....	361
	lACP timeout .....	362
	show lACP .....	362
	show lACP port-channel .....	364
<b>31</b>	<b>GARP VLAN Registration Protocol (GVRP) Commands .....</b>	<b>365</b>
	gvrp enable (Global) .....	365
	gvrp enable (Interface) .....	365
	garp timer .....	366
	gvrp vlan-creation-forbid .....	367
	gvrp registration-forbid .....	367
	clear gvrp statistics .....	368
	show gvrp configuration .....	368
	show gvrp statistics .....	369
	show gvrp error-statistics .....	370
<b>32</b>	<b>DHCP Snooping and ARP Inspection Commands .....</b>	<b>371</b>
	ip dhcp snooping .....	371
	ip dhcp snooping vlan .....	371
	ip dhcp snooping trust .....	372
	ip dhcp snooping information option allowed-untrusted .....	373

## TABLE OF CONTENTS

iPECS ES-4000G Series

ip dhcp snooping verify .....	373
ip dhcp snooping database .....	374
ip dhcp snooping database update-freq .....	374
ip dhcp snooping binding .....	375
clear ip dhcp snooping database .....	376
show ip dhcp snooping .....	376
show ip dhcp snooping binding .....	377
ip arp inspection .....	377
ip arp inspection vlan .....	378
ip arp inspection trust .....	378
ip arp inspection validate .....	379
ip arp inspection list create .....	380
ip mac .....	380
ip arp inspection list assign .....	381
ip arp inspection logging interval .....	381
show ip arp inspection .....	382
show ip arp inspection list .....	382
show ip arp inspection statistics .....	383
clear ip arp inspection statistics .....	383
<b>33 IP Addressing Commands .....</b>	<b>385</b>
ip address .....	385
ip address dhcp .....	386
renew dhcp .....	386
ip default-gateway .....	387
show ip interface .....	388
arp .....	388
arp timeout (Global) .....	389
arp timeout (Interface) .....	389
ip arp proxy disable .....	390
ip proxy-arp .....	390
clear arp-cache .....	391
show arp .....	391
show arp configuration .....	392
directed-broadcast .....	392
broadcast-address .....	393
ip helper-address .....	393
show ip helper-address .....	394
source-precedence .....	395
ip domain lookup .....	395
ip domain name .....	396
ip name-server .....	396
ip host .....	397
clear host .....	398
clear host dhcp .....	398
show hosts .....	399
<b>34 IPv6 Addressing Commands .....</b>	<b>401</b>
ipv6 enable .....	401
ipv6 address autoconfig .....	402
ipv6 icmp error-interval .....	402
show ipv6 icmp error-interval .....	403
ipv6 address .....	403
ipv6 address link-local .....	404
ipv6 unreachable .....	405
ipv6 default-gateway .....	405

	show ipv6 interface .....	406
	show IPv6 route .....	407
	ipv6 nd dad attempts .....	408
	ipv6 host .....	409
	ipv6 neighbor .....	410
	ipv6 set mtu .....	410
	ipv6 mld version .....	411
	ipv6 mld join-group .....	411
	show ipv6 neighbors .....	412
	clear ipv6 neighbors .....	413
<b>35</b>	<b>Tunnel Commands .....</b>	<b>415</b>
	interface tunnel .....	415
	tunnel mode ipv6ip .....	415
	tunnel isatap router .....	416
	tunnel source .....	417
	tunnel isatap query-interval .....	417
	tunnel isatap solicitation-interval .....	418
	tunnel isatap robustness .....	418
	show ipv6 tunnel .....	419
<b>36</b>	<b>DHCP Relay Commands .....</b>	<b>421</b>
	ip dhcp information option .....	421
	show ip dhcp information option .....	421
<b>37</b>	<b>IP Routing Protocol-Independent Commands .....</b>	<b>423</b>
	ip route .....	423
	ip routing .....	424
	show ip route .....	424
<b>38</b>	<b>ACL Commands .....</b>	<b>427</b>
	ip access-list (IP extended) .....	427
	permit (IP) .....	427
	deny (IP) .....	429
	ipv6 access-list (IPv6 extended) .....	430
	permit (IPv6) .....	431
	deny (IPv6) .....	432
	mac access-list .....	434
	permit (MAC) .....	434
	deny (MAC) .....	435
	service-acl input .....	436
	show access-lists .....	436
	show interfaces access-lists .....	437
	clear access-lists counters .....	438
	show interfaces access-lists counters .....	438
<b>39</b>	<b>Quality of Service (QoS) Commands .....</b>	<b>439</b>
	qos .....	439
	qos advanced-mode trust .....	440
	show qos .....	440
	class-map .....	441
	show class-map .....	442
	match .....	442
	policy-map .....	443
	class .....	444

## TABLE OF CONTENTS

iPECS ES-4000G Series

show policy-map .....	444
trust .....	445
set .....	446
police .....	447
service-policy .....	448
qos aggregate-policer .....	448
show qos aggregate-policer .....	449
police aggregate .....	450
wrr-queue cos-map .....	450
wrr-queue bandwidth .....	451
priority-queue out num-of-queues .....	452
traffic-shape .....	453
traffic-shape queue .....	453
rate-limit (Ethernet) .....	454
qos wrr-queue wrtd .....	454
show qos wrr-queue wrtd .....	455
show qos interface .....	455
qos wrr-queue threshold .....	458
qos map policed-dscp .....	458
qos map dscp-queue .....	459
qos map dscp-dp .....	459
qos trust (Global) .....	460
qos trust (Interface) .....	461
qos cos .....	461
qos dscp-mutation .....	462
qos map dscp-mutation .....	462
show qos map .....	463
clear qos statistics .....	464
qos statistics policer .....	464
qos statistics aggregate-policer .....	465
qos statistics queues .....	465
show qos statistics .....	466

## About this Document

This CLI Reference Guide describes how to use the CLI and a list of the CLI commands and their arguments.

The CLI commands described in this document are organized according to feature groups in separate sections.

This section describes how to use the CLI. It contains the following topics:

- [CLI Command Modes](#)
- [Starting the CLI](#)
- [CLI Command Conventions](#)
- [Entering Commands](#)
- [IPv6z Address Conventions](#)

## CLI Command Modes

To configure devices, the CLI is divided into various command modes. Each command mode has its own set of specific commands. Entering a question mark “?” at the console prompt displays a list of commands available for that particular command mode.

A specific command, which varies from mode to mode, is used to navigate from one mode to another. The standard order to access the modes is as follows: *User EXEC* mode, *Privileged EXEC* mode, *Global Configuration* mode, and *Interface Configuration* modes.

When starting a session, the initial mode for non-privileged users is the User EXEC mode. Only a limited subset of commands is available in the User EXEC mode. This level is reserved for tasks that do not change the configuration.

Privileged users enter the Privileged EXEC mode directly using a password. This mode provides access to the device Configuration modes.

The modes are described below.

### User EXEC Mode

After logging into the device, the user is automatically in *User EXEC* command mode unless the user is defined as a privileged user. In general, the *User EXEC* commands enable the user to perform basic tests, and display system information.

The user-level prompt consists of the device “host name” followed by the angle bracket (>).

```
console>
```

The default host name is “console” unless it has been changed using the **hostname** command in the *Global Configuration* mode.

### Privileged EXEC Mode

Privileged access is password-protected to prevent unauthorized use, because many of the privileged commands set operating system parameters: The password is not displayed on the screen and is case sensitive.

Privileged users enter directly into the *Privileged EXEC* mode.

Use **disable** to return to the *User EXEC* mode.

## Global Configuration Mode

*Global Configuration* mode commands apply to features that affect the system as a whole, rather than just a specific interface.

To enter the *Global Configuration* mode, enter **configure** in the Privileged EXEC mode, and press <Enter>.

The *Global Configuration* mode prompt is displayed.

```
console(config)#
```

Use **exit**, **end** or **ctrl/z** to return to the Privileged EXEC mode.

## Interface Configuration Modes

Commands in the following modes perform specific interface operations:

- **Line Interface** — Contains commands to configure the management connections. These include commands such as line speed, timeout settings, etc. The *Global Configuration* mode command **line** is used to enter the *Line Configuration command* mode.
- **VLAN Database** — Contains commands to create a VLAN as a whole. The *Global Configuration* mode command **vlan database** is used to enter the *VLAN Database Interface Configuration* mode.
- **Management Access List** — Contains commands to define management access-lists. The *Global Configuration* mode command **management access-list** is used to enter the *Management Access List Configuration* mode.
- **Port Channel** — Contains commands to configure port-channels, for example, assigning ports to a VLAN or port-channel. The *Global Configuration* mode command **interface port-channel** is used to enter the *Port Channel Interface Configuration* mode.
- **SSH Public Key-Chain** — Contains commands to manually specify other device SSH public keys. The *Global Configuration* mode command **crypto key pubkey-chain ssh** is used to enter the *SSH Public Key-chain Configuration* mode.
- **Interface** — Contains commands that configure the interface. The *Global Configuration* mode command **interface** is used to enter the *Interface Configuration* mode.

## Starting the CLI

The switch can be managed over a direct connection to the switch console port, or via a Telnet connection. The switch is managed by entering command keywords and parameters at the prompt. Using the switch CLI commands is similar to entering commands on a UNIX system.

If access is via a Telnet connection, ensure the device has an IP address defined, corresponding management access is granted, and the workstation used to access the device is connected to the device prior to using CLI commands.

### Accessing the CLI from the Console Line

1. Start the device and wait until the startup procedure is complete. The User Exec mode is entered, and the prompt "console>" is displayed.
2. Configure the device and enter the necessary commands to complete the required tasks.
3. When finished, exit the session with the **quit** or **exit** command.

### Accessing the CLI from Telnet

1. Enter **telnet** and the IP address of the device. A User Name prompt is displayed.
2. Enter the User Name and Password. You are in the Privileged Exec mode.
3. Configure the device and enter the necessary commands to complete the required tasks.
4. When finished, exit the session with the **quit** or **exit** command.

When another user is required to log onto the system, the **login** command is entered in the Privileged EXEC command mode,. This effectively logs off the current user and logs on the new user.



## CLI Command Conventions

The following table describes the command syntax conventions.

Conventions	Description
[ ]	In a command line, square brackets indicates an optional entry.
{ }	In a command line, curly brackets indicate a selection of compulsory parameters separated by the   character. One option must be selected. For example: <b>flowcontrol {auto   on   off}</b> means that for the <b>flowcontrol</b> command either <b>auto</b> , <b>on</b> or <b>off</b> must be selected.
<i>Italic font</i>	Indicates a parameter.
<Enter>	Any individual key on the keyboard. For example click <Enter>.
Ctrl+F4	Any combination keys pressed simultaneously on the keyboard.
Screen Display	Indicates system messages and prompts appearing on the console.
all	When a parameter is required to define a range of ports or parameters and <b>all</b> is an option, the default for the command is <b>all</b> when no parameters are defined. For example, the command <b>interface range port-channel</b> has the option of either entering a range of channels, or selecting <b>all</b> . When the command is entered without a parameter, it automatically defaults to <b>all</b> .
interface-id	This indicates a port, VLAN or LAG. The syntax for interface_id is as follows: <b>{port_type}port-number</b>   <b>{vlan} vlan-id</b>   <b>{port-channel} LAG-number</b>
port_type	Port type can be one of the following depending on the port types on the device: <ul style="list-style-type: none"> <li>1000 Gbps Gigabitethernet can be shortened to gi.</li> <li>10000 - Ten Gigabit Ethernet can be written as either Ten Gigabit Ethernet or te.</li> </ul>

## Entering Commands

A CLI command is a series of keywords and arguments. Keywords identify a command, and arguments specify configuration parameters. For example, in the command "**show interfaces status gi1/0/5**" **show**, **interfaces** and **status** are keywords, **gi** is an argument that specifies the interface type, and **1/0/5** is an argument that specifies the port.

To enter commands that require parameters, enter the required parameters after the command keyword. For example, to set a password for the administrator, enter:

```
console(config)# username admin password smith
```

Help information can be displayed in the following ways:

- **Keyword Lookup** — The character ? is entered in place of a command. A list of all valid commands and corresponding help messages are displayed.
- **Partial Keyword Lookup** — A command is incomplete and the character ? is entered in place of a parameter. The matched parameters for this command are displayed.

The following describes features that assist in using the CLI:

## Terminal Command Buffer

Every time a command is entered in the CLI, it is recorded on an internally managed Command History buffer. Commands stored in the buffer are maintained on a First In First Out (FIFO) basis. These commands can be recalled, reviewed, modified, and reissued. This buffer is not preserved across device resets. The keys that can be used to access the history buffer are described in [Table 1](#).

By default, the history buffer system is enabled, but it can be disabled at any time. For information about the command syntax to enable or disable the history buffer, see the **history** command.

There is a standard default number of commands that are stored in the buffer. The standard number of 10 commands can be increased to 256. By configuring 0, the effect is the same as disabling the history buffer

system. For information about the command syntax for configuring the command history buffer, see the **history size** command.

To display the history buffer, see **show history** command.

## Negating the Effect of Commands

For many configuration commands, the prefix keyword “no” can be entered to cancel the effect of a command or reset the configuration to the default value. This guide describes the negation effect for all applicable commands.

## Command Completion

If the command entered is incomplete, invalid, or has missing or invalid parameters, an appropriate error message is displayed.

To complete an incomplete command, press the <Tab> button. If the characters already entered are not enough for the system to identify a single matching command, press “?” to display the available commands matching the characters already entered.

Incorrect or incomplete commands are automatically re-entered next to the cursor. If a parameter must be added, the parameter can be added to the basic command already displayed next to the cursor. The following example indicates that the command interface requires a missing parameter.

```
(config)#interface
%missing mandatory parameter
(config)#interface
```

## Keyboard Shortcuts

The CLI has a range of keyboard shortcuts to assist in entering the CLI commands.

The following table describes these shortcuts:

**Table 1: Keyboard Keys**

Keyboard Key	Description
Up-arrow key	Recalls commands from the history buffer, beginning with the most recent command. Repeat the key sequence to recall successively older commands.
Down-arrow key	Returns the most recent commands from the history buffer after recalling commands with the up arrow key. Repeating the key sequence will recall successively more recent commands.
Ctrl+A	Moves the cursor to the beginning of the command line.
Ctrl+E	Moves the cursor to the end of the command line.
Ctrl+Z / End	Returns back to the Privileged EXEC mode from any mode.
Backspace key	Moves the cursor back one space.
Up-arrow key	Recalls commands from the history buffer, beginning with the most recent command. Repeat the key sequence to recall successively older commands.

## IPv6z Address Conventions

The following describes how to write an IPv6z address, which is a link-local IPv6 address:

The format is: `<ipv6-link-local-address>%<egress-interface>`

where:

`egress-interface` (also known as zone) = `vlan<vlan-id> | po <number> | tunnel <number> | port<number> | 0`

If the egress interface is not specified, the default interface is selected. Specifying egress interface = 0 is equal to not defining an egress interface.

The following combinations are possible:

- *ipv6\_address%egress-interface*—Refers to the IPv6 address on the interface specified.
- *ipv6\_address%0*—Refers to the IPv6 address on the single interface on which an IPv6 address is defined.
- *ipv6\_address*—Refers to the IPv6 address on the single interface on which an IPv6 address is defined.



---

## 2.1 enable

The **enable** EXEC mode command enters the Privileged EXEC mode.

### Syntax

**enable** [*privilege-level*]

### Parameters

**privilege-level**—Specifies the privilege level at which to enter the system. (Range: 1, 7, 15)

### Default Configuration

The default privilege level is 15.

### Command Mode

EXEC mode

### Example

The following example enters privilege level 7.

---

```
switchxxxxxx# enable 7
enter password:*****
switchxxxxxx#Accepted
```

---

The following example enters privilege level 15.

---

```
switchxxxxxx# enable
enter password:*****
switchxxxxxx#Accepted
```

---

## 2.2 disable

The **disable** Privileged EXEC mode command leaves the Privileged EXEC mode and returns to the User EXEC mode.

### Syntax

**disable** [*privilege-level*]

### Parameters

**privilege-level**—Reduces the privilege level to the specified privileged level. If privilege level is left blank, the level is reduce to 1.

## Default Configuration

The default privilege level is 1.

## Command Mode

Privileged EXEC mode

## Example

The following example returns the user to user level 7.

---

```
switchxxxxxx# disable 7
switchxxxxxx#
```

---

## 2.3 login

The **login** EXEC mode command enables changing the user that is logged in. When this command is logged in, the user is prompted for a username/password.

### Syntax

**login**

### Parameters

N/A

### Default Configuration

N/A

### Command Mode

EXEC mode

### Example

The following example enters Privileged EXEC mode and logs in with the required username 'bob'.

---

```
switchxxxxxx# login
User Name:bob
Password:*****
switchxxxxxx#
```

---

## 2.4 configure

The **configure** Privileged EXEC mode command enters the Global Configuration mode.

### Syntax

**configure** [*terminal*]

### Parameters

**terminal**—Enter the Global Configuration mode with or without the keyword terminal.

### Command Mode

Privileged EXEC mode

### Example

The following example enters Global Configuration mode.

---

```
switchxxxxxx# configure
switchxxxxxx(config)#
```

---

## 2.5 exit (Configuration)

The **exit** command exits any mode and brings the user to the next higher mode in the CLI mode hierarchy.

### Syntax

**exit**

### Parameters

N/A

### Default Configuration

N/A

### Command Mode

All.

### Examples

The following examples change the configuration mode from Interface Configuration mode to Privileged EXEC mode.

---

```
switchxxxxxx(config-if)# exit
switchxxxxxx(config)# exit
```

---

## 2.6 exit (EXEC)

The **exit** EXEC mode command closes an active terminal session by logging off the device.

### Syntax

**exit**

### Parameters

N/A

### Default Configuration

N/A

### Command Mode

EXEC mode

### Example

The following example closes an active terminal session.

---

```
switchxxxxxx# exit
```

---

---

## 2.7 end

The **end** command ends the current configuration session and returns to the Privileged EXEC mode.

### Syntax

**end**

### Parameters

N/A

### Default Configuration

N/A

### Command Mode

All

### Example

The following example ends the Global Configuration mode session and returns to the Privileged EXEC mode.

---

```
switchxxxxxx(config)# end
switchxxxxxx#
```

---

## 2.8 help

The **help** command displays a brief description of the Help system.

### Syntax

**help**

### Parameters

N/A

### Default Configuration

N/A

### Command Mode

All

### Example

The following example describes the Help system.

---

```
switchxxxxxx# help
```

Help may be requested at any point in a command by entering a question mark '?'. If nothing matches the currently entered incomplete command, the help list is empty. This indicates that there is no command matching the input as it currently appears. If the request is within a command, press the Backspace key and erase the entered characters to a point where the request results in a match.



Help is provided when:

1. There is a valid command and a help request is made for entering a parameter or argument (e.g. 'show ?'). All possible parameters or arguments for the entered command are then displayed.
2. An abbreviated argument is entered and a help request is made for arguments matching the input (e.g. 'show pr?').

---

## 2.9 history

The **history** Line Configuration mode command enables saving commands that have been entered. Use the **no** form of this command to disable the command.

### Syntax

**history**

**no history**

### Parameters

N/A

### Default Configuration

Enabled.

### Command Mode

Line Configuration mode

### User Guidelines

This command enables saving user-entered commands for a specified line. You can return to previous lines by using the up or down arrows.

It is effective from the next time that the user logs in via console/telnet/ssh.

The following are related commands:

- Use the [terminal history size](#) EXEC mode command to enable or disable this command for the current terminal session.
- Use the [history size](#) Line Configuration mode command to set the size of the command history buffer.

### Example

The following example enables the command for Telnet.

---

```
switchxxxxxx(config)# line telnet
switchxxxxxx(config-line)# history
```

---

## 2.10 history size

The **history size** Line Configuration mode command changes the maximum number of user commands that are saved in the history buffer for a particular line. Use the **no** form of this command to reset the command history buffer size to the default value.

### Syntax

**history size** *number-of-commands*

**no history size**

### Parameters

**number-of-commands**—Specifies the number of commands the system records in its history buffer. (Range: 10–207)

### Default Configuration

The default command history buffer size is 10 commands.

### Command Mode

Line Configuration mode

### User Guidelines

This command configures the command history buffer size for a particular line. It is effective from the next time that the user logs in via console/telnet/ssh.

Use the **terminal history size** EXEC mode command to configure the command history buffer size for the current terminal session.

The allocated command history buffer is per terminal user, and is taken from a shared buffer. If there is not enough space available in the shared buffer, the command history buffer size cannot be increased above the default size.

### Example

The following example changes the command history buffer size to 100 entries for Telnet.

---

```
switchxxxxxx(config)# line telnet
switchxxxxxx(config-line)# history size 100
```

---

## 2.11 terminal history

The **terminal history** EXEC mode command enables the command history function for the current terminal session, meaning it is not stored in the Running Configuration file. Use the **no** form of this command to disable the command.

### Syntax

**terminal history**

**terminal no history**

### Default Configuration

The default configuration for all terminal sessions is defined by the [history](#) Line Configuration mode command.

### Command Mode

EXEC mode

### User Guidelines

The command enables the command history for the current session. The default is determined by the [history](#) Line Configuration mode command.

This command is effective immediately.

### Example

The following example disables the command history function for the current terminal session.

---

```
switchxxxxxx# terminal no history
```

---

---

## 2.12 terminal history size

The **terminal history size** EXEC mode command changes the command history buffer size for the current terminal session, meaning it is not stored in the Running Configuration file. Use the **no** form of this command to reset the command history buffer size to the default value.

### Syntax

**terminal history size** *number-of-commands*

**terminal no history size**

### Parameters

**number-of-commands**—Specifies the number of commands the system maintains in its history buffer. (Range: 10–207)

### Default Configuration

The default configuration for all terminal sessions is defined by the [history size](#) Line Configuration mode command.

### Command Mode

EXEC mode

### User Guidelines

The **terminal history size** EXEC command changes the command history buffer size for the current terminal session. Use the [history](#) Line Configuration mode command to change the default history buffer size.

The maximum number of commands in all buffers is 207.

### Example

The following example sets the command history buffer size to 20 commands for the current terminal session.

---

```
switchxxxxxx#terminal history size 20
```

---

---

## 2.13 terminal datadump

The **terminal datadump** EXEC mode command enables dumping all the output of a show command without prompting. Use the **no** form of this command to disable dumping.

### Syntax

**terminal datadump**

**no terminal datadump**

### Parameters

N/A

### Default Configuration

When printing, dumping is disabled and printing is paused every 24 lines.

### Command Mode

EXEC mode

## User Guidelines

By default, a **More** prompt is displayed when the output contains more than 24 lines. Pressing the **Enter** key displays the next line; pressing the **Spacebar** displays the next screen of output.

The **terminal datadump** command enables dumping all output immediately after entering the show command by removing the pause.

The width is currently not limited (previously the limit was 77 chars), and the width of the line being printed on the terminal is based on the terminal itself.

This command is relevant only for the current session.

## Example

The following example dumps all output immediately after entering a show command.

---

```
switchxxxxxxx# terminal datadump
```

---

## 2.14 terminal width

Use the **terminal width** EXEC mode command to determine the width of the display for the echo input to CLI sessions and configuration files. Use **terminal no width** to return to the default.

The command is per session and will not be saved in the configuration database.

### Syntax

**terminal width** *number-of-characters*

**terminal no width**

### Parameters

**number-of-characters** - Specifies the number of characters to be displayed for the echo output of the CLI commands and the configuration file, '0' means endless number of characters on a screen line. (Range: 0, 70-512)

### Default Configuration

The default number of characters is 77.

### Command Mode

Privileged EXEC mode

### Example

The following example sets the terminal width to 100 characters

```
switchxxxxxxx# terminal width 100
```

---

## 2.15 terminal prompt

Use the **terminal prompt** EXEC mode command to enable the terminal prompts. Use **terminal no prompt** command to disable the terminal prompts.

The command is per session and will not be saved in the configuration database.

### Syntax

**terminal prompt**

**terminal no prompt**

**Parameters**

N/A

**Default Configuration**

The default configuration is prompts enabled.

**Command Mode**

Privileged EXEC mode

**Example**

The following example disables the terminal prompts

```
switchxxxxxx# terminal no prompt
```

---

## 2.16 debug-mode

The **debug-mode** Privileged EXEC mode command mode switches to debug mode.

**Syntax**

**debug-mode**

**Parameters**

N/A

**Default Configuration**

N/A

**Command Mode**

Privileged EXEC mode

**Example**

The following example enters Debug mode.

---

```
switchxxxxxx# debug-mode
```

---

## 2.17 show history

The **show history** EXEC mode command lists commands entered in the current session.

**Syntax**

**show history**

**Parameters**

N/A

**Default Configuration**

N/A

**Command Mode**

EXEC mode

### User Guidelines

The buffer includes executed and unexecuted commands.

Commands are listed from the first to the most recent command.

The buffer remains unchanged when entering into and returning from configuration modes.

### Example

The following example displays all the commands entered while in the current Privileged EXEC mode.

---

```
switchxxxxxx# show version
SW version 3.131 (date 23-Jul-2005 time 17:34:19)
HW version 1.0.0
switchxxxxxx# show clock
15:29:03 Jun 17 2005
switchxxxxxx# show history
show version
show clock
show history
3 commands were logged (buffer size is 10)
```

---

## 2.18 show privilege

The **show privilege** EXEC mode command displays the current privilege level.

### Syntax

**show privilege**

### Parameters

N/A

### Default Configuration

N/A

### Command Mode

EXEC mode

### Example

The following example displays the privilege level for the user logged on.

---

```
switchxxxxxx# show privilege
Current privilege level is 15
```

---

## 2.19 do

The **do** command executes an EXEC-level command from Global Configuration mode or any configuration submode.

### Syntax

**do** *command*

## Parameters

**command**—Specifies the EXEC-level command to execute.

## Command Mode

All configuration modes

## Example

The following example executes the **show vlan** Privileged EXEC mode command from Global Configuration mode.

## Example

---

```
switchxxxxxx(config)# do show vlan
```

Vlan	Name	Ports	Type	Authorization
1	1	gi1/0/11-39, Po1, Po2,	other	Required
2	2	gi1/0/11	dynamicGvrp	Required
10	v0010	gi1/0/11	permanent	Not Required
11	V0011	gi1/0/11, gi1/0/13	permanent	Required
20	20	gi1/0/11	permanent	Required
30	30	gi1/0/11, gi1/0/13	permanent	Required
31	31	gi1/0/11	permanent	Required
91	91	gi1/0/11, gi1/0/14	permanent	Required
4093	guest-vlan	gi1/0/11, gi1/0/13	permanent	Guest

```
switchxxxxxx(config)#
```

---

## 2.20 banner exec

Use the **banner exec** Global Configuration mode command to specify and enable a message to be displayed after a successful logon. Use the **no** form of this command to delete the existing EXEC banner.

### Syntax

**banner exec** *d message-text d*

**no banner exec**

### Parameters

- **d**—Delimiting character of user's choice—a pound sign (**#**), for example. You cannot use the delimiting character in the banner message.
- **message-text**—The message must start in a new line. You can enter multi-line messages. You can include tokens in the form of **\$(token)** in the message text. Tokens are replaced with the corresponding configuration variable (see User Guidelines). The message can contain up to 2000 characters (after every 510 characters, press **<Enter>** to continue).

### Default Configuration

Disabled (no EXEC banner is displayed).

### Command Mode

Global Configuration mode

## User Guidelines

Follow this command with one or more blank spaces and a delimiting character of your choice. Then enter one or more lines of text, terminating the message with the second occurrence of the delimiting character.

Use tokens in the form of **\$(token)** in the message text to customize the banner. The tokens are described in the table below:

Token	Information Displayed in the Banner
\$(hostname)	Displays the host name for the device.
\$(domain)	Displays the domain name for the device.
\$(bold)	Indicates that the next text is a bold text. Using this token again indicates the end of the bold text.
\$(inverse)	Indicates that the next text is an inverse text. Using this token again indicates the end of the inverse text.
\$(contact)	Displays the system contact string.
\$(location)	Displays the system location string.
\$(mac-address)	Displays the base MAC address of the device.

Use the **no banner exec** Line Configuration command to disable the Exec banner on a particular line or lines.

## Example

The following example sets an EXEC banner that uses tokens. The percent sign (%) is used as a delimiting character. Note that the **\$(token)** syntax is replaced by the corresponding configuration variable.

---

```
switchxxxxxx(config)# banner exec %
Enter TEXT message. End with the character '%'.
$(bold)Session activated.$(bold) Enter commands at the prompt.
%
```

When a user logs on to the system, the following output is displayed:

```
Session activated. Enter commands at the prompt.
```

---

## 2.21 banner login

Use the **banner login** command in Global Configuration mode to specify a message to be displayed before the username and password login prompts. This banner is applied automatically on all the CLI interfaces: Console, Telnet and SSH and also on the WEB GUI. Use the **no** form of this command to delete the existing login banner.

### Syntax

```
banner login d message-text d
```

```
no banner login
```

### Parameters

- **d**—Delimiting character of user's choice—a pound sign (#), for example. You cannot use the delimiting character in the banner message.
- **message-text**—Message text. The message must start on a new line. You can enter multi-line messages. You can include tokens in the form of **\$(token)** in the message text. Tokens are replaced with the corresponding configuration variable (see User Guidelines). The message can contain up to 2000 characters (after every 510 characters, you must press <Enter> to continue).



## Default Configuration

Disabled (no Login banner is displayed).

## Command Mode

Global Configuration mode

## User Guidelines

Follow this command with one or more blank spaces and a delimiting character of your choice. Then enter one or more lines of text, terminating the message with the second occurrence of the delimiting character.

Use tokens in the form of **\$(token)** in the message text to customize the banner. The tokens are described in the table below:

Token	Information displayed in the banner
\$(hostname)	Displays the host name for the device.
\$(domain)	Displays the domain name for the device.
\$(bold)	Indicates that the next text is a bold text. Using this token again indicates the end of the bold text.
\$(inverse)	Indicates that the next text is an inverse text. Using this token again indicates the end of the inverse text.
\$(contact)	Displays the system contact string.
\$(location)	Displays the system location string.
\$(mac-address)	Displays the base MAC address of the device.

Use the **no banner login** Line Configuration command to disable the Login banner on a particular line or lines.

## Example

The following example sets a Login banner that uses tokens. The percent sign (%) is used as a delimiting character. Note that the **\$(token)** syntax is replaced by the corresponding configuration variable.

---

```
switchxxxxxx(config)# banner login %
Enter TEXT message. End with the character '%'.
You have entered $(hostname).$(domain)
%
```

When the login banner is executed, the user will see the following banner:

```
You have entered host123.ourdomain.com
```

## 2.22 banner motd

Use the **banner motd** command in Global Configuration mode to specify and enable a message-of-the-day banner. This message is displayed before the login banner. Use the **no** form of this command to delete the existing MOTD banner.

### Syntax

```
banner motd d message-text d
```

```
no banner motd
```

### Parameters

- **d**—Delimiting character of user's choice—a pound sign (#), for example. You cannot use the delimiting character in the banner message.
- **message-text**—The message must start on a new line. You can enter multi-line messages. You can include tokens in the form of **\$(token)** in the message text. Tokens are replaced with the corresponding configuration variable. Tokens are described in the User Guidelines. The message can contain up to 2000 characters (after every 510 characters, you must press <Enter> to continue).

### Default Configuration

Disabled (no MOTD banner is displayed).

### Command Mode

Global Configuration mode

### User Guidelines

Follow this command with one or more blank spaces and a delimiting character of your choice. Then enter one or more lines of text, terminating the message with the second occurrence of the delimiting character.

When a user connects to a device, the message-of-the-day (MOTD) banner appears first, followed by the login banner and prompts. After the user logs in to the device, the EXEC banner is displayed.

Use tokens in the form of **\$(token)** in the message text to customize the banner. The tokens are described in the table below:

Token	Information displayed in the banner
\$(hostname)	Displays the host name for the device.
\$(domain)	Displays the domain name for the device.
\$(bold)	Indicates that the next text is a bold text. Using this token again to indicates the end of the bold text.
\$(inverse)	Indicates that the next text is an inverse text. Using this token again indicates the end of the inverse text.
\$(contact)	Displays the system contact string.
\$(location)	Displays the system location string.
\$(mac-address)	Displays the base MAC address of the device.

Use the **no banner motd** Line Configuration command to disable the MOTD banner on a particular line or lines.

### Example

The following example sets an MOTD banner that uses tokens. The percent sign (%) is used as a delimiting character. Note that the **\$(token)** syntax is replaced by the corresponding configuration variable.

```
switchxxxxxx(config)# banner motd %
Enter TEXT message. End with the character '%'.
$(bold)Upgrade$(bold) to all devices begins at March 12
%
```

When the login banner is executed, the user will see the following banner:

```
Upgrade to all devices begins at March 12
```

---

## 2.23 exec-banner

Use the **exec-banner** command in Line Configuration mode to enable the display of exec banners. Use the **no** form of this command to disable the display of exec banners.

### Syntax

**exec-banner**

**no exec-banner**

### Parameters

This command has no arguments or keywords.

### Default Configuration

Disabled

### Command Mode

Line Configuration mode

### Example

---

```
switchxxxxxx# configure
switchxxxxxx(config)# line console
switchxxxxxx(config-line)# exec-banner
switchxxxxxx(config-line)# exit
switchxxxxxx(config)# line telnet
switchxxxxxx(config-line)# exec-banner
switchxxxxxx(config-line)# exit
switchxxxxxx(config)# line ssh
switchxxxxxx(config-line)# exec-banner
```

---

## 2.24 login-banner

Use the **login-banner** command in Line Configuration mode to enable the display of login banners. Use the **no** form of this command to disable the display of login banners.

### Syntax

**login-banner**

**no login-banner**

### Parameters

This command has no arguments or keywords.

### Default Configuration

Enabled

### Command Mode

Line Configuration mode

---

## Example

```
switchxxxxxx# configure
switchxxxxxx(config)# line console
switchxxxxxx(config-line)# login-banner
switchxxxxxx(config-line)# exit
switchxxxxxx(config)# line telnet
switchxxxxxx(config-line)# login-banner
switchxxxxxx(config-line)# exit
switchxxxxxx(config)# line ssh
switchxxxxxx(config-line)# login-banner
```

---

## 2.25 motd-banner

Use the **motd-banner** command in Line Configuration mode to enable the display of message-of-the-day banners. Use the **no** form of this command to disable the display of MOTD banners.

### Syntax

**motd-banner**

**no motd-banner**

### Parameters

This command has no arguments or keywords.

### Default Configuration

Enabled

### Command Mode

Line Configuration mode

## Example

---

```
switchxxxxxx# configure
switchxxxxxx(config)# line console
switchxxxxxx(config-line)# motd-banner
switchxxxxxx(config-line)# exit
switchxxxxxx(config)# line telnet
switchxxxxxx(config-line)# motd-banner
switchxxxxxx(config-line)# exit
switchxxxxxx(config)# line ssh
switchxxxxxx(config-line)# motd-banner
```

---

## 2.26 show banner

Use the **show banner** commands in EXEC mode to display the banners that have been defined.

### Syntax

**show banner motd**

**show banner login**

**show banner exec**

### Parameters

This command has no arguments or keywords.

### Command Mode

EXEC mode

### Examples

---

```
switchxxxxxx# show banner motd
```

```
Banner: MOTD
```

```
Line SSH: Enabled
```

```
Line Telnet: Enabled
```

```
Line Console: Enabled
```

```
10000 giga ports switch
```

```
switchxxxxxx# show banner login
```

```
-----  
Banner: Login
```

```
Line SSH: Enabled
```

```
Line Telnet: Enabled
```

```
Line Console: Enabled
```

```
switchxxxxxx# show banner exec
```

---

```
Banner: EXEC
```

```
Line SSH: Enabled
```

```
Line Telnet: Enabled
```

```
Line Console: Enabled
```

```
You have logged on
```



### 3.1 ping

Use the **ping** EXEC mode command to send ICMP echo request packets to another node on the network.

#### Syntax

**ping** **[ip]** {*ipv4-address* | *hostname*} [**size** *packet\_size*] [**count** *packet\_count*] [**timeout** *time\_out*]

**ping** **ipv6** {*ipv6-address* | *hostname*} [**size** *packet\_size*] [**count** *packet\_count*] [**timeout** *time\_out*]

#### Parameters

- **ip**—Use IPv4 to check the network connectivity.
- **ipv6**—Use IPv6 to check the network connectivity.
- **ipv4-address**—IPv4 address to ping.
- **ipv6-address**—Unicast or Multicast IPv6 address to ping. When the IPv6 address is a Link Local address (IPv6Z address), the outgoing interface name must be specified. See [IPv6Z Address Conventions](#).
- **hostname**—Hostname to ping (Length: 1-160 characters. Maximum label size for each part of the host name: 63.)
- **size** *packet\_size*—Number of bytes in the packet not including the VLAN tag. The default is 64 bytes. (IPv4: 64–1518, IPv6: 68–1518)
- **count** *packet\_count*—Number of packets to send, from 1 to 65535 packets. The default is 4 packets. If 0 is entered, it pings until stopped (0–65535).
- **time** *time-out*—Timeout in milliseconds to wait for each reply, from 50 to 65535 milliseconds. The default is 2000 milliseconds (50–65535).

#### Default Usage

N/A

#### Command Mode

EXEC mode

#### User Guidelines

Press **Esc** to stop pinging. Following are sample results of the ping command:

- **Destination does not respond**—If the host does not respond, a “no answer from host” appears within 10 seconds.
- **Destination unreachable**—The gateway for this destination indicates that the destination is unreachable.
- **Network or host unreachable**—The switch found no corresponding entry in the route table.

See [IPv6Z Address Conventions](#).

When using the ping **ipv6** command to check network connectivity of a directly attached host using its link local address, the egress interface may be specified in the **IPv6Z** format. If the egress interface is not specified, the default interface is selected.

When using the ping **ipv6** command with a Multicast address, the information displayed is taken from all received echo responses.

### Examples

#### Example 1 - Ping an IP address.

---

```
switchxxxxxx# ping ip 10.1.1.1
Pinging 10.1.1.1 with 64 bytes of data:
64 bytes from 10.1.1.1: icmp_seq=0. time=11 ms
64 bytes from 10.1.1.1: icmp_seq=1. time=8 ms
64 bytes from 10.1.1.1: icmp_seq=2. time=8 ms
64 bytes from 10.1.1.1: icmp_seq=3. time=7 ms
----10.1.1.1 PING Statistics----
4 packets transmitted, 4 packets received, 0% packet loss
round-trip (ms) min/avg/max = 7/8/11
```

---

#### Example 2 - Ping a site.

```
switchxxxxxx# ping ip yahoo.com
Pinging yahoo.com [66.218.71.198] with 64 bytes of data:
64 bytes from 10.1.1.1: icmp_seq=0. time=11 ms
64 bytes from 10.1.1.1: icmp_seq=1. time=8 ms
64 bytes from 10.1.1.1: icmp_seq=2. time=8 ms
64 bytes from 10.1.1.1: icmp_seq=3. time=7 ms
----10.1.1.1 PING Statistics----
4 packets transmitted, 4 packets received, 0% packet loss
round-trip (ms) min/avg/max = 7/8/11
```

---

#### Example 3 - Ping an IPv6 address.

```
switchxxxxxx# ping ipv6 3003::11
Pinging 3003::11 with 64 bytes of data:
64 bytes from 3003::11: icmp_seq=1. time=0 ms
64 bytes from 3003::11: icmp_seq=2. time=50 ms
64 bytes from 3003::11: icmp_seq=3. time=0 ms
64 bytes from 3003::11: icmp_seq=4. time=0 ms
----3003::11 PING Statistics----
4 packets transmitted, 4 packets received, 0% packet loss
round-trip (ms) min/avg/max = 0/12/50
```

---

```
switchxxxxxx# ping ipv6 FF02::1
Pinging FF02::1 with 64 bytes of data:
64 bytes from 3003::11: icmp_seq=1. time=0 ms
64 bytes from 3003::33: icmp_seq=1. time=70 ms
64 bytes from 3003::11: icmp_seq=2. time=0 ms
64 bytes from 3003::55: icmp_seq=1. time=1050 ms
64 bytes from 3003::33: icmp_seq=2. time=70 ms
64 bytes from 3003::55: icmp_seq=2. time=1050 ms
64 bytes from 3003::11: icmp_seq=3. time=0 ms
64 bytes from 3003::33: icmp_seq=3. time=70 ms
```



```

64 bytes from 3003::11: icmp_seq=4. time=0 ms
64 bytes from 3003::55: icmp_seq=3. time=1050 ms
64 bytes from 3003::33: icmp_seq=4. time=70 ms
64 bytes from 3003::55: icmp_sq=4. time=1050 ms
---- FF02::1 PING Statistics----
4 packets transmitted, 12 packets received

```

## 3.2 traceroute

To display the routes that packets will take when traveling to their destination, use the **traceroute** EXEC mode command.

### Syntax

```
traceroute ip {ipv4-address | hostname} [size packet_size] [ttl max-ttl] [count packet_count] [timeout time_out] [source ip-address] [tos tos]
```

```
traceroute ipv6 {ipv6-address | hostname} [size packet_size] [ttl max-ttl] [count packet_count] [timeout time_out] [source ip-address] [tos tos]
```

### Parameters

- **ip**—Use IPv4 to discover the route.
- **ipv6**—Use IPv6 to discover the route.
- **ipv4-address**—IPv4 address of the destination host.
- **ipv6-address**—IPv6 address of the destination host.
- **hostname**—Hostname of the destination host. (Length: 1-160 characters. Maximum label size for each part of the host name: 63.)
- **size packet\_size**—Number of bytes in the packet not including the VLAN tag. The default is 64 bytes. (IPv4:64-1518, IPv6: 68-1518)
- **ttl max-ttl**—The largest TTL value that can be used. The default is 30. The **traceroute** command terminates when the destination is reached or when this value is reached. (Range: 1–255)
- **count packet\_count**—The number of probes to be sent at each TTL level. The default count is 3. (Range: 1–10)
- **timeout time\_out**—The number of seconds to wait for a response to a probe packet. The default is 3 seconds. (Range: 1–60)
- **source ip-address**—One of the interface addresses of the device to use as a source address for the probes. The device selects the optimal source address by default. (Range: Valid IP address)
- **tos tos**—The Type-Of-Service byte in the IP Header of the packet. (Range: 0–255)

### Default Usage

N/A

### Command Mode

EXEC mode

### User Guidelines

The traceroute command works by taking advantage of the error messages generated by routers when a datagram exceeds its time-to-live (TTL) value.

The traceroute command starts by sending probe datagrams with a TTL value of one. This causes the first router to discard the probe datagram and send back an error message. The traceroute command sends several probes at each TTL level and displays the round-trip time for each.

The traceroute command sends out one probe at a time. Each outgoing packet can result in one or two error messages. A “time exceeded” error message indicates that an intermediate router has seen and discarded the probe. A “destination unreachable” error message indicates that the destination node has received the

probe and discarded it because it could not deliver the packet. If the timer goes off before a response comes in, the traceroute command prints an asterisk (\*).

The traceroute command terminates when the destination responds, when the maximum TTL is exceeded, or when the user interrupts the trace with Esc.

The traceroute command is not relevant to IPv6 link local addresses.

### Example

```
switchxxxxx# traceroute ip umaxp1.physics.lsa.umich.edu
Type Esc to abort.
Tracing the route to umaxp1.physics.lsa.umich.edu (141.211.101.64)
 1 i2-gateway.stanford.edu (192.68.191.83)  0 msec 0 msec 0 msec
 2 STAN.POS.calren2.NET (171.64.1.213)  0 msec 0 msec 0 msec
 3 SUNV--STAN.POS.calren2.net (198.32.249.73)  1 msec 1 msec 1 msec
 4 Abilene--QSV.POS.calren2.net (198.32.249.162)  1 msec 1 msec 1 msec
 5 kscyng-snvang.abilene.ucaid.edu (198.32.8.103)  33 msec 35 msec 35 msec
 6 iplsng-kscyng.abilene.ucaid.edu (198.32.8.80)  47 msec 45 msec 45 msec
 7 so-0-2-0x1.aa1.mich.net (192.122.183.9)  56 msec 53 msec 54 msec
 8 atm1-0x24.michnet8.mich.net (198.108.23.82)  56 msec 56 msec 57 msec
 9 * * *
10 A-ARB3-LSA-NG.c-SEB.umnet.umich.edu(141.211.5.22)58 msec 58msec 58 msec
11 umaxp1.physics.lsa.umich.edu (141.211.101.64)  62 msec 63 msec 63 msec
Trace completed
```

The following table describes the significant fields shown in the display:

Field	Description
1	Indicates the sequence number of the router in the path to the host.
i2-gateway.stanford.edu	Host name of this router.
192.68.191.83	IP address of this router.
1 msec 1 msec 1 msec	Round-trip time for each of the probes that are sent.

The following are characters that can appear in the traceroute command output:

Field	Description
*	The probe timed out.
?	Unknown packet type.
A	Administratively unreachable. Usually, this output indicates that an access list is blocking traffic.
F	Fragmentation required and DF is set.
H	Host unreachable.
N	Network unreachable.
P	Protocol unreachable.
Q	Source quench.
R	Fragment reassembly time exceeded
S	Source route failed.
U	Port unreachable.

## 3.3 telnet

The **telnet** EXEC mode command enables logging on to a host that supports Telnet.

### Syntax

```
telnet {ip-address | hostname} [port] [keyword...]
```

### Parameters

- **ip-address**—Specifies the destination host IP address (IPv4 or IPv6).
- **hostname**—Specifies the destination host name. (Length: 1-160 characters. Maximum label size for each part of the host name: 63.)
- **port**—Specifies the decimal TCP port number or one of the keywords listed in the Ports table in the User Guidelines.
- **keyword**—Specifies the one or more keywords listed in the Keywords table in the User Guidelines.

### Default Configuration

The default port is the Telnet port (23) on the host.

By default, Telnet is disabled.

### Command Mode

EXEC mode

### User Guidelines

Telnet software supports special Telnet commands in the form of Telnet sequences that map generic terminal control functions to operating system-specific functions. To enter a Telnet sequence, press the escape sequence keys (Ctrl-shift-6) followed by a Telnet command character.

### Special Telnet Sequences

Telnet Sequence	Purpose
Ctrl-shift-6-b	Break
Ctrl-shift-6-c	Interrupt Process (IP)
Ctrl-shift-6-h	Erase Character (EC)
Ctrl-shift-6-o	Abort Output (AO)
Ctrl-shift-6-t	Are You There? (AYT)
Ctrl-shift-6-u	Erase Line (EL)

At any time during an active Telnet session, available Telnet commands can be listed by pressing the `?/help` keys at the system prompt.

A sample of this list follows.

```
switchxxxxxx# ?/help
[Special telnet escape help]
^^ B sends telnet BREAK
^^ C sends telnet IP
^^ H sends telnet EC
^^ O sends telnet AO
^^ T sends telnet AYT
^^ U sends telnet EL
```

?/help suspends the session (return to system command prompt)

Several concurrent Telnet sessions can be opened, enabling switching between the sessions. To open a subsequent session, the current connection has to be suspended by pressing the escape sequence keys (Ctrl-shift-6) and x to return to the system command prompt. Then open a new connection with the telnet EXEC mode command.

This command lists concurrent Telnet connections to remote hosts that were opened by the current Telnet session to the local device. It does not list Telnet connections to remote hosts that were opened by other Telnet sessions.

#### Keywords Table

Options	Description
/echo	Enables local echo.
/quiet	Prevents onscreen display of all messages from the software.
/source-interface	Specifies the source interface.
/stream	Turns on stream processing, which enables a raw TCP stream with no Telnet control sequences. A stream connection does not process Telnet options and can be appropriate for connections to ports running UNIX-to-UNIX Copy Program (UUCP) and other non-Telnet protocols.
Ctrl-shift-6 x	Returns to the System Command Prompt.

#### Ports Table

Keyword	Description	Port Number
BGP	Border Gateway Protocol	179
chargen	Character generator	19
cmd	Remote commands	514
daytime	Daytime	13
discard	Discard	9
domain	Domain Name Service	53
echo	Echo	7
exec	Exec	512
finger	Finger	79
ftp	File Transfer Protocol	21
ftp-data	FTP data connections	20
gopher	Gopher	70
hostname	NIC hostname server	101
ident	Ident Protocol	113
irc	Internet Relay Chat	194
klogin	Kerberos login	543
kshell	Kerberos shell	544
login	Login	513
lpd	Printer service	515
nntp	Network News Transport Protocol	119
pim-auto-rp	PIM Auto-RP	496
pop2	Post Office Protocol v2	109

Keyword	Description	Port Number
pop3	Post Office Protocol v3	110
smtp	Simple Mail Transport Protocol	25
sunrpc	Sun Remote Procedure Call	111
syslog	Syslog	514
tacacs	TAC Access Control System	49
talk	Talk	517
telnet	Telnet	23
time	Time	37
uucp	Unix-to-Unix Copy Program	540
whois	Nickname	43
www	World Wide Web	80

**Example**

The following example displays logging in to IP address 176.213.10.50 via Telnet.

---

```
switchxxxxxx# telnet 176.213.10.50
```

## 3.4 resume

The **resume** EXEC mode command enables switching to another open Telnet session.

**Syntax**

```
resume [connection]
```

**Parameters**

**connection**—Specifies the connection number. (Range: 1-4 connections.)

**Default Configuration**

The default connection number is that of the most recent connection.

**Command Mode**

EXEC mode

**Example**

The following command switches to open Telnet session number 1.

---

```
switchxxxxxx# resume 1
```

## 3.5 hostname

The **hostname** Global Configuration mode command specifies or modifies the device host name. Use the **no** form of the command to remove the existing host name.

**Syntax**

```
hostname name
```

```
no hostname
```

**Parameters**

**Name**—Specifies the device host name. (Length: 1-160 characters. Maximum label size for each part of the host name: 63). The hostname must start with a letter, end with a letter or digit, and have as interior characters only letters, digits, and hyphens.

**Default Configuration**

No host name is defined.

**Command Mode**

Global Configuration mode

**Example**

The following example specifies the device host name as 'enterprise'.

---

```
switchxxxxxx(config)# hostname enterprise
enterprise(config)#
```

---

## 3.6 reload

The **reload** Privileged EXEC mode command reloads the operating system.

**Syntax**

**reload**

**Parameters**

N/A

**Default Usage**

N/A

**Command Mode**

Privileged EXEC mode

**Example**

The following example reloads the operating system.

---

```
switchxxxxxx# reload
This command will reset the whole system and disconnect your current session. Do
you want to continue? (y/n) [Y]
```

---

## 3.7 service cpu-utilization

The **service cpu-utilization** Global Configuration mode command enables measuring CPU utilization. Use the **no** form of this command to restore the default configuration.

**Syntax**

**service cpu-utilization**

**no service cpu-utilization**

**Parameters**

N/A

**Default Configuration**

Measuring CPU utilization is disabled.

**Command Mode**

Global Configuration mode

**User Guidelines**

Use the **service cpu utilization** command to measure information on CPU utilization.

**Example**

The following example enables measuring CPU utilization.

---

```
switchxxxxxx(config)# service cpu-utilization
```

---

## 3.8 show cpu utilization

The **show cpu utilization** Privileged EXEC mode command displays information about CPU utilization.

**Syntax**

**show cpu utilization**

**Parameters**

N/A

**Default Usage**

N/A

**Command Mode**

Privileged EXEC mode

**User Guidelines**

Use the **show cpu-utilization** command to enable measuring CPU utilization.

**Example**

The following example displays CPU utilization information.

---

```
switchxxxxxx# show cpu utilization  
CPU utilization service is on.  
CPU utilization  
-----  
five seconds: 5%; one minute: 3%; five minutes: 3%
```

---

## 3.9 clear cpu counters

The **clear cpu counters** EXEC mode command clears traffic counters to and from the CPU.

### Syntax

**clear cpu counters**

### Parameters

N/A

### Default Usage

N/A

### Command Mode

EXEC mode

### Example

The following example clears the CPU traffic counters.

---

```
switchxxxxxx# clear cpu counters
```

---

---

## 3.10 service cpu-counters

The **service cpu-counters** Global Configuration mode command enables traffic counting to and from the CPU. To disable counting, use the **no** form of this command.

### Syntax

**service cpu-counters**

**no service cpu-counters**

### Parameters

N/A

### Default Usage

N/A

### Command Mode

Global Configuration mode

### User Guidelines

Use the **show cpu counters** command to display the CPU traffic counters.

### Example

The following example enables counting CPU traffic.

---

```
switchxxxxxx(config)# service cpu-counters
```

---



---

## 3.11 show cpu counters

The **show cpu counters** EXEC mode command displays traffic counter information to and from the CPU.

### Syntax

**show cpu counters**

### Parameters

N/A

### Default Usage

N/A

### Command Mode

EXEC mode

### User Guidelines

Use the **service cpu-counters** command to enable traffic counting to and from the CPU.

### Example

The following example displays the CPU traffic counters.

---

```
switchxxxxxx# show cpu counters
CPU counters are active.
In Octets: 987891
In Unicast Packets: 3589
In Multicast Packets: 29
In Broadcast Packets: 8
Out Octets: 972181
Out Unicast Packets: 3322
Out Multicast Packets: 22
Out Broadcast Packets: 8
```

---

## 3.12 show users

The **show users** EXEC mode command displays information about the active users.

### Syntax

**show users**

### Parameters

N/A

### Default Usage

N/A

### Command Mode

EXEC mode

**Example**

The following example displays information about the active users.

---

```
switchxxxxxx# show users
```

Username	Protocol	Location
-----	-----	-----
Bob	Serial	
John	SSH	172.16.0.1
Robert	HTTP	172.16.0.8
Betty	Telnet	172.16.1.7
Sam		172.16.1.6

---

**3.13 show sessions**

The **show sessions** EXEC mode command displays open Telnet sessions.

**Syntax**

**show sessions**

**Parameters**

N/A

**Default Usage**

N/A

**Command Mode**

EXEC mode

**User Guidelines**

The **show sessions** command displays Telnet sessions to remote hosts opened by the current Telnet session to the local device. It does not display Telnet sessions to remote hosts opened by other Telnet sessions to the local device.

**Example**

The following example displays open Telnet sessions.

---

```
switchxxxxxx# show sessions
```

Connection	Host	Address	Port	Byte
-----	-----	-----	-----	-----
1	Remote router	172.16.1.1	23	89
2	172.16.1.2	172.16.1.2	23	8

---

The following table describes significant fields shown above.

Field	Description
Connection	The connection number.
Host	The remote host to which the device is connected through a Telnet session.

Field	Description
Address	The remote host IP address.
Port	The Telnet TCP port number.
Byte	The number of unread bytes for the user to see on the connection.

## 3.14 show system

The **show system** EXEC mode command displays system information.

### Syntax

**show system**

### Parameters

N/A.

### Command Mode

EXEC mode

### Example

The following example displays the system information.

```

System Description:                Standalone Managed L3 Switch
System Up Time (days, hour:min:sec): 01,04:29:01
System Contact:
System Name:                       switch030405
System Location:
System MAC Address:                22:02:10:17:07:00
System Object ID:                  1.3.6.1.4.1.572.17389.311

Main Power Supply Status:          OK
Fan 1 Status:                      OK

```

```

          Unit           Temperature (Celsius)           Status
-----
          1             40                               OK

```

## 3.15 show version

The **show version** EXEC mode command displays system version information.

### Syntax

**show version [md5]**

### Parameters

**md5**— Displays external MD5 digest of firmware.

**Default Usage**

N/A

**Command Mode**

EXEC mode

**Example**

The following example displays system version information.

---

```
switchxxxxxx# show version
SW Version      1.1.0.5 ( date 15-Sep-2010 time 10:31:33 )
Boot Version    1.1.0.2 ( date 04-Sep-2010 time 21:51:53 )
HW Version      V01
```

---

## 3.16 system resources routing

The **system resources routing** Global Configuration mode command configures the routing table maximum size. Use the **no** form of this command to return to the default size.

**Syntax****system resources routing** *routes hosts interfaces***no system resources routing****Parameters**

- **routes**—Specifies the maximum number of remote networks in the routing table.
- **hosts**—Specifies the maximum number of directly attached hosts.
- **interfaces**—Specifies the maximum number of IP interfaces.

**Default Configuration**

Hosts: 20-1024, default = 1024

Routes: 20-100, default = 100

IP Interfaces: 2-64, default = 32

**Command Mode**

Global Configuration mode

**User Guidelines**

The settings are effective after reboot.

**Example**

The following example configures the routing table maximum size.

---

```
switchxxxxxx# system resources routing 20 23 5
```

---

## 3.17 show system resources

The **show system resources routings** EXEC mode command displays system routing resource information.

### Syntax

**show system resources [routing]**

### Parameters

**routing**—Displays the number of hosts, routers and IP interfaces that are available.

### Command Mode

EXEC mode

### Example

The following example displays the system routing resources information. The values in the Current Value column show what resources are currently available. The values in the After Reboot Value column show what resources will be available after reboot as a result of system resources routing command.

```
switchxxxxxx# show system resources routing
Parameters          Current Value      After Reboot Value
-----
Hosts:              100
Routes:             32
IP Interfaces:     32
```

## 3.18 show system defaults

Use the **show system defaults** EXEC mode command to display system defaults.

### Syntax

**show system defaults [session]**

### Parameters

**session**—Show information for specific session only. Available values are: management, 802.1x, port, fdb, port-mirroring, spanning-tree, vlan, voice-vlan, ip-addressing, network-security and qos-acl.

### Command Mode

EXEC mode

### Examples

```
switchxxxxxx# show system defaults
```

## 3.19 show services tcp-udp

Use the **show services tcp-udp** Privileged EXEC mode command to display information about the active TCP and UDP services.

### Syntax

**show services tcp-udp**

**Parameters**

This command has no arguments or keywords.

**Command Mode**

Privileged EXEC mode

**User Guidelines**

The output does not show sessions where the device is a TCP/UDP client.

**Examples**


---

```
switchxxxxxx# show services tcp-udp
```

Type	Local IP Address	Remote IP address	Service Name	State
TCP	All:22		SSH	LISTEN
TCP	All:23		Telnet	LISTEN
TCP	All:80		HTTP	LISTEN
TCP	All:443		HTTPS	LISTEN
TCP	172.16.1.1:23	172.16.1.18:8789	Telnet	ESTABLISHED
TCP6	All-23		Telnet	LISTEN
TCP6	fe80::200:b0ff:fe00:0-23		Telnet	
	fe80::200:b0ff:fe00:0-8999			ESTABLISHED
UDP	All:161		SNMP	
UDP6A	11-161		SNMP	

---

## 3.20 show tech-support

Use the **show tech-support** EXEC mode command to display system and configuration information that can be provided to the Technical Assistance Center when reporting a problem.

**Syntax**

**show tech-support** [*config*] [*memory*]

**Parameters**

**Memory**—Displays memory and processor state data.

**Config**—Displays switch configuration within the CLI commands supported on the device.

**Default Configuration**

By default, this command displays the output for technical-support-related show commands. Use keywords to specify the type of information to be displayed. If you do not specify any parameters, the system displays all configuration and memory data.

**Command Types**

Switch command.

**Command Mode**

EXEC mode

### User Guidelines

Caution: Avoid running multiple **show tech-support** commands on a switch or multiple switches on the network segment. Doing so may cause starvation of some time sensitive protocols, like STP.

The show tech-support command may timeout if the configuration file output takes longer to display than the configured session timeout time. If this happens, enter a set logout timeout value of **0** to disable automatic disconnection of idle sessions or enter a longer timeout value.

The show tech-support command output is continuous, it does not display one screen at a time. To interrupt the output, press Esc.

If you specify the **config** keyword, the show tech-support command displays the output of a list of the following commands supported on the device.

- show clock
- show system
- show version
- show system mode
- show ip interface
- show ipv6 interface
- show switch
- show running-config
- show interfaces configuration
- show interfaces status
- show interfaces port-channel
- show vlan
- show interfaces switchport
- show spanning tree
- show bridge multicast address-table
- show ip igmp snooping groups
- show ipv6 mld snooping groups
- show dot1x
- show dot1x users
- show lldp configuration
- show lldp neighbors
- show interfaces counters
- show users
- show sessions
- show logging file
- show errdisable interface
- show logging

If the user specifies the memory keyword, the show tech-support command displays the following output:

- Flash info (dir if existed, or flash mapping)
- Output of command show bootvar
- Buffers info (like print os buff)
- Memory info (like print os mem)
- Proc info (like print os tasks)
- Versions of software components
- Output of command show cpu utilization

---

## 3.21 show system id

The **show system id** EXEC mode command displays the system identity information.

### Syntax

**show system id**

### Parameters

N/A.

### Command Mode

EXEC mode

### Example

The following example displays the system identity information.

---

```
switchxxxxxx# show system id
```



---

## 4.1 clock set

The **clock set** Privileged EXEC mode command manually sets the system clock.

### Syntax

**clock set** *hh:mm:ss* *[[day month] | [month day]]* *year*

### Parameters

- **hh:mm:ss**—Specifies the current time in hours (military format), minutes, and seconds. (Range: hh: 0-23, mm: 0-59, ss: 0-59)
- **day**—Specifies the current day of the month. (Range: 1-31)
- **month**—Specifies the current month using the first three letters of the month name. (Range: Jan–Dec)
- **year**—Specifies the current year. (Range: 2000–2037)

### Command Mode

Privileged EXEC mode

### User Guidelines

It is recommended that the user enter the local clock time and date.

### Example

The following example sets the system time to 13:32:00 on March 7th, 2005.

---

```
switchxxxxxx# clock set 13:32:00 7 Mar 2005
```

---

## 4.2 clock source

The **clock source** Global Configuration mode command configures an external time source for the system clock. Use the **no** form of this command to disable the external time source.

### Syntax

**clock source** *sntp*

**no clock source**

### Parameters

**sntp**—Specifies that an SNTP server is the external clock source.

### Default Configuration

There is no external clock source.

### Command Mode

Global Configuration mode

**Example**

The following example configures an SNTP server as an external time source for the system clock.

---

```
switchxxxxxx(config)# clock source sntp
```

---

**4.3 clock timezone**

Use the **clock timezone** Global Configuration command to set the time zone for display purposes. Use the **no** form of this command to set the time to Coordinated Universal Time (UTC) or Greenwich Mean Time (GMT), which is the same.

**Syntax**

**clock timezone** *zone hours-offset [minutes-offset]*

**no clock timezone**

**Parameters**

- **zone**—The acronym of the time zone. (Range: Up to 4 characters)
- **hours-offset**—Hours difference from UTC. (Range: (-12)–(+13))
- **minutes-offset**—Minutes difference from UTC. (Range: 0–59)

**Default Configuration**

Offsets are **0**.

Acronym is empty.

**Command Mode**

Global Configuration mode

**User Guidelines**

The system internally keeps time in UTC, so this command is used only for display purposes and when the time is manually set.

**Example**


---

```
switchxxxxxx(config)# clock timezone abc +2 minutes 32
```

---

**4.4 clock summer-time**

Use one of the formats of the **clock summer-time** Global Configuration command to configure the system to automatically switch to summer time (Daylight Saving Time). Use the **no** form of this command to configure the software not to automatically switch to summer time.

**Syntax**

**clock summer-time** *zone recurring {usa | eu | {week day month hh:mm week day month hh:mm}} [offset]*

**clock summer-time** *zone date day month year hh:mm date month year hh:mm [offset]*

**clock summer-time** *zone date month day year hh:mm month day year hh:mm [offset]*

**no clock summer-time**

## Parameters

- **zone**—The acronym of the time zone to be displayed when summer time is in effect. (Range: up to 4 characters)
- **recurring**—Indicates that summer time starts and ends on the corresponding specified days every year.
- **date**—Indicates that summer time starts on the first date listed in the command and ends on the second date in the command.
- **usa**—The summer time rules are the United States rules.
- **eu**—The summer time rules are the European Union rules.
- **week**—Week of the month. Can be 1–4, first, last.
- **day**—Day of the week (first three characters by name, such as Sun).
- **date**—Date of the month. (Range: 1–31)
- **month**—Month (first three characters by name, such as Feb).
- **year**—year (no abbreviation). (Range: 2000–2097)
- **hh:mm**—Time (military format) in hours and minutes. (Range: hh:mmhh: 0-23, mm: 0-59)
- **offset**—Number of minutes to add during summer time (default is 60). (Range: 1440)

## Default Configuration

Summer time is disabled.

## Command Mode

Global Configuration mode

## User Guidelines

In both the **date** and **recurring** forms of the command, the first part of the command specifies when summer time begins, and the second part specifies when it ends. All times are relative to the local time zone. The start time is relative to standard time. The end time is relative to summer time. If the starting month is chronologically after the ending month, the system assumes that you are in the southern hemisphere.

USA rules for Daylight Saving Time:

- From 2007:
  - Start: Second Sunday in March
  - End: First Sunday in November
  - Time: 2 AM local time
- Before 2007:
  - Start: First Sunday in April
  - End: Last Sunday in October
  - Time: 2 AM local time

EU rules for Daylight Saving Time:

- Start: Last Sunday in March
- End: Last Sunday in October
- Time: 1.00 am (01:00) Greenwich Mean Time (GMT)

## Example

---

```
switchxxxxxx(config)# clock summer-time abc date apr 1 2010 09:00 aug 2 2010
09:00
```

---

## 4.5 sntp authentication-key

The **sntp authentication-key** Global Configuration mode command defines an authentication key for Simple Network Time Protocol (SNTP). Use the **no** form of this command to remove the authentication key for SNTP.

### Syntax

**sntp authentication-key** *key-number* **md5** *key-value*

**no sntp authentication-key** *key-number*

### Parameters

- **key-number**—Specifies the key number. (Range: 1–4294967295)
- **key-value**—Specifies the key value. (Length: 1–8 characters)

### Default Configuration

No authentication key is defined.

### Command Mode

Global Configuration mode

### Examples

The following example defines the authentication key for SNTP.

---

```
switchxxxxxx(config)# sntp authentication-key 8 md5 ClkKey
switchxxxxxx(config)# sntp authentication-key 8 md5 ClkKey
switchxxxxxx(config)# sntp trusted-key 8
switchxxxxxx(config)# sntp authenticate
```

---

## 4.6 sntp authenticate

The **sntp authenticate** Global Configuration mode command enables authentication for received SNTP traffic from servers. Use the **no** form of this command to disable the feature.

### Syntax

**sntp authenticate**

**no sntp authenticate**

### Parameters

N/A

### Default Configuration

Authentication is disabled.

### Command Mode

Global Configuration mode

### User Guidelines

The command is relevant for both Unicast and Broadcast.

## Examples

The following example enables authentication for received SNTP traffic and sets the key and encryption key.

---

```
switchxxxxxx(config)# sntp authenticate
switchxxxxxx(config)# sntp authentication-key 8 md5 ClkKey
switchxxxxxx(config)# sntp trusted-key 8
```

---

## 4.7 sntp trusted-key

The **sntp trusted-key** Global Configuration mode command authenticates the identity of the system with which SNTP synchronizes. Use the **no** form of this command to disable system identity authentication.

### Syntax

**sntp trusted-key** *key-number*

**no sntp trusted-key** *key-number*

### Parameters

**key-number**—Specifies the key number of the authentication key to be trusted. (Range: 1–4294967295)

### Default Configuration

No keys are trusted.

### Command Mode

Global Configuration mode

### User Guidelines

The command is relevant for both received unicast and broadcast.

## Examples

The following example authenticates key 8.

---

```
switchxxxxxx(config)# sntp trusted-key 8
switchxxxxxx(config)# sntp authentication-key 8 md5 ClkKey
switchxxxxxx(config)# sntp trusted-key 8
switchxxxxxx(config)# sntp authenticate
```

---

## 4.8 sntp client poll timer

The **sntp client poll timer** Global Configuration mode command sets the polling time for the SNTP client. Use the **no** form of this command to restore the default configuration.

### Syntax

**sntp client poll timer** *seconds*

**no sntp client poll timer**

### Parameters

**seconds**—Specifies the polling interval in seconds. (Range: 60–86400)

### Default Configuration

The default polling interval is 1024 seconds.

### Command Mode

Global Configuration mode

### Example

The following example sets the polling time for the SNTP client to 120 seconds.

---

```
switchxxxxxx(config)# sntp client poll timer 120
```

---

## 4.9 sntp broadcast client enable

The **sntp broadcast client enable** Global Configuration mode command enables SNTP Broadcast clients. Use the **no** form of this command to disable SNTP Broadcast clients.

### Syntax

**sntp broadcast client enable**

**no sntp broadcast client enable**

### Default Configuration

The SNTP Broadcast client is disabled.

### Command Mode

Global Configuration mode

### User Guidelines

Use the **sntp broadcast client enable** Interface Configuration mode command to enable the SNTP Broadcast client on a specific interface.

After entering this command, you must enter [clock source snmp](#) for the command to be run. If this command is not run, the switch will not synchronize with Broadcast servers.

### Example

The following example enables SNTP Broadcast clients.

---

```
switchxxxxxx(config)# sntp broadcast client enable
```

---

## 4.10 sntp anycast client enable

The **sntp anycast client enable** Global Configuration mode command enables the SNTP Anycast client. Use the **no** form of this command to disable the SNTP Anycast client.

### Syntax

**sntp anycast client enable**

**no sntp anycast client enable**

### Parameters

N/A

### Default Configuration

The SNTP anycast client is disabled.

### Command Mode

Global Configuration mode

### User Guidelines

Use this command to enable the SNTP Anycast client.

### Example

The following example enables SNTP Anycast clients.

---

```
switchxxxxxx(config)# sntp anycast client enable
```

---

## 4.11 sntp client enable

The **sntp client enable** Global Configuration mode command enables the SNTP Broadcast and Anycast client on an interface. Use the **no** form of this command to disable the SNTP Broadcast and Anycast client.

### Syntax

**sntp client enable** {*interface-id*}

**no sntp client enable** {*interface-id*}

### Parameters

**interface-id**—Specifies an interface ID, which can be one of the following types: Ethernet port, Port-channel or VLAN.

### Default Configuration

The SNTP client is disabled on an interface.

### Command Mode

Global Configuration mode - Ethernet port, Port-channel or VLAN.

### User Guidelines

The [sntp broadcast client enable](#) Global Configuration mode command globally enables Broadcast clients.

The [sntp anycast client enable](#) Global Configuration mode command globally enables Anycast clients.

This command enables both.

### Example

The following example enables the SNTP Broadcast and Anycast client on port gi1/0/13.

---

```
switchxxxxxx(config)# sntp client enable gi1/0/13
```

---

## 4.12 sntp client enable (Interface)

To enable the SNTP Broadcast and Anycast client on an interface, use the **sntp client enable** Interface Configuration command. Use the **no** form of this command to disable the SNTP client.

This command enables the SNTP Broadcast and Anycast client on an interface. Use the **no** form of this command to disable the SNTP client.

### Syntax

**sntp client enable**

**no sntp client enable**

**Parameters**

N/A

**Default Configuration**

The SNTP client is disabled on an interface.

**Command Mode**

Interface Configuration (Ethernet, Port-channel, VLAN) mode

**User Guidelines**

The [sntp broadcast client enable](#) Global Configuration mode command globally enables Broadcast clients.

The [sntp anycast client enable](#) Global Configuration mode command globally enables Anycast clients.

**Example**

The following example enables the SNTP broadcast and anycast client on an interface.

---

```
switchxxxxxx(config-if)# sntp client enable
```

---

## 4.13 sntp unicast client enable

The **sntp unicast client enable** Global Configuration mode command enables the device to use Simple Network Time Protocol (SNTP)-predefined Unicast clients. Use the **no** form of this command to disable the SNTP Unicast clients.

**Syntax**

**sntp unicast client enable**

**no sntp unicast client enable**

**Parameters**

N/A

**Default Configuration**

The SNTP unicast client is disabled.

**Command Mode**

Global Configuration mode

**User Guidelines**

Use the [sntp server](#) Global Configuration mode command to define SNTP servers.

**Example**

The following example enables the device to use SNTP Unicast clients.

---

```
switchxxxxxx(config)# sntp unicast client enable
```

---



## 4.14 sntp unicast client poll

The **sntp unicast client poll** Global Configuration mode command enables polling for the SNTP predefined Unicast clients. Use the **no** form of this command to disable the polling for the SNTP client.

### Syntax

**sntp unicast client poll**

**no sntp unicast client poll**

### Default Configuration

Polling is disabled.

### Command Mode

Global Configuration mode

### User Guidelines

Polling time is configured with the **sntp client poll timer** Global Configuration mode command.

### Example

The following example enables polling for SNTP predefined unicast clients.

---

```
switchxxxxxx(config)# sntp unicast client poll
```

---

## 4.15 sntp server

The **sntp server** Global Configuration mode command configures the device to use the SNTP to request and accept Network Time Protocol (NTP) traffic from a specified server (meaning to accept system time from an SNTP server). Use the **no** form of this command to remove a server from the list of SNTP servers.

### Syntax

**sntp server** {*ip-address* | *hostname*} [**poll**] [**key** *keyid*]

**no sntp server** {*ip-address* | *hostname*}

### Parameters

- **ip-address**—Specifies the server IP address. This can be an IPv4, IPv6 or IPv6z address. See [IPv6z Address Conventions](#).
- **hostname**—Specifies the server hostname. Only translation to IPv4 addresses is supported. (Length: 1–158 characters. Maximum label length for each part of the hostname: 63 characters)
- **poll**—Enables polling.
- **key** *keyid*—Specifies the Authentication key to use when sending packets to this peer. (Range: 1–4294967295)

### Default Configuration

No servers are defined.

### Command Mode

Global Configuration mode

### User Guidelines

Up to 8 SNTP servers can be defined.

The **sntp unicast client enable** Global Configuration mode command enables predefined Unicast clients.

The `sntp unicast client poll` Global Configuration mode command globally enables polling. Polling time is configured with the `sntp client poll timer` Global Configuration mode command.

### Example

The following example configures the device to accept SNTP traffic from the server on 192.1.1.1 with polling.

---

```
switchxxxxxx(config)# sntp server 192.1.1.1 poll
```

---

## 4.16 sntp port

The `sntp port` Global Configuration mode command specifies a SNTP User Datagram Protocol (UDP) port. Use the `no` form of this command to use the SNTP server default port.

### Syntax

`sntp port` *port-number*

`no sntp port`

### Parameters

**port-number**—Specifies the UDP port number used by an SNTP server. (Range 1–65535)

### Default Configuration

The default port number is 123.

### Command Mode

Global Configuration mode

### Example

The following example specifies that port 321 of the SNTP server is the UDP port.

---

```
switchxxxxxx(config)# sntp port 321
```

---

## 4.17 show clock

The `show clock` EXEC mode command displays the time and date from the system clock.

### Syntax

`show clock` [*detail*]

### Parameters

**detail**—Displays the time zone and summer time configuration.

### Command Mode

EXEC mode

### Examples

**Example 1** - The following example displays the system time and date.

---

```
switchxxxxxx# show clock  
15:29:03 PDT(UTC-7) Jun 17 2002
```

---

```
Time source is SNTP
```

---

**Example 2** - The following example displays the system time and date along with the time zone and summer time configuration.

---

```
switchxxxxxx# show clock detail
15:29:03 PDT(UTC-7) Jun 17 2002
Time source is SNTP
Time zone:
Acronym is PST
Offset is UTC-8
Summertime:
Acronym is PDT
Recurring every year.
Begins at first Sunday of April at 2:00.
Ends at last Sunday of October at 2:00.
Offset is 60 minutes.
DHCP timezone: Disabled
```

---

## 4.18 show sntp configuration

The **show sntp configuration** Privileged EXEC mode command displays the SNTP configuration on the device.

### Syntax

**show sntp configuration**

### Parameters

N/A

### Default Configuration

N/A

### Command Mode

Privileged EXEC mode

### Example

The following example displays the device's current SNTP configuration.

---

```
switchxxxxxx# show sntp configuration
SNTP port : 123 .
Polling interval: 1024 seconds.
MD5 authentication keys
-----
2   John123
3   Alice456
-----
Authentication is not required for synchronization.
No trusted keys.
```

```

Unicast Clients: Enabled
Unicast Clients Polling: Enabled
Server          Polling
-----
1.1.1.121      Disabled
Broadcast Clients: disabled
Anycast Clients: disabled
No Broadcast Interfaces.
switchxxxxxx#

```

## 4.19 show sntp status

The **show sntp status** Privileged EXEC mode command displays the SNTP servers status.

### Syntax

**show sntp status**

### Parameters

N/A

### Default Configuration

N/A

### Command Mode

Privileged EXEC mode

### Example

The following example displays the SNTP servers status.

```
switchxxxxxx# show sntp status
```

```

Clock is synchronized, stratum 4, reference is 176.1.1.8, unicast
Reference time is afe2525e.70597b34 (00:10:22.438 PDT Jul 5 1993)

```

Unicast servers:

Server	Status	Last response	Offset [mSec]	Delay [mSec]
-----	-----	-----	-----	-----
176.1.1.8	Up	19:58:22.289 PDT Feb 19	7.33	117.79
176.1.8.179	Unknown	2005	8.98	189.19
		12:17.17.987 PDT Feb 19		
		2005		

Anycast server:

Server	Interface	Status	Last response	Offset [mSec]	Delay [mSec]
-----	-----	-----	-----	-----	-----
176.1.11.8	VLAN 118	Up	9:53:21.789 PDT	-----	-----
			Feb 19 2005	7.19	119.89

```
Broadcast:
Server      Interface      Last response
-----
176.9.1.1   VLAN 119       19:17:59.792
PDT Feb 19 2002
```



## 5.1 copy

The **copy** Privileged EXEC mode command copies a source file to a destination file.

### Syntax

**copy** *source-url destination-url*]

### Parameters

- **source-url**—Specifies the source file URL or source file reserved keyword to be copied. (Length: 1–160 characters)
- **destination-url**—Specifies the destination file URL or destination file reserved keyword. (Length: 1–160 characters).
- **"Flash://"** —The source or destination URL scheme that specifies the access method to the local flash memory. It stands for the root directory of the local flash. It is the default scheme for a URL that does not explicitly contain a scheme/access method (e.g. for copying the running configuration file, the user may either use `flash://running-config` or just `running-config`).

The following table displays the URL options.

Source and/or Destination URL	Source or Destination
<b>running-config</b>	Currently running configuration file.
<b>startup-config</b>	Startup configuration file.
<b>image</b>	Image file. If specified as the source file, it is the active image file. If specified as the destination file, it is the non-active image file.
<b>boot</b>	Boot file.
<b>tftp://</b>	Source or destination URL for a TFTP network server. The syntax for this alias is <code>tftp://host/[directory]/filename</code> . The host can be either an IP address or a host name.
<b>xmodem:</b>	Source for the file from a serial connection that uses the Xmodem protocol.
<b>null:</b>	Null destination for copies or files. A remote file can be copied to null to determine its size. For instance <code>copy running-conf null</code> returns the size of the running configuration file.
<b>backup-config</b>	Backup configuration file. A configuration file can be downloaded to this file (without giving a file name). This can then be copied to the running-conf or startup-conf files.
<b>mirror-config</b>	Mirrored configuration file. If the running config and the startup config have been identical for 24 hours, the startup config is automatically copied to the mirror-conf file by the system. It can then be copied to the startup or running conf if required.
<b>logging</b>	Specifies the SYSLOG file.
<b>Word&lt;1-128&gt;</b>	Name of file (e.g. backup-config).

### Default Configuration

Sensitive data is excluded if no method was specified

### Command Mode

Privileged EXEC mode

### User Guidelines

The location of the file system dictates the format of the source or destination URL.

The entire copying process may take several minutes and differs from protocol to protocol and from network to network.

### IPv6z Address Format

If the IPv6 address is a Link Local address (IPv6z address), the outgoing interface name must be specified. The format of an IPv6z address is: `{ipv6-link-local-address}%{interface-id}`. The subparameters are:

- **ipv6-link-local-address**—Specifies the IPv6 Link Local address.
- **interface-id**—{<port-type>[ ]<port-number>} | {<port-channel | po>[ ]<port-channel-number> | <tunnel | tu>[ ]<tunnel-number> | <vlan[ ]<vlan-id>

If the egress interface is not specified, the default interface is selected. The following combinations are possible:

- **ipv6\_address%interface\_id** - Refers to the IPv6 address on the interface specified.
- **ipv6\_address%0** - Refers to the IPv6 address on the single interface on which an IPv6 address is defined.
- **ipv6\_address** - Refers to the IPv6 address on the single interface on which an IPv6 address is defined.

### Invalid Combinations of Source and Destination

The following are invalid combinations of source and destination files:

- The source file and destination file are the same file.
- **xmodem:** is the destination file. The source file can be copied to **image**, **boot** and **null:** only.
- **tftp://** is the source file and destination file on the same copy.
- **\*.prv** files cannot be copied.
- **mirror-config** cannot be used as a destination

The following table describes the characters displayed by the system when **copy** is being run:

Character	Description
!	For network transfers, indicates that the copy process is taking place. Each exclamation point indicates successful transfer of ten packets (512 bytes each).
.	For network transfers, indicates that the copy process timed out.

### Various Copy Options Guidelines

- **Copying an Image File from a Server to Flash Memory**  
Use the **copy source-url flash://image** command to copy an image file from a server to flash memory. When the administrator copies an image file from the server to a device, the image file is saved to the “inactive” image. To use this image, the administrator must switch the inactive image to the active image and reboot. The device will then use this new image.
- **Copying a Boot File from a Server to Flash Memory**  
Use the **copy source-url boot** command to copy a boot file from a server to flash memory.
- **Copying a Configuration File from a Server to the Running Configuration File**  
Use the **copy source-url running-config** command to load a configuration file from a network server to the running configuration file of the device. The commands in the loaded configuration file are added to those in the running configuration file as if the commands were typed in the command-line interface (CLI). The resulting configuration file is a combination of the previous running configuration and the loaded configuration files, with the loaded configuration file taking precedence.



- **Copying a Configuration File from a Server to the Startup Configuration**

Use the **copy source-url startup-config** command to copy a configuration file from a network server to the device startup configuration file. The startup configuration file is replaced by the copied configuration file.

- **Storing the Running Config or Startup Config on a Server**

Use the **copy running-config destination-url** command to copy the current configuration file to a network server using TFTP.

Use the **copy startup-config destination-url** command to copy the startup configuration file to a network server.

- **Saving the Running Configuration to the Startup Configuration**

Use the **copy running-config startup-config** command to copy the running configuration to the startup configuration file.

- **-Backing Up the Running Configuration or Startup Configuration to a Backup Configuration file**

Use the **copy running-config flash://file\_name** command to back up the running configuration to a backup configuration file.

Use the **copy startup-config flash://file\_name** command to back up the startup configuration to a backup configuration file.

- **Restoring the Mirror Configuration File.**

Use **copy mirror-config startup-config** or **copy mirror-config running-config** to copy the mirror configuration file to one of the configuration files being used.

### Examples

**Example 1** - The following example copies system image file1 from the TFTP server 172.16.101.101 to the non-active image file.

---

```
switchxxxxx# copy tftp://172.16.101.101/file1 image
Accessing file 'file1' on 172.16.101.101...
Loading file1 from 172.16.101.101:
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!! [OK]
Copy took 0:01:11 [hh:mm:ss]
```

---

### Example 2 - Copying an Image from a Server to Flash Memory

The following example copies a system image named file1 from the TFTP server with an IP address of 172.16.101.101 to a non-active image file.

---

```
switchxxxxx# copy tftp://172.16.101.101/file1 flash://image
Accessing file 'file1' on 172.16.101.101...
Loading file1 from 172.16.101.101:
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!! [OK]
Copy took 0:01:11 [hh:mm:ss]
```

---

**Example 3 - Copying the mirror-config file to the startup-configuration file**

The following example copies the mirror configuration file, saved by the system, to the Startup Configuration file.

---

```
switchxxxxxx# copy mirror-config startup-config
```

---

## 5.2 write memory

Use the **write memory** Privileged EXEC mode command to save the Running Configuration file to the Startup Configuration file.

**Syntax**

**write memory**

**Parameters**

N/A

**Default Configuration**

N/A

**Command Mode**

Privileged EXEC mode

**Examples**

This example shows how to overwrite the startup-config with the running-config.

---

```
switchxxxxxx# write memory
Overwrite file [startup-config] ?[Yes/press any key for no]...15-Sep-2010 11:27
:48 %COPY-I-FILECPY: Files Copy - source URL running-config destination URL
flash://startup-config
15-Sep-2010 11:27:50 %COPY-N-TRAP: The copy operation was completed successfully
Copy succeeded
```

---

## 5.3 write

Use the **write** Privileged EXEC mode command to save the running configuration to the startup configuration file.

**Syntax**

**write [memory]**

**Parameters**

N/A

**Default Configuration**

N/A

**Command Mode**

Privileged EXEC mode

**Examples**

The following example shows how to overwrite the startup-config file with the running-config file with the write command.

---

```
switchxxxxxx# write
Overwrite file [startup-config] ?[Yes/press any key for no]...15-Sep-2010 11:27
:48 %COPY-I-FILECPY: Files Copy - source URL running-config destination URL
flash://startup-config
15-Sep-2010 11:27:50 %COPY-N-TRAP: The copy operation was completed successfully
Copy succeeded
```

---

**5.4 delete**

The **delete** Privileged EXEC mode command deletes a file from a flash memory device.

**Syntax****delete** *url***Parameters**

**url**—Specifies the location URL or reserved keyword of the file to be deleted. (Length: 1–160 characters)

"Flash://" is the source or destination URL scheme that specifies the access method to the local flash memory. It simply stands for the root directory of the local flash. It is the default scheme for a URL that does not explicitly contain a scheme/access method (e.g. for copying the running configuration file, the user may either use flash://running-config or just running-config).

The following table displays keywords and URL prefixes:

<b>URL</b>	
<b>startup-config</b>	Startup configuration file.
<b>WORD</b>	Name of file (e.g. backup-config).

**Default Configuration**

N/A

**Command Mode**

Privileged EXEC mode

**User Guidelines**

**mirror-config**, **\*.sys**, **\*.prv**, **image-1** and **image-2** files cannot be deleted.

**Example**

The following example deletes the file called 'backup-config' from the flash memory.

---

```
switchxxxxxx# delete flash://backup-config
Delete flash:backup-config? [confirm]
```

---

## 5.5 dir

The **dir** Privileged EXEC mode command displays the list of files on a flash file system.

### Syntax

**dir** *[directory-path]*

### Parameters

N/A

### Default Configuration

N/A

### Command Mode

Privileged EXEC mode

### Example

The following example displays the list of files on a flash file system

```
Total size of flash: 33292288 bytes
Free size of flash: 20708893 bytes
switchxxxxxx# dir
Directory of flash:
File Name      Permission  Flash Size  Data Size  Modified
-----
backup-config  rw          524288      104        01-Jan-2010 05:35:04
image-1        rw          10485760    10485760   01-Jan-2010 06:10:23
image-2        rw          10485760    10485760   01-Jan-2010 05:43:54
mirror-config  rw          524288      104        01-Jan-2010 05:35:04
dhcpsn.prv     --          262144      --         01-Jan-2010 05:25:07
sshkeys.prv    --          262144      --         04-Jan-2010 06:05:00
syslog1.sys    r-          524288      --         01-Jan-2010 05:57:00
syslog2.sys    r-          524288      --         01-Jan-2010 05:57:00
directry.prv   --          262144      --         01-Jan-2010 05:25:07
startup-config rw          786432      1081       01-Jan-2010 10:05:34
Total size of flash: 66322432 bytes
Free size of flash: 42205184 bytes
```

## 5.6 more

The **more** Privileged EXEC mode command displays a file.

### Syntax

**more** *url*

### Parameters

**url**—Specifies the location URL or reserved keyword of the source file to be displayed. (Length: 1–160 characters).

"Flash://"  
"Flash://" is the source or destination URL scheme that specifies the access method to the local flash memory. It simply stands for the root directory of the local flash. It is the default scheme for a URL that does not explicitly

contain a scheme/access method (e.g. for copying the running configuration file, the user may either use `flash://running-config` or just `running-config`).

The following table displays options for the URL parameter:

Keyword	Source or Destination
<b>running-config</b>	Current running configuration file.
<b>startup-config</b>	Startup configuration file.
<b>mirror-config</b>	Mirrored configuration file.
<b>WORD</b>	Name of file (e.g. <code>backup-config</code> ).

### Default Configuration

N/A

### Command Mode

Privileged EXEC mode

### User Guidelines

Files are displayed in ASCII format, except for the images, which are displayed in a hexadecimal format.

\*.prv files cannot be displayed.

### Example

The following example displays the running configuration file contents.

---

```
switchxxxxxx# more running-config
no spanning-tree
interface range gi1/0/11-48
speed 1000
exit
no lldp run
line console
exec-timeout 0
```

---

## 5.7 rename

The **rename** Privileged EXEC mode command renames a file.

### Syntax

**rename** *url new-url*

### Parameters

- **url**—Specifies the file location URL. (Length: 1–160 characters)
- **new-url**—Specifies the file's new URL. (Length: 1–160 characters)

"Flash://" is the source or destination URL scheme that specifies the access method to the local flash memory. It simply stands for the root directory of the local flash. It is the default scheme for a URL that does not explicitly contain a scheme/access method (e.g. for copying the running configuration file, the user may either use `flash://running-config` or just `running-config`).

The following table displays options for the URL parameter:

Keyword	Source or Destination
WORD<1-128>	Name of file (e.g. backup-config)..

### Default Configuration

N/A

### Command Mode

Privileged EXEC mode

### User Guidelines

**mirror-config**, \*.sys and \*.prv files cannot be renamed.

### Example

The following example renames the configuration backup file.

---

```
switchxxxxxx# rename backup-config m-config.bak
```

## 5.8 boot system

The **boot system** Privileged EXEC mode command specifies the active system image file that will be loaded by the device at startup.

### Syntax

```
boot system {image-1 | image-2}
```

### Parameters

- **image-1**—Specifies that image-1 is loaded as the system image during the next device startup.
- **image-2**—Specifies that image-2 is loaded as the system image during the next device startup.

### Default Configuration

This command has no default configuration.

### Command Mode

Privileged EXEC mode

### User Guidelines

Use the [show bootvar](#) command to display the active image.

### Example

The following example specifies that **image-1** is the active system image file loaded by the device at startup. The results of this command is displayed in [show bootvar](#).

---

```
switchxxxxxx# boot system image-1
switchxxxxxx#show bootvar
```

Image	Filename	Version	Date	Status
1	image-1	1.1.0.73	19-Jun-2011 18:10:49	Not active*

```
2      image-2      1.1.0.73      19-Jun-2011  18:10:49  Active
```

"\*" designates that the image was selected for the next boot

---

## 5.9 show running-config

Use the **show running-config** privileged EXEC command to display the contents of the currently running configuration file.

### Syntax

**show running-config**

### Parameters

N/A

### Default Configuration

N/A

### Command Mode

Privileged EXEC mode

### Example

The following example displays the running configuration file contents.

---

```
switchxxxxxx# show running-config
no spanning-tree
interface range gi1/0/11-48
speed 1000
exit
no lldp run
interface vlan 1
ip address 1.1.1.1 255.0.0.0
exit
line console
exec-timeout 0
exit
switchxxxxxx#
```

---

## 5.10 show startup-config

Use the **show startup-config** Privileged EXEC mode command to display the Startup Configuration file contents.

### Syntax

**show startup-config**

### Parameters

N/A

**Default Configuration**

N/A

**Command Mode**

Privileged EXEC mode

**Example**

The following example displays the startup configuration file contents.

---

```
switchxxxxxx# show startup-config
no spanning-tree
interface range gil/0/11-48
speed 1000
exit
no lldp run
interface vlan 1
ip address 1.1.1.1 255.0.0.0
exit
line console
exec-timeout 0
exit
switchxxxxxx#
```

**5.11 show bootvar**

Use the **show bootvar** EXEC mode command to display the active system image file that was loaded by the device at startup, and to display the system image file that will be loaded after rebooting the switch.

**Syntax****show bootvar****Parameters**

N/A

**Command Mode**

EXEC mode

**Example**

The following example displays the active system image file that was loaded by the device at startup and the system image file that will be loaded after rebooting the switch.

---

```
switchxxxxxx# show bootvar
```

Image	filename	Version	Date	Status
1	image-1	1.1.04	23-Jul-2010	Active
2	image-2	1.1.0.5	22-Jan-2010	Not active*

"\*": Designates that the image was selected for the next boot.



---

## 6.1 boot host auto-config

Use the **boot host auto-config** Global Configuration mode command to enable auto configuration via DHCP. Use the **no** form of this command to disable DHCP auto configuration.

### Syntax

**boot host auto-config**

**no boot host auto-config**

### Parameters

N/A

### Default Configuration

Enabled by default.

### Command Mode

Global Configuration mode

### Default Configuration

Enabled by default.

### Example

---

```
switchxxxxxx(conf)# boot host auto-config
```

---

## 6.2 boot host dhcp

Use the **boot host dhcp** Global Configuration mode command to force downloading a configuration file at the next system startup. Use the **no** form of this command to restore the host configuration file to the default.

### Syntax

**boot host dhcp**

**no boot host dhcp**

### Parameters

N/A

### Default Configuration

Disabled.

### Command Mode

Global Configuration mode

**User Guidelines**

Configuring **boot host dhcp** does not take effect until the next reboot.

**6.3 show boot**

Use the **show boot** Privilege EXEC mode command to show the status of the IP DHCP Auto Config process.

**Syntax**

**show boot**

**Parameters**

N/A

**Default Configuration**

N/A

**Command Mode**

Privilege EXEC mode

**Examples**


---

```
switchxxxxxx show boot
switchxxxxxx show boot
Config Download via DHCP: enabled
Next Boot Config Download via DHCP: default
Auto Config
-----
Config Download via DHCP: enable
Next Boot Config Download via DHCP: force
Auto Config State: Finished
TFTP Server IP address: 1.2.20.2
Configuration filename: /config/configfile1.cfg
    Auto Update
    -----
Image Download via DHCP: enabled
```

---

```
switchxxxxxx# show boot
Auto Config
-----
Config Download via DHCP: enable
Next Boot Config Download via DHCP: default
Auto Config State: Opening <hostname>-config file
    Auto Update
    -----
Image Download via DHCP: enabled
```

---

Example 3.

```
switchxxxxxx# show boot
```

```
Auto Config
```

```
-----
```

```
Config Download via DHCP: enable
```

```
Next Boot Config Download via DHCP: default
```

```
Auto Config State: Downloading configuration file
```

```
Auto Update
```

```
-----
```

```
Image Download via DHCP: enabled
```

---

```
switchxxxxxx# show boot
```

```
Auto Config
```

```
-----
```

```
Config Download via DHCP: enable
```

```
Next Boot Config Download via DHCP: default
```

```
Auto Config State: Searching hostname in indirect configuration file
```

```
Auto Update
```

```
-----
```

```
Image Download via DHCP: enabled
```

---

```
switchxxxxxx# show boot
```

```
Auto Config
```

```
-----
```

```
Config Download via DHCP: enable
```

```
Next Boot Config Download via DHCP: default
```

```
Auto Config State: Quit - failed all steps of finding existing configuration file
```

```
Auto Update
```

```
-----
```

```
Image Download via DHCP: enabled
```

---

```
switchxxxxxx# show boot
```

```
Auto Config
```

```
-----
```

```
Config Download via DHCP: enable
```

```
Next Boot Config Download via DHCP: default
```

```
Auto Update
```

```
-----
```

```
Image Download via DHCP: enabled
```

```
Auto Update State: Downloaded indirect image file
```

---

```

switchxxxxxx# show boot
Auto Config
-----
Config Download via DHCP: enable
Next Boot Config Download via DHCP: default
Auto Update
-----
Image Download via DHCP: enabled
Auto Update State: Downloading image file

```

---

```

switchxxxxxx# show boot
Auto Config
-----
Config Download via DHCP: enable
Next Boot Config Download via DHCP: default
Auto Config State: Finished
TFTP Server IP address: 1.2.20.2
Configuration filename: /config/configfile1.cfg
Auto Update
-----
Image Download via DHCP: enabled
Auto Update State: Downloading image file

```

---

## 6.4 ip dhcp tftp-server ip address

Use the **ip dhcp tftp-server ip address** Global Configuration mode command to set the TFTP server's IP address. This address server as the default address used by a switch when it has not been received from the DHCP server.

Use the **no** form of this command to remove the address.

### Syntax

**ip dhcp tftp-server ip address** *ip-addr*

**no ip dhcp tftp-server ip address**

### Parameters

**ip addr** *ip-addr*—Address of TFTP server

### Default Configuration

No IP address

### Command Mode

Global Configuration mode

### Examples

---

```

switchxxxxxx(conf)# ip dhcp tftp-server ip address 10.5.234.232

```

---

## 6.5 ip dhcp tftp-server file

Use the **ip dhcp tftp-server file** Global Configuration mode command to set the full file name of the configuration file to be downloaded on the TFTP server when it has not been received from the DHCP server. This serves as the default configuration file.

Use the **no** form of this command to remove the name.

### Syntax

**ip dhcp tftp-server file** *file-path*

**no ip dhcp tftp-server file**

### Parameters

**file-path**—Full file path and name of the configuration file on TFTP server

### Default Configuration

No file name

### Command Mode

Global Configuration mode

### Examples

---

```
switchxxxxxx(conf)# ip dhcp tftp-server file conf/conf-file
```

---

## 6.6 show ip dhcp tftp-server

Use the **show ip dhcp tftp-server** EXEC mode command to display information about the TFTP server.

### Syntax

**show ip dhcp tftp-server**

### Parameters

N/A

### Default Configuration

N/A

### Command Mode

EXEC

### Example

---

```
switchxxxxxx# show ip dhcp tftp server
tftp server address
active      1.1.1.1 from sname
manual     2.2.2.2
file path on tftp server
active     conf/conf-file from option 67
```



---

## 7.1 management access-list

The **management access-list** Global Configuration mode command configures a management access list (ACL) and enters the Management Access-List Configuration command mode. Use the **no** form of this command to delete an ACL.

### Syntax

**management access-list** *name*

**no management access-list** *name*

### Parameters

**name**—Specifies the ACL name. (Length: 1–32 characters)

### Default Configuration

N/A

### Command Mode

Global Configuration mode

### User Guidelines

Use this command to configure a management access list. This command enters the Management Access-List Configuration mode, where the denied or permitted access conditions are defined with the **deny** and **permit** commands.

If no match criteria are defined, the default value is **deny**.

When re-entering the access-list context, the new rules are entered at the end of the access list.

Use the [management access-class](#) command to select the active access list.

The active management list cannot be updated or removed.

For IPv6 management traffic that is tunneled in IPv4 packets, the management ACL is applied first on the external IPv4 header (rules with the service field are ignored), and then again on the inner IPv6 header.

### Example

**Example 1** - The following example creates a management access list called **m1ist**, configures management `gi1/0/11` and `gi1/0/19`, and makes the new access list the active list.

---

```
switchxxxxxx(config)# management access-list m1ist
switchxxxxxx(config-macl)# permit gi1/0/11
switchxxxxxx(config-macl)# permit gi1/0/19
switchxxxxxx(config-macl)# exit
switchxxxxxx(config)# management access-class m1ist
```

---

**Example 2** - The following example creates a management access list called 'mlist', configures all interfaces to be management interfaces except `gi1/0/11` and `9`, and makes the new access list the active list.

---

```
switchxxxxxx(config)# management access-list mlist
switchxxxxxx(config-macl)# deny gi1/0/11
switchxxxxxx(config-macl)# deny gi1/0/19
switchxxxxxx(config-macl)# permit
switchxxxxxx(config-macl)# exit
switchxxxxxx(config)# management access-class mlist
```

---

## 7.2 permit (Management)

The **permit** Management Access-List Configuration mode command sets permit rules (ACEs) for the management access list (ACL).

### Syntax

**permit** [*interface-id*] [*service service*]

**permit ip-source** {*ipv4-address* | *ipv6-address/ipv6-prefix-length*} [*mask {mask | prefix-length}*] [*interface-id*] [*service service*]

### Parameters

- **interface-id**:—Specify an interface ID. The interface ID can be one of the following types: Ethernet port, Port-channel or VLAN
- **service service** — Specifies the service type. Possible values are: Telnet, SSH, HTTP, HTTPS and SNMP.
- **ipv4-address**— Specifies the source IPv4 address.
- **ipv6-address/ipv6-prefix-length**— Specifies the source IPv6 address and source IPv6 address prefix length. The prefix length must be preceded by a forward slash (/). The parameter is optional.
- **mask mask** — Specifies the source IPv4 address network mask. This parameter is relevant only to IPv4 addresses.
- **mask prefix-length** — Specifies the number of bits that comprise the source IPv4 address prefix. The prefix length must be preceded by a forward slash (/). This parameter is relevant only to IPv4 addresses. (Range: 0–32)

### Default Configuration

No rules are configured.

### Command Mode

Management Access-List Configuration mode

### User Guidelines

Rules with Ethernet, VLAN, and port-channel parameters are valid only if an IP address is defined on the appropriate interface.

### Example

The following example permits all ports in the ACL called **mlist**

---

```
switchxxxxxx(config)# management access-list mlist
switchxxxxxx(config-macl)# permit
```



## 7.3 deny (Management)

The **deny** Management Access-List Configuration mode command sets permit rules (ACEs) for the management access list (ACL).

### Syntax

**deny** [*interface-id*] [*service service*]

**deny ip-source** {*ipv4-address* | *ipv6-address/ipv6-prefix-length*} [**mask** {*mask* | *prefix-length*}] [*interface-id*] [*service service*]

### Parameters

- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port, Port-channel or VLAN
- **service service**—Specifies the service type. Possible values are: Telnet, SSH, HTTP, HTTPS and SNMP.
- **ipv4-address**—Specifies the source IPv4 address.
- **ipv6-address/ipv6-prefix-length**—Specifies the source IPv6 address and source IPv6 address prefix length. The prefix length must be preceded by a forward slash (/). The parameter is optional.
- **mask mask**—Specifies the source IPv4 address network mask. The parameter is relevant only to IPv4 addresses.
- **mask prefix-length**—Specifies the number of bits that comprise the source IPv4 address prefix. The prefix length must be preceded by a forward slash (/). The parameter is relevant only to IPv4 addresses. (Range: 0–32)

### Default Configuration

No rules are configured.

### Command Mode

Management Access-List Configuration mode

### User Guidelines

Rules with ethernet, VLAN, and port-channel parameters are valid only if an IP address is defined on the appropriate interface.

### Example

The following example denies all ports in the ACL called **m1ist**.

```
switchxxxxxx(config)# management access-list m1ist
switchxxxxxx(config-macl)# deny
```

## 7.4 management access-class

The **management access-class** Global Configuration mode command restricts management connections by defining the active management access list (ACL). To disable management connection restrictions, use the **no** form of this command.

### Syntax

**management access-class** {*console-only* | *name*}

**no management access-class**

### Parameters

- **console-only**—Specifies that the device can be managed only from the console.

- **name**—Specifies the ACL name to be used. (Length: 1–32 characters)

### Default Configuration

The default configuration is no management connection restrictions.

### Command Mode

Global Configuration mode

### Example

The following example defines an access list called **mlist** as the active management access list.

---

```
switchxxxxxx(config)# management access-class mlist
```

---

## 7.5 show management access-list

The **show management access-list** Privileged EXEC mode command displays management access lists (ACLs).

### Syntax

**show management access-list** [*name*]

### Parameters

**name**—Specifies the name of a management access list to be displayed. (Length: 1–32 characters)

### Default Configuration

All management ACLs are displayed.

### Command Mode

Privileged EXEC mode

### Example

The following example displays the **mlist** management ACL.

---

```
switchxxxxxx# show management access-list mlist
-only
-----
deny
! (Note: all other access implicitly denied)
mlist
-----
permit gi1/0/11
permit gi1/0/19
! (Note: all other access implicitly denied)
switchxxxxxx#
```

---

## 7.6 show management access-class

The **show management access-class** Privileged EXEC mode command displays information about the active management access list (ACLs).

### Syntax

**show management access-class**

### Command Mode

Privileged EXEC mode

### Example

The following example displays the active management ACL information.

---

```
switchxxxxx# show management access-class  
Management access-class is enabled, using access list mlist
```



# Network Management Protocol (SNMP) Commands

---

## 8.1 snmp-server server

Use the **snmp-server server** Global Configuration mode command to enable the device to be configured by the SNMP protocol. Use the **no** form of this command to disable this function.

### Syntax

**snmp-server server**

**no snmp-server server**

### Parameters

N/A

### Default Configuration

Enabled

### Command Mode

Global Configuration mode

### Example

---

```
switchxxxxxx(config)# snmp-server server
```

---

## 8.2 snmp-server community

Use the **snmp-server community** Global Configuration mode command to set the community access string (password) that permits access to SNMP commands (v1 and v2). This is used for SNMP commands, such as GETs and SETs.

This command configures both SNMP v1 and v2.

Use the **no** form of this command to remove the specified community string.

### Syntax

**snmp-server community** *community-string* [**ro** | **rw** | **su**] [*ip-address* | *ipv6-address*] [**mask** *mask* | **prefix** *prefix-length*] [**view** *view-name*]

**no snmp-server community** *community-string* [*ip-address*]

### Parameters

- **community-string**—Define the password that permits access to the SNMP protocol. (Range: 1–20 characters). This string is used as an input parameter to [snmp-server user](#) for SNMP v3.
- **ro**—Specifies read-only access (default)
- **rw**—Specifies read-write access
- **su**—Specifies SNMP administrator access

- **view** *view-name*—Specifies the name of a view configured using the command `snmp-server view` (no specific order of the command configurations is imposed on the user). The view defines the objects available to the community. It is not relevant for `su`, which has access to the whole MIB. If unspecified, all the objects, except the community-table and SNMPv3 user and access tables, are available. (Range: 1–30 characters)
- **ip-address**—Management station IP address. The default is all IP addresses. This can be an IPv4 address, IPv6 or IPv6z address. See [IPv6z Address Conventions](#).
- **mask**—Specifies the mask of the IPv4 address. This is not a network mask, but rather a mask that defines which bits of the packet's source address are compared to the configured IP address. If unspecified, it defaults to 255.255.255.255. The command returns an error if the mask is specified without an IPv4 address.
- **prefix-length**—Specifies the number of bits that comprise the IPv4 address prefix. If unspecified, it defaults to 32. The command returns an error if the prefix-length is specified without an IPv4 address.

### Default Configuration

No community is defined

### Command Mode

Global Configuration mode

### User Guidelines

The logical key of the command is the pair (community, ip-address). If ip-address is omitted then the key is (community, All-IPs). This means that there cannot be two commands with the same community, ip address pair.

The *view-name* is used to restrict the access rights of a community string. When a view-name is specified, the software:

- Generates an internal security-name.
- Maps the internal security-name for SNMPv1 and SNMPv2 security models to an internal group-name.
- Maps the internal group-name for SNMPv1 and SNMPv2 security models to view-name (read-view and notify-view always, and for rw for write-view also),

### Example

Defines a password for administrator access to the management station at IP address 1.1.1.121 and mask 255.0.0.0.

---

```
switchxxxxxx(config)# snmp-server community abcd su 1.1.1.121 mask 255.0.0.0
```

---

## 8.3 snmp-server community-group

Use `snmp-server community-group` to configure access rights to a user group. The group must exist in order to be able to specify the access rights. This command configures both SNMP v1 and v2.

### Syntax

```
snmp-server community-group community-string group-name [ip-address | ipv6-address] [mask mask | prefix prefix-length]
```

### Parameters

- **community-string**—Define the password that permits access to the SNMP protocol. (Range: 1–20 characters). This string is used as an input parameter to `snmp-server user` for SNMP v3.
- **ip-address**—Management station IP address. The default is all IP addresses. This can be an IPv4 address, IPv6 or IPv6z address. See [IPv6z Address Conventions](#).

- **mask**—Specifies the mask of the IPv4 address. This is not a network mask, but rather a mask that defines which bits of the packet's source address are compared to the configured IP address. If unspecified, it defaults to 255.255.255.255. The command returns an error if the mask is specified without an IPv4 address.
- **prefix-length**—Specifies the number of bits that comprise the IPv4 address prefix. If unspecified, it defaults to 32. The command returns an error if the prefix-length is specified without an IPv4 address.
- **group-name**—This is the name of a group configured using `snmp-server group` with v1 or v2 (no specific order of the two command configurations is imposed on the user). The group defines the objects available to the community. (Range: 1–30 characters)

### Default Configuration

No community is defined

### Command Mode

Global Configuration mode

### User Guidelines

The *group-name* is used to restrict the access rights of a community string. When a group-name is specified, the software:

- Generates an internal security-name.
- Maps the internal security-name for SNMPv1 and SNMPv2 security models to the group-name.

### Example

---

Defines a password *tom* for the group *abcd* that enables this group to access the management station 1.1.1.121 with prefix 8.

```
switchxxxxxx(config)# snmp-server community-group tom abcd 1.1.1.122 prefix 8
```

## 8.4 snmp-server view

The **snmp-server view** Global Configuration mode command creates or updates an SNMP view. Use the **no** form of this command to remove an SNMP view.

### Syntax

```
snmp-server view view-name oid-tree {included | excluded}
```

```
no snmp-server view view-name [oid-tree]
```

### Parameters

- **view-name**—Specifies the name for the view that is being created or updated. (Length: 1–30 characters)
- **oid-tree**—Specifies the ASN.1 subtree object identifier to be included or excluded from the view. To identify the subtree, specify a text string consisting of numbers, such as 1.3.6.2.4, or a word, such as System and, optionally, a sequence of numbers. Replace a single sub-identifier with the asterisk (\*) wildcard to specify a subtree family; for example 1.3.\*.4. This parameter depends on the MIB being specified.
- **included**—Specifies that the view type is included.
- **excluded**—Specifies that the view type is excluded.

### Default Configuration

The following views are created by default:

- **Default** - Contains all MIBs except for those that configure the SNMP parameters themselves.
- **DefaultSuper** - Contains all MIBs.

**Command Mode**

Global Configuration mode

**User Guidelines**

This command can be entered multiple times for the same view.

The command's logical key is the pair (view-name, oid-tree). Therefore there cannot be two commands with the same view-name and oid-tree.

The number of views is limited to 64.

Default and DefaultSuper views are reserved for internal software use and cannot be deleted or modified.

**Example**

The following example creates a view that includes all objects in the MIB-II system group except for sysServices (System 7) and all objects for interface 1 in the MIB-II interface group (this format is specified on the parameters specified in ifEntry).

---

```
switchxxxxxx(config)# snmp-server view user-view system included
switchxxxxxx(config)# snmp-server view user-view system.7 excluded
switchxxxxxx(config)# snmp-server view user-view ifEntry.*.1 included
```

---

**8.5 show snmp views**

Use the **show snmp views** Privileged EXEC mode command to display the SNMP views.

**Syntax**

**show snmp views** [viewname]

**Parameters**

**viewname**—Specifies the view name. (Length: 1–30 characters)

**Default Configuration**

If viewname is not specified, all views are displayed.

**Command Mode**

Privileged EXEC mode

**Example**

The following example displays the configured SNMP views.

---

```
switchxxxxxx# show snmp views
```

Name	OID Tree	Type
-----	-----	-----
Default	iso	Included
Default	snmpNotificationMIB	Excluded
DefaultSuper	iso	Included



## 8.6 snmp-server group

Use the **snmp-server group** Global Configuration mode command to configure an SNMP group. Groups are used to map SNMP users to SNMP views (using **snmp-server user**). Use the **no** form of this command to remove an SNMP group.

### Syntax

```
snmp-server group groupname {v1 | v2 | v3 {noauth | auth | priv} [notify notifyview]} [read readview] [write writeview]
```

```
no snmp-server group groupname {v1 | v2 | v3 [noauth | auth | priv]}
```

### Parameters

- **group** *groupname*—Specifies the group name. (Length: 1–30 characters)
- **v1**—Specifies the SNMP Version 1 security model.
- **v2**—Specifies the SNMP Version 2 security model.
- **v3**—Specifies the SNMP Version 3 security model.
- **noauth**—Specifies that no packet authentication will be performed. Applicable only to the SNMP version 3 security model.
- **auth**—Specifies that packet authentication without encryption will be performed. Applicable only to the SNMP version 3 security model.
- **priv**—Specifies that packet authentication with encryption will be performed. Applicable only to the SNMP version 3 security model. Note that creation of SNMPv3 users with both authentication and privacy must be done in the GUI. All other users may be created in the CLI.
- **notify** *notifyview*—Specifies the view name that enables generating informs or a traps. An inform is a trap that requires acknowledgement. Applicable only to the SNMP version 3 security model. (Length: 1–30 characters)
- **read** *readview*—Specifies the view name that enables viewing only. (Length: 1–30 characters)
- **write** *writeview*—Specifies the view name that enables configuring the agent. (Length: 1–30 characters)

### Default Configuration

No group entry exists.

If *notifyview* is not specified, the notify view is not defined.

If *readview* is not specified, all objects except for the community-table and SNMPv3 user and access tables are available for retrieval.

If *writeview* is not specified, the write view is not defined.

### Command Mode

Global Configuration mode

### User Guidelines

The group defined in this command is used in **snmp-server user** to map users to the group. These users are then automatically mapped to the views defined in this command.

The command logical key is (**groupname, snmp-version, security-level**). For snmp-version v1/v2 the security-level is always **noauth**.

**Example**

The following example attaches a group called *user-group* to SNMPv3, assigns the encrypted security level to the group, and limits the access rights of a view called *user-view* to read-only. User *tom* is then assigned to *user-group*. So that user *tom* has the rights assigned in *user-view*.

```
switchxxxxxx(config)# snmp-server group user-group v3 priv read user-view
switchxxxxxx(config)# snmp-server user tom user-group v3
```

## 8.7 show snmp groups

Use the **show snmp groups** Privileged EXEC mode command to display the configured SNMP groups.

**Syntax**

**show snmp groups** [*groupname*]

**Parameters**

**groupname**—Specifies the group name. (Length: 1–30 characters)

**Default Configuration**

Display all groups.

**Command Mode**

Privileged EXEC mode

**Example**

The following example displays the configured SNMP groups.

```
switchxxxxxx# show snmp groups
```

Name	Security		Views		
	Model	Level	Read	Write	Notify
user-group	V3	priv	Default	" "	" "
managers-group	V3	priv	Default	Default	" "

The following table describes significant fields shown above.

Field		Description
<b>Name</b>		Group name.
<b>Security</b>	Model	SNMP model in use (v1, v2 or v3).
<b>Security</b>	Level	Packet authentication with encryption. Applicable to SNMP v3 security only.
<b>Views</b>	Read	View name enabling viewing the agent contents. If unspecified, all objects except the community-table and SNMPv3 user and access tables are available.
	Write	View name enabling data entry and managing the agent contents.
	Notify	View name enabling specifying an inform or a trap.

## 8.8 snmp-server user

Use the **snmp-server user** Global Configuration mode command to configure a new SNMP Version user. Use the **no** form of the command to remove a user. Use the **encrypted** form of this command to enter the authentication and privacy passwords in encrypted form (see SSD).

### Syntax

**snmp-server user** *username* *groupname* {*v1* | *v2c* | [*remote host*] *v3*[*auth* {*md5* | *sha*} *auth-password* [*priv* *priv-password*]]}

**no snmp-server user** *username* [*remote host*]

### Parameters

- **username**—Define the name of the user on the host that connects to the agent. (Range: Up to 20 characters). For SNMP v1 or v2c, this username must match the community string entered in [snmp-server host](#).
- **groupname**—The name of the group to which the user belongs. The group should be configured using the command [snmp-server group](#) with v1 or v2c parameters (no specific order of the 2 command configurations is imposed on the user). (Range: Up to 30 characters)
- **remote host**—IP address (IPv4, IPv6 or IPv6z) or host name of the remote SNMP host. See [IPv6z Address Conventions](#).
- **v1**—Specifies that the user is a v1 user.
- **v2c**—Specifies that the user is a v2c user.
- **v3**—Specifies that the user is a v3 user.
- **auth**—Specifies which authentication level is to be used.
- **md5**—Specifies the HMAC-MD5-96 authentication level.
- **Sha**—Specifies the HMAC-SHA-96 authentication level.
- **auth-password**—Specifies the authentication password. Range: Up to 32 characters.
- **priv-password**—Specifies the privacy password (The encryption algorithm used is data encryption standard - DES). Range: Up to 64 characters.

### Default Configuration

No group entry exists.

### Command Mode

Global configuration

### User Guidelines

For SNMP v1 and v2, this performs the same actions as **snmp-server community-group**, except that **snmp-server community-group** configures both v1 and v2 at the same time. With this command, you must perform it once for v1 and once for v2.

When you enter a **show running-config** command, you do not see a line for this SNMP user. To see if this user has been added to the configuration, type the **show snmp user** command.

An SNMP EngineID must be defined in order to add SNMPv3 users to the device (in the [snmp-server engineID local](#) or [snmp-server engineID remote](#) commands).

Changing or removing the value of **snmpEngineID** deletes the SNMPv3 users' database.

The logical key of the command is username.

Configuring a remote host is required in order to send informs to that host, because an inform is a trap that requires acknowledgement. A configured remote host is also able to manage the device (besides getting the informs)

To configure a remote user, specify the IP address for the remote SNMP agent of the device where the user resides. Also, before you configure remote users for a particular agent, configure the SNMP engine ID, using

the `snmp-server engineID remote` command. The remote agent's SNMP engine ID is needed when computing the authentication and privacy digests from the password. If the remote engine ID is not configured first, the configuration command fails.

Since the same group may be defined several times, each time with different version or different access level (noauth, auth or auth & priv), when defining a user it is not sufficient to specify the group name, rather you must specify group name, version and access level for complete determination of how to handle packets from this user.

### Example

This example assigns user *tom* to group *abcd* using SNMP v1 and v2c. The default is assigned as the engineID. User *tom* is assigned to group *abcd* using SNMP v1 and v2c

---

```
switchxxxxxx(config)# snmp-server user tom acbd v1
switchxxxxxx(config)# snmp-server user tom acbd v2c
switchxxxxxx(config)# snmp-server user tom acbd v3
```

---

## 8.9 show snmp users

Use the `show snmp users` Privileged EXEC mode command to display the configured SNMP users.

### Syntax

`show snmp users [username]`

### Parameters

**username**—Specifies the user name. (Length: 1–30 characters)

### Default Configuration

Display all users.

### Command Mode

Privileged EXEC mode

### Example

The following example displays the configured SNMP users

### Example

The following examples displays the configured SNMP users.  
console#show snmp users

```
User name           : u1rem
Group name          : group1
Authentication Algorithm : None
Privacy Algorithm   : None
Remote              : 11223344556677
Auth Password       :
Priv Password       :
```

```
User name           : qqg
Group name          : www
Authentication Algorithm : MD5
```

```

Privacy Algorithm      : None
Remote                :
Auth Password         : helloworld1234567890987665
Priv Password        :

```

```

User name             : hello
Group name            : world
Authentication Algorithm : MD5
Privacy Algorithm     : DES
Remote               :
Auth Password (encrypted): Z/tC3UF5j0pYfmXm8xeMvclOQ6LQ4GOACCGYLrDgOE6XQKTC
                        qMlRnpWuHraRIZj
Priv Password (encrypted) : kN1ZHzSLo6WWxlkuZVzhLOo1gl5waaNf7Vq6yLBpJdS4N68tL
                        1tbTRSz2H4c4Q4o

```

```

User name             : u1noAuth
Group name            : group1
Authentication Algorithm : None
Privacy Algorithm     : None
Remote               :
Auth Password (encrypted):
Priv Password (encrypted) :

```

```

User name             : u1OnlyAuth
Group name            : group1
Authentication Algorithm : SHA
Privacy Algorithm     : None
Remote               :
Auth Password (encrypted): 8nPzy2hzuba9pG3iiC/q0451RynUn7kq94L9WORFrRM=
Priv Password (encrypted) :

```

---

## 8.10 snmp-server filter

The **snmp-server filter** Global Configuration mode command creates or updates an SNMP server notification filter. Use the **no** form of this command to remove a notification filter.

### Syntax

**snmp-server filter** *filter-name* *oid-tree* {*included* | *excluded*}

**no snmp-server filter** *filter-name* [*oid-tree*]

**Parameters**

- **filter-name**—Specifies the label for the filter record that is being updated or created. The name is used to reference the filter in other commands. (Length: 1–30 characters)
- **oid-tree**—Specifies the ASN.1 subtree object identifier to be included or excluded from the view. To identify the subtree, specify a text string consisting of numbers, such as 1.3.6.2.4, or a word, such as System. Replace a single sub-identifier with the asterisk (\*) wildcard to specify a subtree family; for example, 1.3.\*.4.
- **included**—Specifies that the filter type is included.
- **excluded**—Specifies that the filter type is excluded.

**Default Configuration**

No view entry exists.

**Command Mode**

Global Configuration mode

**User Guidelines**

This command can be entered multiple times for the same filter. If an object identifier is included in two or more lines, later lines take precedence. The command's logical key is the pair (filter-name, oid-tree).

**Example**

The following example creates a filter that includes all objects in the MIB-II system group except for sysServices (System 7) and all objects for interface 1 in the MIB-II interfaces group (this format depends on the parameters define din ifEntry).

---

```
switchxxxxxx(config)# snmp-server filter f1 system included
switchxxxxxx(config)# snmp-server filter f2 system.7 excluded
switchxxxxxx(config)# snmp-server filter f3 ifEntry.*.1 included
```

---

## 8.11 show snmp filters

Use the **show snmp filters** Privileged EXEC mode command to display the defined SNMP filters.

**Syntax**

```
show snmp filters [filtername]
```

**Parameters**

**filtername**—Specifies the filter name. (Length: 1–30 characters)

**Default Configuration**

If filtername is not defined, all filters are displayed.

**Command Mode**

Privileged EXEC mode

**Example**

The following example displays the configured SNMP filters.

```
switchxxxxxx# show snmp filters user-filter
```

Name	OID Tree	Type
-----	-----	-----
user-filter	1.3.6.1.2.1.1	Included
user-filter	1.3.6.1.2.1.1.7	Excluded
user-filter	1.3.6.1.2.1.2.2.1.*.1	Included

## 8.12 snmp-server host

Use the **snmp-server host** Global Configuration mode command to configure the host for SNMP notifications: (traps/informs). Use the **no** form of this command to remove the specified host.

**Syntax**

**snmp-server host** {*host-ip* | *hostname*} [*traps* | *informs*] [*version* {1 | 2c | 3 [*auth* | *noauth* | *priv*]}] *community-string* [*udp-port* *port*] [*filter* *filtername*] [*timeout* *seconds*] [*retries* *retries*]

**no snmp-server host** {*ip-address* | *hostname*} [*traps* | *informs*] [*version* {1 | 2c | 3}]

**Parameters**

- **host-ip**—IP address of the host (the targeted recipient). The default is all IP addresses. This can be an IPv4 address, IPv6 or IPv6z address. See [IPv6z Address Conventions](#).
- **hostname**—Hostname of the host (the targeted recipient). (Range: 1–158 characters. Maximum label size of each part of the host name: 63)
- **trap**—Sends SNMP traps to this host (default).
- **informs**—Sends SNMP informs to this host. An inform is a trap that requires acknowledgement. Not applicable to SNMPv1.
- **1**—SNMPv1 traps are used.
- **2c**—SNMPv2 traps or informs are used
- **3**—SNMPv2 traps or informs are used
- **community-string**—Password-like community string sent with the notification operation. (Range: 1–20 characters). For v1 and v2, any community string can be entered here. For v3, the community string must match the user name defined in [snmp-server user](#) for v3.
- Authentication options are available for SNMP v3 only. The following options are available:
  - **noauth**—Specifies no authentication of a packet.
  - **auth**—Specifies authentication of a packet without encryption.
  - **priv**—Specifies authentication of a packet with encryption.
- **udp-port** *port*—UDP port of the host to use. The default is 162. (Range: 1–65535)
- **filter** *filtername*—Filter for this host. If unspecified, nothing is filtered. The filter is defined using [snmp-server filter](#) (no specific order of commands is imposed on the user). (Range: Up to 30 characters)
- **timeout** *seconds*—(For informs only) Number of seconds to wait for an acknowledgment before resending informs. The default is 15 seconds. (Range: 1–300)
- **retries** *retries*—(For informs only) Maximum number of times to resend an inform request, when a response is not received for a generated message. The default is 3. (Range: 0–255)

**Default Configuration**

Version: SNMP V1

Type of notification: Traps

udp-port: 162

If informs are specified, the default for retries: 3

Timeout: 15

### Command Mode

Global Configuration mode

### User Guidelines

The logical key of the command is the pair (ip-address/hostname, traps/informs, version).

When configuring SNMP v1 or v2 notifications recipient, the software automatically generates a notification view for that recipient for all MIBs.

For SNMPv3 the software does not automatically create a user or a notify view.

Use the commands [snmp-server user](#), [snmp-server group](#) and [snmp-server view](#) to create a user, a group or a notification group, respectively.

### Example

The following defines a host at the IP address displayed.

---

```
switchxxxxx(config)# snmp-server host 1.1.1.121 abc
```

---

## 8.13 snmp-server engineID local

The **snmp-server engineID local** Global Configuration mode command specifies the SNMP engineID on the local device for SNMP v3. Use the **no** form of this command to remove this engine ID.

### Syntax

**snmp-server engineID local** {*engineid-string* | **default**}

**no snmp-server engineID local**

### Parameters

- **engineid-string**—Specifies a concatenated hexadecimal character string identifying the engine ID. Each byte in a hexadecimal character string is two hexadecimal digits. Bytes are separated by a period or colon. If an odd number of hexadecimal digits are entered, the system automatically prefixes the digit 0 to the string. (Length: 5–32 characters, 9–64 hexadecimal digits)
- **default**—Specifies that the engine ID is created automatically based on the device MAC address.

### Default Configuration

The default engine ID is defined per standard as:

- First 4 octets: First bit = 1, the rest is IANA Enterprise number = 674.
- Fifth octet: Set to 3 to indicate the MAC address that follows.
- Last 6 octets: The device MAC address.

### Command Mode

Global Configuration mode

### User Guidelines

To use SNMPv3, an engine ID must be specified for the device. Any ID can be specified or the default string, which is generated using the device MAC address, can be used.

As the engineID should be unique within an administrative domain, the following guidelines are recommended:

- For standalone devices, use the default keyword to configure the Engine ID.



- For stackable systems, configure an EngineID, and verify that it is unique within the administrative domain.

Changing or removing the value of **snmpEngineID** deletes the SNMPv3 users database.

The SNMP EngineID cannot be all 0x0 or all 0xF or 0x000000001

### Example

The following example enables SNMPv3 on the device and sets the device local engine ID to the default value.

---

```
switchxxxxxx(config)# snmp-server engineid local default
The engine-id must be unique within your administrative domain.
Do you wish to continue? [Y/N]Y
The SNMPv3 database will be erased. Do you wish to continue? [Y/N]Y
```

## 8.14 snmp-server engineID remote

To specify the SNMP engine ID of a remote SNMP device, use the **snmp-server engineID remote** Global Configuration mode command. Use the **no** form of this command to remove the configured engine ID.

### Syntax

**snmp-server engineID remote** *{ip-address} engineid-string*

**no snmp-server engineID remote** *{ip-address}*

### Parameters

- **ip-address** —IPv4, IPv6 or IPv6z address of the remote device. See [IPv6z Address Conventions](#).
- **engineid-string**—The character string that identifies the engine ID. The engine ID is a concatenated hexadecimal string. Each byte in hexadecimal character strings is two hexadecimal digits. Each byte can be separated by a period or colon. If the user enters an odd number of hexadecimal digits, the system automatically prefixes the hexadecimal string with a zero. (Range: engineid-string5–32 characters. 9–64 hexadecimal digits)

### Default Configuration

The remote engineID is not configured by default.

### Command Mode

Global Configuration mode

### User Guidelines

A remote engine ID is required when an SNMP version 3 inform is configured. The remote engine ID is used to compute the security digest for authenticating and encrypting packets sent to a user on the remote host.

## 8.15 show snmp engineID

Use the **show snmp engineID** Privileged EXEC mode command to display the local SNMP engine ID.

### Syntax

**show snmp engineID**

### Parameters

N/A

**Default Configuration**

N/A

**Command Mode**

Privileged EXEC mode

**Example**

The following example displays the SNMP engine ID.

---

```
switchxxxxxx # show snmp engineID
Local SNMP engineID: 08009009020C0B099C075878
IP address          Remote SNMP engineID
-----
172.16.1.1         08009009020C0B099C075879
```

---

## 8.16 snmp-server enable traps

Use the **snmp-server enable traps** Global Configuration mode command to enable the device to send all SNMP traps. Use the **no** form of the command to disable all SNMP traps.

**Syntax****snmp-server enable traps****no snmp-server enable traps****Default Configuration**

SNMP traps are enabled.

**Command Mode**

Global Configuration mode

**User Guidelines**

If **no snmp-server enable traps** has been entered, you can enable failure traps by using [snmp-server trap authentication](#) as shown in the example.

**Example**

The following example enables SNMP traps except for SNMP failure traps.

---

```
switchxxxxxx(config)# snmp-server enable traps
switchxxxxxx(config)# no snmp-server trap authentication
```

---

## 8.17 snmp-server trap authentication

Use the **snmp-server trap authentication** Global Configuration mode command to enable the device to send SNMP traps when authentication fails. Use the **no** form of this command to disable SNMP failed authentication traps.

**Syntax****snmp-server trap authentication****no snmp-server trap authentication**

**Parameters**

N/A

**Default Configuration**

SNMP failed authentication traps are enabled.

**Command Mode**

Global Configuration mode

**User Guidelines**

The command `snmp-server enable traps` enables all traps including failure traps. Therefore, if that command is enabled (it is enabled by default), this command is not necessary.

**Example**

The following example disables all SNMP traps and enables only failed authentication traps.

---

```
switchxxxxxx(config)# no snmp-server enable traps
switchxxxxxx(config)# snmp-server trap authentication
```

---

## 8.18 snmp-server contact

Use the `snmp-server contact` Global Configuration mode command to set the value of the system contact (sysContact) string. Use the `no` form of the command to remove the system contact information.

**Syntax**

`snmp-server contact text`

`no snmp-server contact`

**Parameters**

**text**—Specifies system contact information. (Length: 1–168 characters)

**Default Configuration**

N/A

**Command Mode**

Global Configuration mode

**Example**

The following example sets the system contact information to Technical\_Support.

---

```
switchxxxxxx(config)# snmp-server contact Technical_Support
```

---

## 8.19 snmp-server location

Use the **snmp-server location** Global Configuration mode command to set the value of the system location string. Use the **no** form of this command to remove the location string.

### Syntax

**snmp-server location** *text*

**no snmp-server location**

### Parameters

**text**—Specifies the system location information. (Length: 1–160 characters)

### Default Configuration

N/A

### Command Mode

Global Configuration mode

### Example

The following example sets the device location to New\_York.

---

```
switchxxxxxx(config)# snmp-server location New_York
```

---

## 8.20 snmp-server set

Use the **snmp-server set** Global Configuration mode command to define SNMP MIB commands in the configuration file if a MIB performs an action for which there is no corresponding CLI command.

### Syntax

**snmp-server set** *variable-name name value [name2 value2...]*

### Parameters

- **variable-name**—Specifies an SNMP MIB variable name, which must be a valid string.
- **name value**—Specifies a list of names and value pairs. Each name and value must be a valid string. In the case of scalar MIBs, there is only a single name-value pair. In the case of an entry in a table, there is at least one name-value pair, followed by one or more fields.

### Default Configuration

N/A

### Command Mode

Global Configuration mode

### User Guidelines

Although the CLI can set any required configuration, there might be a situation where an SNMP user sets a MIB variable that does not have an equivalent CLI command. To generate configuration files that support those situations, the system uses **snmp-server set**. This command is not intended for the end user.

**Example**

The following example configures the scalar MIB sysName with the value TechSupp.

```
switchxxxxxx(config)# snmp-server set sysName sysname TechSupp
```

**8.21 show snmp**

Use the **show snmp** Privileged EXEC mode command to display the SNMP status.

**Syntax**

**show snmp**

**Parameters**

N/A

**Default Configuration**

N/A

**Command Mode**

Privileged EXEC mode

**Example**

The following example displays the SNMP communications status.

```
switchxxxxxx# show snmp
SNMP is enabled
```

Community-String	Community-Access	View name	IP Address	Mask
public	read only	user-view	All	
private	read write	Default	172.16.1.1/10	
private	su	DefaultSuper	172.16.1.1	

Community-string	Group name	IP Address	Mask	Type
public	user-group	All		Router

Traps are enabled.

Authentication trap is enabled.

Version 1,2 notifications

Target Address	Type	Community	Version	UDP Port	Filter Name	TO Sec	Retries
192.122.173.42	Trap	public	2	162		15	3
192.122.173.42	Inform	public	2	162		15	3

Version 3 notifications

Target Address	Type	Username	Security Level	UDP Port	Filter name	TO Sec	Retries
192.122.173.42	Inform	Bob	Priv	162		15	3

System Contact: Robert

System Location: Marketing

The following table describes the significant fields shown in the display.

Field	Description
<b>Community-string</b>	The community access string permitting access to SNMP.
<b>Community-access</b>	The permitted access type—read-only, read-write, super access.
<b>IP Address</b>	The management station IP Address.
<b>Target Address</b>	The IP address of the targeted recipient.
<b>Version</b>	The SNMP version for the sent trap.

---

## 9.1 crypto key generate dsa

The **crypto key generate dsa** Global Configuration mode command generates a public and private DSA key (DSA key pair).

### Syntax

**crypto key generate dsa**

### Parameters

N/A

### Default Configuration

DSA key pairs do not exist.

### Command Mode

Global Configuration mode

### User Guidelines

DSA keys are generated in pairs - one public DSA key and one private DSA key.

If the device already has DSA keys, a warning is displayed with a prompt to replace the existing keys with new keys.

This command is not saved in the Running configuration file. However, the keys generated by this command are saved in a private configuration (which is never displayed to the user or backed up to another device).

### Example

The following example generates a DSA key pair.

---

```
switchxxxxxx(config)# crypto key generate dsa
The SSH service is generating a private DSA key.
This may take a few minutes, depending on the key size.
.....
```

---

## 9.2 crypto key generate rsa

The **crypto key generate rsa** Global Configuration mode command generates RSA key pairs.

### Syntax

**crypto key generate rsa**

### Parameters

N/A

**Default Configuration**

RSA key pairs do not exist.

**Command Mode**

Global Configuration mode

**User Guidelines**

RSA keys are generated in pairs - one public RSA key and one private RSA key.

If the device already has RSA keys, a warning is displayed with a prompt to replace the existing keys with new keys.

This command is not saved in the Running configuration file; however, the keys generated by this command are saved in a private configuration (which is never displayed to the user or backed up to another device).

**Example**

The following example generates RSA key pairs where a RSA key already exists.

---

```
switchxxxxxx(config)# crypto key generate rsa
Replace Existing RSA Key [y/n]? N
switchxxxxxx(config)#
```

---

## 9.3 crypto certificate generate

The **crypto certificate generate** Global Configuration mode command generates a self-signed certificate for HTTPS.

**Syntax**

**crypto certificate number generate** [*key-generate* [*length*]] [*passphrase string*] [*cn common-name*] [*ou organization-unit*] [*or organization*] [*loc location*] [*st state*] [*cu country*] [*duration days*]

**Parameters**

- **number**—Specifies the certificate number. (Range: 1–2)
- **key-generate length**—Regenerates SSL RSA key and specifies the SSL's RSA key length. (Range: 512–2048)
- **passphrase string**—Specifies the passphrase used for exporting the certificate in PKCS12 file format. (Length: 8–96 characters)
- The following elements can be associated with the key. When the key is displayed, they are also displayed.
  - **cn common-name**—Specifies the fully qualified device URL or IP address. (Length: 1–64 characters). If unspecified, defaults to the lowest IP address of the device (when the certificate is generated).
  - **ou organization-unit**—Specifies the organization-unit or department name. (Length: 1–64 characters)
  - **or organization**—Specifies the organization name. (Length: 1–64 characters)
  - **loc location**—Specifies the location or city name. (Length: 1–64 characters)
  - **st state**—Specifies the state or province name. (Length: 1–64 characters)
  - **cu country**—Specifies the country name. (Length: 2 characters)
- **duration days**—Specifies the number of days a certification is valid. (Range: 30–3650)

**Default Configuration**

The default SSL's RSA key length is 1024.

If **passphrase string** is not specified, the certificate is not exportable.



If **cn common-name** is not specified, it defaults to the device's lowest static IPv6 address (when the certificate is generated), or to the device's lowest static IPv4 address if there is no static IPv6 address, or to 0.0.0.0 if there is no static IP address.

If **duration days** is not specified, it defaults to 365 days.

### Command Mode

Global Configuration mode

### User Guidelines

This command is not saved in the Running configuration file. However, the certificate and keys generated by this command are saved in a private configuration (which is never displayed to the user or backed up to another device).

When exporting a RSA key pair to a PKCS#12 file, the RSA key pair is as secure as the passphrase. Keep the passphrase secure.

If the RSA key does not exist, you must use the parameter **key-generate**.

If both certificates 1 and 2 have been generated, use [ip https certificate](#) to active one of them.

### Example

The following example generates a self-signed certificate for HTTPS whose length is 2048 bytes.

---

```
switchxxxxxx(config)# crypto certificate generate key-generate 2048
```

---

## 9.4 crypto certificate request

The **crypto certificate request** Privileged EXEC mode command generates and displays a certificate request for HTTPS.

### Syntax

**crypto certificate number request** [*cn common-name*] [*ou organization-unit*] [*or organization*] [*loc location*] [*st state*] [*cu country*]

### Parameters

- **number**—Specifies the certificate number. (Range: 1–2)
- The following elements can be associated with the key. When the key is displayed, they are also displayed.
  - **cn common-name**—Specifies the fully qualified device URL or IP address. (Length: 1–64 characters). If unspecified, defaults to the lowest IP address of the device (when the certificate is generated).
  - **ou organization-unit**—Specifies the organization-unit or department name. (Length: 1–64 characters)
  - **or organization**—Specifies the organization name. (Length: 1–64 characters)
  - **loc location**—Specifies the location or city name. (Length: 1–64 characters)
  - **st state**—Specifies the state or province name. (Length: 1–64 characters)
  - **cu country**—Specifies the country name. (Length: 2 characters)

### Default Configuration

If **cn common-name** is not specified, it defaults to the device's lowest static IPv6 address (when the certificate is generated), or to the device's lowest static IPv4 address if there is no static IPv6 address, or to 0.0.0.0 if there is no static IP address.

### Command Mode

Privileged EXEC mode

**User Guidelines**

Use this command to export a certificate request to a Certification Authority. The certificate request is generated in Base64-encoded X.509 format.

Before generating a certificate request, first generate a self-signed certificate using the [crypto certificate generate](#) Global Configuration mode command to generate the keys. The certificate fields must be re-entered.

After receiving the certificate from the Certification Authority, use the [crypto certificate import](#) Global Configuration mode command to import the certificate into the device. This certificate replaces the self-signed certificate.

**Example**

The following example displays the certificate request for HTTPS.

---

```
switchxxxxxx# crypto certificate 1 request
-----BEGIN CERTIFICATE REQUEST-----
MIwTCCASoCAQAwYjELMAkGA1UEBhMCUFACzAJBgNVBAgTAkNDMQswCQYDVQQH
EwRDEMMAoGA1UEChMDZGxkMQwwCgYDVQQLEwNkbGQxYzAJBgNVBAMTAmxkMRAw
DgKoZiIhvcNAQkBFgFsmIGfMA0GCSqGSIb3DQEBAQUAA4GNADCBiQKBgQC8ecwQ
HdML0831i0fh/F0MV/Kib6Sz5p+3nUUenbfHp/igVPmFM+1nbqTDeKb2ymCu6K
aKvEbVLF9F2LmM7VPjDBb9bb4jnxkvwW/wzDLvW2rsy5NPmH1QVl+8Ubx3GyCm
/oW93BSOFwxwEsP58kf+sPYPy+/8wwmoNtDwIDAQABoB8wHQYJKoZIhvcNAQkH
MRDjEyMwgICCAgICCAgICCAgICCAgICCAgICCAgICCAgICCAgICCAgICCAgICCAg
m5ZZPhIw18ARSPXwhVdJexFjbnmvcacqjPG8pIiRV6LkxryGF2bVU3jKEipcZa
g+uNpyTkDt3ZVU72pjz/fa8TF0n3
-----END CERTIFICATE REQUEST-----
CN= router.gm.com
O= General Motors
C= US
```

---

## 9.5 crypto certificate import

The **crypto certificate import** Global Configuration mode command imports a certificate signed by a Certification Authority for HTTPS. In addition, the RSA key-pair can also be imported.

**Syntax**

**crypto certificate** *number* **import**

**Parameters**

**number**—Specifies the certificate number. (Range: 1–2)

**Default Configuration**

N/A

**Command Mode**

Global Configuration mode

**User Guidelines**

To end the session (return to the command line to enter the next command), enter a blank line.

The imported certificate must be based on a certificate request created by the [crypto certificate request](#) privileged EXEC command.

If only the certificate is imported, and the public key found in the certificate does not match the device's SSL RSA key, the command fails. If both the public key and the certificate are imported, and the public key found in the certificate does not match the imported RSA key, the command fails.

This command is saved in the Running configuration file.

### Example

The following example imports a certificate signed by the Certification Authority for HTTPS.

```
switchxxxxxx(config)# crypto certificate 1 import
Please paste the input now, add a period (.) on a separate line after the
input, and press Enter.
-----BEGIN CERTIFICATE-----
MIIBkzCB/QIBADBUMQswCQYDVQQGEwIgdEIDEKMAgGA1UECBMBIDEKMAgGA1UEBxMB
IDEVMBMGA1UEAxMMMTAuNS4yMzQuMjA5MQowCAYDVQQKEwEgMQowCAYDVQQLEwEg
MIGfMA0GCSqGSIb3DQEBAQUAA4GNADCBiQKBgQDK+beogIcke73sBSL7tC2DMZrY
OOg9XM1AxfOiqL1QJHd4xP+BHGZwWfKjKjUDBpZn52LxdDu1KrpB/h0+TZP0Fv38
7mIDqtnoF1NLSWxkVKRM5LPka0L/halpYxp7EWAt5iDBzSw5s04lv0bSN7oaGjFA
6t4SW2rrnDy8JbwjWQIDAQABAAAwDQYJKoZIhvcNAQEEBQADgYEAuYQiNjst6hI
XFDxe7I80d3Uyt3Dmf7KE/AmUV0Pif2yUluY/RuxRwKhDp/lGrK12tzLQz+s50x7
Klft/IcjzbBYXLvih45ASWG3TRv2WVKyWs89rPPXu5hKxggEeTvWqpuS+gXrIqjW
WVZd0n1fXhMacoflgnnEmweIzmrqXBs=
.
-----END CERTIFICATE-----
Certificate imported successfully.
Issued by : C= , ST= , L= , CN=0.0.0.0, O= , OU=
Valid From: Jan 24 18:41:24 2011 GMT
Valid to: Jan 24 18:41:24 2012 GMT
Subject: C=US , ST= , L= , CN=router.gm.com, O= General Motors, OU=
SHA1 Finger print: DC789788 DC88A988 127897BC BB789788
```

The following example imports a certificate signed by the Certification Authority for HTTPS, and the RSA key-pair.

```
switchxxxxxx(config)# crypto certificate 1 import
Please paste the input now, add a period (.) on a separate line after the
input, and press Enter.
-----BEGIN RSA PRIVATE KEY-----
ACnrqImEGLXkwxBuZU1AO9nHq9IGJsnkf7/MauGPVqxt5vfDf77uQ5CPf49JWQhu07cVXh
2OwrBhJgB69vLULJuJm9p1IXFpMk8qR3NS7Jz1InYAWjHKKbEZBMsKSA6+t/UzVxevKK6H
TGB7vMxi+hv1bL9zygvMq6+/6QfqA51c4nP/8a6NjO/ZOAgvNAMKNr2Wa+tGUOoAgL0b/C
11EozpCq5mT7+VOFhPSO4dUU+NwLv1YCb1Fb7MFoAa0N+y+2NwoGp0pxOvDA9ENY17qsZ
MwMcfXu52/Ixc7fD8FWxEBtks4V81Xqa7K6ET657xS7m8yTJFLZJyVawGXkNIUs6uTzhhW
dKWwC0e/vwMgPtLlWyxWynnaP0fAJ+PawOAdsK75bo79NBim3HcNVXhWNzqfg2s3AYCRBx
WuGoazpxHZ0s4+7swmNZtS0xI4ek43d7RaoedGKljhPqLHuzXHUon7Zx15CUtP3sbH1+XI
B3u4EEcEngYMewy5obn1vnFSot+d5JHuRwzEaRAIKfbHa34alVJaN+2AMCb0hpI3IkreYo
A8Lk6UMouIQaMnhYf+RyPXhPOqs01PpIPhKBGTi6pj39XMviyRXvSpn5+eIYPhve5jYaEn
UeOnVZRhNCVnruJAYXSLhjApf5iIqr1JiJb/mVt8+zpqcCU9HCWQqsMrNFOFrSpCbHu5V4
ZX4jmd9tTJ2mhkoQf1dwUZbfYkRYsK70ps8u7BtgpRfSRUr7g0LfzhzMuswoDSnB65pkC
ql7yZnBeRS0zrUDgHLLRfzwjwmXjmwObxYfRGMLp4=
-----END RSA PRIVATE KEY-----
-----BEGIN RSA PUBLIC KEY-----
MIGHAoGBAMVuFgfJYlbUzmbm6UoLD3ewHYd1ZMXY4A3KLF2SXUd1TIXq84aME8DIitSfB2
```

```

Cqy4QB5InhgAobBKC96VRsUe2rzoNG4QDkj2L9ukQOvoFBYnmbzHc7a+7043wfVmH+QOXf
TbnRDhIMVrZJGbz11c9IzGky1l21Xmicy0/nwsXDAGeJ
-----END RSA PUBLIC KEY-----
-----BEGIN CERTIFICATE-----
MIIBkzCB/QIBADBUMQswCQYDVQQGEWIGIDEKMAgGA1UECBMBIDEKMAgGA1UEBxMB
IDEVMBMGA1UEAxMMMTAuNS4yMzQuMjA5MQowCAYDVQQKEWUgMQowCAYDVQQLEWUg
MIGfMA0GCsGSIb3DQEBAQUAA4GNADCBiQKBgQDK+beogIcke73sBSL7tC2DMZrY
OOg9XM1AxfOiqLlQJHd4xP+BHGZWwfKjKjUDBPzn52LxdDu1KrpB/h0+TZP0Fv38
7mIDqtnoF1NLsWxkVKRM5LPka0L/ha1pYxp7EWAt5iDBzSw5s041v0bSN7oaGjFA
6t4SW2rrnDy8JbwjWQIDAQABoAAwDQYJKoZIhvcNAQEEBQADgYEAAuqYQiNjst6hI
XFDxe7I8Od3Uyt3Dmf7KE/AmUV0Pif2yUluy/RuxRwKhDp/lGrK12tzLQz+s5Ox7
Klft/IcjzbBYXLvih45ASWG3TRv2WVKyWs89rPPXu5hKxggEeTvWqpuS+gXrIqjW
WVZd0n1fXhMacoflgnnEmweIzmrqXBs=
-----END CERTIFICATE-----
.
Certificate imported successfully.
Issued by : C= , ST= , L= , CN=0.0.0.0, O= , OU=
Valid From: Jan 24 18:41:24 2011 GMT
Valid to: Jan 24 18:41:24 2012 GMT
Subject: C=US , ST= , L= , CN=router.gm.com, O= General Motors, OU=
SHA1 Finger print: DC789788 DC88A988 127897BC BB789788

```

## 9.6 crypto certificate export pkcs12

The **crypto certificate export pkcs12** Privileged EXEC mode command exports the certificate and the RSA keys within a PKCS12 file.

### Syntax

**crypto certificate** *number* **export pkcs12**

### Parameters

**number**—Specifies the certificate number. (Range: 1–2)

### Default Configuration

N/A

### Command Mode

Privileged EXEC mode

### User Guidelines

This command creates a PKCS 12 file that contains the certificate and an RSA key pair. This is used by [crypto certificate import pkcs12](#).

The passphrase for the export is determined when the key is generated.

The certificate and key pair are exported in a standard PEM-format PKCS12 file. This format can be converted to and from the binary PFX file used by Windows and Linux by using the **openssl** command-line tool. See an open source OpenSSL user manual ([man pkcs12](#)) for more information.



**Command Mode**

Privileged EXEC mode

**User Guidelines**

This command enables using the passphrase that was exported by `crypto certificate export pkcs12`. This passphrase must be saved for later exports.

**Example**

The following example imports the certificate and the RSA keys within a PKCS12 file.

---

```
switchxxxxx# crypto certificate 1 import pkcs12 encrypted_passphrase
Bag Attributes
localKeyID: 0C 75 81 77 5A 31 53 D1 FF 4E 26 BE 8D 4A FD 8B 22 9F 45 D4
subject=/C=us/ST= /L= /CN= /O= /OU=
issuer= /C=us/ST= /L= /CN= /O= /OU=
-----BEGIN CERTIFICATE-----
MIIBfDCCASYCAQAwDQYJKoZIhvcNAQEEBQAwSTELMAkGA1UEBhMCdXMxCjAIBgNV
BAGTASAxCjAIBgNVBACjAIBgNVBAMTASAxCjAIBgNVBAoTASAxCjAIBgNV
BAStASAwHhcNMDQwMjA3MTU1NDQ4WhcNMDUwMjA2MTU1NDQ4WjBjMQswCQYD
VQGG
EwJ1czEKMAgGA1UECBMIDEKMAgGA1UEBxMBIDEKMAgGA1UEAxMBIDEKMAgGA1UE
ChMBIDEKMAgGA1UECxMBIDBcMA0GCSqGSIb3DQEBAQUAA0sAMEgCQQCZXP/tk3e/
jrulfZw8q8T2oS5ymrEIES/sRJE8uahTBJqKu1VHqRYJR3VYa/03HSJ741w5MzPI
iuWZzrbbuXAxAgMBAAEwDQYJKoZIhvcNAQEEBQADQQBQ+GTLen1p1kARxI4C1fTU
efig3ffZ/tjW5q1t1r5F6zNv/GuXWw7rGzmRyoMXDcYp1TaA4gAIFQCpFGqiSbAx
-----END CERTIFICATE-----
Bag Attributes
localKeyID: 0C 75 81 77 5A 31 53 D1 FF 4E 26 BE 8D 4A FD 8B 22 9F 45 D4
Key Attributes: <No Attributes>
-----BEGIN RSA PRIVATE KEY-----
Proc-Type: 4, ENCRYPTED
DEK-Info: DES-EDE3-CBC, 085DCBF3A41D2669
dac0m9jqEp1DM50sIDb8Jq1jxW/1P0kqSxuMhc250dBE/1fPBg9VSvV1ARaYt16W
bX67UyJ8t7HHF3AowjcWzElQ5GJgSQ0VemsqsRQzjpCTb090rx+cNwVfIvjoedgQ
Mt15+fKIAcqsFegEGJNXQ4jEzsXAkwfQLFfgt4703IpkUn0AxrQzutJDOcC28Uxp
raMVTVS1SkJIvaPuXJxdZ279tDMwZffILBfKJGACT5V5/4WEqDkrF+uuF9/oxm2
5SVL8TvUmXB/3hX4UoaXtxAhuyOdh1kyyZSpw9BPPR/8bc/wUYERh7+7JXLKHpd
ueeu3znfIX4dDeti8B3xYvvE8kGZjxFN1c3zc3JsD0IVu1LkyiAa93P4LPEvAwG
Fw1LqmGiiqw9JM/tzc6kykZXylFzCrSVf2exP+/tEvM=
-----END RSA PRIVATE KEY-----
```

---

## 9.8 show crypto certificate

The `show crypto certificate` Privileged EXEC mode command displays the device SSL certificates and key-pair.

**Syntax**

`show crypto certificate [mycertificate] [number]`

**Parameters**

- **number**—Specifies the certificate number. (Range: 1–3)

**Default Configuration**

Certificate number 1.

**Command Mode**

Privileged EXEC mode

**Example**

The following example displays SSL certificate # 1 present on the device.

---

```
switchxxxxx# show crypto certificate mycertificate
-----BEGIN CERTIFICATE-----
dHmUgUm9vdCBDZXXJ0aWZpZXIwXDANBgkqhkiG9w0BAQEFAANLADBIAkEAp4HS
nnH/xQSGA2ffkRBwU2XIxb7n8VPsTm1xyJ1t11a1GaqchfMqqe0kmfhcoHSWr
yf1FpD0MWOTgDAwIDAQABo4IBojCCAZ4wEwYJKwYBBAGCNxQCBAYeBABDAEEw
CwR0PBAQDAgFGMA8GA1UdEwEB/wQFMAMBAf8wHQYDVR0OBByEFAf4MT9BRD47
ZvKBAEL9Ggp+6MIIBNgYDVR0fBIIBLTCCASkwdKggc+ggcyGgclsZGFwOi8v
L0VByb3h5JTlWU29mdHdhcmU1mjbSb290JTlWQ2VydG1maWVyLENOPXN1cnZl
-----END CERTIFICATE-----
Issued by: www.verisign.com
Valid from: 8/9/2003 to 8/9/2004
Subject: CN= router.gm.com, O= General Motors, C= US
Finger print: DC789788 DC88A988 127897BC BB789788
```

---





---

## 10.1 ip http server

Use the **ip http server** Global Configuration mode command to enable configuring and monitoring the device from a web browser. Use the **no** form of this command to disable this function.

### Syntax

**ip http server**

**no ip http server**

### Parameters

N/A

### Default Configuration

HTTP server is enabled.

### Command Mode

Global Configuration mode

### Example

The following example enables configuring the device from a web browser.

---

```
switchxxxxxx(config)# ip http server
```

---

## 10.2 ip http port

The **ip http port** Global Configuration mode command specifies the TCP port used by the web browser interface. Use the **no** form of this command to restore the default configuration.

### Syntax

**ip http port** *port-number*

**no ip http port**

### Parameters

**port** *port-number*—For use by the HTTP server. (Range: 0–65534)

### Default Configuration

The default port number is 80.

### Command Mode

Global Configuration mode

**Example**

The following example configures the http port number as 100.

---

```
switchxxxxxx(config)# ip http port 100
```

---

## 10.3 ip http timeout-policy

Use the **ip http timeout-policy** Global Configuration mode command to set the interval for the system to wait for user input in http/https sessions before automatic logoff. Use the **no** form of this command to return to the default value.

**Syntax**

**ip http timeout-policy** *idle-seconds*

**no ip http timeout-policy**

**Parameters**

**idle-seconds**—Specifies the maximum number of seconds that a connection is kept open if no data is received or response data cannot be sent out. (Range: 0–86400)

**Default Configuration**

600 seconds

**Command Mode**

Global Configuration mode

**User Guidelines**

To specify no timeout, enter the **ip http timeout-policy 0** command.

**Example**

The following example configures the http timeout to be 1000 seconds.

---

```
switchxxxxxx(config)# ip http timeout-policy 1000
```

---

## 10.4 ip http secure-server

Use the **ip http secure-server** Global Configuration mode command to enable the device to be configured or monitored securely from a browser. Use the **no** form of this command to disable this function.

**Syntax**

**ip http secure-server**

**no ip http secure-server**

**Parameters**

N/A

**Default Configuration**

Disabled

**Command Mode**

Global Configuration mode

### User Guidelines

After this command is used, you must generate a certificate using [crypto certificate generate](#). If no certificate is generated, this command has no effect.

### Example

---

```
switchxxxxxx(config)# ip http secure-server
```

---

## 10.5 ip http secure-port

Use the **ip http secure-port** Global Configuration mode command to specify the TCP port to be used by the secure web browser. To use the default port, use the **no** form of this command.

### Syntax

**ip http secure-port** *port-number*

**no ip http secure-port**

### Parameters

**port-number**—Port number for use by the HTTPS server (Range: 0–65534)

### Default Configuration

The default port number is 443.

### Command Mode

Global Configuration mode

### Example

---

```
switchxxxxxx(config)# ip http secure-port 1234
```

---

## 10.6 ip https certificate

Use the **ip https certificate** Global Configuration mode command to configure the active certificate for HTTPS. Use the **no** form of this command to restore the default configuration.

### Syntax

**ip https certificate** *number*

**no ip https certificate**

### Parameters

**number**—Specifies the certificate number. (Range: 1–2)

### Default Configuration

The default certificate number is 1.

### Command Mode

Global Configuration mode

**User Guidelines**

First, use [crypto certificate generate](#) to generate one or two HTTPS certificates. Then use this command to specify which is the active certificate.

**Example**

The following example configures the active certificate for HTTPS.

---

```
switchxxxxxx(config)# ip https certificate 2
```

---

## 10.7 show ip http

The **show ip http** EXEC mode command displays the HTTP server configuration.

**Syntax**

**show ip http**

**Command Mode**

EXEC mode

**Example**

The following example displays the HTTP server configuration.

---

```
switchxxxxxx# show ip http
HTTP server enabled
Port: 80
Interactive timeout: 10 minutes
```

---

## 10.8 show ip https

The **show ip https** Privileged EXEC mode command displays the HTTPS server configuration.

**Syntax**

**show ip https**

**Command Mode**

Privileged EXEC mode

**Example**

The following example displays the HTTPS server configuration.

---

```
switchxxxxxx# show ip https
HTTPS server enabled
Port: 443
Interactive timeout: Follows the HTTP interactive timeout (10 minutes)
Certificate 1 is active
Issued by: www.verisign.com
Valid from: 8/9/2003 to 8/9/2004
Subject: CN= router.gm.com, O= General Motors, C= US
```

---

```
Finger print: DC789788 DC88A988 127897BC BB789788
Certificate 2 is inactive
Issued by: self-signed
Valid from: 8/9/2003 to 8/9/2004
Subject: CN= router.gm.com, O= General Motors, C= US
Finger print: 1873B936 88DC3411 BC8932EF 782134BA
```

---

## 10.9 ssl versions

Use the **ssl version** Global Configuration command to define the version of the supported SSL.

Use the **no** form to return to the default.

### Syntax

**ssl versions {v2&v3 | v3}**

**no ssl versions**

### Parameters

- **v2&v3**—SSLv2 and SSLv3 are supported after reboot.
- **v3**—Only versions starting with SSLv3 are supported after reboot.

### Defaults

v3

### Command Modes

Global configuration

### Examples

```
switchxxxxxx#ssl versions v3&v3
```

---

## 10.10 show ssl versions

Use the **show ssl versions** Privilege EXEC command to display the SSL supported version.

### Syntax

**show ssl versions**

### Parameters

N/A

### Defaults

N/A

### Command Modes

Privilege EXEC

### Examples

```
switchxxxxxx#show ssl versions
```

Current supported version: SSLv2 and SSLv3



# Teletype Network (Telnet), Secure Shell (SSH) and Secure Login (Slogin) Commands

---

## 11.1 ip telnet server

Use the **ip telnet server** Global Configuration mode command to enable the device to be configured from a Telnet server. Use the **no** form of this command to disable the device configuration from a Telnet server.

### Syntax

**ip telnet server**

**no ip telnet server**

### Default Configuration

Configuration from a Telnet server is Enabled by default.

### Command Mode

Global Configuration mode

### User Guidelines

The device can be configured from an SSH server or Telnet (or both). To control the device configuration by SSH, use the [ip ssh password-auth](#) Global Configuration mode command.

### Example

The following example enables the device to be configured from a Telnet server.

---

```
switchxxxxxx(config)# ip telnet server
```

---

## 11.2 ip ssh server

The **ip ssh server** Global Configuration mode command enables the device to be configured from an SSH server. Use the **no** form of this command to disable the device configuration from an SSH server.

### Syntax

**ip ssh server**

**no ip ssh server**

### Default Configuration

Device configuration from an SSH server is disabled.

### Command Mode

Global Configuration mode

### User Guidelines

The device can be configured from an SSH server or Telnet (or both). To control the device configuration by SSH, use the `ip telnet server` Global Configuration mode command

If encryption keys are not generated, the SSH server is in standby until the keys are generated. To generate SSH server keys, use the `crypto key generate dsa` and `crypto key generate rsa` Global Configuration mode commands.

### Example

The following example enables configuring the device from an SSH server.

---

```
switchxxxxxx(config)# ip ssh server
```

---

## 11.3 ip ssh port

The `ip ssh port` Global Configuration mode command specifies the port used by the SSH server. Use the `no` form of this command to restore the default configuration.

### Syntax

`ip ssh port port-number`

`no ip ssh port`

### Parameters

**port-number**—Specifies the port number to be used by the SSH server. (Range: 1–65535)

### Default Configuration

The default port number is 22.

### Command Mode

Global Configuration mode

### Example

The following example specifies that port number 8080 is used by the SSH server.

---

```
switchxxxxxx(config)# ip ssh port 8080
```

---

## 11.4 ip ssh password-auth

Use the `ip ssh password-auth` Global Configuration mode command to enable password authentication of incoming SSH sessions. Use the `no` form of this command to disable this function.

### Syntax

`ip ssh password-auth`

`no ip ssh password-auth`

### Default Configuration

Password authentication of incoming SSH sessions is disabled.

### Command Mode

Global Configuration mode



**User Guidelines**

This command enables password authentication by local SSH server of remote SSH clients.

The local SSH server will advertise all enabled authentications and a remote SSH client is responsible for choosing one of them.

If the password method was chosen by the client the SSH server validates received name and password using AAA. After SSH successful password authentication the login authentication is not required and the user gets access to the switch in accordance with his AAA privilege level.

If no SSH authentication was enabled the user should pass the AAA authentication.

**Example**

The following example enables password authentication of the SSH client.

---

```
switchxxxxxx(config)# ip ssh password-auth
```

**11.5 ip ssh pubkey-auth**

Use the **ip ssh pubkey-auth** Global Configuration mode command to enable public key authentication of incoming SSH sessions. Use the **no** form of this command to disable this function.

**Syntax**

**ip ssh pubkey-auth**

**no ip ssh pubkey-auth**

**Default Configuration**

Public Key authentication of incoming SSH sessions is disabled.

**Command Mode**

Global Configuration mode

**User Guidelines**

This command enables public key authentication by local SSH server of remote SSH clients.

The local SSH server will advertise all enabled authentications and a remote SSH client is responsible for choosing one of them.

If a public key method was chosen then after SSH successful password authentication the login authentication the user should pass the AAA authentication.

If no SSH authentication was enabled the user should pass the AAA authentication.

**Example**

The following example configures authentication of the SSH client.

---

```
switchxxxxxx(config)# ip ssh pubkey-auth
switchxxxxxx(config)# crypto key pubkey-chain ssh
switchxxxxxx(config-pubkey-chain)# user-key bob
switchxxxxxx(config-pubkey-key)# key-string rsa
AAAAB3NzaC1yc2EAAAADAQABAAQACvTnRwPWl
Al4kpgIw9GBRonZQZxjHKcqKL6rMlQ+
ZNXfZSkvHG+QusIZ/76ILmFT34v7u7ChFAE+
Vu4GRfpSwoQUvV35LqJk67IOU/zfw011g
kTwm175QR9gHujS6KwGN2QWXgh3ub8gDjTSq
```

```

muSn/Wd05iDX2IExQWu08licg1k02LYciz
+Z4TrEU/9FJxwPiVQ0jc+KBXuR0juNg5nFYsY
0ZCk0N/W9a/tnkm1shRE7Di71+w3fNiOA
6w9o44t6+AINEICCCA4YcF6zMzaT1wefWwX6f+
Rmt5nhhqAtN/4oJfce166DqVX1gWmN

```

---

## 11.6 crypto key pubkey-chain ssh

The **crypto key pubkey-chain ssh** Global Configuration mode command enters the SSH Public Key-chain Configuration mode. This mode is used to manually specify device public keys, such as SSH client public keys.

### Syntax

**crypto key pubkey-chain ssh**

### Default Configuration

Keys do not exist.

### Command Mode

Global Configuration mode

### User Guidelines

Use this command when you want to manually specify SSH client's public keys.

### Example

The following example enters the SSH Public Key-chain Configuration mode and manually configures the RSA key pair for SSH public key-chain to the user 'bob'.

---

```

switchxxxxxx(config)# crypto key pubkey-chain ssh
switchxxxxxx(config-pubkey-chain)# user-key bob
switchxxxxxx(config-pubkey-key)# key-string rsa
AAAAB3NzaC1yc2EAAAADAQABAAQACvTnRwPWl
Al4kpqIw9GBRonZQZxjHKcqKL6rMlQ+
ZNXfZSkvHG+QusIZ/76ILmFT34v7u7ChFAE+
Vu4GRfpSwoQUvV35LqJJK67IOU/zfw011g
kTwm175QR9gHujS6KwGN2QWXgh3ub8gDjTSq
muSn/Wd05iDX2IExQWu08licg1k02LYciz
+Z4TrEU/9FJxwPiVQ0jc+KBXuR0juNg5nFYsY
0ZCk0N/W9a/tnkm1shRE7Di71+w3fNiOA
6w9o44t6+AINEICCCA4YcF6zMzaT1wefWwX6f+
Rmt5nhhqAtN/4oJfce166DqVX1gWmN
zNR4DYDvSzg01DnwCAC8Qh
Fingerprint: a4:16:46:23:5a:8d:1d:b5:37:59:eb:44:13:b9:33:e9

```

## 11.7 user-key

The **user-key** SSH Public Key-string Configuration mode command associates a username with an SSH public key that was manually configured. Use the **no** form of this command to remove an SSH public key.

### Syntax

**user-key** *username* {*rsa* | *dsa*}

**no user-key** *username*

### Parameters

- **username**—Specifies the remote SSH client username. (Length: 1–48 characters)
- **rsa**—Specifies that the RSA key pair is manually configured.
- **dsa**—Specifies that the DSA key pair is manually configured.

### Default Configuration

No SSH public keys exist.

### Command Mode

SSH Public Key-string Configuration mode

### User Guidelines

Follow this command with [key-string](#) to specify the key.

Note that after entering this command, the existing key is deleted even if no new key is defined by [key-string](#).

### Example

The following example enables manually configuring an SSH public key for SSH public key-chain **bob**.

```
switchxxxxxx(config)# crypto key pubkey-chain ssh
switchxxxxxx(config-pubkey-chain)# user-key bob rsa
switchxxxxxx(config-pubkey-key)# key-string row
AAAAB3NzaC1yc2EAAAADAQABAAQ=CvTnRwPWl
```

## 11.8 key-string

The **key-string** SSH Public Key-string Configuration mode command manually specifies an SSH public key.

### Syntax

**key-string** [*row* *key-string*]

### Parameters

- **row**—Specifies the SSH public key row by row.
- **key-string**—Specifies the key in UU-encoded DER format. UU-encoded DER format is the same format as in the `authorized_keys` file used by OpenSSH. (Length:0–160)

### Default Configuration

Keys do not exist.

### Command Mode

SSH Public Key-string Configuration mode

**User Guidelines**

Use the **key-string** SSH Public Key-string Configuration mode command without the **row** parameter to specify which SSH public key is to be interactively configured next. Enter a row with no characters to complete the command.

Use the **key-string row** SSH Public Key-string Configuration mode command to specify the SSH public key, row by row. Each row must begin with a **key-string row** command.

The UU-encoded DER format is the same format as in the authorized\_keys file used by OpenSSH.

**Example**

The following example enters public key strings for SSH public key client 'bob'.

---

```
switchxxxxxx(config)# crypto key pubkey-chain ssh
switchxxxxxx(config-pubkey-chain)# user-key bob rsa
switchxxxxxx(config-pubkey-key)# key-string
AAAAB3NzaC1yc2EAAAADAQABAAQ=CvTnRwPwL
Al4kpqIw9GBRonZQZxjHKcqKL6rMlQ+
ZNXfZSkvHG+QusIZ/76ILmFT34v7u7ChFAE+
Vu4GRfpSwoQUvV35LqJJk67IOU/zfwO11g
kTwm175QR9gHujS6KwGN2QWXgh3ub8gDjTSq
muSn/Wd05iDX2IExQWu08licg1k02LYciz
+Z4TrEU/9FJxwPiVQOjc+KBXuR0juNg5nFYsY
0ZCk0N/W9a/tnkm1shRE7Di71+w3fNiOA
6w9o44t6+AINEICBCCA4YcF6zMzaT1wefWwX6f+
Rmt5nhhqAtN/4oJfce166DqVX1gWmN
zNR4DYDvSzg01DnwCAC8Qh
Fingerprint: a4:16:46:23:5a:8d:1d:b5:37:59:eb:44:13:b9:33:e9
switchxxxxxx(config)# crypto key pubkey-chain ssh
switchxxxxxx(config-pubkey-chain)# user-key bob rsa
switchxxxxxx(config-pubkey-key)# key-string row AAAAB3Nza
switchxxxxxx(config-pubkey-key)# key-string row C1yc2
```

---

**11.9 show ip ssh**

The **show ip ssh** Privileged EXEC mode command displays the SSH server configuration.

**Syntax**

**show ip ssh**

**Command Mode**

Privileged EXEC mode

**Example**

The following example displays the SSH server configuration.

```
switchxxxxxx# show ip ssh
SSH server enabled. Port: 22
RSA key was generated.
DSA (DSS) key was generated.
SSH Public Key Authentication is enabled.
SSH Password Authentication is enabled.
Active incoming sessions:
IP Address SSH Username Version Cipher Auth Code
```

IP Address	SSH Username	Version	Cipher	Auth Code
172.16.0.1	John Brown	1.5	3DES	HMAC-SHA1
182.20.2.1	Bob Smith	1.5	3DES	Password

The following table describes the significant fields shown in the display.

Field	Description
<b>IP Address</b>	The client address
<b>SSH Username</b>	The user name
<b>Version</b>	The SSH version number
<b>Cipher</b>	The encryption type (3DES, Blowfish, RC4)
<b>Auth Code</b>	The authentication Code (HMAC-MD5, HMAC-SHA1) or Password

---

## 11.10 show crypto key pubkey-chain ssh

The **show crypto key pubkey-chain ssh** Privileged EXEC mode command displays SSH public keys stored on the device.

**Syntax**

**show crypto key pubkey-chain ssh** [*username username*] [*fingerprint {bubble-babble | hex}*]

**Parameters**

- **username** *username*—Specifies the remote SSH client username. (Length: 1–48 characters)
- **fingerprint {bubble-babble | hex}**—Specifies the fingerprint display format. The possible values are:
  - **bubble-babble**—Specifies that the fingerprint is displayed in Bubble Babble format.
  - **hex**—Specifies that the fingerprint is displayed in hexadecimal format.

**Default Configuration**

The default fingerprint format is hexadecimal.

**Command Mode**

Privileged EXEC mode

**Example**

The following examples display SSH public keys stored on the device.

---

```
switchxxxxxx# show crypto key pubkey-chain ssh
Username
-----
bob
john
Fingerprint
-----
9A:CC:01:C5:78:39:27:86:79:CC:23:C5:98:59:F1:86
98:F7:6E:28:F2:79:87:C8:18:F8:88:CC:F8:89:87:C8
switchxxxxxx# show crypto key pubkey-chain ssh username bob
Username: bob
Key: 005C300D 06092A86 4886F70D 01010105 00034B00 30480241 00C5E23B 55D6AB22
04AEF1BA A54028A6 9ACC01C5 129D99E4
Fingerprint: 9A:CC:01:C5:78:39:27:86:79:CC:23:C5:98:59:F1:86
```

---

## 12.1 line

The **line** Global Configuration mode command identifies a specific line for configuration and enters the Line Configuration command mode.

### Syntax

**line** {*console* | *telnet* | *ssh*}

### Parameters

- **console**—Enters the terminal line mode.
- **telnet**—Configures the device as a virtual terminal for remote access (Telnet).
- **ssh**—Configures the device as a virtual terminal for secured remote access (SSH).

### Command Mode

Global Configuration mode

### Example

The following example configures the device as a virtual terminal for remote (Telnet) access.

---

```
switchxxxxxx(config)# line telnet
switchxxxxxx(config-line)#
```

---

## 12.2 speed

The **speed** Line Configuration mode command sets the line baud rate. Use the **no** form of this command to restore the default configuration.

### Syntax

**speed** *bps*

**no speed**

### Parameters

**bps**—Specifies the baud rate in bits per second (bps). Possible values are 2400, 4800, 9600, 19200, 38400, 57600, and 115200.

### Default Configuration

The default speed is 115200 bps.

### Command Mode

Line Configuration mode

**User Guidelines**

This configuration applies to the current session only.

**Example**

The following example configures the line baud rate as 9600 bits per second.

---

```
switchxxxxxx(config-line)# speed 9600
```

---

## 12.3 autobaud

The **autobaud** Line Configuration mode command sets the line for automatic baud rate detection (autobaud). Use the **no** form of this command to disable automatic baud rate detection.

**Syntax**

**autobaud**

**no autobaud**

**Default Configuration**

Automatic baud rate detection is enabled.

**Command Mode**

Line Configuration mode

**User Guidelines**

To start communication using Autobaud, press the **Enter** key twice.

**Example**

The following example enables autobaud.

---

```
switchxxxxxx(config)# line  
switchxxxxxx(config-line)# autobaud
```

---

## 12.4 exec-timeout

The **exec-timeout** Line Configuration mode command sets the session idle time interval, during which the system waits for user input before automatic logoff. Use the **no** form of this command to restore the default configuration.

**Syntax**

**exec-timeout** *minutes* [*seconds*]

**no exec-timeout**

**Parameters**

- **minutes**—Specifies the number of minutes. (Range: 0-65535)
- **seconds**—Specifies the number of seconds. (Range: 0-59)

**Default Configuration**

The default idle time interval is 10 minutes.



**Command Mode**

Line Configuration mode

**Example**

The following example sets the HTTP session idle time interval before automatic logoff to 20 minutes and 10 seconds.

---

```
switchxxxxxx(config)# line
switchxxxxxx(config-line)# exec-timeout 20 10
```

---

**12.5 show line**

The **show line** EXEC mode command displays line parameters.

**Syntax**

**show line** [*console* | *telnet* | *ssh*]

**Parameters**

- **console**—Displays the console configuration.
- **telnet**—Displays the Telnet configuration.
- **ssh**—Displays the SSH configuration.

**Default Configuration**

If the line is not specified, all line configuration parameters are displayed.

**Command Mode**

EXEC mode

**Example**

The following example displays the line configuration.

---

```
switchxxxxxx# show line
configuration:
Interactive timeout: Disabled
History: 10
Baudrate: 9600
Databits: 8
Parity: none
Stopbits: 1
Telnet configuration:
Telnet is enabled.
Interactive timeout: 10 minutes 10 seconds
History: 10
SSH configuration:
SSH is enabled.
Interactive timeout: 10 minutes 10 seconds
History: 10
```

---



## 13.1 aaa authentication login

Use the **aaa authentication login** Global Configuration mode command to set one or more authentication methods to be applied during login. A list of authentication methods may be assigned a list name, and this list name can be used in [login authentication](#). Use the **no** form of this command to restore the default authentication method.

### Syntax

```
aaa authentication login {default | list-name} method1 [method2...]
```

```
aaa authentication login list-name method1 method2...
```

```
no aaa authentication login {default | list-name}
```

### Parameters

- **default**—Uses the authentication methods that follow this argument as the default method list when a user logs in (this list is unnamed).
- **list-name**—Specifies a name of a list of authentication methods activated when a user logs in. (Length: 1–12 characters)
- **method1 [method2...]**—Specifies a list of methods that the authentication algorithm tries (in the given sequence). Each additional authentication method is used only if the previous method returns an error, not if it fails. To ensure that the authentication succeeds even if all methods return an error, specify **none** as the final method in the command line. Select one or more methods from the following list:

Keyword	Description
<b>enable</b>	Uses the enable password for authentication.
<b>line</b>	Uses the line password for authentication.
<b>local</b>	Uses the locally-defined usernames for authentication.
<b>none</b>	Uses no authentication.
<b>radius</b>	Uses the list of all RADIUS servers for authentication.
<b>tacacs</b>	Uses the list of all TACACS+ servers for authentication.

### Default Configuration

If no methods are specified, the default are the locally-defined users and passwords. This is the same as entering the command **aaa authentication login local**.



### Note

If no authentication method is defined, console users can log in without any authentication verification.

### Command Mode

Global Configuration mode

### User Guidelines

Create a list of authentication methods by entering this command with the *list-name* parameter where *list-name* is any character string. The method arguments identifies the list of methods that the authentication algorithm tries, in the given sequence.

The default and list names created with this command are used with [login authentication](#).

**no aaa authentication login list-name** deletes a list-name only if it has not been referenced by another command.

### Example

The following example sets the authentication login methods for the console.

```
switchxxxxxx (config)# aaa authentication login authen-list radius local none
switchxxxxxx (config)#line console
switchxxxxxx (config-line)#login authentication authen-list
```

## 13.2 aaa authentication enable

The **aaa authentication enable** Global Configuration mode command sets one or more authentication methods for accessing higher privilege levels. A user, who logons with a lower privilege level, must pass these authentication methods to access a higher level.

To restore the default authentication method, use the **no** form of this command.

### Syntax

**aaa authentication enable** {**default** | *list-name*} *method* [*method2...*]

**no aaa authentication enable** {**default** | *list-name*}

### Parameters

- **default**—Uses the listed authentication methods that follow this argument as the default method list, when accessing higher privilege levels.
- **list-name** —Specifies a name for the list of authentication methods activated when a user accesses higher privilege levels. (Length: 1–12 characters)
- **method [method2...]**—Specifies a list of methods that the authentication algorithm tries, in the given sequence. The additional authentication methods are used only if the previous method returns an error, not if it fails. Specify **none** as the final method in the command line to ensure that the authentication succeeds, even if all methods return an error. Select one or more methods from the following list:

Keyword	Description
<b>enable</b>	Uses the enable password for authentication.
<b>line</b>	Uses the line password for authentication.
<b>none</b>	Uses no authentication.
<b>radius</b>	Uses the list of all RADIUS servers for authentication. Uses username "\$enabx\$." where x is the privilege level.
<b>tacacs</b>	Uses the list of all TACACS servers for authentication. Uses username "\$enabx\$." where x is the privilege level.

### Default Configuration

The [enable password](#) command defines the default authentication login method. This is the same as entering the command **aaa authentication enable default enable**.

On a console, the enable password is used if a password exists. If no password is set, authentication still succeeds. This is the same as entering the command **aaa authentication enable default enable none**.

**Command Mode**

Global Configuration mode

**User Guidelines**

Create a list by entering the **aaa authentication enable list-name method1 [method2...]** command where *list-name* is any character string used to name this list. The method argument identifies the list of methods that the authentication algorithm tries, in the given sequence.

The default and list names created by this command are used with [enable authentication](#).

All **aaa authentication enable default** requests sent by the device to a RADIUS or TACACS+ server include the username **\$enabx\$.**, where **x** is the requested privilege level.

The additional methods of authentication are used only if the previous method returns an error, not if it fails. Specify **none** as the final method in the command line to ensure that the authentication succeeds even if all methods return an error.

**no aaa authentication enable list-name** deletes list-name if it has not been referenced.

**Example**

The following example sets the enable password for authentication for accessing higher privilege levels.

---

```
switchxxxxxx(config)# aaa authentication enable enable-list radius none
switchxxxxxx(config)# line console
switchxxxxxx(config-line)# enable authentication enable-list
```

---

## 13.3 login authentication

The **login authentication** Line Configuration mode command specifies the login authentication method list for a remote Telnet or console session. Use the **no** form of this command to restore the default authentication method.

**Syntax**

**login authentication** {*default* | *list-name*}

**no login authentication**

**Parameters**

- **default**—Uses the default list created with the **aaa authentication login** command.
- **list-name**—Uses the specified list created with [aaa authentication login](#).

**Default Configuration**

The default is the [aaa authentication login](#) command default.

**Command Mode**

Line Configuration mode

**Examples**

**Example 1** - The following example specifies the login authentication method as the default method for a console session.

---

```
switchxxxxxx(config)# line console
switchxxxxxx(config-line)# login authentication default
```

---

**Example 2** - The following example sets the authentication login methods for the console as a list of methods.

---

```
switchxxxxxx (config)# aaa authentication login authen-list radius local none
switchxxxxxx (config)#line console
switchxxxxxx (config-line)#login authentication authen-list
```

---

## 13.4 enable authentication

The **enable authentication** Line Configuration mode command specifies the authentication method for accessing a higher privilege level from a remote Telnet or console. Use the **no** form of this command to restore the default authentication method.

### Syntax

**enable authentication** {*default* | *list-name*}

**no enable authentication**

### Parameters

- **default**—Uses the default list created with the [aaa authentication enable](#) command.
- **list-name**—Uses the specified list created with the [aaa authentication enable](#) command.

### Default Configuration

The default is the [aaa authentication enable](#) command default.

### Command Mode

Line Configuration mode

### Example

**Example 1** - The following example specifies the authentication method as the default method when accessing a higher privilege level from a console.

---

```
switchxxxxxx(config)# line console
switchxxxxxx(config-line)# enable authentication default
```

---

**Example 2** - The following example sets a list of authentication methods for accessing higher privilege levels.

---

```
switchxxxxxx(config)# aaa authentication enable enable-list radius none
switchxxxxxx(config)# line console
switchxxxxxx(config-line)# enable authentication enable-list
```

---

## 13.5 ip http authentication

The **ip http authentication** Global Configuration mode command specifies authentication methods for HTTP server access. Use the **no** form of this command to restore the default authentication method.

### Syntax

**ip http authentication aaa login-authentication** *method1* [*method2...*]

**no ip http authentication aaa login-authentication**

**Parameters**

**method [method2...]**—Specifies a list of methods that the authentication algorithm tries, in the given sequence. The additional authentication methods are used only if the previous method returns an error, not if it fails. Specify **none** as the final method in the command line to ensure that the authentication succeeds, even if all methods return an error. Select one or more methods from the following list:

Keyword	Description
<b>local</b>	Uses the local username database for authentication.
<b>none</b>	Uses no authentication.
<b>radius</b>	Uses the list of all RADIUS servers for authentication.
<b>tacacs</b>	Uses the list of all TACACS+ servers for authentication.

**Default Configuration**

The local user database is the default authentication login method. This is the same as entering the **ip http authentication local** command.

**Command Mode**

Global Configuration mode

**User Guidelines**

The command is relevant for HTTP and HTTPS server users.

**Example**

The following example specifies the HTTP access authentication methods.

---

```
switchxxxxxx(config)# ip http authentication aaa login-authentication radius
local none
```

---

## 13.6 show authentication methods

The **show authentication methods** Privileged EXEC mode command displays information about the authentication methods.

**Syntax**

**show authentication methods**

**Parameters**

N/A

**Default Configuration**

N/A

**Command Mode**

Privileged EXEC mode

**Example**

The following example displays the authentication configuration.

---

```

switchxxxxxx# show authentication methods
Login Authentication Method Lists
-----
Default: Radius, Local, Line
Console_Login: Line, None
Enable Authentication Method Lists
-----
Default: Radius, Enable
Console_Enable: Enable, None

Line                Login Method List    Enable Method List
-----
Console             Console_Login         Console_Enable
Telnet              Default               Default
SSH                 Default               Default

HTTP: Radius, local
HTTPS: Radius, local
Dot1x: Radius

```

---

## 13.7 password

Use the **password** Line Configuration mode command to specify a password on a line (also known as an access method, such as a console or Telnet). Use the **no** form of this command to return to the default password.

**Syntax**

**password** *password* [*encrypted*]

**no password**

**Parameters**

- **password**—Specifies the password for this line. (Length: 0–159 characters)
- **encrypted**—Specifies that the password is encrypted and copied from another device configuration.

**Default Configuration**

No password is defined.

**Command Mode**

Line Configuration mode

**Example**

The following example specifies the password 'secret' on a console.

---

```

switchxxxxxx(config)# line console
switchxxxxxx(config-line)# password secret

```



## 13.8 enable password

Use the **enable password** Global Configuration mode command to set a local password to control access to normal and privilege levels. Use the **no** form of this command to return to the default password.

When the administrator configures a new **enable** password, this password is encrypted automatically and saved to the configuration file. No matter how the password was entered, it appears in the configuration file with the keyword **encrypted** and the encrypted value.

If the administrator wants to manually copy a password that was configured on one switch (for instance, switch B) to another switch (for instance, switch A), the administrator must add **encrypted** in front of this encrypted password when entering the **enable** command in switch A. In this way, the two switches will have the same password.

### Syntax

**enable password** [*level privilege-level*] {*unencrypted-password* | **encrypted** *encrypted-password*}

**no enable password** [*level level*]

### Parameters

- **level privilege-level**—Level for which the password applies. If not specified the level is 15. (Range: 1–15)
- **password unencrypted-password**—Password for this level. (Range: 0–159 chars)
- **password encrypted encrypted-password**—Specifies that the password is encrypted. Use this keyword to enter a password that is already encrypted (for instance that you copied from another the configuration file of another device). (Range: 1–40)

### Default Configuration

Default for **level** is 15.

Passwords are encrypted by default.

### Command Mode

Global Configuration mode

### User Guidelines

Passwords are encrypted by default. You only are required to use the **encrypted** keyword when you are actually entering an encrypted keyword.

### Example

The first command sets an unencrypted password for level 7 (it will be encrypted in the configuration file).

The second command sets a password that has already been encrypted. It will copied to the configuration file just as it is entered. To use it, the user must know its unencrypted form.

```
switchxxxxxx(config)# enable password level 7 let-me-in
switchxxxxxx(config)# enable password level 15 encrypted
4b529f21c93d4706090285b0c10172eb073ffebc4
```

## 13.9 username

Use the **username** Global Configuration mode command to establish a username-based authentication system. Use the **no** form to remove a user name.

### Syntax

**username** *name* {**nopassword** | **password** *password* | **privilege** *privilege-level* | **unencrypted-password** | **encrypted** *encrypted-password*}

**username** *name*

**no username** *name*

### Parameters

- **name**—The name of the user. (Range: 1–20 characters)
- **nopassword**—No password is required for this user to log in.
- **unencrypted-password**—The authentication password for the user. (Range: 1–159)
- **encrypted** *encrypted-password*—Specifies that the password is encrypted. Use this keyword to enter a password that is already encrypted (for instance that you copied from another the configuration file of another device). (Range: 1–40)
- **privilege** *privilege-level* —Privilege level for which the password applies. If not specified the level is 15. (Range: 1–15).

### Default Configuration

No user is defined.

### Command Mode

Global Configuration mode

### Examples

**Example 1** - Sets an unencrypted password for user tom (level 15). It will be encrypted in the configuration file.

---

```
switchxxxxxx(config)# username tom privilege 15 password 1234
```

---

**Example 2** - Sets a password for user jerry (level 15) that has already been encrypted. It will be copied to the configuration file just as it is entered. To use it, the user must know its unencrypted form.

```
switchxxxxxx(config)# username jerry privilege 15 encrypted  
4b529f21c93d4706090285b0c10172eb073ffe4
```

---

## 13.10 show users accounts

The **show users accounts** Privileged EXEC mode command displays information about the users local database.

### Syntax

**show user accounts**

### Parameters

N/A

**Default Configuration**

N/A

**Command Mode**

Privileged EXEC mode

**Example**

The following example displays information about the users local database.

---

```
switchxxxxx# show users accounts
```

```

Username      Privilege
-----      -
Bob           15
Robert        15
Smith         15

```

The following table describes the significant fields shown in the display:

Field	Description
Username	The user name.
Privilege	The user's privilege level.

## 13.11 aaa accounting login

Use the **aaa accounting login** command in Global Configuration mode to enable accounting of device management sessions. Use the **no** form of this command to disable accounting.

**Syntax**

**aaa accounting login** *start-stop group radius*

**no aaa accounting login** *start-stop group radius*

**Parameters**

N/A

**Default Configuration**

Disabled

**Command Mode**

Global Configuration mode

**User Guidelines**

This command enables the recording of device management sessions (Telnet, serial and WEB but not SNMP).

It records only users that were identified with a username (e.g. a user that was logged in with a line password is not recorded).

If accounting is activated, the device sends a "start"/"stop" messages to a Radius server when a user logs in / logs out respectively.

The device uses the configured priorities of the available Radius servers in order to select the Radius server.

The following table describes the supported Radius accounting attributes values, and when they are sent by the switch.

Name	Start	Stop	Description
<b>User-Name (1)</b>	Yes	Yes	User's identity.
<b>NAS-IP-Address (4)</b>	Yes	Yes	The switch IP address that is used for the session with the Radius server.
<b>Class (25)</b>	Yes	Yes	Arbitrary value is included in all accounting packets for a specific session.
<b>Called-Station-ID (30)</b>	Yes	Yes	The switch IP address that is used for the management session.
<b>Calling-Station-ID (31)</b>	Yes	Yes	The user IP address.
<b>Acct-Session-ID (44)</b>	Yes	Yes	A unique accounting identifier.
<b>Acct-Authentic (45)</b>	Yes	Yes	Indicates how the supplicant was authenticated.
<b>Acct-Session-Time (46)</b>	No	Yes	Indicates how long the user was logged in.
<b>Acct-Terminate-Cause (49)</b>	No	Yes	Reports why the session was terminated.

### Example

```
switchxxxxxx(config)# aaa accounting login start-stop group radius
```

## 13.12 aaa accounting dot1x

To enable accounting of 802.1x sessions, use the **aaa accounting dot1x** Global Configuration mode command. Use the **no** form of this command to disable accounting.

### Syntax

**aaa accounting dot1x start-stop group radius**

**no aaa accounting dot1x start-stop group radius**

### Parameters

N/A

### Default Configuration

Disabled

### Command Mode

Global Configuration mode

### User Guidelines

This command enables the recording of 802.1x sessions.

If accounting is activated, the device sends a "start"/"stop" messages to a Radius server when a user logs in / logs out to the network, respectively.

The device uses the configured priorities of the available Radius servers in order to select the Radius server.

If a new supplicant replaces an old supplicant (even if the port state remains authorized), the software sends a "stop" message for the old supplicant and a "start" message for the new supplicant.

In multiple sessions mode (dot1x multiple-hosts authentication), the software sends "start"/"stop" messages for each authenticated supplicant.

In multiple hosts mode (dot1x multiple-hosts), the software sends “start”/“stop” messages only for the supplicant that has been authenticated.

The software does not send “start”/“stop” messages if the port is force-authorized.

The software does not send “start”/“stop” messages for hosts that are sending traffic on the guest VLAN or on the unauthenticated VLANs.

The following table describes the supported Radius accounting Attributes Values and when they are sent by the switch.

Name	Start	Stop	Description
<b>User-Name (1)</b>	Yes	Yes	Supplicant’s identity.
<b>NAS-IP-Address (4)</b>	Yes	Yes	The switch IP address that is used for the session with the Radius server.
<b>NAS-Port (5)</b>	Yes	Yes	The switch port from where the supplicant has logged in.
<b>Class (25)</b>	Yes	Yes	Arbitrary value is included in all accounting packets for a specific session.
<b>Called-Station-ID (30)</b>	Yes	Yes	The switch MAC address.
<b>Calling-Station-ID (31)</b>	Yes	Yes	The supplicant MAC address.
<b>Acct-Session-ID (44)</b>	Yes	Yes	A unique accounting identifier.
<b>Acct-Authentic (45)</b>	Yes	Yes	Indicates how the supplicant was authenticated.
<b>Acct-Session-Time (46)</b>	No	Yes	Indicated how long the supplicant was logged in.
<b>Acct-Terminate-Cause (49)</b>	No	Yes	Reports why the session was terminated.
<b>Nas-Port-Type (61)</b>	Yes	Yes	Indicates the supplicant physical port type.

### Example

```
switchxxxxxx(config)# aaa accounting dot1x start-stop group radius
```

## 13.13 show accounting

The **show accounting** EXEC mode command displays information about the accounting status.

### Syntax

**show accounting**

### Parameters

N/A

### Default Configuration

N/A

### Command Mode

EXEC mode

### Example

The following example displays information about the accounting status.

---

```
switchxxxxxx# show accounting  
Login: Radius  
802.1x: Disabled
```

# Remote Authentication Dial-In User Service (RADIUS) Commands

## 14.1 radius-server host

Use the **radius-server host** Global Configuration mode command to configure a RADIUS server host. Use the no form of the command to delete the specified RADIUS server host.

### Syntax

**radius-server host** {*ip-address* | *hostname*} [**auth-port** *auth-port-number*] [**acct-port** *acct-port-number*] [**timeout** *timeout*] [**retransmit** *retries*] [**deadtime** *deadtime*] [**key** *key-string*] [**source** {*source-ip*}] [**priority** *priority*] [**usage** {*login* | *802.1x* | *all*}]

**no radius-server host** {*ip-address* | *hostname*}

### Parameters

- **ip-address**—Specifies the RADIUS server host IP address. The IP address can be an IPv4, IPv6 or IPv6z address. See [IPv6z Address Conventions](#).
- **hostname**—Specifies the RADIUS server host name. Translation to IPv4 addresses only is supported. (Length: 1–158 characters. Maximum label length of each part of the hostname: 63 characters)
- **auth-port** *auth-port-number*—Specifies the port number for authentication requests. If the port number is set to 0, the host is not used for authentication. (Range: 0–65535)
- **acct-port-number**—Port number for accounting requests. The host is not used for accountings if set to 0. If unspecified, the port number defaults to 1813.
- **timeout** *timeout*—Specifies the timeout value in seconds. (Range: 1–30)
- **retransmit** *retries*—Specifies the retransmit value. (Range: 1–10)
- **deadtime** *deadtime*—Specifies the length of time in minutes during which a RADIUS server is skipped over by transaction requests. (Range: 0–2000)
- **key** *key-string*—Specifies the authentication and encryption key for all RADIUS communications between the device and the RADIUS server. This key must match the encryption used on the RADIUS daemon. To specify an empty string, enter "". (Length: 0–128 characters). If this parameter is omitted, the globally-configured radius key will be used.
- **key** *encrypted-key-string*—Same as key-string, but the key is in encrypted format.
- **source** *source-ip*—Specifies the source IPv4 or IPv6 address to use for communication. 0.0.0.0 is interpreted as a request to use the IP address of the outgoing IP interface.
- **priority** *priority*—Specifies the order in which servers are used, where 0 has the highest priority. (Range: 0–65535)
- **usage** {*login* | *802.1x* | *all*}—Specifies the RADIUS server usage type. The possible values are:
  - **login**—Specifies that the RADIUS server is used for user login parameters authentication.
  - **802.1x**—Specifies that the RADIUS server is used for 802.1x port authentication.
  - **all**—Specifies that the RADIUS server is used for user login authentication and 802.1x port authentication.

### Default Configuration

The default authentication port number is 1812.

If **timeout** is not specified, the global value (set in [radius-server timeout](#)) is used.

If **retransmit** is not specified, the global value (set in [radius-server retransmit](#)) is used.

If **key-string** is not specified, the global value (set in [radius-server key](#)) is used.

If the **source** value is not specified, the global value (set in [radius-server source-ip](#) or [radius-server source-ipv6](#)) is used.

If a parameter was not set in one of the above commands, the default for that command is used. For example, if a timeout value was not set in the current command or in [radius-server timeout](#), the default timeout for [radius-server timeout](#) is used.

The default usage type is **all**.

### Command Mode

Global Configuration mode

### User Guidelines

To specify multiple hosts, this command is used for each host.

The **source** parameter address type (IPv4 or IPv6) must be the same as that of the **host** IP address type.

### Example

The following example specifies a RADIUS server host with IP address 192.168.10.1, authentication request port number 20, and a 20-second timeout period.

---

```
switchxxxxxx(config)# radius-server host 192.168.10.1 auth-port 20 timeout 20
```

---

## 14.2 radius-server key

Use the **radius-server key** Global Configuration mode command to set the authentication for RADIUS communications between the device and the RADIUS daemon.

Use the **no** form of this command to restore the default configuration.

### Syntax

**radius-server key** *[key-string]*

**no radius-server key**

### Parameters

- **key-string**—Specifies the authentication and encryption key for all RADIUS communications between the device and the RADIUS server. This key must match the encryption used on the RADIUS daemon. (Range: 0–128 characters)

### Default Configuration

The key-string is an empty string.

### Command Mode

Global Configuration mode

### Example

The following example defines the authentication for all RADIUS communications between the device and the RADIUS daemon.

---

```
switchxxxxxx(config)# radius-server key enterprise-server
```

---



---

## 14.3 radius-server retransmit

Use the **radius-server retransmit** Global Configuration mode command to specify the number of times the software searches the list of RADIUS server hosts. Use the no form of this command to restore the default configuration.

### Syntax

**radius-server retransmit** *retries*

**no radius-server retransmit**

### Parameters

**retransmit** *retries*—Specifies the retransmit value. (Range: 1–10)

### Default Configuration

The software searches the list of RADIUS server hosts 3 times.

### Command Mode

Global Configuration mode

### Example

The following example configures the number of times the software searches all RADIUS server hosts as 5.

---

```
switchxxxxxx(config)# radius-server retransmit 5
```

---

## 14.4 radius-server source-ip

Use the **radius-server source-ip** Global Configuration mode command to specify the source IP address used for communication with RADIUS servers. Use the no form of this command to restore the default configuration.

### Syntax

**radius-server source-ip** {*source-ip-address*}

**no radius-server source-ip** {*source-ip-address*}

### Parameters

**source-ip-address**—Specifies the source IP address.

### Default Configuration

The source IP address is the IP address of the outgoing IP interface.

### Command Mode

Global Configuration mode

### User Guidelines

If there is no available IP interface of the configured IP source address, an error message is issued when attempting to communicate with the IP address.

**Example**

The following example configures the source IP address used for communication with all RADIUS servers to 10.1.1.1.

---

```
switchxxxxxx(config)# radius-server source-ip 10.1.1.1
```

---

## 14.5 radius-server source-ipv6

Use the **radius-server source-ipv6** Global Configuration mode command to specify the source IPv6 address used for communication with RADIUS servers. Use the no form of this command to restore the default configuration.

**Syntax**

```
radius-server source-ipv6 {source}
```

```
no radius-server source-ipv6 {source}
```

**Parameters**

**source**—Specifies the source IPv6 address.

**Default Configuration**

The source IP address is the IP address of the outgoing IP interface.

**Command Mode**

Global Configuration mode

**User Guidelines**

If there is no available IP interface of the configured IP source address, an error message is issued when attempting to communicate with the IP address.

**Example**

The following example configures the source IP address used for communication with all RADIUS servers to 3ffe:1900:4545:3:200:f8ff:fe21:67cf.

---

```
switchxxxxxx(config)# radius-server source-ipv6  
3ffe:1900:4545:3:200:f8ff:fe21:67cf
```

---

## 14.6 radius-server timeout

Use the **radius-server timeout** Global Configuration mode command to set how long the device waits for a server host to reply. Use the **no** form of this command to restore the default configuration.

**Syntax**

```
radius-server timeout timeout-seconds
```

```
no radius-server timeout
```

**Parameters**

**timeout** *timeout-seconds*—Specifies the timeout value in seconds. (Range: 1–30)

**Default Configuration**

The default timeout value is 3 seconds.

**Command Mode**

Global Configuration mode

**Example**

The following example sets the timeout interval on all RADIUS servers to 5 seconds.

---

```
switchxxxxxx(config)# radius-server timeout 5
```

---

## 14.7 radius-server deadtime

Use the **radius-server deadtime** Global Configuration mode command to configure how long unavailable RADIUS servers are skipped over by transaction requests. This improves RADIUS response time when servers are unavailable. Use the **no** form of this command to restore the default configuration.

**Syntax**

**radius-server deadtime** *deadtime*

**no radius-server deadtime**

**Parameters**

**deadtime**—Specifies the time interval in minutes during which a RADIUS server is skipped over by transaction requests. (Range: 0–2000)

**Default Configuration**

The default deadtime interval is 0.

**Command Mode**

Global Configuration mode

**Example**

The following example sets all RADIUS server deadtimes to 10 minutes.

---

```
switchxxxxxx(config)# radius-server deadtime 10
```

---

## 14.8 show radius-servers

Use the **show radius-servers** Privileged EXEC mode command to display the RADIUS server settings.

**Syntax**

**show radius-servers**

**Command Mode**

Privileged EXEC mode

**Example**

The following example displays RADIUS server settings.

---

```
switchxxxxx# show radius-servers
```

IP address	Port Auth	Port Acct	Time Out	Retransmission	Dead time	Source IP	Priority	Usage
172.16.1.1	1812	1813	Global	Global	Global	Global	1	All
172.16.1.2	1812	1813	11	8	Global	Global	2	All

Global values  
-----

```
TimeOut: 3
Retransmit: 3
Deadtime: 0
Source IP: 172.16.8.1
Source IPv6 : ::
```

# Terminal Access Controller Access-Control System Plus (TACACS+) Commands

## 15.1 tacacs-server host

Use the **tacacs-server host** Global Configuration mode command to specify a TACACS+ host. Use the **no** form of this command to delete the specified TACACS+ host.

### Syntax

**tacacs-server host** {*ip-address* | *hostname*} [*single-connection*] [**port** *port-number*] [**timeout** *timeout*] [**key** *key-string*] [**source** {*source-ip*}] [**priority** *priority*]

**no tacacs-server host** {*ip-address* | *hostname*}

### Parameters

- **host** *ip-address*—Specifies the TACACS+ server host IP address. Specifies the RADIUS server host IP address. The IP address can be an IPv4, IPv6 or IPv6z address.
- **host** *hostname*—Specifies the TACACS+ server host name. (Length: 1?158 characters. Maximum label length of each part of the host name: 63 characters)
- **single-connection**—Specifies that a single open connection is maintained between the device and the daemon, instead of the device opening and closing a TCP connection to the daemon each time it communicates.
- **port** *port-number*—Specifies the TACACS server TCP port number. If the port number is 0, the host is not used for authentication. (Range: 0-65535)
- **timeout** *timeout*—Specifies the timeout value in seconds. (Range: 1-30)
- **key** *key-string*—Specifies the authentication and encryption key for all TACACS+ communications between the device and the TACACS+ server. This key must match the encryption used on the TACACS+ daemon. To specify an empty string, enter "". (Length: 0-128 characters). If this parameter is omitted, the globally-defined key (set in [tacacs-server key](#)) will be used.
- **source** *source-ip*—Specifies the source IPv4 or IPv6 address to use for communication. 0.0.0.0 is interpreted as a request to use the IP address of the outgoing IP interface.
- **priority** *priority*—Specifies the order in which the TACACS+ servers are used, where 0 is the highest priority. (Range: 0-65535)

### Default Configuration

No TACACS+ host is specified.

The default **port-number** is 49.

The default authentication port number is 1812.

If **timeout** is not specified, the global value (set in [tacacs-server timeout](#)) is used.

If **key-string** is not specified, the global value (set in [tacacs-server key](#)) is used.

If the **source** value is not specified, the global value (set in [tacacs-server source-ip](#) or [tacacs-server source-ipv6](#)) is used.

If a parameter was not set in one of the above commands, the default for that command is used. For example, if a timeout value was not set in the current command or in [tacacs-server timeout](#), the default timeout for [tacacs-server timeout](#) is used.

**Command Mode**

Global Configuration mode

**User Guidelines**

Multiple **tacacs-server host** commands can be used to specify multiple hosts.

**Example**

The following example specifies a TACACS+ host.

---

```
switchxxxxxx(config)# tacacs-server host 172.16.1.1
```

---

## 15.2 tacacs-server key

Use the **tacacs-server key** Global Configuration mode command to set the authentication encryption key used for all TACACS+ communications between the device and the TACACS+ daemon. Use the **no** form of this command to disable the key.

**Syntax**

**tacacs-server key** *key-string*

**no tacacs-server key**

**Parameters**

- **key-string**—Specifies the authentication and encryption key for all TACACS+ communications between the device and the TACACS+ server. This key must match the encryption used on the TACACS+ daemon. (Length: 0–128 characters)

**Default Configuration**

The default key is an empty string.

**Command Mode**

Global Configuration mode

**Example**

The following example sets Enterprise as the authentication key for all TACACS+ servers.

---

```
switchxxxxxx(config)# tacacs-server key enterprise
```

---

## 15.3 tacacs-server timeout

Use the **tacacs-server timeout** Global Configuration mode command to set the interval during which the device waits for a TACACS+ server to reply. Use the **no** form of this command to restore the default configuration.

**Syntax**

**tacacs-server timeout** *timeout*

**no tacacs-server timeout**

**Parameters**

**timeout**—Specifies the timeout value in seconds. (Range: 1-30)

### Default Configuration

The default timeout value is 5 seconds.

### Command Mode

Global Configuration mode

### Example

The following example sets the timeout value to 30 for all TACACS+ servers.

---

```
switchxxxxxx(config)# tacacs-server timeout 30
```

---

## 15.4 tacacs-server source-ip

Use the **tacacs-server source-ip** Global Configuration mode command to configure the source IP address to be used for communication with TACACS+ servers. Use the no form of this command to restore the default configuration.

### Syntax

**tacacs-server source-ip** {source}

**no tacacs-server source-ip** {source}

### Parameters

**source**—Specifies the source IP address. (Range: Valid IP address)

### Default Configuration

The default source IP address is the outgoing IP interface address.

### Command Mode

Global Configuration mode

### User Guidelines

If the configured IP source address has no available IP interface, an error message is issued when attempting to communicate with the IP address.

### Example

The following example specifies the source IP address for all TACACS+ servers.

---

```
switchxxxxxx(config)# tacacs-server source-ip 172.16.8.1
```

---

## 15.5 show tacacs

Use the **show tacacs** Privileged EXEC mode command to display configuration and statistical information for a TACACS+ server.

### Syntax

**show tacacs** [ip-address]

### Parameters

**ip-address**—Specifies the TACACS+ server name, IP or IPv6 address.

**Default Configuration**

If **ip-address** is not specified, information for all TACACS+ servers is displayed.

**Command Mode**

Privileged EXEC mode

**Example**

The following example displays configuration and statistical information for all TACACS+ servers.

```
switchxxxxxx# show tacacs
```

---

IP address	Status	Port	Single Connection	Time Out	Source IP	Priority
-----	-----	----	-----	-----	-----	-----
172.16.1.1	Connected	49	No	Global	Global	1

Global values  
-----  
Time Out: 3  
Source IP: 172.16.8.1



---

## 16.1 logging on

Use the **logging on** Global Configuration mode command to control error message logging. This command sends debug or error messages asynchronously to designated locations. Use the **no** form of this command to disable the logging.

### Syntax

**logging on**

**no logging on**

### Parameters

N/A

### Default Configuration

Message logging is enabled.

### Command Mode

Global Configuration mode

### User Guidelines

The logging process controls the logging messages distribution at various destinations, such as the logging buffer, logging file or SYSLOG server. Logging on and off at these destinations can be individually configured using the [logging buffered](#), [logging file](#), and [logging on](#) Global Configuration mode commands. However, if the [logging on](#) command is disabled, no messages are sent to these destinations. Only the console receives messages.

### Example

The following example enables logging error messages.

---

```
switchxxxxxx(config)# logging on
```

---

## 16.2 logging host

Use the **logging host** Global Configuration command to log messages to the specified SYSLOG server. Use the **no** form of this command to delete the SYSLOG server with the specified address from the list of SYSLOG servers.

### Syntax

**logging host** {*ip-address* | *ipv6-address* | *hostname*} [**port** *port*] [**severity** *level*] [**facility** *facility*] [**description** *text*]

**no logging host** {*ipv4-address* | *ipv6-address* | *hostname*}

**Parameters**

- **ip-address**—IP address of the host to be used as a SYSLOG server. The IP address can be an IPv4, IPv6 or Ipv6z address. See [IPv6z Address Conventions](#).
- **hostname**—Hostname of the host to be used as a SYSLOG server. Only translation to IPv4 addresses is supported. (Range: 1–158 characters. Maximum label size for each part of the host name: 63)
- **port port**—Port number for SYSLOG messages. If unspecified, the port number defaults to 514. (Range: 1–65535)
- **severity level**—Limits the logging of messages to the SYSLOG servers to a specified level: emergencies, alerts, critical, errors, warnings, notifications, informational, debugging.
- **facility facility**—The facility that is indicated in the message. It can be one of the following values: local0, local1, local2, local3, local4, local5, local 6, local7. If unspecified, the port number defaults to local7.
- **description text**—Description of the SYSLOG server. (Range: Up to 64 characters)

**Default Configuration**

No messages are logged to a SYSLOG server.

if unspecified, the **severity level** defaults to Informational.

**Command Mode**

Global Configuration mode

**User Guidelines**

You can use multiple SYSLOG servers.

**Examples**


---

```
switchxxxxxx(config)# logging host 1.1.1.121
```

---

```
switchxxxxxx(config)# logging host 3000::100/SYSLOG1
```

---

## 16.3 logging console

Use the **logging console** Global Configuration mode command to limit messages logged to the console to messages to a specific severity level. Use the **no** form of this command to restore the default.

**Syntax**

**logging console** *level*

**no logging console**

**Parameters**

**level**—Specifies the severity level of logged messages displayed on the console. The possible values are: emergencies, alerts, critical, errors, warnings, notifications, informational and debugging.

**Default Configuration**

Informational.

**Command Mode**

Global Configuration mode

**Example**

The following example limits logging messages displayed on the console to messages with severity level **errors**.

---

```
switchxxxxxx(config)# logging console errors
```

---

## 16.4 logging buffered

Use the **logging buffered** Global Configuration mode command to limit the SYSLOG message display to messages with a specific severity level, and to define the buffer size (number of messages that can be stored). Use the **no** form of this command to cancel displaying the SYSLOG messages, and to return the buffer size to default.

**Syntax**

**logging buffered** [*buffer-size*] [*severity-level* | *severity-level-name*]

**no logging buffered**

**Parameters**

- **buffer-size**—Specifies the maximum number of messages stored in the history table. (Range: 20–400)
- **severity-level**—Specifies the severity level of messages logged in the buffer. The possible values are: 1-7.
- **severity-level-name**—Specifies the severity level of messages logged in the buffer. The possible values are: emergencies, alerts, critical, errors, warnings, notifications, informational and debugging.

**Default Configuration**

The default severity level is informational.

The default buffer size is 200.

**Command Mode**

Global Configuration mode

**User Guidelines**

All the SYSLOG messages are logged to the internal buffer. This command limits the messages displayed to the user.

**Example**

The following example shows two ways of limiting the SYSLOG message display from an internal buffer to messages with severity level **debugging**. In the second example, the buffer size is set to 100.

---

```
switchxxxxxx(config)# logging buffered debugging
switchxxxxxx(config)# logging buffered 100 7
```

---

## 16.5 clear logging

Use the **clear logging** Privileged EXEC mode command to clear messages from the internal logging buffer.

**Syntax**

**clear logging**

**Parameters**

N/A

**Default Configuration**

N/A

**Command Mode**

Privileged EXEC mode

**Example**

The following example clears messages from the internal logging buffer.

---

```
switchxxxxxx# clear logging  
Clear logging buffer [confirm]
```

---

## 16.6 logging file

Use the **logging file** Global Configuration mode command to limit SYSLOG messages sent to the logging file to messages with a specific severity level. Use the **no** form of this command to cancel sending messages to the file.

**Syntax****logging file** *level***no logging file****Parameters**

**level**—Specifies the severity level of SYSLOG messages sent to the logging file. The possible values are: emergencies, alerts, critical, errors, warnings, notifications, informational and debugging.

**Default Configuration**

The default severity level is **errors**.

**Command Mode**

Global Configuration mode

**Example**

The following example limits SYSLOG messages sent to the logging file to messages with severity level **alerts**.

---

```
switchxxxxxx(config)# logging file alerts
```

---

## 16.7 clear logging file

Use the **clear logging file** Privileged EXEC mode command to clear messages from the logging file.

**Syntax****clear logging file****Parameters**

N/A

**Default Configuration**

N/A

**Command Mode**

Privileged EXEC mode

**Example**

The following example clears messages from the logging file.

---

```
switchxxxxxx# clear logging file
Clear Logging File [y/n]
```

---

## 16.8 aaa logging

Use the **aaa logging** Global Configuration mode command to enable logging AAA logins. Use the **no** form of this command to disable logging AAA logins.

**Syntax****aaa logging** {login}**no aaa logging** {login}**Parameters**

**login**—Enables logging messages related to successful AAA login events, unsuccessful AAA login events and other AAA login-related events.

**Default Configuration**

Enabled.

**Command Mode**

Global Configuration mode

**User Guidelines**

This command enables logging messages related to successful login events, unsuccessful login events and other login-related events. Other types of AAA events are not subject to this command.

**Example**

The following example enables logging AAA login events.

---

```
switchxxxxxx(config)# aaa logging login
```

---

## 16.9 file-system logging

Use the **file-system logging** Global Configuration mode command to enable logging file system events. Use the **no** form of this command to disable logging file system events.

**Syntax****file-system logging** {copy | delete-rename}**no file-system logging** {copy | delete-rename}

**Parameters**

- **copy**—Specifies logging messages related to file copy operations.
- **delete-rename**—Specifies logging messages related to file deletion and renaming operations.

**Default Configuration**

Enabled.

**Command Mode**

Global Configuration mode

**Example**

The following example enables logging messages related to file copy operations.

---

```
switchxxxxxx(config)# file-system logging copy
```

---

## 16.10 management logging

Use the **management logging** Global Configuration mode command to enable logging Management Access List (ACL) deny events (rejected logins). Use the **no** form of this command to disable logging management access list events.

**Syntax**

```
management logging {deny}
```

```
no management logging {deny}
```

**Parameters**

**deny**—Enables logging messages related to management ACL deny actions (rejected logins).

**Default Configuration**

Logging management ACL deny events is enabled.

**Command Mode**

Global Configuration mode

**User Guidelines**

Other management ACL events are not subject to this command.

**Example**

The following example enables logging messages related to management ACL deny actions.

---

```
switchxxxxxx(config)# management logging deny
```

---

## 16.11 show logging

Use the **show logging** Privileged EXEC mode command to display the logging status and SYSLOG messages stored in the internal buffer.

**Syntax**

```
show logging
```

**Parameters**

N/A

**Default Configuration**

N/A

**Command Mode**

Privileged EXEC mode

**Example**

The following example displays the logging status and the SYSLOG messages stored in the internal buffer.

---

```
switchxxxxxx# show logging
Logging is enabled.
Console Logging: Level info. Console Messages: 0 Dropped.
Buffer Logging: Level info. Buffer Messages: 61 Logged, 61 Displayed, 200 Max.
File Logging: Level error. File Messages: 898 Logged, 64 Dropped.
4 messages were not logged
Application filtering control
Application          Event                      Status
-----
AAA                  Login                       Enabled
File system          Copy                         Enabled
File system          Delete-Rename               Enabled
Management ACL       Deny                         Enabled
Aggregation: Disabled.
Aggregation aging time: 300 Sec
01-Jan-2010 05:29:46 :%INIT-I-Startup: Warm Startup
01-Jan-2010 05:29:02 :%LINK-I-Up:  Vlan 1
01-Jan-2010 05:29:02 :%LINK-I-Up:  SYSLOG6
01-Jan-2010 05:29:02 :%LINK-I-Up:  SYSLOG7
01-Jan-2010 05:29:00 :%LINK-W-Down:  SYSLOG8
```

**16.12 show logging file**

Use the **show logging file** Privileged EXEC mode command to display the logging status and the SYSLOG messages stored in the logging file.

**Syntax****show logging file****Parameters**

N/A

**Default Configuration**

N/A

**Command Mode**

Privileged EXEC mode

**Example**

The following example displays the logging status and the SYSLOG messages stored in the logging file.

---

```
switchxxxxx# show logging file
Logging is enabled.
Console Logging: Level info. Console Messages: 0 Dropped.
Buffer Logging: Level info. Buffer Messages: 61 Logged, 61 Displayed, 200 Max.
File Logging: Level error. File Messages: 898 Logged, 64 Dropped.
4 messages were not logged
Application filtering control
Application          Event          Status
-----
AAA                 Login          Enabled
File system         Copy           Enabled
File system         Delete-Rename  Enabled
Management ACL     Deny          Enabled
Aggregation: Disabled.
Aggregation aging time: 300 Sec
01-Jan-2010 05:57:00 :%SSHD-E-ERROR: SSH error: key_read: type mismatch:
encoding error
01-Jan-2010 05:56:36 :%SSHD-E-ERROR: SSH error: key_read: type mismatch:
encoding error
01-Jan-2010 05:55:37 :%SSHD-E-ERROR: SSH error: key_read: type mismatch:
encoding error
01-Jan-2010 05:55:03 :%SSHD-E-ERROR: SSH error: key_read: key_from_blob bgEgGnt9
z6NHgZwKI5xKqF7cBtd11xmFgSEWuDhho5UedydAjVkKS5XR2... failed
01-Jan-2010 05:55:03 :%SSHD-E-ERROR: SSH error: key_from_blob: invalid key type.
01-Jan-2010 05:56:34 :%SSHD-E-ERROR: SSH error: bad sigbloblen 58 != SIGBLOB_LEN
console#
```

---

**16.13 show syslog-servers**

Use the **show syslog-servers** Privileged EXEC mode command to display the SYSLOG server settings.

**Syntax**

**show syslog-servers**

**Parameters**

N/A

**Default Configuration**

N/A

**Command Mode**

Privileged EXEC mode



**Example**

The following example provides information about the SYSLOG servers.

---

```
switchxxxxxx# show syslog-servers
Device Configuration
IP address      Port    Facility Severity  Description
-----
1.1.1.121      514    local7   info
3000::100      514    local7   info
```



## Remote Network Monitoring (RMON) Commands

### 17.1 show rmon statistics

Use the **show rmon statistics** EXEC mode command to display RMON Ethernet statistics.

#### Syntax

**show rmon statistics** *{interface-id}*

#### Parameters

**interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

#### Command Mode

EXEC mode

#### Example

The following example displays RMON Ethernet statistics for gigabitethernet port `gi1/0/11`.

```
switchxxxxxx# show rmon statistics gi1/0/11
Port gi1/0/11
Dropped: 0
Octets: 0                               Packets: 0
Broadcast: 0                             Multicast: 0
CRC Align Errors: 0                       Collisions: 0
Undersize Pkts: 0                         Oversize Pkts: 0
Fragments: 0                              Jabbers: 0
64 Octets: 0                              65 to 127 Octets: 1
128 to 255 Octets: 1                      256 to 511 Octets: 1
512 to 1023 Octets: 0                     1024 to max Octets: 0
```

The following table describes the significant fields displayed.

Field	Description
<b>Dropped</b>	Total number of events in which packets were dropped by the probe due to lack of resources. Note that this number is not necessarily the number of packets dropped. It is the number of times this condition was detected.
<b>Octets</b>	Total number of octets of data (including those in bad packets) received on the network (excluding framing bits but including FCS octets).
<b>Packets</b>	Total number of packets (including bad packets, broadcast packets, and multicast packets) received.
<b>Broadcast</b>	Total number of good packets received and directed to the broadcast address. This does not include multicast packets.

Field	Description
<b>Multicast</b>	Total number of good packets received and directed to a multicast address. This number does not include packets directed to the broadcast address.
<b>CRC Align Errors</b>	Total number of packets received with a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, but with either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
<b>Collisions</b>	Best estimate of the total number of collisions on this Ethernet segment.
<b>Undersize Pkts</b>	Total number of packets received, less than 64 octets long (excluding framing bits, but including FCS octets) and otherwise well formed.
<b>Oversize Pkts</b>	Total number of packets received, longer than 1518 octets (excluding framing bits, but including FCS octets) and otherwise well formed.
<b>Fragments</b>	Total number of packets received, less than 64 octets in length (excluding framing bits but including FCS octets) and either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
<b>Jabbers</b>	Total number of packets received, longer than 1518 octets (excluding framing bits, but including FCS octets), and either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
<b>64 Octets</b>	Total number of packets (including bad packets) received that are 64 octets in length (excluding framing bits but including FCS octets).
<b>65 to 127 Octets</b>	Total number of packets (including bad packets) received that are between 65 and 127 octets in length inclusive (excluding framing bits but including FCS octets).
<b>128 to 255 Octets</b>	Total number of packets (including bad packets) received that are between 128 and 255 octets in length inclusive (excluding framing bits but including FCS octets).
<b>256 to 511 Octets</b>	Total number of packets (including bad packets) received that are between 256 and 511 octets in length inclusive (excluding framing bits but including FCS octets).
<b>512 to 1023 Octets</b>	Total number of packets (including bad packets) received that were between 512 and 1023 octets in length inclusive (excluding framing bits but including FCS octets).
<b>1024 to max</b>	Total number of packets (including bad packets) received that were between 1024 octets and the maximum frame size in length inclusive (excluding framing bits but including FCS octets).

## 17.2 rmon collection stats

Use the **rmon collection stats** Interface Configuration mode command to enable RMON MIB collecting history statistics (in groups) on an interface. Use the **no** form of this command to remove a specified RMON history group of statistics.

### Syntax

**rmon collection stats** *index* [*owner ownername*] [*buckets bucket-number*] [*interval seconds*]

**no rmon collection stats** *index*

### Parameters

- **index**—The requested group of statistics index.(Range: 1–65535)
- **owner ownername**—Records the name of the owner of the RMON group of statistics. If unspecified, the name is an empty string. (Range: Valid string)
- **buckets bucket-number**—A value associated with the number of buckets specified for the RMON collection history group of statistics. If unspecified, defaults to 50.(Range: 1–50)

- **interval seconds**—The number of seconds in each polling cycle. If unspecified, defaults to 1800 (Range: 1–3600).

### Command Mode

Interface Configuration (Ethernet, Port-channel) mode. Cannot be configured for a range of interfaces (range context).

## 17.3 show rmon collection stats

Use the **show rmon collection stats** EXEC mode command to display the requested RMON history group statistics.

### Syntax

**show rmon collection stats** [*interface-id*]

### Parameters

**interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

### Command Mode

EXEC mode

### Example

The following example displays all RMON history group statistics.

```
switchxxxxxx# show rmon collection stats
```

Index	Interface	Interval	Requested Samples	Granted Samples	Owner
1	gi1/0/11	30	50	50	CLI
2	gi1/0/11	1800	50	50	Manager

The following table describes the significant fields shown in the display.

Field	Description
<b>Index</b>	An index that uniquely identifies the entry.
<b>Interface</b>	The sampled Ethernet interface.
<b>Interval</b>	The interval in seconds between samples.
<b>Requested Samples</b>	The requested number of samples to be saved.
<b>Granted Samples</b>	The granted number of samples to be saved.
<b>Owner</b>	The entity that configured this entry.

## 17.4 show rmon history

Use the **show rmon history** EXEC mode command to display RMON Ethernet history statistics.

### Syntax

**show rmon history** *index* {*throughput* | *errors* | *other*} [*period seconds*]

**Parameters**

- **index**—Specifies the set of samples to display. (Range: 1–65535)
- **throughput**—Displays throughput counters.
- **errors**—Displays error counters.
- **other**—Displays drop and collision counters.
- **period seconds**—Specifies the period of time in seconds to display. (Range: 1–2147483647)

**Command Mode**

EXEC mode

**Example**

The following examples display RMON Ethernet history statistics for index 1

---

```
switchxxxxxx# show rmon history 1 throughput
```

```
Sample Set: 1                      Owner: CLI
Interface: gil/0/11                 Interval: 1800
Requested samples: 50               Granted samples: 50

Maximum table size: 500
```

Time	Octets	Packets	Broadcast	Multicast	Util
Jan 18 2005 21:57:00	303595962	357568	3289	7287	19%
Jan 18 2005 21:57:30	287696304	275686	2789	5878	20%

---

```
switchxxxxxx# show rmon history 1 errors
```

```
Sample Set: 1                      Owner: Me
Interface:gil/0/11                 Interval: 1800
Requested samples: 50               Granted samples: 50

Maximum table size: 500 (800 after reset)
```

Time	CRC Align	Under size	Oversize	Fragments	Jabbers
Jan 18 2005 21:57:00	1	1	0	49	0
Jan 18 2005 21:57:30	1	1	0	27	0

---

```
switchxxxxxx# show rmon history 1 other
```

```
Sample Set: 1                      Owner: Me
Interface: gil/0/11                 Interval: 1800
Requested samples: 50               Granted samples: 50

Maximum table size: 500
```

Time	Dropped	Collisions
Jan 18 2005 21:57:00	3	0
Jan 18 2005 21:57:30	3	0

The following table describes significant fields shown in the display:

Field	Description
<b>Time</b>	Date and Time the entry is recorded.
<b>Octets</b>	Total number of octets of data (including those in bad packets and excluding framing bits but including FCS octets) received on the network.
<b>Packets</b>	Number of packets (including bad packets) received during this sampling interval.
<b>Broadcast</b>	Number of good packets received during this sampling interval that were directed to the broadcast address.
<b>Multicast</b>	Number of good packets received during this sampling interval that were directed to a multicast address. This number does not include packets addressed to the broadcast address.
<b>Utilization</b>	Best estimate of the mean physical layer network utilization on this interface during this sampling interval, in hundredths of a percent.
<b>CRC Align</b>	Number of packets received during this sampling interval that had a length (excluding framing bits but including FCS octets) between 64 and 1518 octets, inclusive, but had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
<b>Undersize</b>	Number of packets received during this sampling interval that were less than 64 octets long (excluding framing bits but including FCS octets) and were otherwise well formed.
<b>Oversize</b>	Number of packets received during this sampling interval that were longer than 1518 octets (excluding framing bits but including FCS octets) but were otherwise well formed.
<b>Fragments</b>	Total number of packets received during this sampling interval that were less than 64 octets in length (excluding framing bits but including FCS octets) and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error), or a bad FCS with a non-integral number of octets (Alignment Error). It is normal for etherHistoryFragments to increment because it counts both runts (which are normal occurrences due to collisions) and noise hits.
<b>Jabbers</b>	Number of packets received during this sampling interval that were longer than 1518 octets (excluding framing bits but including FCS octets), and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
<b>Dropped</b>	Total number of events in which packets were dropped by the probe due to lack of resources during this sampling interval. This number is not necessarily the number of packets dropped, it is the number of times this condition has been detected.
<b>Collisions</b>	Best estimate of the total number of collisions on this Ethernet segment during this sampling interval.

## 17.5 rmon alarm

Use the **rmon alarm** Global Configuration mode command to configure alarm conditions. Use the **no** form of this command to remove an alarm.

### Syntax

```
rmon alarm index mib-object-id interval rising-threshold falling-threshold rising-event falling-event [type {absolute | delta}] [startup {rising | rising-falling | falling}] [owner name]
```

```
no rmon alarm index
```

### Parameters

- **index**—Specifies the alarm index. (Range: 1–65535)
- **mib-object-id**—Specifies the object identifier of the variable to be sampled. (Valid OID)

- **interval**—Specifies the interval in seconds during which the data is sampled and compared with rising and falling thresholds. (Range: 1–4294967295)
- **rising-threshold**—Specifies the rising threshold value. (Range: 0–4294967295)
- **falling-threshold**—Specifies the falling threshold value. (Range: 0–4294967295)
- **rising-event**—Specifies the index of the event triggered when a rising threshold is crossed. (Range: 0–65535)
- **falling-event**—Specifies the index of the event triggered when a falling threshold is crossed. (Range: 0–65535)
- **type {absolute | delta}**—Specifies the method used for sampling the selected variable and calculating the value to be compared against the thresholds. The possible values are:
  - **absolute**—Specifies that the selected variable value is compared directly with the thresholds at the end of the sampling interval.
  - **delta**—Specifies that the selected variable value of the last sample is subtracted from the current value, and the difference is compared with the thresholds.
- **startup {rising | rising-falling | falling}**—Specifies the alarm that may be sent when this entry becomes valid. The possible values are:
  - **rising**—Specifies that if the first sample (after this entry becomes valid) is greater than or equal to **rising-threshold**, a single rising alarm is generated.
  - **rising-falling**—Specifies that if the first sample (after this entry becomes valid) is greater than or equal to **rising-threshold**, a single rising alarm is generated. If the first sample (after this entry becomes valid) is less than or equal to **falling-threshold**, a single falling alarm is generated.
  - **falling**—Specifies that if the first sample (after this entry becomes valid) is less than or equal to **falling-threshold**, a single falling alarm is generated.
- **owner name**—Specifies the name of the person who configured this alarm. (Valid string)

### Default Configuration

The default method type is **absolute**.

The default **startup** direction is **rising-falling**.

If the owner **name** is not specified, it defaults to an empty string.

### Command Mode

Global Configuration mode

### Example

The following example configures an alarm with index 1000, MIB object ID D-Link, sampling interval 360000 seconds (100 hours), rising threshold value 1000000, falling threshold value 1000000, rising threshold event index 10, falling threshold event index 10, absolute method type and rising-falling alarm.

---

```
switchxxxxxx(config)# rmon alarm 1000 1.3.6.1.2.1.2.2.1.10.1 360000 1000000
1000000 10 20
```

---

## 17.6 show rmon alarm-table

Use the **show rmon alarm-table** EXEC mode command to display a summary of the alarms table.

### Syntax

**show rmon alarm-table**

### Command Mode

EXEC mode



**Example**

The following example displays the alarms table.

---

```
switchxxxxxx# show rmon alarm-table
```

Index	OID	Owner
-----	-----	-----
1	1.3.6.1.2.1.2.2.1.10.1	CLI
2	1.3.6.1.2.1.2.2.1.10.1	Manager
3	1.3.6.1.2.1.2.2.1.10.9	CLI

The following table describes the significant fields shown in the display:

Field	Description
<b>Index</b>	An index that uniquely identifies the entry.
<b>OID</b>	Monitored variable OID.
<b>Owner</b>	The entity that configured this entry.

---

## 17.7 show rmon alarm

Use the **show rmon alarm** EXEC mode command to display alarm configuration.

**Syntax**

**show rmon alarm** *number*

**Parameters**

**alarm** *number*—Specifies the alarm index. (Range: 1–65535)

**Command Mode**

EXEC mode

**Example**

The following example displays RMON 1 alarms.

---

```
switchxxxxxx# show rmon alarm 1
```

```
Alarm 1
-----
OID: 1.3.6.1.2.1.2.2.1.10.1
Last sample Value: 878128
Interval: 30
Sample Type: delta
Startup Alarm: rising
Rising Threshold: 8700000
Falling Threshold: 78
Rising Event: 1
Falling Event: 1
Owner: CLI
```

---

The following table describes the significant fields shown in the display:

Field	Description
<b>Alarm</b>	Alarm index.
<b>OID</b>	Monitored variable OID.
<b>Last Sample Value</b>	Value of the statistic during the last sampling period. For example, if the sample type is <b>delta</b> , this value is the difference between the samples at the beginning and end of the period. If the sample type is <b>absolute</b> , this value is the sampled value at the end of the period.
<b>Interval</b>	Interval in seconds over which the data is sampled and compared with the rising and falling thresholds.
<b>Sample Type</b>	Method of sampling the variable and calculating the value compared against the thresholds. If the value is <b>absolute</b> , the variable value is compared directly with the thresholds at the end of the sampling interval. If the value is <b>delta</b> , the variable value at the last sample is subtracted from the current value, and the difference is compared with the thresholds.
<b>Startup Alarm</b>	Alarm that is sent when this entry is first set. If the first sample is greater than or equal to the rising threshold, and startup alarm is equal to rising or rising-falling, then a single rising alarm is generated. If the first sample is less than or equal to the falling threshold, and startup alarm is equal falling or rising-falling, then a single falling alarm is generated.
<b>Rising Threshold</b>	Sampled statistic rising threshold. When the current sampled value is greater than or equal to this threshold, and the value at the last sampling interval is less than this threshold, a single event is generated.
<b>Falling Threshold</b>	Sampled statistic falling threshold. When the current sampled value is less than or equal to this threshold, and the value at the last sampling interval is greater than this threshold, a single event is generated.
<b>Rising Event</b>	Event index used when a rising threshold is crossed.
<b>Falling Event</b>	Event index used when a falling threshold is crossed.
<b>Owner</b>	Entity that configured this entry.

## 17.8 rmon event

Use the **rmon event** Global Configuration mode command to configure an event. Use the **no** form of this command to remove an event.

### Syntax

```
rmon event index {none | log | trap | log-trap} [community text] [description text] [owner name]
```

```
no rmon event index
```

### Parameters

- **index**—Specifies the event index. (Range: 1–65535)
- **none**— Specifies that no notification is generated by the device for this event.
- **log**—Specifies that a notification entry is generated in the log table by the device for this event.
- **trap**—Specifies that an SNMP trap is sent to one or more management stations by the device for this event.
- **log-trap**—Specifies that an entry is generated in the log table and an SNMP trap is sent to one or more management stations by the device for this event.
- **community text**—Specifies the SNMP community (password) used when an SNMP trap is sent. (Octet string; length: 0–127 characters)
- **description text**—Specifies a comment describing this event. (Length: 0–127 characters)

- **owner name**—Specifies the name of the person who configured this event. (Valid string)

### Default Configuration

If the owner name is not specified, it defaults to an empty string.

### Command Mode

Global Configuration mode

### Example

The following example configures an event identified as index 10, for which the device generates a notification in the log table.

---

```
switchxxxxxx(config)# rmon event 10 log
```

---

## 17.9 show rmon events

Use the **show rmon events** EXEC mode command to display the RMON event table.

### Syntax

**show rmon events**

### Command Mode

EXEC mode

### Example

The following example displays the RMON event table.

---

```
switchxxxxxx# show rmon events
```

Index	Description	Type	Community	Owner	Last time sent
----	-----	-----	-----	-----	-----
1	Errors	Log	router	CLI	Jan 18 2006 23:58:17
2	High Broadcast	Log Trap		Manager	Jan 18 2006 23:59:48

The following table describes significant fields shown in the display:

Field	Description
<b>Index</b>	Unique index that identifies this event.
<b>Description</b>	Comment describing this event.
<b>Type</b>	Type of notification that the device generates about this event. Can have the following values: <b>none</b> , <b>log</b> , <b>trap</b> , <b>log-trap</b> . In the case of log, an entry is made in the log table for each event. In the case of trap, an SNMP trap is sent to one or more management stations.
<b>Community</b>	If an SNMP trap is to be sent, it is sent with the SNMP community string specified by this octet string.
<b>Owner</b>	The entity that configured this event.
<b>Last time sent</b>	The time this entry last generated an event. If this entry has not generated any events, this value is zero.

## 17.10 show rmon log

Use the **show rmon log** EXEC mode command to display the RMON log table.

### Syntax

**show rmon log** [*event*]

### Parameters

**event**—Specifies the event index. (Range: 0–65535)

### Command Mode

EXEC mode

### Example

The following example displays event 1 in the RMON log table.

```
switchxxxxxx# show rmon log 1
Maximum table size: 500 (800 after reset)

Event          Description          Time
-----
1              MIB Var.:          Jan 18 2006 23:48:19
                1.3.6.1.2.1.2.2.1.10.
                53, Delta, Rising,
                Actual Val: 800,
                Thres.Set: 100,
                Interval (sec):1
```

## 17.11 rmon table-size

Use the **rmon table-size** Global Configuration mode command to configure the maximum size of RMON tables. Use the no form of this command to return to the default size.

### Syntax

**rmon table-size** {*history entries* | *log entries*}

**no rmon table-size** {*history* | *log*}

### Parameters

- **history entries**—Specifies the maximum number of history table entries. (Range: 20–270)
- **log entries**—Specifies the maximum number of log table entries. (Range: 20–100)

### Default Configuration

The default history table size is 270 entries.

The default log table size is 200 entries.

### Command Mode

Global Configuration mode

### User Guidelines

The configured table size takes effect after the device is rebooted.

**Example**

The following example configures the maximum size of RMON history tables to 100 entries.

---

```
switchxxxxxx(config)# rmon table-size history 100
```



---

## 18.1 aaa authentication dot1x

Use the **aaa authentication dot1x** Global Configuration mode command to specify how ports are authenticated when 802.1x is enabled. You can select either authentication by a RADIUS server, no authentication, or both methods. Use the **no** form of this command to restore the default configuration.

### Syntax

**aaa authentication dot1x default** *method1* [*method2*]

**no aaa authentication dot1x default**

### Parameters

**method1** [**method2**]—Specify at least one method from the following:

- **radius** - Uses the list of all RADIUS servers for authentication
- **none** - Uses no authentication

### Default Configuration

The default method is RADIUS.

### Command Mode

Global Configuration mode

### User Guidelines

You can select either authentication by a RADIUS server, no authentication (**none**), or both methods.

If you require that authentication succeeds even if the RADIUS server is not found or returns an error, specify **none** as the final method in the command line.

### Example

The following example sets the 802.1X authentication mode to RADIUS server authentication. If no response is received, no authentication is performed.

---

```
switchxxxxxx(config)# aaa authentication dot1x default radius none
```

---

## 18.2 dot1x system-auth-control

Use the **dot1x system-auth-control** Global Configuration mode command to enable 802.1x globally. Use the **no** form of this command to restore the default configuration.

### Syntax

**dot1x system-auth-control**

**no dot1x system-auth-control**

**Parameters**

N/A

**Default Configuration**

Disabled.

**Command Mode**

Global Configuration mode

**Example**

The following example enables 802.1x globally.

---

```
switchxxxxxx(config)# dot1x system-auth-control
```

## 18.3 dot1x port-control

Use the **dot1x port-control** Interface Configuration (Ethernet) mode command to enable manual control of the port authorization state. Use the **no** form of this command to restore the default configuration.

**Syntax**

```
dot1x port-control {auto | force-authorized | force-unauthorized}
```

```
no dot1x port-control
```

**Parameters**

- **auto**—Enables 802.1x authentication on the port and causes it to transition to the authorized or unauthorized state, based on the 802.1x authentication exchange between the device and the client.
- **force-authorized**—Disables 802.1x authentication on the interface and causes the port to transition to the authorized state without any authentication exchange required. The port resends and receives normal traffic without 802.1x-based client authentication.
- **force-unauthorized**—Denies all access through this port by forcing it to transition to the unauthorized state and ignoring all attempts by the client to authenticate. The device cannot provide authentication services to the client through this port.

**Default Configuration**

The port is in the force-authorized state.

**Command Mode**

Interface Configuration (Ethernet) mode

**User Guidelines**

It is recommended to disable spanning tree or to enable spanning-tree PortFast mode on 802.1x edge ports (ports in **auto** state that are connected to end stations), in order to proceed to the forwarding state immediately after successful authentication.

**Example**

The following example sets 802.1x authentication on `gi1/0/115` to auto mode.

---

```
switchxxxxxx(config)# interface gi1/0/115
switchxxxxxx(config-if)# dot1x port-control auto
```



---

## 18.4 dot1x reauthentication

Use the **dot1x reauthentication** Interface Configuration mode command to enable periodic re-authentication of the client. Use the **no** form of this command to return to the default setting.

### Syntax

**dot1x reauthentication**

**no dot1x reauthentication**

### Parameters

N/A

### Default Configuration

Periodic re-authentication is disabled.

### Command Mode

Interface configuration (Ethernet)

### Example

---

```
switchxxxxxx(config)# interface gi1/0/11
switchxxxxxx(config-if)# dot1x reauthentication
```

---

## 18.5 dot1x timeout reauth-period

Use the **dot1x timeout reauth-period** Interface Configuration mode command to set the number of seconds between re-authentication attempts. Use the **no** form of this command to return to the default setting.

### Syntax

**dot1x timeout reauth-period** *seconds*

**no dot1x timeout reauth-period**

### Parameters

**reauth-period** *seconds*—Number of seconds between re-authentication attempts. (Range: 300-4294967295)

### Default Configuration

3600

### Command Mode

Interface Configuration (Ethernet) mode

### Example

---

```
switchxxxxxx(config)# interface gi1/0/11
switchxxxxxx(config-if)# dot1x timeout reauth-period 5000
```

---

## 18.6 dot1x re-authenticate

The **dot1x re-authenticate** Privileged EXEC mode command manually initiates re-authentication of all 802.1x-enabled ports or the specified 802.1x-enabled port.

### Syntax

**dot1x re-authenticate** [*interface-id*]

### Parameters

**interface-id**—Specifies an Ethernet port ID.

### Default Configuration

If no port is specified, command is applied to all ports.

### Command Mode

Privileged EXEC mode

### Example

The following command manually initiates re-authentication of 802.1x-enabled `gi1/0/115`.

---

```
switchxxxxxx# dot1x re-authenticate gi1/0/115
```

---

---

## 18.7 dot1x timeout quiet-period

Use the **dot1x timeout quiet-period** Interface Configuration (Ethernet) mode command to set the time interval that the device remains in a quiet state following a failed authentication exchange (for example, the client provided an invalid password). Use the **no** form of this command to restore the default configuration.

### Syntax

**dot1x timeout quiet-period** *seconds*

**no dot1x timeout quiet-period**

### Parameters

**seconds**—Specifies the time interval in seconds that the device remains in a quiet state following a failed authentication exchange with the client. (Range: 0–65535 seconds)

### Default Configuration

The default quiet period is 60 seconds.

### Command Mode

Interface Configuration (Ethernet) mode

### User Guidelines

During the quiet period, the device does not accept or initiate authentication requests.

The default value of this command should only be changed to adjust to unusual circumstances, such as unreliable links or specific behavioral problems with certain clients and authentication servers.

To provide faster response time to the user, a smaller number than the default value should be entered.

### Example

The following example sets the time interval that the device remains in the quiet state following a failed authentication exchange to 10 seconds.

---

```
switchxxxxxx(config)# interface gi1/0/115
switchxxxxxx(config-if)# dot1x timeout quiet-period 10
```

---

## 18.8 dot1x timeout tx-period

Use the **dot1x timeout tx-period** Interface Configuration (Ethernet) mode command to set the time interval during which the device waits for a response to an Extensible Authentication Protocol (EAP) request/identity frame from the client before resending the request. Use the **no** form of this command to restore the default configuration.

### Syntax

**dot1x timeout tx-period** *seconds*

**no dot1x timeout tx-period**

### Parameters

**seconds**—Specifies the time interval in seconds during which the device waits for a response to an EAP-request/identity frame from the client before resending the request. (Range: 30–65535 seconds)

### Default Configuration

The default timeout period is 30 seconds.

### Command Mode

Interface Configuration (Ethernet) mode

### User Guidelines

The default value of this command should be changed only to adjust to unusual circumstances, such as unreliable links or specific behavioral problems with certain clients and authentication servers.

### Example

The following command sets the time interval during which the device waits for a response to an EAP request/identity frame to 60 seconds.

---

```
switchxxxxxx(config)# interface gi1/0/115
switchxxxxxx(config-if)# dot1x timeout tx-period 60
```

---

## 18.9 dot1x max-req

Use the **dot1x max-req** Interface Configuration mode command to set the maximum number of times that the device sends an Extensible Authentication Protocol (EAP) request/identity frame (assuming that no response is received) to the client before restarting the authentication process. Use the **no** form of this command to restore the default configuration.

### Syntax

**dot1x max-req** *count*

**no dot1x max-req**

**Parameters**

**max-req** *count*—Specifies the maximum number of times that the device sends an EAP request/identity frame before restarting the authentication process. (Range: 1–10)

**Default Configuration**

The default maximum number of attempts is 2.

**Command Mode**

Interface Configuration (Ethernet) mode

**User Guidelines**

The default value of this command should be changed only to adjust to unusual circumstances, such as unreliable links or specific behavioral problems with certain clients and authentication servers.

**Example**

The following example sets the maximum number of times that the device sends an EAP request/identity frame to 6

---

```
switchxxxxxx(config)# interface gi1/0/115  
switchxxxxxx(config-if)# dot1x max-req 6
```

---

## 18.10 dot1x timeout supp-timeout

Use the **dot1x timeout supp-timeout** Interface Configuration (Ethernet) mode command to set the time interval during which the device waits for a response to an Extensible Authentication Protocol (EAP) request frame from the client before resending the request. Use the **no** form of this command to restore the default configuration.

**Syntax**

**dot1x timeout supp-timeout** *seconds*

**no dot1x timeout supp-timeout**

**Parameters**

**supp-timeout** *seconds*—Specifies the time interval in seconds during which the device waits for a response to an EAP request frame from the client before resending the request. (Range: 1–65535 seconds)

**Default Configuration**

The default timeout period is 30 seconds.

**Command Mode**

Interface Configuration (Ethernet) mode

**User Guidelines**

The default value of this command should be changed only to adjust to unusual circumstances, such as unreliable links or specific behavioral problems with certain clients and authentication servers.

**Example**

The following example sets the time interval during which the device waits for a response to an EAP request frame from the client before resending the request to 3600 seconds.

---

```
switchxxxxxx(config)# interface gi1/0/115
switchxxxxxx(config-if)# dot1x timeout supp-timeout 3600
```

---

**18.11 dot1x timeout server-timeout**

Use the **dot1x timeout server-timeout** Interface Configuration (Ethernet) mode command to set the time interval during which the device waits for a response from the authentication server. Use the **no** form of this command to restore the default configuration.

**Syntax**

**dot1x timeout server-timeout** *seconds*

**no dot1x timeout server-timeout**

**Parameters**

**server-timeout** *seconds*—Specifies the time interval in seconds during which the device waits for a response from the authentication server. (Range: 1–65535 seconds)

**Default Configuration**

The default timeout period is 30 seconds.

**Command Mode**

Interface Configuration (Ethernet) mode

**User Guidelines**

The actual timeout period can be determined by comparing the value specified by the **dot1x timeout server-timeout** command to the result of multiplying the number of retries specified by the [radius-server retransmit](#) command by the timeout period specified by the [radius-server retransmit](#) command, and selecting the lower of the two values.

**Example**

The following example sets the time interval between retransmission of packets to the authentication server to 3600 seconds.

---

```
switchxxxxxx(config)# interface gi1/0/115
switchxxxxxx(config-if)# dot1x timeout server-timeout 3600
```

---

**18.12 show dot1x**

Use the **show dot1x** Privileged EXEC mode command to display the 802.1x interfaces or specified interface status.

**Syntax**

**show dot1x** [*interface interface-id* | *detailed*]

**Parameters**

- **interface-id**—Specify an Ethernet port ID.
- **detailed**—Displays information for non-present ports in addition to present ports.

**Default Configuration**

Display for all ports. If detailed is not used, only present ports are displayed.

**Command Mode**

Privileged EXEC mode

**Examples**

**Example 1** - The following example displays the status of a single 802.1x-enabled Ethernet ports.

```
switchxxxxxx# show dot1x interface gi1/0/13
802.1x is enabled.
```

Port	Admin Mode	Oper Mode	Reauth Control	Reauth Period	Username
gi1/0/1 3	Auto	Unauthorized	Ena	3600	Clark

```

Time-range:                work-hours (Inactive now)60 Seconds
Quiet period:              30 Seconds
Tx period:                 2
Max req:                   30 Seconds
Supplicant timeout:

Server timeout:           30 Seconds
Session Time (HH:MM:SS): 08:19:17
MAC Address:              00:08:78:32:98:78
Authentication Method:    Remote
Termination Cause:       Supplicant logoff

Authenticator State Machine

State:                     HELD

Backend State Machine

State:                     IDLE
Authentication success:    9
Authentication fails:      1

```

**Example 2** - The following example displays the status of all 802.1x-enabled Ethernet ports.

```
switchxxxxxx# show dot1x
802.1x is enabled
```

Port	Admin Mode	Oper Mode	Reauth Control	Reauth Period	Username
gi1/0/1	Auto	Authorized	Ena	3600	Bob
1	Auto	Authorized	Ena	3600	John
gi1/0/1	Auto	Unauthorized	Ena	3600	Clark
2	Force-auth	Authorized	Dis	3600	n/a
gi1/0/1	Force-auth	Unauthorized	Dis	3600	n/a
3					
gi1/0/1					
4					
gi1/0/1					
5					

\* Port is down or not present.

The following table describes the significant fields shown in the display.

Field	Description
<b>Port</b>	The port number.
<b>Admin mode</b>	The port administration (configured) mode. Possible values: Force-auth, Force-unauth, Auto.
<b>Oper mode</b>	The port operational (actual) mode. Possible values: Authorized, Unauthorized or Down.
<b>Reauth Control</b>	Reauthentication control.
<b>Reauth Period</b>	Reauthentication period.
<b>Username</b>	Username representing the supplicant identity. This field shows the username if the port control is auto. If the port is Authorized, it displays the username of the current user. If the port is Unauthorized, it displays the last user authenticated successfully.
<b>Quiet period</b>	Number of seconds that the device remains in the quiet state following a failed authentication exchange (for example, the client provided an invalid password).
<b>Tx period</b>	Number of seconds that the device waits for a response to an Extensible Authentication Protocol (EAP) request/identity frame from the client before resending the request.
<b>Max req</b>	Maximum number of times that the device sends an EAP request frame (assuming that no response is received) to the client before restarting the authentication process.
<b>Supplicant timeout</b>	Number of seconds that the device waits for a response to an EAP-request frame from the client before resending the request.
<b>Server timeout</b>	Number of seconds that the device waits for a response from the authentication server before resending the request.
<b>Session Time</b>	Amount of time (HH:MM:SS) that the user is logged in.
<b>MAC address</b>	Supplicant MAC address.
<b>Authentication Method</b>	Authentication method used to establish the session.
<b>Termination Cause</b>	Reason for the session termination.
<b>State</b>	Current value of the Authenticator PAE state machine and of the Backend state machine.
<b>Authentication success</b>	Number of times the state machine received a Success message from the Authentication Server.
<b>Authentication fails</b>	Number of times the state machine received a Failure message from the Authentication Server.

## 18.13 show dot1x users

Use the **show dot1x users** Privileged EXEC mode command to display active 802.1x authenticated users for the device.

### Syntax

```
show dot1x users [username username]
```

### Parameters

**username**—Specifies the supplicant username (Length: 1–160 characters)

### Default Configuration

Display all users.

**Command Mode**

Privileged EXEC mode

**Example**

The following example displays 802.1x user with supplicant username Bob.

---

```
switchxxxxxx# show dot1x users username Bob
Port      Username      Session      Auth      MAC      VLAN
          Username      Time         Method    Address
-----
gi1/0/11 Bob          1d 09:07:38 Remote     0008.3b79.8787 3
```

---

**18.14 show dot1x statistics**Use the **show dot1x statistics** Privileged EXEC mode command to display 802.1x statistics for the specified port.**Syntax****show dot1x statistics interface** *interface-id***Parameters****interface-id**—Specifies an Ethernet port ID.**Default Configuration**

N/A

**Command Mode**

Privileged EXEC mode

**Example**

The following example displays 802.1x statistics for gi1/0/11.

---

```
switchxxxxxx# show dot1x statistics interface gi1/0/11
EapolFramesRx: 11
EapolFramesTx: 12
EapolStartFramesRx: 1
EapolLogoffFramesRx: 1
EapolRespIdFramesRx: 3
EapolRespFramesRx: 6
EapolReqIdFramesTx: 3
EapolReqFramesTx: 6
InvalidEapolFramesRx: 0
EapLengthErrorFramesRx: 0
LastEapolFrameVersion: 1
LastEapolFrameSource: 00:08:78:32:98:78
```

---



The following table describes the significant fields shown in the display:

Field	Description
<b>EapolFramesRx</b>	Number of valid EAPOL frames of any type that have been received by this Authenticator.
<b>EapolFramesTx</b>	Number of EAPOL frames of any type that have been transmitted by this Authenticator.
<b>EapolStartFramesRx</b>	Number of EAPOL Start frames that have been received by this Authenticator.
<b>EapolLogoffFramesRx</b>	Number of EAPOL Logoff frames that have been received by this Authenticator.
<b>EapolRespIdFramesRx</b>	Number of EAP Resp/Id frames that have been received by this Authenticator.
<b>EapolRespFramesRx</b>	Number of valid EAP Response frames (other than Resp/Id frames) that have been received by this Authenticator.
<b>EapolReqIdFramesTx</b>	Number of EAP Req/Id frames that have been transmitted by this Authenticator.
<b>EapolReqFramesTx</b>	Number of EAP Request frames (other than Req/Id frames) that have been transmitted by this Authenticator.
<b>InvalidEapolFramesRx</b>	Number of EAPOL frames that have been received by this Authenticator for which the frame type is not recognized.
<b>EapLengthErrorFramesRx</b>	Number of EAPOL frames that have been received by this Authenticator in which the Packet Body Length field is invalid.
<b>LastEapolFrameVersion</b>	Protocol version number carried in the most recently received EAPOL frame.
<b>LastEapolFrameSource</b>	Source MAC address carried in the most recently received EAPOL frame.

## 18.15 clear dot1x statistics

Use the **clear dot1x statistics** Privileged EXEC mode command to clear 802.1x statistics.

### Syntax

**clear dot1x statistics** [*interface-id*]

### Parameters

*interface-id*—Specify an Ethernet port ID.

### Default Configuration

Statistics on all ports are cleared.

### Command Mode

Privileged EXEC

### User Guidelines

The command clears the statistics displayed in the [show dot1x statistics](#) command

### Example

```
switchxxxxxx# clear dot1x statistics
```

---

## 18.16 dot1x auth-not-req

Use the **dot1x auth-not-req** Interface Configuration (VLAN) mode command to enable unauthorized devices access to the VLAN. Use the **no** form of this command to disable access to the VLAN.

### Syntax

**dot1x auth-not-req**

**no dot1x auth-not-req**

### Parameters

N/A

### Default Configuration

Access is enabled.

### Command Mode

Interface Configuration (VLAN) mode

### User Guidelines

An access port cannot be a member in an unauthenticated VLAN.

The native VLAN of a trunk port cannot be an unauthenticated VLAN.

For a general port, the PVID can be an unauthenticated VLAN (although only tagged packets are accepted in the unauthorized state).

### Example

The following example enables unauthorized devices access to VLAN 5.

---

```
switchxxxxxx(config)# interface vlan 5  
switchxxxxxx(config-if)# dot1x auth-not-req
```

---

## 18.17 dot1x host-mode

Use the **dot1x host-mode** Interface Configuration mode command to allow a single host (client) or multiple hosts on an IEEE 802.1x-authorized port. Use the **no** form of this command to return to the default setting.

### Syntax

**dot1x host-mode** {*multi-host* | *single-host* | *multi-sessions*}

### Parameters

- **multi-host**—Enable multiple-hosts mode.
- **single-host**—Enable single-hosts mode.
- **multi-sessions**—Enable multiple-sessions mode.

### Default Configuration

Default mode is multi-host.

### Command Mode

Interface Configuration (Ethernet) mode

**User Guidelines**

In multiple hosts mode only one of the attached hosts must be successfully authorized for all hosts to be granted network access. If the port becomes unauthorized, all attached clients are denied access to the network.

In multiple sessions mode each host must be successfully authorized in order to grant network access. Please note that packets are NOT encrypted, and after success full authentication filtering is based on the source MAC address only.

Port security on a port cannot be enabled in single-host mode and in multiple-sessions mode.

It is recommended to enable reauthentication when working in multiple-sessions mode in order to detect user logout for users that have not logged off.

In single host mode there is only one attached host and only this authenticated host can access the network.

**Example**


---

```
switchxxxxxx(config)# interface gi1/0/11
switchxxxxxx(config-if)# dot1x host-mode multi-host
switchxxxxxx(config-if)# dot1x host-mode single-host
switchxxxxxx(config-if)# dot1x host-mode multi-sessions
```

---

**18.18 dot1x violation-mode**

Use the **dot1x violation-mode** Interface Configuration (Ethernet) mode command to configure the action to be taken, when a station whose MAC address is not the supplicant MAC address, attempts to access the interface. Use the **no** form of this command to return to default.

**Syntax**

**dot1x violation-mode** {*restrict* | *protect* | *shutdown*}

**no dot1x violation-mode**

**Parameters**

- **restrict**—Generates a trap when a station whose MAC address is not the supplicant MAC address, attempts to access the interface. The minimum time between the traps is 1 second. Those frames are forwarded but their source address are not learned.
- **protect**—Discard frames with source addresses not the supplicant address.
- **shutdown**—Discard frames with source addresses not the supplicant address and shutdown the port

**Default Configuration**

Protect

**Command Mode**

Interface Configuration (Ethernet) mode

**User Guidelines**

The command is relevant only for single-host mode.

BPDU message whose MAC address is not the supplicant MAC address wouldn't be discarded in the protect mode.

BPDU message whose MAC address is not the supplicant MAC address would cause a shutdown in the shutdown mode.

### Example

---

```
switchxxxxxx(config)# interface gi1/0/11  
switchxxxxxx(config-if)# dot1x violation-mode protect
```

---

## 18.19 dot1x guest-vlan

Use the **dot1x guest-vlan** Interface Configuration (VLAN) mode command to define a guest VLAN. Use the **no** form of this command to restore the default configuration.

### Syntax

**dot1x guest-vlan**

**no dot1x guest-vlan**

### Parameters

N/A

### Default Configuration

No VLAN is defined as a guest VLAN.

### Command Mode

Interface Configuration (VLAN) mode

### User Guidelines

Use the **dot1x guest-vlan enable** Interface Configuration mode command to enable unauthorized users on an interface to access the guest VLAN.

If the guest VLAN is defined and enabled, the port automatically joins the guest VLAN when the port is unauthorized and leaves it when the port becomes authorized. To be able to join or leave the guest VLAN, the port should not be a static member of the guest VLAN.

### Example

The following example defines VLAN 2 as a guest VLAN.

---

```
switchxxxxxx(config)# interface vlan 2  
switchxxxxxx(config-if)# dot1x guest-vlan
```

---

## 18.20 dot1x guest-vlan timeout

Use the **dot1x guest-vlan timeout** Global Configuration mode command to set the time delay between enabling 802.1x (or port up) and adding a port to the guest VLAN. Use the **no** form of this command to restore the default configuration.

### Syntax

**dot1x guest-vlan timeout** *timeout*

**no dot1x guest-vlan timeout**

### Parameters

**timeout**—Specifies the time delay in seconds between enabling 802.1x (or port up) and adding the port to the guest VLAN. (Range: 30–180)

### Default Configuration

The guest VLAN is applied immediately.

### Command Mode

Global Configuration mode

### User Guidelines

This command is relevant if the guest VLAN is enabled on the port. Configuring the timeout adds delay from enabling 802.1X (or port up) to the time the device adds the port to the guest VLAN.

### Example

The following example sets the delay between enabling 802.1x and adding a port to a guest VLAN to 60 seconds.

---

```
switchxxxxxx(config)# dot1x guest-vlan timeout 60
```

---

## 18.21 dot1x guest-vlan enable

Use the **dot1x guest-vlan enable** Interface Configuration (Ethernet) mode command to enable unauthorized users on the interface access to the guest VLAN. Use the **no** form of this command to disable access.

### Syntax

**dot1x guest-vlan enable**

**no dot1x guest-vlan enable**

### Parameters

N/A

### Default Configuration

The default configuration is disabled.

### Command Mode

Interface Configuration (Ethernet) mode

### User Guidelines

A device can have only one global guest VLAN. The guest VLAN is defined using the [dot1x guest-vlan](#) Interface Configuration mode command.

### Example

The following example enables unauthorized users on `gi1/0/11` to access the guest VLAN.

---

```
switchxxxxxx(config)# interface gi1/0/115  
switchxxxxxx(config-if)# dot1x guest-vlan enable
```

---

---

## 18.22 dot1x mac-authentication

Use the **dot1x mac-authentication** Interface Configuration (Ethernet) mode command to enable authentication based on the station's MAC address. Use the **no** form of this command to disable this feature.

### Syntax

**dot1x mac-authentication** {*mac-only* | *mac-and-802.1x*}

**no dot1x mac-authentication**

### Parameters

- **mac-only**—Enables authentication based on the station's MAC address only. 802.1X frames are ignored.
- **mac-and-802.1x**—Enables 802.1X authentication and MAC address authentication on the interface.

### Default Configuration

Authentication based on the station's MAC address is disabled.

### Command Mode

Interface Configuration (Ethernet) mode

### User Guidelines

The guest VLAN must be enabled when MAC authentication is enabled.

Static MAC addresses cannot be authorized. Do not change an authenticated MAC address to a static address.

It is not recommended to delete authenticated MAC addresses.

Reauthentication must be enabled when working in this mode.

### Example

The following example enables authentication based on the station's MAC address on `gi1/0/11`.

---

```
switchxxxxxx(config)# interface gi1/0/11
switchxxxxxx(config-if)# dot1x mac-authentication mac-only
```

---

---

## 18.23 dot1x radius-attributes vlan

Use the **dot1x radius-attributes vlan** Interface Configuration mode command, to enable user-based VLAN assignment. Use the **no** form of this command to disable user-based VLAN assignment.

### Syntax

**dot1x radius-attributes vlan**

**no dot1x radius-attributes vlan**

### Parameters

N/A

### Default Configuration

Disabled

**Command Mode**

Interface Configuration (Ethernet) mode

**User Guidelines**

The configuration of this command is allowed only when the port is Forced Authorized.

RADIUS attributes are supported only in the multiple sessions mode (multiple hosts with authentication)

When RADIUS attributes are enabled and the RADIUS Accept message does not contain the supplicant's VLAN as an attribute, then the supplicant is rejected.

Packets to the supplicant are sent untagged.

After successful authentication, the port remains a member in the unauthenticated VLANs and in the Guest VLAN. Other static VLAN configuration is not applied on the port. If the supplicant VLAN does not exist on the switch, the supplicant is rejected.

**Example**

---

```
switchxxxxxx(config)# interface gi1/0/11  
switchxxxxxx(config-if)# dot1x radius-attributes vlan
```

---

**18.24 show dot1x advanced**

Use the **show dot1x advanced** Privileged EXEC mode command to display 802.1x advanced features for the device or specified interface.

**Syntax**

**show dot1x advanced** [*interface-id* | *detailed*]

**Parameters**

- **interface-id**—Specify an Ethernet port ID.
- **detailed**—Displays information for non-present ports in addition to present ports.

**Default Configuration**

Display for all ports. If detailed is not used, only present ports are displayed.

**Command Mode**

Privileged EXEC mode

**Example**

The following example displays 802.1x advanced features for the device.

---

```
switchxxxxxx# show dot1x advanced
Guest VLAN: 3978
Guest VLAN Timeout:
Unauthenticated VLANs: 91, 92
Interface Multiple Guest MAC VLAN Legacy- Policy
                Hosts VLAN Authentication Assignment supp Mode Assignment
-----
gil/0/11 Disabled Enabled MAC-and-802.1X Enabled Enable Disabled
gil/0/12 Enabled Disabled Disabled Enabled Enable Disabled
```

---

```
switchxxxxxx# show dot1x advanced gil/0/11
Interface Multiple Guest MAC VLAN Legacy- Policy
                Hosts VLAN Authentication Assignment sup Mode Assignment
-----
gil/0/11 Disabled Enabled MAC-and-802.1X Enabled Enable
Legacy-Supp mode is disabled
Policy assignment resource err handling: Accept
Single host parameters
Violation action: Discard
Trap: Enabledx
Status: Single-host locked
Violations since last trap: 9
```



---

## 19.1 interface

Use the **interface** Global Configuration mode command to enter Interface configuration mode in order to configure an interface.

### Syntax

**interface** *interface-id*

### Parameters

**interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port, Port-channel, VLAN, range, IP interface or tunnel.

### Default Configuration

N/A

### Command Mode

Interface Configuration (Ethernet, Port-channel, VLAN, range, IP interface or tunnel) mode

### Examples

**Example 1** - For Gigabit Ethernet ports:

---

```
switchxxxxxx(config)# interface gi1/0/11
switchxxxxxx(config-if)#
```

---

**Example 2** - For Fast Ethernet ports:

---

```
switchxxxxxx(config)# interface fa1
switchxxxxxx(config-if)#
```

---

**Example 3** - For port channels (LAGs):

---

```
switchxxxxxx(config)# interface po1
switchxxxxxx(config-if)#
```

---

---

## 19.2 interface range

Use the **interface range** command to execute a command on multiple ports at the same time.

### Syntax

**interface range** *interface-id-list*

**Parameters**

**interface-id-list**—Specify list of interface IDs. The interface ID can be one of the following types: Ethernet port, VLAN, or Port-channel

**Default Configuration**

N/A

**Command Mode**

Interface Configuration (Ethernet, Port-channel, or VLAN) mode

**User Guidelines**

Commands under the interface range context are executed independently on each interface in the range: If the command returns an error on one of the interfaces, it does not stop the execution of the command on other interfaces.

**Example**

---

```
switchxxxxxx(config)# interface range gi1/0/11-20
switchxxxxxx(config-if-range)#
```

---

## 19.3 shutdown

Use the **shutdown** Interface Configuration (Ethernet, Port-channel) mode command to disable an interface. Use the **no** form of this command to restart a disabled interface.

**Syntax**

**shutdown**

**no shutdown**

**Parameters**

N/A

**Default Configuration**

The interface is enabled.

**Command Mode**

Interface Configuration (Ethernet, Port-channel) mode

**Example**

**Example 1** - The following example disables `gi1/0/15` operations.

---

```
switchxxxxxx(config)# interface gi1/0/15
switchxxxxxx(config-if)# shutdown
switchxxxxxx(config-if)#
```

---

**Example 2** - The following example restarts the disabled Ethernet port.

---

```
switchxxxxxx(config)# interface gi1/0/15
switchxxxxxx(config-if)# no shutdown
switchxxxxxx(config-if)
```

---

---

## 19.4 description

Use the **description** Interface Configuration (Ethernet, Port-channel) mode command to add a description to an interface. Use the **no** form of this command to remove the description.

### Syntax

**description** *string*

**no description**

### Parameters

**string**—Specifies a comment or a description of the port to assist the user. (Length: 1–64 characters).

### Default Configuration

The interface does not have a description.

### Command Mode

Interface Configuration (Ethernet, Port-channel) mode

### Example

The following example adds the description 'SW#3' to `gi1/0/15`.

---

```
switchxxxxxx(config)# interface gi1/0/15
switchxxxxxx(config-if)# description SW#3
```

---

## 19.5 speed

Use the **speed** Interface Configuration (Ethernet, Port-channel) mode command to configure the speed of a given Ethernet interface when not using auto-negotiation. Use the **no** form of this command to restore the default configuration.

### Syntax

**speed** {*10* | *100* | *1000* | *10000*}

**no speed**

### Parameters

- **10**—Forces 10 Mbps operation.
- **100**—Forces 100 Mbps operation.
- **1000**—Forces 1000 Mbps operation.
- **10000**—Forces 10000 Mbps operation.

### Default Configuration

The port operates at its maximum speed capability.

### Command Mode

Interface Configuration (Ethernet, Port-channel) mode

### User Guidelines

The **no speed** command in a port-channel context returns each port in the port-channel to its maximum capability.

**Example**

The following example configures the speed of `gi1/0/15` to 100 Mbps operation.

```
switchxxxxxx(config)# interface gi1/0/15
switchxxxxxx(config-if)# speed 100
```

---

**19.6 duplex**

Use the **duplex** Interface Configuration (Ethernet, Port-channel) mode command to configure the full/half duplex operation of a given Ethernet interface when not using auto-negotiation. Use the **no** form of this command to restore the default configuration.

**Syntax**

**duplex** {*half* | *full*}

**no duplex**

**Parameters**

- **half**—Forces half-duplex operation.
- **full**—Forces full-duplex operation.

**Default Configuration**

The interface operates in full duplex mode.

**Command Mode**

Interface Configuration (Port-channel) mode

**Example**

The following example configures `gi1/0/15` to operate in full duplex mode.

```
switchxxxxxx(config)# interface gi1/0/15
switchxxxxxx(config-if)# duplex full
```

---

**19.7 negotiation**

Use the **negotiation** Interface Configuration (Ethernet, Port-channel) mode command to enable auto-negotiation operation for the speed and duplex parameters and master-slave mode of a given interface. Use the **no** form of this command to disable auto-negotiation.

**Syntax**

**negotiation** [*capability* [*capability2*... *capability5*]] [*preferred* {*master* | *slave*}]

**no negotiation**

**Parameters**

- **Capability**—Specifies the capabilities to advertise. (Possible values: 10h, 10f, 100h,100f, 1000f).
  - **10h** - Advertise 10 half-duplex
  - **10f** - Advertise 10 full-duplex
  - **100h** - Advertise 100 half-duplex
  - **100f** - Advertise 100 full-duplex
  - **1000f** - Advertise 1000 full-duplex

- Preferred - Specifies the master-slave preference:
  - Master - Advertise master preference
  - Slave - Advertise slave preference

### Default Configuration

If capability is unspecified, defaults to list of all the capabilities of the port and preferred master mode.

### Command Mode

Interface Configuration (Ethernet, Port-channel) mode

### Example

The following example enables auto-negotiation on `gi1/0/15`.

---

```
switchxxxxxx(config)# interface gi1/0/15
switchxxxxxx(config-if)# negotiation
```

---

## 19.8 flowcontrol

Use the **flowcontrol** Interface Configuration (Ethernet, Port-channel) mode command to configure the Flow Control on a given interface. Use the **no** form of this command to disable Flow Control.

### Syntax

**flowcontrol** {*auto* | *on* | *off*}

**no flowcontrol**

### Parameters

- **auto**—Specifies auto-negotiation of Flow Control.
- **on**—Enables Flow Control.
- **off**—Disables Flow Control.

### Default Configuration

Flow control is disabled.

### Command Mode

Interface Configuration (Ethernet, Port-channel) mode

### User Guidelines

Use the **negotiation** command to enable **flow control auto**.

### Example

The following example enables Flow Control on port `gi1/0/11`

---

```
switchxxxxxx(config)# interface gi1/0/11
switchxxxxxx(config-if)# flowcontrol on
```

---

---

## 19.9 mdix

Use the **mdix** Interface Configuration (Ethernet) mode command to enable cable crossover on a given interface. Use the **no** form of this command to disable cable crossover.

### Syntax

**mdix** {*on* | *auto*}

**no mdix**

### Parameters

- **on**—Enables manual MDIX.
- **auto**—Enables automatic MDI/MDIX.

### Default Configuration

The default setting is On.

### Command Mode

Interface Configuration (Ethernet) mode

### Example

The following example enables automatic crossover on port `gi1/0/15`.

---

```
switchxxxxxx(config)# interface gi1/0/15  
switchxxxxxx(config-if)# mdix auto
```

---

## 19.10 back-pressure

Use the **back-pressure** Interface Configuration (Ethernet) mode command to enable back pressure on a specific interface. Use the **no** form of this command to disable back pressure.

### Syntax

**back-pressure**

**no back-pressure**

### Default Configuration

Back pressure is disabled.

### Command Mode

Interface Configuration (Ethernet) mode

### Example

The following example enables back pressure on port `gi1/0/15`.

---

```
switchxxxxxx(config)# interface gi1/0/15  
switchxxxxxx(config-if)# back-pressure
```

---

## 19.11 port jumbo-frame

Use the **port jumbo-frame** Global Configuration mode command to enable jumbo frames on the device. Use the **no** form of this command to disable jumbo frames.

### Syntax

**port jumbo-frame**

**no port jumbo-frame**

### Default Configuration

Jumbo frames are disabled on the device.

### Command Mode

Global Configuration mode

### User Guidelines

This command takes effect only after resetting the device.

### Example

The following example enables jumbo frames on the device.

---

```
switchxxxxxx(config)# port jumbo-frame
```

---

## 19.12 clear counters

Use the **clear counters** EXEC mode command to clear counters on all or on a specific interface.

### Syntax

**clear counters** [*interface-id*]

### Parameters

**interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

### Default Configuration

All counters are cleared.

### Command Mode

EXEC mode

### Example

The following example clears the statistics counters for `gi1/0/15`.

---

```
switchxxxxxx# clear counters gi1/0/15.
```

## 19.13 set interface active

Use the **set interface active** EXEC mode command to reactivate an interface that was shut down.

### Syntax

**set interface active** *{interface-id}*

### Parameters

**interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

### Command Mode

EXEC mode

### User Guidelines

This command is used to activate interfaces that were configured to be active, but were shut down by the system.

### Example

The following example reactivates *gi1/0/11*.

---

```
switchxxxxxx# set interface active gi1/0/11
```

---

## 19.14 errdisable recovery cause

Use the **errdisable recovery cause** Global Configuration mode command to enable automatic re-activation of an interface after Err-Disable shutdown. Use the **no** form of this command to disable automatic re-activation.

### Syntax

**errdisable recovery cause** *{all | port-security | dot1x-src-address | acl-deny | stp-bpdu-guard | stp-loopback-guard}*

**no errdisable recovery cause** *{all | port-security | dot1x-src-address | acl-deny | stp-bpdu-guard | stp-loopback-guard}*

### Parameters

**all** - Enables the error recovery mechanism for all the reasons

**port-security** - Enables the error recovery mechanism for the port security Err-Disable state.

**dot1x-src-address** - Enables the error recovery mechanism for the 802.1x Err-Disable state.

**acl-deny** - Enables the error recovery mechanism for the ACL Deny Err-Disable state.

**stp-bpdu-guard** - Enables the error recovery mechanism for the STP BPDU Guard Err-Disable state.

**stp-loopback-guard** - Enables the error recovery mechanism for the STP Loopback Guard Err-Disable state.

### Default Configuration

Automatic re-activation is disabled.

### Command Mode

Global Configuration mode



**Example**

The following example enables automatic re-activation of an interface after Loopback Detection Err-Disable shutdown.

---

```
switchxxxxxx(config)# errdisable recovery cause loopback-detection
```

---

## 19.15 errdisable recovery interval

Use the **errdisable recovery interval** Global Configuration mode command timeout interval to set the error recovery timeout interval. Use the **no** form of this command to return to the default configuration.

**Syntax**

**errdisable recovery interval** *seconds*

**no errdisable recovery interval**

**Parameters**

**seconds**—Specifies the error recovery timeout interval in seconds. (Range: 30–86400)

**Default Configuration**

The default error recovery timeout interval is 300 seconds.

**Command Mode**

Global Configuration mode

**Example**

The following example sets the error recovery timeout interval to 10 minutes.

---

```
switchxxxxxx(config)# errdisable recovery interval 600
```

---

## 19.16 show interfaces configuration

Use the **show interfaces configuration** EXEC mode command to display the configuration for all configured interfaces or for a specific interface.

**Syntax**

**show interfaces configuration** [*interface-id* | **detailed**]

**Parameters**

- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.
- **detailed**—Displays information for non-present ports in addition to present ports.

**Default Configuration**

Display all interfaces. If detailed is not used, only present ports are displayed.

**Command Mode**

EXEC mode

**Example**

The following example displays the configuration of all configured interfaces:

```
switchxxxxxx# show interfaces configuration
```

Port	Type	Duplex	Speed	Neg	Flow control	Admin State	Back Pressure	Mdix Mode
-----	-----	-----	-----	-----	-----	-----	-----	-----
gi1/0/11	1G-Copper	Full	10000	Disabled	Off	Up	Disabled	Off
gi1/0/12	1G-Copper	Full	1000	Disabled	Off	Up	Disabled	Off

  

PO	Type	Speed	Neg	Flow Control	Admin State
-----	-----	-----	-----	-----	-----
Po1			Disabled	Off	Up

## 19.17 show interfaces status

Use the **show interfaces status** EXEC mode command to display the status of all interfaces or of a specific interface.

**Syntax**

**show interfaces status** [*interface-id* | **detailed**]

**Parameters**

- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.
- **detailed**—Displays information for non-present ports in addition to present ports.

**Command Mode**

EXEC mode

**Default Configuration**

Display for all interfaces. If detailed is not used, only present ports are displayed.

**Example**

The following example displays the status of all configured interfaces.

```
switchxxxxxx# show interfaces status
```

Port	Type	Duplex	Speed	Neg	Flow ctrl	Link State	Back Pressure	Mdix Mode
-----	-----	-----	-----	-----	-----	-----	-----	-----
gi1/0/11	1G-Copper	Full	1000	Disabled	Off	Up	Disabled	Off
gi1/0/12	1G-Copper	--	--	--	--	Down	--	--

  

PO	Type	Duplex	Speed	Neg	Flow control	Link State
-----	-----	-----	-----	-----	-----	-----
Po1	1G	Full	10000	Disabled	Off	Up

## 19.18 show interfaces advertise

Use the **show interfaces advertise** EXEC mode command to display auto-negotiation advertisement information for all configured interfaces or for a specific interface.

### Syntax

**show interfaces advertise** [*interface-id* | **detailed**]

### Parameters

- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.
- **detailed**—Displays information for non-present ports in addition to present ports.

### Default Configuration

Display for all interfaces. If detailed is not used, only present ports are displayed.

### Command Mode

EXEC mode

### Examples

The following examples display auto-negotiation information.

```
switchxxxxxx# show interfaces advertise

Port      Type      Neg      Operational Link Advertisement
----      -
gil/0/11  1G-Copper Enable    1000f, 100f, 10f, 10h
gil/0/12  1G-Copper Enable    1000f

switchxxxxxx# show interfaces advertise gil/0/11
Port:gil/0/11
Type: 1G-Copper
Link state: Up
Auto Negotiation: enabled

                               10h   10f   100h   100f   1000f
                               ---   ---   ----   ----   -----
Admin Local link Advertisement  yes   yes   yes   yes   yes
Oper Local link Advertisement    yes   yes   yes   yes   yes
Remote Local link Advertisement  no    no    yes   yes   yes
Priority Resolution               -    -    -    -    yes

switchxxxxxx# show interfaces advertise gil/0/11
Port: gil/0/11
Type: 1G-Copper
Link state: Up
Auto negotiation: disabled.
```

## 19.19 show interfaces description

Use the **show interfaces description** EXEC mode command to display the description for all configured interfaces or for a specific interface.

### Syntax

**show interfaces description** [*interface-id* | **detailed**]

### Parameters

- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.
- **detailed**—Displays information for non-present ports in addition to present ports.

### Default Configuration

Display description for all interfaces. If detailed is not used, only present ports are displayed.

### Command Mode

EXEC mode

### Example

The following example displays the description of all configured interfaces.

---

```
switchxxxxxx# show interfaces description

Port          Descriptions
-----
gi1/0/11      -----
gi1/0/12      Port that should be used for management only
gi1/0/13
gi1/0/14

PO            Description
-----
Po1          Output
```

## 19.20 show interfaces counters

Use the **show interfaces counters** EXEC mode command to display traffic seen by all the physical interfaces or by a specific interface.

### Syntax

**show interfaces counters** [*interface-id* | **detailed**]

### Parameters

- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.
- **detailed**—Displays information for non-present ports in addition to present ports.

### Default Configuration

Display counters for all interfaces. If detailed is not used, only present ports are displayed.

### Command Mode

EXEC mode

**Example**

The following example displays traffic seen by all the physical interfaces.

```

switchxxxxx# show interfaces counters gil/0/11
Port          InUcastPkts  InMcastPkts  InBcastPkts  InOctets
-----
gil/0/11      0            0            0            0
Port          OutUcastPkts OutMcastPkts OutBcastPkts OutOctets
-----
gil/0/11      0            1            35           7051
Alignment Errors: 0
FCS Errors: 0
Single Collision Frames: 0
Multiple Collision Frames: 0
SQE Test Errors: 0
Deferred Transmissions: 0
Late Collisions: 0
Excessive Collisions: 0
Carrier Sense Errors: 0
Oversize Packets: 0
Internal MAC Rx Errors: 0
Symbol Errors: 0
Received Pause Frames: 0
Transmitted Pause Frames: 0

```

The following table describes the fields shown in the display.

Field	Description
<b>InOctets</b>	Number of received octets.
<b>InUcastPkts</b>	Number of received unicast packets.
<b>InMcastPkts</b>	Number of received multicast packets.
<b>InBcastPkts</b>	Number of received broadcast packets.
<b>OutOctets</b>	Number of transmitted octets.
<b>OutUcastPkts</b>	Number of transmitted unicast packets.
<b>OutMcastPkts</b>	Number of transmitted multicast packets.
<b>OutBcastPkts</b>	Number of transmitted broadcast packets.
<b>FCS Errors</b>	Number of frames received that are an integral number of octets in length but do not pass the FCS check.
<b>Single Collision Frames</b>	Number of frames that are involved in a single collision, and are subsequently transmitted successfully.
<b>Multiple Collision Frames</b>	Number of frames that are involved in more than one collision and are subsequently transmitted successfully.
<b>SQE Test Errors</b>	Number of times that the SQE TEST ERROR is received. The SQE TEST ERROR is set in accordance with the rules for verification of the SQE detection mechanism in the PLS Carrier Sense Function as described in IEEE Std. 802.3, 2000 Edition, section 7.2.4.6.
<b>Deferred Transmissions</b>	Number of frames for which the first transmission attempt is delayed because the medium is busy.

Field	Description
<b>Late Collisions</b>	Number of times that a collision is detected later than one slotTime into the transmission of a packet.
<b>Excessive Collisions</b>	Number of frames for which transmission fails due to excessive collisions.
<b>Oversize Packets</b>	Number of frames received that exceed the maximum permitted frame size.
<b>Internal MAC Rx Errors</b>	Number of frames for which reception fails due to an internal MAC sublayer receive error.
<b>Received Pause Frames</b>	Number of MAC Control frames received with an opcode indicating the PAUSE operation.
<b>Transmitted Pause Frames</b>	Number of MAC Control frames transmitted on this interface with an opcode indicating the PAUSE operation.

## 19.21 show ports jumbo-frame

Use the **show ports jumbo-frame** EXEC mode command to display the whether jumbo frames are enabled on the device.

### Syntax

**show ports jumbo-frame**

### Parameters

N/A

### Default Configuration

N/A

### Command Mode

EXEC mode

### Example

The following example displays whether jumbo frames are enabled on the device.

```
switchxxxxxx# show ports jumbo-frame
Jumbo frames are disabled
Jumbo frames will be enabled after reset
```

## 19.22 show errdisable recovery

Use the **show errdisable recovery** EXEC mode command to display the Err-Disable configuration of the device.

### Syntax

**show errdisable recovery**

### Parameters

N/A

### Default Configuration

N/A

**Command Mode**

EXEC mode

**Example**

The following example displays the Err-Disable configuration.

---

```
switchxxxxxx# show errdisable recovery
Timer interval: 300 Seconds
      Reason          Automatic Recovery
-----
port-security        Disable
dot1x-src-address    Disable
acl-deny              Enable
stp-bpdu-guard       Disable
stp-loopback-guard   Disable
```

---

**19.23 show errdisable interfaces**

Use the **show errdisable interfaces** EXEC mode command to display the Err-Disable state of all interfaces or of a specific interface.

**Syntax**

**show errdisable interfaces** [*interface-id*]

**Parameters**

- **interface**—Interface number
- **port-channel-number**—Port channel index.

**Default Configuration**

Display for all interfaces.

**Command Mode**

EXEC mode

**Example**

The following example displays the Err-Disable state of all interfaces.

---

```
switchxxxxxx# show errdisable interfaces
Interface          Reason
-----
gi1/1/50           stp-bpdu-guard
```

---

---

## 19.24 storm-control broadcast enable

Use the **storm-control broadcast enable** Interface Configuration mode command to enable storm control on a port. Use the **no** form of this command to disable storm control.

### Syntax

**storm-control broadcast enable**

**no storm-control broadcast enable**

### Parameters

This command has no arguments or keywords.

### Default Configuration

Disabled

### Command Mode

Interface Configuration mode (Ethernet)

### User Guidelines

Use the [storm-control include-multicast](#) Interface Configuration command to count Multicast packets and optionally unknown Unicast packets in the storm control calculation.

### Example

---

```
switchxxxxxx(config)# interface gi1/0/11
switchxxxxxx(config-if)# storm-control broadcast enable
```

---

## 19.25 storm-control broadcast level kbps

Use the **storm-control broadcast level** Interface Configuration mode command to configure the maximum rate of broadcast on a port. Use the **no** form of this command to return to default.

### Syntax

**storm-control broadcast level kbps** *kbps*

**no storm-control broadcast level**

### Parameters

**kbps**—Maximum number of kilo bits per second of Broadcast traffic on a port. (Range 3.5M–10G)

### Default Configuration

1000

### Command Mode

Interface Configuration mode (Ethernet)

### User Guidelines

Use the **storm-control broadcast enable** Interface Configuration command to enable storm control.

The calculated rate includes the 20 bytes of Ethernet framing overhead (preamble+SFD+IPG).



**Example**


---

```
switchxxxxxx(config)# interface gi1/0/11
switchxxxxxx(config-if)# storm-control broadcast level kbps 12345
```

---

**19.26 storm-control include-multicast**

Use the **storm-control include-multicast** Interface Configuration mode command to count Multicast packets in a Broadcast storm control. Use the **no** form of this command to disable counting of Multicast packets in the Broadcast storm control.

**Syntax**

**storm-control include-multicast** [*unknown-unicast*]

**no storm-control include-multicast**

**Parameters**

**unknown-unicast**—Specifies also the count of unknown unicast packets.

**Default Configuration**

Disabled

**Command Mode**

Interface Configuration mode (Ethernet)

**Example**


---

```
switchxxxxxx(config)# interface gi1/0/11
switchxxxxxx(config-if)# storm-control include-multicast
```

---

**19.27 show storm-control**

Use the **show storm-control** EXEC mode command to display the configuration of storm control for all ports or for a specific one.

**Syntax**

**show storm-control** [*interface-id* | **detailed**]

**Parameters**

- **interface-id**—Specifies an Ethernet port.
- **detailed**—Displays information for non-present ports in addition to present ports.

**Default Configuration**

Display for all interfaces. If detailed is not used, only present ports are displayed.

**Command Mode**

EXEC mode

**User Guidelines**

Use the **storm-control broadcast enable** Interface Configuration command to enable storm control.

The calculated rate includes the 20 bytes of Ethernet framing overhead (preamble+SFD+IPG).

If the suppression level in percentage is translated to a rate that is lower than the minimum rate, the minimum rate is set.

### Example

---

```
switchxxxxxx# show storm-control
Port   State   Rate [Kbits/Sec]  Included
-----
gil/0/11   Enabled  12345             Broadcast, Multicast,
Unknown unicast
gil/0/12   Disabled 100000           Broadcast
```

---

## 20.1 test cable-diagnostics tdr

Use the **test cable-diagnostics tdr** Privileged EXEC mode command to use Time Domain Reflectometry (TDR) technology to diagnose the quality and characteristics of a copper cable attached to a port.

### Syntax

**test cable-diagnostics tdr interface** *interface-id*

### Parameters

**interface-id**—Specifies an Ethernet port ID.

### Command Mode

Privileged EXEC mode

### User Guidelines

The port to be tested should be shut down during the test, unless it is a combination port with fiber port active.

The maximum length of cable for the TDR test is 120 meters.

### Example

The following examples test the copper cables attached to ports 7 and 8.

---

```
switchxxxxxx# test cable-diagnostics tdr interface gi1/0/17
Cable is open at 64 meters
switchxxxxxx# test cable-diagnostics tdr interface gi1/0/18
Can't perform the test on fiber ports
```

---

## 20.2 show cable-diagnostics tdr

Use the **show cable-diagnostics tdr** EXEC mode command to display information on the last Time Domain Reflectometry (TDR) test performed on all copper ports or on a specific copper port.

### Syntax

**show cable-diagnostics tdr** [*interface interface-id* | *detailed*]

### Parameters

- **interface-id**—Specify an Ethernet port ID.
- **detailed**—Displays information for non-present ports in addition to present ports.

### Default Configuration

All ports are displayed. If *detailed* is not used, only present ports are displayed.

**Command Mode**

EXEC mode

**User Guidelines**

The maximum length of cable for the TDR test is 120 meters.

**Example**

The following example displays information on the last TDR test performed on all copper ports.

```
switchxxxxxx# show cable-diagnostics tdr

Port      Result      Length      Date
----      -
          [meters]
          -----

gi1/0/11  OK
gi1/0/12  Short      50          13:32:00 23 July 2010
gi1/0/13  Test has not been performed
gi1/0/14  Open       64          13:32:00 23 July 2010
gi1/0/15  Fiber      -           -
```

---

**20.3 show cable-diagnostics cable-length**

Use the **show cable-diagnostics cable-length** EXEC mode command to display the estimated copper cable length attached to all ports or to a specific port.

**Syntax**

**show cable-diagnostics cable-length** [*interface interface-id* | *detailed*]

**Parameters**

- **interface-id**—Specify an Ethernet port ID.
- **detailed**—Displays information for non-present ports in addition to present ports.

**Default Configuration**

All ports are displayed. If *detailed* is not used, only present ports are displayed.

**Command Mode**

EXEC mode

**User Guidelines**

The port must be active and working at 100 M or 1000 M.

**Example**

The following example displays the estimated copper cable length attached to all ports.

```
switchxxxxxx# show cable-diagnostics cable-length

Port          Length [meters]
-----
gi1/0/11      < 50
gi1/0/12      Copper not active
gi1/0/13      110-140
gi1/0/14      Fiber
```

---

## 20.4 show fiber-ports optical-transceiver

Use the **show fiber-ports optical-transceiver** EXEC mode command to display the optical transceiver diagnostics.

**Syntax**

**show fiber-ports optical-transceiver** [*interface interface-id* | *detailed*]

**Parameters**

- **interface-id**—Specify an Ethernet port ID.
- **detailed**—Displays information for non-present ports in addition to present ports.

**Default Configuration**

All ports are displayed. If detailed is not used, only present ports are displayed.

**Command Mode**

EXEC mode

**Example**

The following examples display the optical transceiver diagnostics results.

---

```
switchxxxxxx# show fiber-ports optical-transceiver

Port      Temp  Voltage Current  Output Input  LOS
          Power Power
-----
gi1/0/11  W     OK     OK     OK     OK     OK
gi1/0/12  OK    OK     OK     E     OK     OK

Temp      - Internally measured transceiver temperature
Voltage   - Internally measured supply voltage
Current   - Measured TX bias current
Output Power - Measured TX output power in milliWatts
Input Power - Measured RX received power in milliWatts
LOS       - Loss of signal
N/A - Not Available, N/S - Not Supported,
W - Warning, E - Error
```

---

```
switchxxxxxx# show fiber-ports optical-transceiver
```

```

Port      Temp  Voltage Current Output  Input  LOS
          [C]   [Volt] [mA]   Power  Power
                   [mWatt] [mWatt]
-----

```

```

gil/0/11   Copper
gil/0/16   Copper
gil/0/17   28    3.32   7.26   3.53   3.68   No
gil/0/18   29    3.33   6.50   3.53   3.71   No

```

```

Temp      - Internally measured transceiver temperature
Voltage    - Internally measured supply voltage
Current    - Measured TX bias current
Output Power - Measured TX output power in milliWatts
Input Power - Measured RX received power in milliWatts
LOS        - Loss of signal
N/A - Not Available, N/S - Not Supported, W - Warning, E - Error

```

---

---

## 21.1 channel-group

Use the **channel-group** Interface Configuration (Ethernet) mode command to associate a port with a port-channel. Use the **no** form of this command to remove a port from a port-channel.

### Syntax

**channel-group** *port-channel mode {on | auto}*

**no channel-group**

### Parameters

- **port-channel**—Specifies the port channel number for the current port to join.
- **mode**—Specifies the mode of joining the port channel. The possible values are:
  - **on**—Forces the port to join a channel without an LACP operation.
  - **auto**—Forces the port to join a channel as a result of an LACP operation.

### Default Configuration

The port is not assigned to a port-channel.

### Command Mode

Interface Configuration (Ethernet) mode

Default mode is **on**.

### Example

The following example forces port `gi1/0/11` to join port-channel 1 without an LACP operation.

---

```
switchxxxxxx(config)# interface gi1/0/11
switchxxxxxx(config-if)# channel-group 1 mode on
```

---

## 21.2 port-channel load-balance

Use the **port-channel load-balance** Global Configuration mode command to configure the load balancing policy of the port channeling. Use the **no** form of this command to reset to default.

### Syntax

**port-channel load-balance** *{src-dst-mac | src-dst-ip | src-dst-mac-ip | src-dst-mac-ip-port}*

**no port-channel load-balance**

### Parameters

- **src-dst-mac**—Port channel load balancing is based on the source and destination MAC address.

- **src-dst-mac-ip**—Port channel load balancing is based on the source and destination of MAC and IP addresses.
- **src-dst-mac-ip-port**—Port channel load balancing is based on the source and destination of MAC and IP addresses and on source and destination TCP/UDP port numbers.
- **src-dst-ip**—Port channel load balancing is based on the source and destination IP address.

### Default Configuration

src-dst-mac is the default option.

### Command Mode

Global Configuration mode

### User Guidelines

In **src-dst-mac-ip-port** load balancing policy, fragmented packets might be reordered.

### Example

---

```
switchxxxxxx(config)# port-channel load-balance src-dst-mac
switchxxxxxx(config)# port-channel load-balance src-dst-mac-ip
```

---

## 21.3 show interfaces port-channel

Use the **show interfaces port-channel** EXEC mode command to display port-channel information for all port channels or for a specific port channel.

### Syntax

**show interfaces port-channel** [*interface-id*]

### Parameters

**interface-id**—Specify an interface ID. The interface ID must be a Port Channel.

### Command Mode

EXEC mode

### Examples

**Example 1** - The following example displays information on all port-channels.

---

```
switchxxxxxx# show interfaces port-channel
Load balancing: src-dst-mac.
Gathering information...
Channel  Ports
-----  -----
Po1      Active: gi1/0/11,Inactive: gi1/0/12-3
Po2      Active: gi1/0/15 Inactive: gi1/0/14
```

---

**Example 2** - The following example displays information on port-channels containing port 1

```
switchxxxxxx# show interfaces switchport gi1/0/11
Gathering information...
Name: gi1/0/11
Switchport: enable
```



```
Administrative Mode: access
Operational Mode: down
Access Mode VLAN: 1
Access Multicast TV VLAN: none
Trunking Native Mode VLAN: 1
Trunking VLANs Enabled: 1
                        2-4094 (Inactive)
General PVID: 1
General VLANs Enabled: none
General Egress Tagged VLANs Enabled: none
General Forbidden VLANs: none
General Ingress Filtering: enabled
General Acceptable Frame Type: all
General GVRP status: disabled
Customer Mode VLAN: none
Private-vlan promiscuous-association primary VLAN: none
Private-vlan promiscuous-association Secondary VLANs Enabled: none
Private-vlan host-association primary VLAN: none
Private-vlan host-association Secondary VLAN Enabled: none
DVA: disable
```

---



---

## 22.1 bridge multicast filtering

Use the **bridge multicast filtering** Global Configuration mode command to enable the filtering of Multicast addresses. Use the **no** form of this command to disable Multicast address filtering.

### Syntax

**bridge multicast filtering**

**no bridge multicast filtering**

### Default Configuration

Multicast address filtering is disabled. All Multicast addresses are flooded to all ports.

### Command Mode

Global Configuration mode

### User Guidelines

When this feature is enabled, unregistered Multicast traffic (as opposed to registered) will still be flooded.

All registered Multicast addresses will be forwarded to the Multicast groups. There are two ways to manage Multicast groups, one is the IGMP Snooping feature, and the other is the [bridge multicast forward-all](#) command.

### Example

The following example enables bridge Multicast filtering.

---

```
switchxxxxxx(config)# bridge multicast filtering
```

---

## 22.2 bridge multicast mode

Use the **bridge multicast mode** Interface Configuration (VLAN) mode command to configure the Multicast bridging mode. Use the **no** form of this command to return to the default configuration.

### Syntax

**bridge multicast mode** {*mac-group* | *ip-group* | *ip-src-group*}

**no bridge multicast mode**

### Parameters

- **mac-group**—Specifies that Multicast bridging is based on the packet's VLAN and MAC address.
- **ipv4-group**—Specifies that Multicast bridging is based on the packet's VLAN and MAC address for non-IPv4 packets, and on the packet's VLAN and IPv4 destination address for IPv4 packets.

- **ipv4-src-group**—Specifies that Multicast bridging is based on the packet's VLAN and MAC address for non-IPv4 packets, and on the packet's VLAN, IPv4 destination address and IPv4 source address for IPv4 packets.

### Default Configuration

The default mode is mac-group.

### Command Mode

Interface Configuration (VLAN) mode

### User Guidelines

Use the mac-group option when using a network management system that uses a MIB based on the Multicast MAC address. Otherwise, it is recommended to use the ipv4-group or ipv4-src-group mode, because there is no overlapping of IPv4 Multicast addresses in these modes.

For each Forwarding Data Base (FDB) mode, use different CLI commands to configure static entries in the FDB, as described in the following table:

FDB Mode	CLI Commands	
mac-group	bridge multicast address	bridge multicast forbidden address
ipv4-group	bridge multicast ip-address	bridge multicast forbidden ip-addresss
ipv4-src-group	bridge multicast source group	bridge multicast forbidden source group

The following table describes the actual data that is written to the Forwarding Data Base (FDB) as a function of the IGMP version that is used in the network:

FDB mode	IGMP version 2	IGMP version 3
mac-group	MAC group address	MAC group address
ipv4-group	IP group address	IP group address
ipv4-src-group	(*)	IP source and group addresses

(\*) Note that (\*,G) cannot be written to the FDB if the mode is **ipv4-src-group**. In that case, no new FDB entry is created, but the port is added to the static (S,G) entries (if they exist) that belong to the requested group. It is recommended to set the FDB mode to ipv4-group or mac-group for IGMP version 2.

If an application on the device requests (\*,G), the operating FDB mode is changed to ipv4-group.

### Example

The following example configures the Multicast bridging mode as an ipv4-group on VLAN 2.

```
switchxxxxxx(config)# interface vlan 2
switchxxxxxx(config-if)# bridge multicast mode ipv4-group
```

## 22.3 bridge multicast address

Use the **bridge multicast address** Interface Configuration (VLAN) mode command to register a MAC-layer Multicast address in the bridge table and statically add or remove ports to or from the group. Use the **no** form of this command to unregister the MAC address.

### Syntax

**bridge multicast address** {*mac-multicast-address* | *ipv4-multicast-address*} [**add** | **remove**] {*ethernet interface-list* | **port-channel** *port-channel-list*}

**no bridge multicast address** {*mac-multicast-address*}

### Parameters

- **mac-multicast-address** | **ipv4-multicast-address**—Specifies the group Multicast address.
- **add**—Adds ports to the group.
- **remove**—Removes ports from the group.
- **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces; use a hyphen to designate a range of port channels.

### Default Configuration

No Multicast addresses are defined.

If **ethernet interface-list** or **port-channel port-channel-list** is specified without specifying **add** or **remove**, the default option is **add**.

### Command Mode

Interface Configuration (VLAN) mode

### User Guidelines

To register the group in the bridge database without adding or removing ports or port channels, specify the **mac-multicast-address** parameter only.

Static Multicast addresses can be defined on static VLANs only.

You can execute the command before the VLAN is created.

### Examples

**Example 1** - The following example registers the MAC address to the bridge table:

---

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast address 01:00:5e:02:02:03
```

---

**Example 2** - The following example registers the MAC address and adds ports statically.

---

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast address 01:00:5e:02:02:03 add
gil/0/11-2
```

---

## 22.4 bridge multicast forbidden address

Use the **bridge multicast forbidden address** Interface Configuration (VLAN) mode command to forbid adding or removing a specific Multicast address to or from specific ports. Use the **no** form of this command to restore the default configuration.

### Syntax

**bridge multicast forbidden address** {*mac-multicast-address* | *ipv4-multicast-address*} {**add** | **remove**} {*ethernet interface-list* | **port-channel** *port-channel-list*}

**no bridge multicast forbidden address** {*mac-multicast-address*}

### Parameters

- **mac-multicast-address** | **ipv4-multicast-address**—Specifies the group Multicast address.
- **add**—Forbids adding ports to the group.
- **remove**—Forbids removing ports from the group.
- **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces. Use a hyphen to designate a range of port channels.

### Default Configuration

No forbidden addresses are defined.

Default option is **add**.

### Command Mode

Interface Configuration (VLAN) mode

### User Guidelines

Before defining forbidden ports, the Multicast group should be registered, using [bridge multicast address](#).

You can execute the command before the VLAN is created.

### Example

The following example forbids MAC address 0100.5e02.0203 on port `gi1/0/19` within VLAN 8.

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast address 0100.5e02.0203
switchxxxxxx(config-if)# bridge multicast forbidden address 0100.5e02.0203 add
gi1/0/19
```

## 22.5 bridge multicast ip-address

Use the **bridge multicast ip-address** Interface Configuration (VLAN) mode command to register IP-layer Multicast addresses to the bridge table, and statically add or remove ports to or from the group. Use the **no** form of this command to unregister the IP address.

### Syntax

**bridge multicast ip-address** *ip-multicast-address* [[**add** | **remove**] {*ethernet interface-list* | **port-channel** *port-channel-list*}]

**no bridge multicast ip-address** *ip-multicast-address*

**Parameters**

- **ip-multicast-address**—Specifies the group IP Multicast address.
- **add**—Adds ports to the group.
- **remove**—Removes ports from the group.
- **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces. Use a hyphen to designate a range of port channels.

**Default Configuration**

No Multicast addresses are defined.

Default option is **add**.

**Command Mode**

Interface Configuration (VLAN) mode

**User Guidelines**

To register the group in the bridge database without adding or removing ports or port channels, specify the **ip-multicast-address** parameter only.

Static Multicast addresses can be defined on static VLANs only.

You can execute the command before the VLAN is created.

**Example**

The following example registers the specified IP address to the bridge table:

---

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast ip-address 239.2.2.2
```

---

The following example registers the IP address and adds ports statically.

---

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast ip-address 239.2.2.2 add gi1/0/19
```

---

## 22.6 bridge multicast forbidden ip-address

Use the **bridge multicast forbidden ip-address** Interface Configuration (VLAN) mode command to forbid adding or removing a specific IP Multicast address to or from specific ports. Use the no form of this command to restore the default configuration.

**Syntax**

**bridge multicast forbidden ip-address** *{ip-multicast-address}* **{add | remove}** *{ethernet interface-list | port-channel port-channel-list}*

**no bridge multicast forbidden ip-address** *{ip-multicast-address}*

**Parameters**

- **ip-multicast-address**—Specifies the group IP Multicast address.
- **add**—Forbids adding ports to the group.
- **remove**—Forbids removing ports from the group.
- **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.

- **port-channel** *port-channel-list*—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces. Use a hyphen to designate a range of port channels.

### Default Configuration

No forbidden addresses are defined.

### Command Mode

Interface Configuration (VLAN) mode

### User Guidelines

Before defining forbidden ports, the Multicast group should be registered.

You can execute the command before the VLAN is created.

### Example

The following example registers IP address 239.2.2.2, and forbids the IP address on port `gi1/0/19` within VLAN 8.

---

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast ip-address 239.2.2.2
switchxxxxxx(config-if)# bridge multicast forbidden ip-address 239.2.2.2 add
gi1/0/19
```

---

## 22.7 bridge multicast source group

Use the **bridge multicast source group** Interface Configuration (VLAN) mode command to register a source IP address - Multicast IP address pair to the bridge table, and statically add or remove ports to or from the source-group. Use the no form of this command to unregister the source-group-pair.

### Syntax

**bridge multicast source** *ip-address* **group** *ip-multicast-address* **[[add | remove]** **{ethernet interface-list | port-channel port-channel-list}**

**no bridge multicast source** *ip-address* **group** *ip-multicast-address*

### Parameters

- **ip-address**—Specifies the source IP address.
- **ip-multicast-address**—Specifies the group IP Multicast address.
- **add**—Adds ports to the group for the specific source IP address.
- **remove**—Removes ports from the group for the specific source IP address.
- **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces; use a hyphen to designate a range of port channels.

### Default Configuration

No Multicast addresses are defined.

The default option is **add**.

### Command Mode

Interface Configuration (VLAN) mode



**User Guidelines**

You can execute the command before the VLAN is created.

**Example**

The following example registers a source IP address - Multicast IP address pair to the bridge table:

---

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast source 13.16.1.1 group 239.2.2.2
```

---

## 22.8 bridge multicast forbidden source group

Use the **bridge multicast forbidden source group** Interface Configuration (VLAN) mode command to forbid adding or removing a specific IP source address - Multicast address pair to or from specific ports. Use the no form of this command to return to the default configuration.

**Syntax**

**bridge multicast forbidden source** *ip-address* **group** *ip-multicast-address* {**add** | **remove**} {**ethernet** *interface-list* | **port-channel** *port-channel-list*}

**no bridge multicast forbidden source** *ip-address* **group** *ip-multicast-address*

**Parameters**

- **ip-address**—Specifies the source IP address.
- **ip-multicast-address**—Specifies the group IP Multicast address.
- **add**—Forbids adding ports to the group for the specific source IP address.
- **remove**—Forbids removing ports from the group for the specific source IP address.
- **ethernet** *interface-list*—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- **port-channel** *port-channel-list*—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces; use a hyphen to designate a range of port channels.

**Default Configuration**

No forbidden addresses are defined.

**Command Mode**

Interface Configuration (VLAN) mode

**User Guidelines**

Before defining forbidden ports, the Multicast group should be registered.

You can execute the command before the VLAN is created.

**Example**

The following example registers a source IP address - Multicast IP address pair to the bridge table, and forbids adding the pair to port *gi1/0/19* on VLAN 8:

---

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast source 13.16.1.1 group 239.2.2.2
switchxxxxxx(config-if)# bridge multicast forbidden source 13.16.1.1 group
239.2.2.2 add gi1/0/19
```

---

## 22.9 bridge multicast ipv6 mode

Use the **bridge multicast ipv6 mode** Interface Configuration (VLAN) mode command to configure the Multicast bridging mode for IPv6 Multicast packets. Use the no form of this command to return to the default configuration.

### Syntax

**bridge multicast ipv6 mode** {*mac-group* | *ip-group* | *ip-src-group*}

**no bridge multicast ipv6 mode**

### Parameters

- **mac-group**—Specifies that Multicast bridging is based on the packet's VLAN and MAC destination address.
- **ip-group**—Specifies that Multicast bridging is based on the packet's VLAN and IPv6 destination address for IPv6 packets.
- **ip-src-group**—Specifies that Multicast bridging is based on the packet's VLAN, IPv6 destination address and IPv6 source address for IPv6 packets.

### Default Configuration

The default mode is **mac-group**.

### Command Mode

Interface Configuration (VLAN) mode

### User Guidelines

Use the **mac-group** mode when using a network management system that uses a MIB based on the Multicast MAC address.

For each Forwarding Data Base (FDB) mode, use different CLI commands to configure static entries for IPv6 Multicast addresses in the FDB, as described in the following table:

FDB Mode	CLI Commands	
<b>mac-group</b>	<a href="#">bridge multicast address</a>	<a href="#">bridge multicast forbidden address</a>
<b>ipv6-group</b>	<a href="#">bridge multicast ipv6 ip-address</a>	<a href="#">bridge multicast ipv6 forbidden ip-address</a>
<b>ipv6-src-group</b>	<a href="#">bridge multicast ipv6 source group</a>	<a href="#">bridge multicast ipv6 forbidden source group</a>

The following table describes the actual data that is written to the Forwarding Data Base (FDB) as a function of the MLD version that is used in the network: (\*) Note that (\*,G) cannot be written to the FDB if the mode is

FDB mode	MLD version 1	MLD version 2
<b>mac-group</b>	MAC group address	MAC group address
<b>ipv6-group</b>	IPv6 group address	IPv6 group address
<b>ipv6-src-group</b>	(*)	IPv6 source and group addresses

**ip-src-group**. In that case, no new FDB entry is created, but the port is added to the (S,G) entries (if they exist) that belong to the requested group. If an application on the device requests (\*,G), the operating FDB mode is changed to **ip-group**.

You can execute the command before the VLAN is created.

**Example**

The following example configures the Multicast bridging mode as an **ip-group** on VLAN 2.

---

```
switchxxxxxx(config)# interface vlan 2
switchxxxxxx(config-if)# bridge multicast ipv6 mode ip-group
```

---

**22.10 bridge multicast ipv6 ip-address**

Use the **bridge multicast ipv6 ip-address** Interface Configuration (VLAN) mode command to register an IPv6 Multicast address to the bridge table, and statically add or remove ports to or from the group. Use the **no** form of this command to unregister the IPv6 address.

**Syntax**

**bridge multicast ipv6 ip-address** *ipv6-multicast-address* [**add** | **remove**] {*ethernet interface-list* | *port-channel port-channel-list*}

**no bridge multicast ipv6 ip-address** *ip-multicast-address*

**Parameters**

- **ipv6-multicast-address**—Specifies the group IPv6 multicast address.
- **add**—Adds ports to the group.
- **remove**—Removes ports from the group.
- **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces; use a hyphen to designate a range of ports.
- **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces. Use a hyphen to designate a range of port channels.

**Default Configuration**

No Multicast addresses are defined.

The default option is **add**.

**Command Mode**

Interface Configuration (VLAN) mode

**User Guidelines**

To register the group in the bridge database without adding or removing ports or port channels, specify the **ipv6-multicast-address** parameter only.

Static Multicast addresses can be defined on static VLANs only.

You can execute the command before the VLAN is created.

**Example**

**Example 1** - The following example registers the IPv6 address to the bridge table:

---

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast ipv6 ip-address FF00:0:0:0:4:4:4:1
```

---

**Example 2** - The following example registers the IPv6 address and adds ports statically.

---

```
switchxxxxxx(config)# interface vlan 8
```

---

```
switchxxxxxx(config-if)# bridge multicast ipv6 ip-address FF00:0:0:0:4:4:4:1
add gi1/0/11-2
```

---

## 22.11 bridge multicast ipv6 forbidden ip-address

Use the **bridge multicast ipv6 forbidden ip-address** Interface Configuration (VLAN) mode command to forbid adding or removing a specific IPv6 Multicast address to or from specific ports. To restore the default configuration, use the **no** form of this command.

### Syntax

**bridge multicast ipv6 forbidden ip-address** {*ipv6-multicast-address*} {**add** | **remove**} {*ethernet interface-list* | **port-channel** *port-channel-list*}

**no bridge multicast ipv6 forbidden ip-address** {*ipv6-multicast-address*}

### Parameters

- **ipv6-multicast-address**—Specifies the group IPv6 Multicast address.
- **add**—Forbids adding ports to the group.
- **remove**—Forbids removing ports from the group.
- **ethernet** *interface-list*—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- **port-channel** *port-channel-list*—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces. Use a hyphen to designate a range of port channels.

### Default Configuration

No forbidden addresses are defined.

The default option is **add**.

### Command Mode

Interface Configuration (VLAN) mode

### User Guidelines

Before defining forbidden ports, the Multicast group should be registered.

You can execute the command before the VLAN is created.

### Example

The following example registers an IPv6 Multicast address, and forbids the IPv6 address on port *gi1/0/19* within VLAN 8.

---

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast ipv6 ip-address FF00:0:0:0:4:4:4:1
switchxxxxxx(config-if)# bridge multicast ipv6 forbidden ip-address
FF00:0:0:0:4:4:4:1 add gi1/0/19
```

## 22.12 bridge multicast ipv6 source group

Use the **bridge multicast ipv6 source group** Interface Configuration (VLAN) mode command to register a source IPv6 address - Multicast IPv6 address pair to the bridge table, and statically add or remove ports to or from the source-group. Use the **no** form of this command to unregister the source-group-pair.

### Syntax

**bridge multicast ipv6 source** *ipv6-source-address* **group** *ipv6-multicast-address* *[[add | remove] {ethernet interface-list | port-channel port-channel-list}]*

**no bridge multicast ipv6 source** *ipv6-address* **group** *ipv6-multicast-address*

### Parameters

- **ipv6-source-address**—Specifies the source IPv6 address.
- **ipv6-multicast-address**—Specifies the group IPv6 Multicast address.
- **add**—Adds ports to the group for the specific source IPv6 address.
- **remove**—Removes ports from the group for the specific source IPv6 address.
- **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces. Use a hyphen to designate a range of port channels.

### Default Configuration

No Multicast addresses are defined.

The default option is **add**.

### Command Mode

Interface Configuration (VLAN) mode

### Example

The following example registers a source IPv6 address - Multicast IPv6 address pair to the bridge table:

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast source 2001:0:0:0:4:4:4 group
FF00:0:0:0:4:4:4:1
```

## 22.13 bridge multicast ipv6 forbidden source group

Use the **bridge multicast ipv6 forbidden source group** Interface Configuration (VLAN) mode command to forbid adding or removing a specific IPv6 source address - Multicast address pair to or from specific ports. Use the **no** form of this command to return to the default configuration.

### Syntax

**bridge multicast ipv6 forbidden source** *ipv6-source-address* **group** *ipv6-multicast-address* *{add | remove}* *{ethernet interface-list | port-channel port-channel-list}*

**no bridge multicast ipv6 forbidden source** *ipv6-address* **group** *ipv6-multicast-address*

### Parameters

- **ipv6-source-address**—Specifies the source IPv6 address.
- **ipv6-multicast-address**—Specifies the group IPv6 multicast address.
- **add**—Forbids adding ports to the group for the specific source IPv6 address.

- **remove**—Forbids removing ports from the group for the specific source IPv6 address.
- **ethernet *interface-list***—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- **port-channel *port-channel-list***—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces; use a hyphen to designate a range of port channels.

### Default Configuration

No forbidden addresses are defined.

### Command Mode

Interface Configuration (VLAN) mode

### User Guidelines

Before defining forbidden ports, the Multicast group should be registered.

You can execute the command before the VLAN is created.

### Example

The following example registers a source IPv6 address - Multicast IPv6 address pair to the bridge table, and forbids adding the pair to `gi1/0/19` on VLAN 8:

---

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast source 2001:0:0:0:4:4:4 group
  FF00:0:0:0:4:4:4:1
switchxxxxxx(config-if)# bridge multicast forbidden source 2001:0:0:0:4:4:4:1
  group FF00:0:0:0:4:4:4:1 add gi1/0/19
```

---

## 22.14 bridge multicast unregistered

Use the **bridge multicast unregistered** Interface Configuration (Ethernet, Port-Channel) mode command to configure forwarding unregistered Multicast addresses. Use the **no** form of this command to restore the default configuration.

### Syntax

**bridge multicast unregistered** {*forwarding* | *filtering*}

**no bridge multicast unregistered**

### Parameters

- **forwarding**—Forwards unregistered Multicast packets.
- **filtering**—Filters unregistered Multicast packets.

### Default Configuration

Unregistered Multicast addresses are forwarded.

### Command Mode

Interface Configuration (Ethernet, Port-Channel) mode

### User Guidelines

Do not enable unregistered Multicast filtering on ports that are connected to routers, because the 224.0.0.x address range should not be filtered. Note that routers do not necessarily send IGMP reports for the 224.0.0.x range.

You can execute the command before the VLAN is created.

### Example

The following example specifies that unregistered Multicast packets are filtered on `gi1/0/11`:

---

```
switchxxxxxx(config)# interface gi1/0/11
switchxxxxxx(config-if)# bridge multicast unregistered filtering
```

---

## 22.15 bridge multicast forward-all

Use the **bridge multicast forward-all** Interface Configuration (VLAN) mode command to enable forwarding all multicast packets for a range of ports or port channels. Use the **no** form of this command to restore the default configuration.

### Syntax

**bridge multicast forward-all** *{add | remove}* *{ethernet interface-list | port-channel port-channel-list}*

**no bridge multicast forward-all**

### Parameters

- **add**—Forces forwarding of all Multicast packets.
- **remove**—Does not force forwarding of all Multicast packets.
- **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces. Use a hyphen to designate a range of port channels.

### Default Configuration

Forwarding of all Multicast packets is disabled.

### Command Mode

Interface Configuration (VLAN) mode

### Example

The following example enables all Multicast packets on port `gi1/0/18` to be forwarded.

---

```
switchxxxxxx(config)# interface vlan 2
switchxxxxxx(config-if)# bridge multicast forward-all add gi1/0/18
```

---

## 22.16 bridge multicast forbidden forward-all

Use the **bridge multicast forbidden forward-all** Interface Configuration (VLAN) mode command to forbid a port to dynamically join Multicast groups. Use the **no** form of this command to restore the default configuration.

### Syntax

**bridge multicast forbidden forward-all** *{add | remove}* *{ethernet interface-list | port-channel port-channel-list}*

**no bridge multicast forbidden forward-all**

**Parameters**

- **add**—Forbids forwarding of all Multicast packets.
- **remove**—Does not forbid forwarding of all Multicast packets.
- **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces; use a hyphen to designate a range of port channels.

**Default Configuration**

Ports are not forbidden to dynamically join Multicast groups.

The default option is **add**.

**Command Mode**

Interface Configuration (VLAN) mode

**User Guidelines**

Use this command to forbid a port to dynamically join (by IGMP, for example) a Multicast group.

The port can still be a Multicast router port.

**Example**

The following example forbids forwarding of all Multicast packets to gi1/0/11 within VLAN 2.

---

```
switchxxxxxx(config)# interface vlan 2
switchxxxxxx(config-if)# bridge multicast forbidden forward-all add ethernet
gi1/0/11
```

---

## 22.17 bridge unicast unknown

Use the **bridge unicast unknown** Interface Configuration mode command to enable egress filtering of Unicast packets where the destination MAC address is unknown to the device. Use the **no** form of this command to restore the default configuration.

**Syntax**

**bridge unicast unknown** {*filtering* | *forwarding*}

**no bridge unicast unknown**

**Parameters**

- **filtering**— Filter unregistered Unicast packets.
- **forwarding**— Forward unregistered Unicast packets.

**Default Configuration**

Forwarding.

**Command Mode**

Interface Configuration mode



**Example**

The following example drops Unicast packets on VLAN 2 when the destination is unknown.

```
switchxxxxxx(config)# interface vlan 2
switchxxxxxx(config-if)# bridge unicast unknown filtering
```

**22.18 mac address-table static**

Use the **mac address-table static** Global Configuration mode command to add a MAC-layer station source address to the MAC address table. Use the **no** form of this command to delete the MAC address.

**Syntax**

**mac address-table static** *mac-address* **vlan** *vlan-id* **interface** *interface-id* [**permanent** | **delete-on-reset** | **delete-on-timeout** | **secure**]

**no mac address-table static** [*mac-address*] **vlan** *vlan-id*

**Parameters**

- **mac-address**— MAC address (Range: Valid MAC address)
- **vlan-id**— Specify the VLAN
- **interface-id**— Specify an interface ID. The interface ID can be one of the following types: Ethernet port or port-channel (Range: valid ethernet port, valid port-channel)
- **permanent**— The permanent static MAC address. The keyword is applied by the default.
- **delete-on-reset**— The delete-on-reset static MAC address.
- **delete-on-timeout**— The delete-on-timeout static MAC address.
- **secure**—The secure MAC address. May be used only in a secure mode.

**Default Configuration**

No static addresses are defined. The default mode for an added address is permanent.

**Command Mode**

Global Configuration mode

**User Guidelines**

Use the command to add a static MAC address with given time-to-live in any mode or to add a secure MAC address in a secure mode.

Each MAC address in the MAC address table is assigned two attributes: **type** and **time-to-live**.

The following value of time-of-live is supported:

- **permanent**— a MAC address is saved until it is removed manually.
- **delete-on-reset**— a MAC address is saved until the next reboot.
- **delete-on-timeout**— a MAC address that may be removed by the aging timer.

The following types are supported:

- **static**— MAC address manually added by the command with the following keywords specifying its time-of-live:
  - **permanent**
  - **delete-on-reset**
  - **delete-on-timeout**

A static MAC address may be added in any port mode.

- **secure**— A MAC address added manually or learned in a secure mode. Use the **mac address-table static** command with the **secure** keyword to add a secure MAC address. The MAC address cannot be relearned.  
A secure MAC address may be added only in a secure port mode.
- **dynamic**— a MAC address learned by the switch in non secure mode. A value of its **time-to-live** attribute is **delete-on-timeout**.

### Examples

**Example 1** - The following example adds two permanent static MAC address:

---

```
switchxxxxxx(conf)#mac address-table static 00:3f:bd:45:5a:b1 vlan 1 gi1/0/11
switchxxxxxx(conf)mac address-table static 00:3f:bd:45:5a:b2 vlan 1 gi1/0/11
permanent
```

---

**Example 2** - The following example adds a deleted-on-reset static MAC address:

---

```
switchxxxxxx(conf)mac address-table static 00:3f:bd:45:5a:b2 vlan 1 gi1/0/11
delete-on-reset
```

---

**Example 3** - The following example adds a deleted-on-timeout static MAC address:

---

```
switchxxxxxx(conf)mac address-table static 00:3f:bd:45:5a:b2 vlan 1 gi1/0/11
delete-on-timeout
```

---

**Example 4** - The following example adds a secure MAC address:

---

```
switchxxxxxx(conf)mac address-table static 00:3f:bd:45:5a:b2 vlan 1 gi1/0/11
secure
```

---

## 22.19 clear mac address-table

Use the **clear mac address-table** Privileged EXEC command to remove learned or secure entries from the forwarding database (FDB).

### Syntax

**clear mac address-table dynamic** [*interface interface-id*]

**clear mac address-table secure interface** *interface-id*

### Parameters

- **dynamic interface** *interface-id*—Delete all dynamic (learned) addresses on the specified interface. The interface ID can be one of the following types: Ethernet port or port-channel. If interface ID is not supplied, all dynamic addresses are deleted.
- **secure interface** *interface-id*—Delete all the secure addresses learned on the specific interface. A secure address on a MAC address learned on ports on which port security is defined.

### Default Configuration

For dynamic addresses, if *interface-id* is not supplied, all dynamic entries are deleted.

### Command Mode

Privileged EXEC mode

**Examples:**

**Example 1** - Delete all dynamic entries from the FDB.

---

```
switchxxxxxx# clear mac address-table dynamic
```

---

**Example 2** - Delete all secure entries from the FDB learned on secure port gi1.

---

```
switchxxxxxx# clear mac address-table secure interface gi1
```

---

## 22.20 mac address-table aging-time

Use the **mac address-table aging-time** Global configuration command to set the aging time of the address table. Use the **no** form of this command to restore the default.

**Syntax**

**mac address-table aging-time** *seconds*

**no mac address-table aging-time**

**Parameters**

**seconds**—Time is number of seconds. (Range:16-630)

**Default Configuration**

300

**Command Mode**

Global Configuration mode

**Example**

---

```
switchxxxxxx(config)# mac address-table aging-time 600
```

---

## 22.21 port security

Use the **port security** Interface Configuration (Ethernet, Port-channel) mode command to enable port security learning mode on an interface. Use the **no** form of this command to disable port security learning mode on an interface.

**Syntax**

**port security** [**forward** | **discard** | **discard-shutdown**] [**trap** *seconds*]

**no port security**

**Parameters**

- **forward**—Forwards packets with unlearned source addresses, but does not learn the address.
- **discard**—Discards packets with unlearned source addresses.
- **discard-shutdown**—Discards packets with unlearned source addresses and shuts down the port.
- **trap** *seconds*—Sends SNMP traps and specifies the minimum time interval in seconds between consecutive traps. (Range: 1–1000000)

**Default Configuration**

The feature is disabled by default.

The default mode is **discard**.

The default number of seconds is zero, but if **traps** is entered, a number of seconds must also be entered.

**Command Mode**

Interface Configuration (Ethernet, port-channel) mode

**User Guidelines**

The command may be used only when the interface is in the regular (non-secure with unlimited MAC learning) mode.

See the [bridge unicast unknown](#) command for information about MAC address attributes (type and time-to-live) definitions.

When the **port security** command enables the **lock** mode on a port all dynamic addresses learned on the port are changed to **permanent secure** addresses.

When the **port security** command enables a mode on a port differing from the **lock** mode all dynamic addresses learned on the port are deleted.

When the **no port security** command cancels a secure mode on a port all secure addresses defined on the port are changed to **dynamic** addresses.

Additionally to set a mode, use the **port security** command to set an action that the switch should perform on a frame which source MAC address cannot be learned.

**Example**

The following example forwards all packets to port gi1/0/11 without learning addresses of packets from unknown sources and sends traps every 100 seconds, if a packet with an unknown source address is received.

---

```
switchxxxxxx(config)#interface gi1/0/17
switchxxxxxx(config-if)#port security mode lock
switchxxxxxx(config-if)#port security forward trap 100
switchxxxxxx(config-if)#exit
```

---

**22.22 port security mode**

Use the **port security mode** Interface Configuration (Ethernet, port-channel) mode command to configure the port security learning mode. Use the **no** form of this command to restore the default configuration.

**Syntax**

**port security mode** {max-addresses | lock}

**no port security mode**

**Parameters**

- **max-addresses**— Non secure mode with limited learning dynamic MAC addresses. The static MAC addresses may be added on the port manually by the [bridge unicast unknown](#) command.
- **lock**— Secure mode without MAC learning. The static and secure MAC addresses may be added on the port manually by the [bridge unicast unknown](#) command.

**Default Configuration**

The default port security mode is **lock**.

**Command Mode**

Interface Configuration (Ethernet, port-channel) mode

**User Guidelines**

The default port mode is called regular. In this mode, the port allows unlimited learning of dynamic addresses. The static MAC addresses may be added on the port manually by the [bridge unicast unknown](#) command.

The command may be used only when the interface in the regular (non-secure with unlimited MAC learning) mode.

Use the **port security mode** command to change the default mode before the [port security mode](#) command.

**Example**

The following example sets the port security mode to Lock for gi1/0/17.

---

```
switchxxxxxx(config) interface gi1/0/17
switchxxxxxx(config-if) port security mode lock
switchxxxxxx(config-if) port security
switchxxxxxx(config-if) exit
```

---

## 22.23 port security max

Use the **port security max** Interface Configuration (Ethernet, Port-channel) mode command to configure the maximum number of addresses that can be learned on the port while the port is in port, max-addresses or secure mode. Use the **no** form of this command to restore the default configuration.

**Syntax**

**port security max** *max-addr*

**no port security max**

**Parameters**

**max-addr**—Specifies the maximum number of addresses that can be learned on the port. (Range: 0–256)

**Default Configuration**

This default maximum number of addresses is 1.

**Command Mode**

Interface Configuration (Ethernet, Port-channel) mode

**User Guidelines**

The command may be used only when the interface in the regular (non-secure with unlimited MAC learning) mode.

Use this command to change the default value before the [port security](#) command.

**Example**

The following example sets the port to limited learning mode:

---

```
switchxxxxxx(config) #interface gi7
switchxxxxxx(config-if) port security mode max
switchxxxxxx(config-if) port security max 20
switchxxxxxx(config-if) port security
```

---

```
switchxxxxxx(config-if) exit
```

---

## 22.24 port security routed secure-address

Use the **port security routed secure-address** Interface Configuration (Ethernet, Port-channel) mode command to add a MAC-layer secure address to a routed port. (port that has an IP address defined on it). Use the no form of this command to delete a MAC address from a routed port.

### Syntax

**port security routed secure-address** *mac-address*

**no port security routed secure-address** [*mac-address*]

### Parameters

**mac-address**—Specifies the MAC address.

### Default Configuration

No addresses are defined.

### Command Mode

Interface Configuration (Ethernet, port-channel) mode. It cannot be configured for a range of interfaces (range context).

### User Guidelines

This command enables adding secure MAC addresses to a routed port in port security mode. The command is available when the port is a routed port and in port security mode. The address is deleted if the port exits the security mode or is not a routed port.

### Example

The following example adds the MAC-layer address 00:66:66:66:66:66 to *gi1/0/11*.

---

```
switchxxxxxx(config)# interface gi1/0/11
switchxxxxxx(config-if)# port security routed secure-address 00:66:66:66:66:66
```

---

## 22.25 show mac address-table

Use the **show mac address-table** EXEC command to view entries in the MAC address table.

### Syntax

**show mac address-table** [*dynamic* | *static* | *secure*] [*vlan vlan*] [*interface interface-id*] [*address mac-address*]

### Parameters

- **dynamic**—Displays only dynamic MAC address table entries.
- **static**—Displays only static MAC address table entries.
- **secure**—Displays only secure MAC address table entries.
- **vlan**—Displays entries for a specific VLAN.
- **interface-id**—SDisplays entries for a specific interface ID. The interface ID can be one of the following types: Ethernet port or port-channel.
- **mac-address**—Displays entries for a specific MAC address.

**Default Configuration**

If no parameters are entered, the entire table is displayed.

**Command Mode**

EXEC mode

**User Guidelines**

Internal usage VLANs (VLANs that are automatically allocated on routed ports) are presented in the VLAN column by a port number and not by a VLAN ID.

**Example**

**Example 1** - Displays entire address table.

---

```
switchxxxxxx# show mac address-table
Aging time is 300 sec
VLAN          MAC Address          Port          Type
-----
1             00:00:26:08:13:23    0             self
1             00:3f:bd:45:5a:b1    gi1/0/11      static
1             00:a1:b0:69:63:f3    gi1/0/14      dynamic
2             00:a1:b0:69:63:f3    gi1/0/15      dynamic
```

---

**Example 2** - Displays address table entries containing the specified MAC address.

```
switchxxxxxx# show mac address-table 00:3f:bd:45:5a:b1
Aging time is 300 sec
VLAN          MAC Address          Port          Type
-----
1             00:3f:bd:45:5a:b1    static        gi1/0/19
```

---

**22.26 show mac address-table count**

Use the **show mac address-table count** EXEC mode command to display the number of addresses present in the Forwarding Database.

**Syntax**

**show mac address-table count** [*vlan vlan* | *interface interface-id*]

**Parameters**

- **vlan**—Specifies VLAN.
- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or port-channel.

**Command Mode**

EXEC mode

**Example**


---

```
switchxxxxxx# show mac address-table count
Capacity: 8192
```

---

```

Free: 8083
Used: 109
Secure   : 0
Dynamic  : 25
Static   : 1
Internal : 0

```

---

## 22.27 show bridge multicast mode

Use the **show bridge multicast mode** EXEC mode command to display the Multicast bridging mode for all VLANs or for a specific VLAN.

### Syntax

**show bridge multicast mode** [*vlan vlan-id*]

### Parameters

**vlan** *vlan-id*—Specifies the VLAN ID.

### Command Mode

EXEC mode

### Example

The following example displays the Multicast bridging mode for all VLANs.

```

switchxxxxxx# show bridge multicast mode

```

VLAN	IPv4 Multicast Mode		IPv6 Multicast Mode	
	Admin	Oper	Admin	Oper
1	MAC-GROUP	MAC-GROUP	MAC-GROUP	-MAC-GROUP
11	IPv4-GROUP	IPv4-GROUP	IPv6-GROUP	IPv6-GROUP
12	IPv4-SRC-GROUP	IPv4-SRC-GROUP	IPv6-SRC-GROUP	IPv6-SRC-GROUP

---

## 22.28 show bridge multicast address-table

Use the **show bridge multicast address-table** EXEC mode command to display Multicast MAC addresses or IP Multicast address table information.

### Syntax

**show bridge multicast address-table** [*vlan vlan-id*] [**address** {*mac-multicast-address* | *ipv4-multicast-address* | *ipv6-multicast-address*}] [**format** {*ip* | *mac*}] [**source** {*ipv4-source-address* | *ipv6-source-address*}]

### Parameters

- **vlan-id**/*vlan-id*—Display entries for specified VLAN ID.
- **address** —Display entries for specified Multicast address. The possible values are:
  - **mac-multicast-address**—Specifies the MAC Multicast address.
  - **ipv4-multicast-address**—Specifies the IPv4 Multicast address.
  - **ipv6-multicast-address**—Specifies the IPv6 Multicast address.



- **format**—(this applies if picked mac-multicast-address). then i can display it either in mac or ip format) Display entries for specified Multicast address format. The possible values are:
  - **ip**—Specifies that the Multicast address is an IP address.
  - **mac**—Specifies that the Multicast address is a MAC address.
- **source {ipv4-source-address | ipv6-source-address}**—Specifies the source address. The possible values are:
  - **ipv4-address**—Specifies the source IPv4 address.
  - **ipv6-address**—Specifies the source IPv6 address.

### Default Configuration

If the **format** is not specified, it defaults to **mac** (only if mac-multicast-address was entered).

If VLAN ID is not entered, entries for all VLANs are displayed.

If MAC or IP address is not supplied, entries for all addresses are displayed.

### Command Mode

EXEC mode

### User Guidelines

A MAC address can be displayed in IP format only if it is within the range 0100.5e00.0000 through 0100.5e7f.ffff.

Multicast router ports (defined statically or discovered dynamically) are members in all MAC groups.

Ports that were defined via the **bridge multicast forbidden forward-all** command are displayed in all forbidden MAC entries.

Changing the Multicast mode can move static Multicast addresses that are written in the device FDB to a shadow configuration because of FDB hash collisions.

### Example

The following example displays bridge Multicast address information.

```
switchxxxxxx# show bridge multicast address-table
Multicast address table for VLANs in MAC-GROUP bridging mode:
Vlan    MAC Address          Type          Ports
----  -
8       01:00:5e:02:02:03   Static        1-2

Forbidden ports for Multicast addresses:
Vlan    MAC Address          Ports
----  -
8       01:00:5e:02:02:03   gi1/0/19

Multicast address table for VLANs in IPv4-GROUP bridging mode:
Vlan    MAC Address          Type          Ports
----  -
1       224.0.0.251         Dynamic       gi1/0/12

Forbidden ports for Multicast addresses:
Vlan    MAC Address          Ports
----  -
1       232.5.6.5
1       233.22.2.6
```

```

Multicast address table for VLANs in IPv4-SRC-GROUP bridging mode:
Vlan  Group Address  Source address  Type        Ports
----  -
1     224.2.2.251     11.2.2.3       Dynamic     gi1/0/11
Forbidden ports for Multicast addresses:
Vlan  Group Address  Source Address  Ports
----  -
8     239.2.2.2       *               gi1/0/19
8     239.2.2.2       1.1.1.11       gi1/0/19
Multicast address table for VLANs in IPv6-GROUP bridging mode:
VLAN  IP/MAC Address  Type        Ports
----  -
8     ff02::4:4:4     Static      gi1/0/11-2, gi1/0/17, Po1
Forbidden ports for Multicast addresses:
VLAN  IP/MAC Address  Ports
----  -
8     ff02::4:4:4     gi1/0/19
Multicast address table for VLANs in IPv6-SRC-GROUP bridging mode:
Vlan  Group Address  Source address  Type        Ports
----  -
8     ff02::4:4:4     *               Static      gi1/0/11-2, gi1/0/17, Po1
8     ff02::4:4:4     fe80::200:7ff:fe00:200
                        Static
Forbidden ports for Multicast addresses:
Vlan  Group Address  Source address  Ports
----  -
8     ff02::4:4:4     *               gi1/0/19
8     ff02::4:4:4     fe80::200:7ff:fe00:200
                        gi1/0/19

```

---

## 22.29 show bridge multicast address-table static

Use the **show bridge multicast address-table static** EXEC mode command to display the statically configured Multicast addresses.

### Syntax

```

show bridge multicast address-table static [vlan vlan-id] [address mac-multicast-address |
ipv4-multicast-address | ipv6-multicast-address] [source ipv4-source-address | ipv6-source-address] [all |
mac | ip]

```

### Parameters

- **vlan** *vlan-id*—Specifies the VLAN ID.
- **address**—Specifies the Multicast address. The possible values are:
  - **mac-multicast-address**—Specifies the MAC Multicast address.
  - **ipv4-multicast-address**—Specifies the IPv4 Multicast address.
  - **ipv6-multicast-address**—Specifies the IPv6 Multicast address.
- **source**—Specifies the source address. The possible values are:
  - **ipv4-address**—Specifies the source IPv4 address.
  - **ipv6-address**—Specifies the source IPv6 address.

**Default Configuration**

When **all/mac/ip** is not specified, all entries (MAC and IP) will be displayed.

**Command Mode**

EXEC mode

**User Guidelines**

A MAC address can be displayed in IP format only if it is within the range 0100.5e00.0000— 0100.5e7f.ffff.

**Example**

The following example displays the statically configured Multicast addresses.

```

switchxxxxxx# show bridge multicast address-table static
MAC-GROUP table
Vlan      MAC Address      Ports
----      -
1         0100.9923.8787   gil/0/11, gil/0/12
Forbidden ports for multicast addresses:
Vlan      MAC Address      Ports
----      -
IPv4-GROUP Table
Vlan      IP Address       Ports
----      -
1         231.2.2.3        gil/0/11, gil/0/12
19        231.2.2.8        gil/0/1-8
19        231.2.2.8        gil/0/19-21
Forbidden ports for multicast addresses:
Vlan      IP Address       Ports
----      -
1         231.2.2.3        gil/0/18
19        231.2.2.8        gil/0/13
IPv4-SRC-GROUP Table:
Vlan      Group Address    Source          Ports
----      -
Forbidden ports for multicast addresses:
Vlan      Group Address    Source          Ports
----      -
IPv6-GROUP Table
Vlan      IP Address       Ports
----      -
191      -                gil/0/11-8
        FF12::8

```

Forbidden ports for multicast addresses:

Vlan	IP Address	Ports
----	-----	-----
11	-	gi1/0/18
191	FF12::3	gi1/0/18
	FF12::8	

IPv6-SRC-GROUP Table:

Vlan	Group Address	Source address	Ports
----	-----	-----	-----
192	FF12::8	FE80::201:C9A9:FE40:8988	gi1/0/11-8

Forbidden ports for multicast addresses:

Vlan	Group Address	Source address	Ports
----	-----	-----	-----
192	FF12::3	FE80::201:C9A9:FE40:8988	gi1/0/18

---

## 22.30 show bridge multicast filtering

Use the **show bridge multicast filtering** EXEC mode command to display the Multicast filtering configuration.

### Syntax

**show bridge multicast filtering** *vlan-id*

### Parameters

**vlan-id**—Specifies the VLAN ID. (Range: Valid VLAN)

### Default Configuration

N/A

### Command Mode

EXEC mode

### Example

The following example displays the Multicast configuration for VLAN 1.

---

```
switchxxxxxx# show bridge multicast filtering 1
Filtering: Enabled
VLAN: 1

Port          Forward-All
-----
gi1/0/11     Static      Status
gi1/0/12     Forbidden   Filter
gi1/0/13     Forward     Forward(s)
              -         Forward(d)
```

## 22.31 show bridge multicast unregistered

Use the **show bridge multicast unregistered** EXEC mode command to display the unregistered Multicast filtering configuration.

### Syntax

**show bridge multicast unregistered** [*interface-id*]

### Parameters

**interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

### Default Configuration

Display for all interfaces.

### Command Mode

EXEC mode

### Example

The following example displays the unregistered Multicast configuration.

```
switchxxxxxx# show bridge multicast unregistered
Port          Unregistered
-----
gi1/0/11      Forward
gi1/0/12      Filter
gi1/0/13      Filter
```

## 22.32 show ports security

Use the **show ports security** Privileged EXEC mode command to display the port-lock status.

### Syntax

**show ports security** [*interface-id* | **detailed**]

### Parameters

- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or port-channel.
- **detailed**—Displays information for non-present ports in addition to present ports.

### Default Configuration

Display for all interfaces. If detailed is not used, only present ports are displayed.

### Command Mode

Privileged EXEC mode

**Example**

The following example displays the port-lock status of all ports.

---

```
switchxxxxxx# show ports security
```

Port	Status	Learning	Action	Maximum	Trap	Frequency
gi1/0/11	Enabled	Max-Addresses	Discard	3	Enabled	100
gi1/0/12	Disabled	Max-Addresses	-	28	-	-
gi1/0/13	Enabled	Lock	Discard, Shutdown	8	Disabled	-

The following table describes the fields shown above.

Field	Description
<b>Port</b>	The port number.
<b>Status</b>	The port security status. The possible values are: Enabled or Disabled.
<b>Action</b>	The action taken on violation.
<b>Maximum</b>	The maximum number of addresses that can be associated on this port in the Max-Addresses mode.
<b>Trap</b>	The status of SNMP traps. The possible values are: Enable or Disable.
<b>Frequency</b>	The minimum time interval between consecutive traps.

---

## 22.33 show ports security addresses

Use the **show ports security addresses** Privileged EXEC mode command to display the current dynamic addresses in locked ports.

**Syntax**

**show ports security addresses** [*interface-id* | **detailed**]

**Parameters**

- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or port-channel.
- **detailed**—Displays information for non-present ports in addition to present ports.

**Default Configuration**

Display for all interfaces. If detailed is not used, only present ports are displayed.

**Command Mode**

Privileged EXEC mode

**Example**

The following example displays dynamic addresses in all currently locked port:

Port	Status	Learning	Current	Maximum
gi1	Disabled	Lock	0	10
gi2	Disabled	Lock	0	1
gi3	Disabled	Lock	0	1
gi4	Disabled	Lock	0	1
gi5	Disabled	Lock	0	1
gi6	Disabled	Lock	0	1
gi7	Disabled	Lock	0	1
...				





## 23.1 port monitor

Use the **port monitor** Interface Configuration (Ethernet) mode command to start a port monitoring session (mirroring). Use the **no** form of this command to stop a port monitoring session.

### Syntax

**port monitor** *src-interface-id* [*rx* | *tx*]

**no port monitor** *src-interface-id*

**port monitor** *vlan* *vlan-id*

**no port monitor** *vlan* *vlan-id*

### Parameters

- **rx**—Monitors received packets only. If no option is specified, it monitors both rx and tx.
- **tx**—Monitors transmitted packets only. If no option is specified, it monitors both rx and tx.
- **vlan** *vlan-id*—VLAN number
- **src-interface-id**—Specifies an interface ID. The interface ID must be an Ethernet port.

### Default Configuration

Monitors both received and transmitted packets.

### Command Mode

Interface Configuration (Ethernet) mode. It cannot be configured for a range of interfaces (range context).

### User Guidelines

This command enables port copy between Source Port (src-interface) to a Destination Port (The port in context).

The analyzer port for port ingress traffic mirroring should be the same port for all mirrored ports.

The analyzer port for port egress traffic mirroring should be the same port for all mirrored ports.

The following restriction applies to ports that are configured to be source ports:

- The port cannot be a destination port.

The following restrictions apply to ports that are configured to be monitor ports:

- The port cannot be source port.
- The port is not a member in port-channel.
- IP interface is not configured on the port.
- GVRP is not enabled on the port.
- The port is not a member in any VLAN, except for the default VLAN (will be automatically removed from the default VLAN).
- L2 protocols, such as: LLDP, CDP, LBD, STP, LACP, are not active on the destination port.

**Notes:**

- In this mode some traffic duplication on the analyzer port may be observed. For example:
  - Port 2 is being egress monitored by port 4.
  - Port 2 & 4 are members in VLAN 3.
  - Unknown Unicast packet sent to VLAN 3 will egress from port 4 twice, one instance as normal forward and another instance as mirrored from port 2.
  - Moreover, if port 2 is an untagged member in VLAN 3 and port 4 is a tagged member then both instances will look different (one tagged and the other is not).
- When the port is configured to 802.1X auto mode it will forward any mirrored traffic regardless of the 1X state. However, it will operate as a normal network port (forward traffic) only after authorization is done.
- Mirrored traffic is exposed to STP state, i.e. if the port is in STP blocking, it will not egress any mirrored traffic.

**Example**

The following example copies traffic for both directions (Tx and Rx) from the source port `gi1/0/12` to destination port `gi1/0/11`.

---

```
switchxxxxxx(config)# interface gi1/0/11
switchxxxxxx(config-if)# port monitor gi1/0/12
```

---

## 23.2 show ports monitor

Use the **show ports monitor** EXEC mode command to display the port monitoring status.

**Syntax**

**show ports monitor**

**Command Mode**

EXEC mode

**Example**

The following example displays the port monitoring status.

---

```
switchxxxxxx# show ports monitor
```

Source port	Destination Port	Type	Status
gi1/0/18	gi1/0/11		RX,TX Active
gi1/0/12	gi1/0/11		RX,TX Active
gi1/0/118	gi1/0/11	Rx	Active

---

## 23.3 port monitor mode

Use the **port monitor mode** Global Configuration mode command to define the monitoring mode. Use the **no** form of this command to return to default.

**Syntax**

**port monitor mode** {*monitor-only* | *network*}

**no port monitor mode**

**Parameters**

- **monitor-only**—Specifies that the monitor port acts only as a monitor port. Other network traffic is discarded at ingress and egress.
- **network**—Specifies that the monitor port acts also as a network port.

**Default Configuration**

The default is monitor-only.

**Command Mode**

Global Configuration mode

**User Guidelines**

Once the port monitor mode is defined, no changing between modes is allowed. Any mode change will have to first go through un-defining the monitor port.

**Example**

---

```
switchxxxxxx(config)# port monitor mode network
```



---

## 24.1 sflow receiver

Use the **sflow receiver** Global Configuration mode command to define sFlow collector. Use the **no** form of this command to remove the definition of the collector.

### Syntax

**sflow receiver** *index* {*ipv4-address* | *ipv6-address* | *hostname*} [*port port*] [*max-datagram-size bytes*]

**no sflow receiver** *index*

### Parameters

- **index**—The index of the receiver. (Range: 1–8)
- **ipv4-address**—Pv4 address of the host to be used as an sFlow Collector.
- **ipv6-address**—IPv6 address of the host to be used as an sFlow Collector. When the IPv6 address is a Link Local address (IPv6Z address), the outgoing interface name must be specified. Refer to the User Guidelines for the interface name syntax.
- **hostname**—Hostname of the host to be used as an sFlow Collector. Only translation to IPv4 addresses is supported.
- **port**—Port number for sflow messages. If unspecified, the port number defaults to 6343. The range is 1-65535.
- **bytes**—Specifies the maximum datagram size that can be sent. If unspecified, it defaults to 1400.

### Default

No receiver is defined.

### Command Mode

Global Configuration mode

### User Guidelines

If the IP address of the sFlow receiver is set to 0.0.0.0, no sFlow datagrams are sent.

---

## 24.2 sflow flow-sampling

Use the **sflow flow-sampling** Interface Configuration mode command to enable sFlow Flow sampling and configure the average sampling rate of a specific port. Use the **no** form of this command to disable Flow sampling.

### Syntax

**sflow flow-sampling** *rate receiver-index* [*max-header-size bytes*]

**no sflow flow-sampling**

**Parameters**

- **rate**—Specifies the average sampling rate (Range: 1, 1024–1073741823)
- **receiver-index**—Index of the receiver/collector (Range: 1–8)
- **bytes**—Specifies the maximum number of bytes that would be copied from the sampled packet. If unspecified, defaults to 128. (Range: 20–256)

**Default**

Disabled

**Command Mode**

Interface Configuration (Ethernet) mode

**User Guidelines**

A new sampling rate configuration is not immediately loaded to the hardware. It will be loaded to the hardware only after the next packet is sampled (based on the current sampling rate).

---

## 24.3 sflow counters-sampling

Use the **sflow counters-sampling** Interface Configuration mode command to enable sFlow Counters sampling and to configure the maximum interval of a specific port. Use the **no** form of this command to disable sFlow Counters sampling.

**Syntax**

**sflow counters-sampling** *interval receiver-index*

**no sflow counters-sampling**

**Parameters**

- **interval**—Specifies the maximum number of seconds between successive samples of the interface counters. (Range: 1, 15–86400)
- **receiver-index**—Index of the receiver/collector. (Range: 1–8)

**Default**

Disabled

**Command Mode**

Interface Configuration (Ethernet) mode

---

## 24.4 clear sflow statistics

Use the **clear sFlow statistics** EXEC mode command to clear sFlow statistics.

**Syntax**

**clear sflow statistics** [*interface-id*]

**Parameters**

**interface-id**—Specifies an interface ID. The interface ID must be an Ethernet port.

**Command Mode**

EXEC mode

## User Guidelines

If no interface is specified by the user, the command clears all the sFlow statistics counters (including datagrams sent). If an interface is specified by the user, the command clears only the counter of the specific interface.

## 24.5 show sflow configuration

Use the **show sflow configuration** EXEC mode command to display the sFlow configuration for ports that are enabled for Flow sampling or Counters sampling.

### Syntax

**show sflow configuration** [*interface-id*]

### Parameters

**interface-id**—Specifies an interface ID. The interface ID must be an Ethernet port.

### Command Mode

EXEC mode

### Example

Console # **show sflow configuration**

Receivers

Index	IP Address	Port	Max Datagram Size
1	0.0.0.0	6343	1400
2	172.16.1.2	6343	1400
3	0.0.0.0	6343	1400
4	0.0.0.0	6343	1400
5	0.0.0.0	6343	1400
6	0.0.0.0	6343	1400
7	0.0.0.0	6343	1400
8	0.0.0.0	6343	1400

Interfaces

Inter- face	Flow Sampling	Counters Sampling	Max Header Size	Flow Collector	Counters Index	Collector Index
gi1/0/11	1/2048	60 sec	128	1		1
gi1/0/12	1/4096	Disabled	128	0		2

## 24.6 show sflow statistics

Use the **show sflow statistics** EXEC mode command to display the sFlow statistics for ports that are enabled for Flow sampling or Counters sampling.

### Syntax

**show sflow statistics** [*interface-id*]

## Parameters

**interface-id**—Specifies an interface ID. The interface ID must be an Ethernet port.

## Command Mode

EXEC mode

## Example

---

```
Console # show sflow statistics
```

```
Total sFlow datagrams sent to collectors: 100
```

---

Interface	Packets sampled	Datagrams sent to collector
-----	-----	-----
gi1/0/11	30	50
gi1/0/12	30	50
gi1/0/13	30	50



# Link Layer Discovery Protocol (LLDP) Commands

---

## 25.1 lldp run

Use the **lldp run** Global Configuration mode command to enable LLDP. To disable LLDP, use the **no** form of this command.

### Syntax

**lldp run**

**no lldp run**

### Parameters

N/A.

### Default Configuration

Enabled

### Command Mode

Global Configuration mode

### Example

---

```
console(config)# lldp run
```

---

## 25.2 lldp transmit

Use the **lldp transmit** Interface Configuration mode command to enable transmitting LLDP on an interface. Use the **no** form of this command to stop transmitting LLDP on an interface.

### Syntax

**lldp transmit**

**no lldp transmit**

### Parameters

N/A

### Default Configuration

Enabled

### Command Mode

Interface Configuration (Ethernet) mode

**User Guidelines**

LLDP manages LAG ports individually. LLDP sends separate advertisements on each port in a LAG.

LLDP operation on a port is not dependent on the STP state of a port. I.e. LLDP frames are sent on blocked ports.

If a port is controlled by 802.1x, LLDP operates only if the port is authorized.

**Example**

---

```
console(config)# interface gi1/0/11
console(config-if)# lldp transmit
```

---

**25.3 Ildp receive**

Use the **lldp receive** Interface Configuration mode command to enable receiving LLDP on an interface. Use the **no** form of this command to stop receiving LLDP on an interface.

**Syntax**

**lldp receive**

**no lldp receive**

**Parameters**

N/A

**Default Configuration**

Enabled

**Command Mode**

Interface Configuration (Ethernet) mode

**User Guidelines**

LLDP manages LAG ports individually. LLDP data received through LAG ports is stored individually per port.

LLDP operation on a port is not dependent on the STP state of a port. I.e. LLDP frames are received on blocked ports.

If a port is controlled by 802.1x, LLDP operates only if the port is authorized.

**Example**

---

```
console(config)# interface gi1/0/11
console(config-if)# lldp receive
```

---

**25.4 Ildp timer**

Use the **lldp timer** Global Configuration mode command to specify how often the software sends LLDP updates. Use the **no** form of this command to restore the default configuration.

**Syntax**

**lldp timer** *seconds*

**no lldp timer**

**Parameters**

**timer** *seconds*—Specifies, in seconds, how often the software sends LLDP updates. (Range: 5-32768 seconds)

**Default Configuration**

30 seconds.

**Command Mode**

Global Configuration mode

**Example**

The following example sets the interval for sending LLDP updates to 60 seconds.

---

```
Console(config)# lldp timer 60
```

---

## 25.5 lldp hold-multiplier

Use the **lldp hold-multiplier** Global Configuration mode command to specify how long the receiving device holds a LLDP packet before discarding it. Use the **no** form of this command to restore the default configuration.

**Syntax**

**lldp hold-multiplier** *number*

**no lldp hold-multiplier**

**Parameters**

**hold-multiplier** *number*—Specifies the LLDP packet hold time interval as a multiple of the LLDP timer value. (Range: 2-10)

**Default Configuration**

The default LLDP hold multiplier is 4.

**Command Mode**

Global Configuration mode

**User Guidelines**

The actual Time-To-Live (TTL) value of LLDP frames is calculated by the following formula:

$$\text{TTL} = \min(65535, \text{LLDP-Timer} * \text{LLDP-hold-multiplier})$$

For example, if the value of the LLDP timer is 30 seconds, and the value of the LLDP hold multiplier is 4, then the value 120 is encoded in the TTL field of the LLDP header.

**Example**

The following example sets the LLDP packet hold time interval to 90 seconds.

---

```
Console(config)# lldp timer 30  
Console(config)# lldp hold-multiplier 3
```

---

---

## 25.6 lldp reinit

Use the **lldp reinit** Global Configuration mode command to specify the minimum time an LLDP port waits before reinitializing LLDP transmission. Use the **no** form of this command to revert to the default setting.

### Syntax

**lldp reinit** *seconds*

**no lldp reinit**

### Parameters

**reinit** *seconds*—Specifies the minimum time in seconds an LLDP port waits before reinitializing LLDP transmission. (Range: 1–10)

### Default Configuration

2 seconds

### Command Mode

Global Configuration mode

### Example

---

```
console(config)# lldp reinit 4
```

---

## 25.7 lldp tx-delay

Use the **lldp tx-delay** Global Configuration mode command to set the delay between successive LLDP frame transmissions initiated by value/status changes in the LLDP local systems MIB. Use the **no** form of this command to restore the default configuration.

### Syntax

**lldp tx-delay** *seconds*

**no lldp tx-delay**

### Parameters

**tx-delay** *seconds*—Specifies the delay in seconds between successive LLDP frame transmissions initiated by value/status changes in the LLDP local systems MIB. (Range: 1-8192 seconds)

### Default Configuration

The default LLDP frame transmission delay is 2 seconds.

### Command Mode

Global Configuration mode

### User Guidelines

It is recommended that the tx-delay be less than 0.25 of the LLDP timer interval.

### Example

The following example sets the LLDP transmission delay to 10 seconds.

---

```
Console(config)# lldp tx-delay 10
```

## 25.8 lldp optional-tlv

Use the **lldp optional-tlv** Interface Configuration (Ethernet) mode command to specify which optional TLVs are transmitted. Use the **no** form of this command to restore the default configuration.

For 802.1, see the [lldp optional-tlv 802.1](#) command.

### Syntax

```
lldp optional-tlv tlv [tlv2 ... tlv5]
```

### Parameters

**tlv**—Specifies the TLVs to be included. Available optional TLVs are: 802.1, port-desc, sys-name, sys-desc, sys-cap, 802.1, 802.3-mac-phy, 802.3-lag, 802.3-max-frame-size.

If the 802.1 protocol is selected, see the command below.

### Default Configuration

No optional TLV is transmitted.

### Command Mode

Interface Configuration (Ethernet) mode

### Example

The following example specifies that the port description TLV is transmitted on `gi1/0/12`.

```
Console(config)# interface gi1/0/12
Console(config-if)# lldp optional-tlv port-desc
```

## 25.9 lldp optional-tlv 802.1

Use the **lldp optional-tlv** Interface Configuration mode command to specify which optional TLVs to transmit. Use the **no** form of this command to revert to the default setting.

### Syntax

**lldp optional-tlv 802.1 pvid** - The PVID is advertised.

**no lldp optional-tlv 802.1 pvid** - The PVID is not advertised

**lldp optional-tlv 802.1 ppvid add ppvid** - The Protocol Port VLAN ID (PPVID) is advertised. The PPVID is the PVID that is used depending on the packet's protocol.

**lldp optional-tlv 802.1 ppvid remove ppvid** - The PPVID is not advertised.

**lldp optional-tlv 802.1 vlan add vlan-id** - This *vlan-id* is advertised.

**lldp optional-tlv 802.1 vlan remove vlan-id** - This *vlan-id* is not advertised.

**lldp optional-tlv 802.1 protocol add {stp | rstp | mstp | pause | 802.1x | lacp | gvrp}** - The protocols selected are advertised.

**lldp optional-tlv 802.1 protocol remove {stp | rstp | mstp | pause | 802.1x | lacp | gvrp}** - The protocols selected are not advertised.

### Parameters

- **lldp optional-tlv 802.1 pvid**—Advertises the PVID of the port.
- **lldp optional-tlv 802.1 ppvid add/remove ppvid**—Adds/removes PPVID for advertising. (Range: 0–4094) PPVID = 0 indicates that the port is not capable of supporting port and protocol VLANs and/or the port is not enabled with any protocol VLANs.

- **add/remove** *vlan-id*—Adds/removes VLAN for advertising. (Range: 0–4094)
- **add/remove** {*stp* | *rstp* | *mstp* | *pause* | *802.1x* | *lACP* | *gvrp*}—Add specifies to advertise the specified protocols; remove specifies not to advertise the specified protocol.

### Default Configuration

No optional TLV is transmitted.

### Command Mode

Interface Configuration (Ethernet) mode

### Example

---

```
console(config)# lldp optional-tlv 802.1 protocol add stp
```

---

## 25.10 lldp management-address

Use the **lldp management-address** Interface Configuration (Ethernet) mode command to specify the management address advertised by an interface. Use the **no** form of this command to stop advertising management address information.

### Syntax

**lldp management-address** {*ip-address* | *none* | *automatic* [*interface-id*]}

**no lldp management-address**

### Parameters

- **ip-address**—Specifies the static management address to advertise.
- **none**—Specifies that no address is advertised.
- **automatic**—Specifies that the software automatically selects a management address to advertise from all the IP addresses of the product. In case of multiple IP addresses, the software selects the lowest IP address among the dynamic IP addresses. If there are no dynamic addresses, the software selects the lowest IP address among the static IP addresses.
- **automatic interface-id**—Specifies that the software automatically selects a management address to advertise from the IP addresses that are configured on the interface ID. In case of multiple IP addresses, the software selects the lowest IP address among the dynamic IP addresses of the interface. If there are no dynamic addresses, the software selects the lowest IP address among the static IP addresses of the interface. The interface ID can be one of the following types: Ethernet port, port-channel or VLAN. Note that if the port or port-channel are members in a VLAN that has an IP address, that address is not included because the address is associated with the VLAN.

### Default Configuration

No IP address is advertised.

The default advertisement is **automatic**.

### Command Mode

Interface Configuration (Ethernet) mode

### User Guidelines

Each port can advertise one IP address.

**Example**

The following example sets the LLDP management address advertisement mode to **automatic** on `gi1/0/12`.

---

```
Console(config)# interface gi1/0/12
Console(config-if)# lldp management-address automatic
```

---

## 25.11 lldp notifications

Use the **lldp notifications** Interface Configuration (Ethernet) mode command to enable/disable sending LLDP notifications on an interface. Use the **no** form of this command to restore the default configuration.

**Syntax**

**lldp notifications** {*enable* | *disable*}

**no lldp notifications**

**Parameters**

- **enable**—Enables sending LLDP notifications.
- **disable**—Disables sending LLDP notifications.

**Default Configuration**

Disabled.

**Command Mode**

Interface Configuration (Ethernet) mode

**Example**

The following example enables sending LLDP notifications on `gi1/0/15`.

---

```
Console(config)# interface gi1/0/15
Console(config-if)# lldp notifications enable
```

---

## 25.12 lldp notifications interval

Use the **lldp notifications interval** Global Configuration mode command to configure the maximum transmission rate of LLDP notifications. Use the **no** form of this command to return to the default.

**Syntax**

**lldp notifications interval** *seconds*

**no lldp notifications interval**

**Parameters**

**interval** *seconds*—The device does not send more than a single notification in the indicated period. (Range: 5–3600)

**Default Configuration**

5 seconds

**Command Mode**

Global Configuration mode

**Example**


---

```
console(config)# lldp notifications interval 10
```

---

**25.13 lldp med**

Use the **lldp med** Interface Configuration (Ethernet) mode command to enable or disable LLDP Media Endpoint Discovery (MED) on a port. Use the **no** form of this command to return to the default state.

**Syntax**

```
lldp med {enable [tlv ... tlv4] | disable}
```

```
no lldp med
```

**Parameters**

**enable** - Enable LLDP MED

**tlv**—Specifies the TLV that should be included. Available TLVs are: network-policy, location, and poe-pse, inventory. The capabilities TLV is always included if LLDP-MED is enabled.

**disable**—Disable LLDP MED on the port

**Default Configuration**

Disabled

**Command Mode**

Interface Configuration (Ethernet) mode

**Example**

The following example enables LLDP MED with the **location** TLV on **gi1/0/13**.

---

```
Console(config)# interface gi1/0/13
Console(config-if)# lldp med enable location
```

---

**25.14 lldp med notifications topology-change**

Use the **lldp med notifications topology-change** Interface Configuration (Ethernet) mode command to enable sending LLDP MED topology change notifications on a port. Use the **no** form of this command to restore the default configuration.

**Syntax**

```
lldp med notifications topology-change {enable | disable}
```

```
no lldp med notifications topology-change
```

**Parameters**

- **enable**—Enables sending LLDP MED topology change notifications.
- **disable**—Disables sending LLDP MED topology change notifications.

**Default Configuration**

Disable is the default.



**Command Mode**

Interface Configuration (Ethernet) mode

**Example**

The following example enables sending LLDP MED topology change notifications on gi1/0/12.

---

```
Console(config)# interface gi1/0/12
Console(config-if)# lldp med notifications topology-change enable
```

---

**25.15 lldp med fast-start repeat-count**

When a port comes up, LLDP can send packets more quickly than usual using its fast-start mechanism.

Use the **lldp med fast-start repeat-count** Global Configuration mode command to configure the number of packets that is sent during the activation of the fast start mechanism. Use the **no** form of this command return to default.

**Syntax**

**lldp med fast-start repeat-count** *number*

**no lldp med fast-start repeat-count**

**Parameters**

**repeat-count** *number*—Specifies the number of times the fast start LLDPDU is being sent during the activation of the fast start mechanism. The range is 1-10.

**Default Configuration**

3

**Command Mode**

Global Configuration mode

**Example**


---

```
console(config)# lldp med fast-start repeat-count 4
```

---

**25.16 lldp med network-policy (global)**

Use the **lldp med network-policy** Global Configuration mode command to define a LLDP MED network policy.

The **lldp med network-policy** command creates the network policy, which is attached to a port by [lldp med network-policy \(interface\)](#).

The network policy defines how LLDP packets are constructed.

Use the **no** form of this command to remove LLDP MED network policy.

**Syntax**

**lldp med network-policy** *number application [vlan vlan-id] [vlan-type {tagged | untagged}] [up priority] [dscp value]*

**no lldp med network-policy** *number*

**Parameters**

- **number**—Network policy sequential number. The range is 1-32.
- **application**—The name or the number of the primary function of the application defined for this network policy. Available application names are:
  - voice
  - voice-signaling
  - guest-voice
  - guest-voice-signaling
  - softphone-voice
  - video-conferencing
  - streaming-video
  - video-signaling.
- **vlan** *vlan-id*—VLAN identifier for the application.
- **vlan-type**—Specifies if the application is using a tagged or an untagged VLAN.
- **up** *priority*—User Priority (Layer 2 priority) to be used for the specified application.
- **dscp** *value*—DSCP value to be used for the specified application.

**Default Configuration**

No network policy is defined.

**Command Mode**

Global Configuration mode

**User Guidelines**

Use the **lldp med network-policy** Interface Configuration command to attach a network policy to a port.

Up to 32 network policies can be defined.

**Example**

This example creates a network policy for the voice-signally application and attaches it to port 1. LLDP packets sent on port 1 will contain the information defined in the network policy.

---

```

console(config)# lldp med network-policy 1 voice-signaling vlan 1 vlan-type
untagged up 1 dscp 2
Console(config)# interface gi1/0/11
Console(config-if)# lldp med network-policy add 1

```

---

**25.17 lldp med network-policy (interface)**

Use the **lldp med network-policy** Interface Configuration (Ethernet) mode command to attach or remove an LLDP MED network policy on a port. Network policies are created in [lldp med network-policy \(global\)](#).

Use the **no** form of this command to remove all the LLDP MED network policies from the port.

**Syntax**

**lldp med network-policy** {*add* | *remove*} *number*

**no lldp med network-policy** *number*

**Parameters**

- **number**—Specifies the network policy sequential number. The range is 1-32
- **add/remove** *number*—Attaches/removes the specified network policy to the interface.

**Default Configuration**

No network policy is attached to the interface.

**Command Mode**

Interface Configuration (Ethernet) mode

**User Guidelines**

For each port, only one network policy per application (voice, voice-signaling, etc.) can be defined.

**Example**

This example creates a network policy for the voice-signaling application and attaches it to port 1. LLDP packets sent on port 1 will contain the information defined in the network policy.

---

```
console(config)# lldp med network-policy 1 voice-signaling vlan 1 vlan-type
untagged up 1 dscp 2
Console(config)# interface gi1/0/11
Console(config-if)# lldp med network-policy add 1
```

---

## 25.18 clear lldp table

Use the **clear lldp table** command in Privileged EXEC mode to clear the neighbors table for all ports or for a specific port.

**Syntax**

**clear lldp table** [*interface-id*]

**Parameters**

**interface-id**—Specifies a port ID.

**Default Configuration**

If no interface is specified, the default is to clear the LLDP table for all ports.

**Command Mode**

Privileged EXEC mode

**Example**


---

```
console# clear lldp table gi1/0/11
```

---

## 25.19 lldp med location

Use the **lldp med location** Interface Configuration (Ethernet) mode command to configure the location information for the LLDP Media Endpoint Discovery (MED) for a port. Use the **no** form of this command to delete location information for a port.

**Syntax**

**lldp med location** *{{coordinate data} | {civic-address data} | {ecs-elin data}}*

**no lldp med location** *{coordinate | civic-address | ecs-elin}*

**Parameters**

- **coordinate data**—Specifies the location data as coordinates in hexadecimal format.
- **civic-address data**—Specifies the location data as a civic address in hexadecimal format.
- **ecs-elin data**—Specifies the location data as an Emergency Call Service Emergency Location Identification Number (ECS ELIN) in hexadecimal format.
- **data**—Specifies the location data in the format defined in ANSI/TIA 1057: dotted hexadecimal data: Each byte in a hexadecimal character string is two hexadecimal digits. Bytes are separated by a period or colon. (Length: coordinate: 16 bytes. Civic-address: 6-160 bytes. Ecs-elin: 10-25 bytes)

**Default Configuration**

The location is not configured.

**Command Mode**

Interface Configuration (Ethernet) mode

**Example**

The following example configures the LLDP MED location information on `gi1/0/12` as a civic address.

---

```
console(config)# interface gi1/0/12
console(config-if)# lldp med location civic-address 616263646566
```

---

## 25.20 show lldp configuration

Use the **show lldp configuration** Privileged EXEC mode command to display the LLDP configuration for all ports or for a specific port.

**Syntax**

**show lldp configuration** [*interface-id* | **detailed**]

**Parameters**

- **interface-id**—Specifies the port ID.
- **detailed**—Displays information for non-present ports in addition to present ports.

**Default Configuration**

Display for all ports. If detailed is not used, only present ports are displayed.

**Command Mode**

Privileged EXEC mode

**Examples**

**Example 1** - Display LLDP configuration for all ports.

---

```
Switch# show lldp configuration
State: Enabled
Timer: 30 Seconds
Hold multiplier: 4
Reinit delay: 2 Seconds
Tx delay: 2 Seconds
Notifications interval: 5 seconds
LLDP packets handling: Filtering
```

Port	State	Optional TLVs	Address	Notifications
gil/0/11	RX,TX	PD, SN, SD, SC	172.16.1.1	Disabled
gil/0/12	TX	PD, SN	172.16.1.1	Disabled
gil/0/13	RX,TX	PD, SN, SD, SC	None	Disabled
gil/0/15	RX,TX	D, SN, SD, SC	automatic	Disabled
gil/0/16	RX,TX	PD, SN, SD, SC	auto vlan 1	Disabled
gil/0/17	RX,TX	PD, SN, SD, SC	auto g1	Disabled
gil/0/18	RX,TX	PD, SN, SD, SC	auto ch1	Disabled

### Example 2 - Display LLDP configuration for port 1.

```
Switch# show lldp configuration gil/0/11
State: Enabled
Timer: 30 Seconds
Hold multiplier: 4
Reinit delay: 2 Seconds
Tx delay: 2 Seconds
Notifications interval: 5 seconds
LLDP packets handling: Filtering
Port State   Optional TLVs   Address   Notifications
-----
gil/0/11 RX, TX   PD, SN, SD, SC   72.16.1.1   Disabled
802.3 optional TLVs: 802.3-mac-phy, 802.3-lag, 802.3-max-frame-size
802.1 optional TLVs
PVID: Enabled
PPVIDs: 0, 1, 92
VLANs: 1, 92
Protocols: 802.1x
```

The following table describes the significant fields shown in the display:

Field	Description
<b>Timer</b>	The time interval between LLDP updates.
<b>Hold multiplier</b>	The amount of time (as a multiple of the timer interval) that the receiving device holds a LLDP packet before discarding it.
<b>Reinit timer</b>	The minimum time interval an LLDP port waits before re-initializing an LLDP transmission.
<b>Tx delay</b>	The delay between successive LLDP frame transmissions initiated by value/status changes in the LLDP local systems MIB.
<b>Port</b>	The port number.
<b>State</b>	The port's LLDP state.
<b>Optional TLVs</b>	Optional TLVs that are advertised. Possible values are: PD - Port description SN - System name SD - System description SC - System capabilities
<b>Address</b>	The management address that is advertised.
<b>Notifications</b>	Indicates whether LLDP notifications are enabled or disabled.
<b>PVID</b>	Port VLAN ID advertised.

Field	Description
PPVID	Protocol Port VLAN ID advertised.
Protocols	Protocols advertised.

## 25.21 show lldp med configuration

Use the **show lldp med configuration** Privileged EXEC mode command to display the LLDP Media Endpoint Discovery (MED) configuration for all ports or for a specific port.

### Syntax

**show lldp med configuration** [*interface-id* | *detailed*]

### Parameters

- **interface-id**—Specifies the port ID.
- **detailed**—Displays information for non-present ports in addition to present ports.

### Default Configuration

If no port ID is entered, the command displays information for all ports. If detailed is not used, only present ports are displayed.

### Command Mode

Privileged EXEC mode

### Examples

**Example 1** - The following example displays the LLDP MED configuration for all interfaces.

```
console# show lldp med configuration
Fast Start Repeat Count: 4.
Network policy 1
-----
Application type: voiceSignaling
VLAN ID: 1 untagged
Layer 2 priority: 0
DSCP: 0
Port    Capabilities  Network Policy Location  Notifications  Inventory
-----
gil/0/11  Yes           Yes           Yes           Enabled         Yes
gil/0/12  Yes           Yes           No            Enabled         No
gil/0/13  No            No            No            Enabled         No
```

**Example 2** - The following example displays the LLDP MED configuration for gi1/0/11.

```
console# show lldp med configuration gi1/0/11

Port    Capabilities  Network Policy  Location  Notifications  Inventory
-----
gil/0/11  Yes           Yes           Yes           Enabled         Yes
Network policies:
```

Location:  
Civic-address: 61:62:63:64:65:66

---

## 25.22 show lldp local tlvs-overloading

When an LLDP packet contains too much information for one packet, this is called overloading. Use the **show lldp local tlvs-overloading** EXEC mode command to display the status of TLVs overloading of the LLDP on all ports or on a specific port.

### Syntax

**show lldp local tlvs-overloading** [*interface-id*]

### Parameters

**interface-id**—Specifies a port ID.

### Default Configuration

If no port ID is entered, the command displays information for all ports.

### Command Mode

EXEC mode

### User Guidelines

The command calculates the overloading status of the current LLDP configuration, and not for the last LLDP packet that was sent.

### Example

---

```
Switch# show lldp local tlvs-overloading gi1/0/11
TLVs Group           Bytes           Status
-----
Mandatory             31             Transmitted
LLDP-MED Capabilities  9              Transmitted
LLDP-MED Location     200            Transmitted
802.1                 1360           Overloading
Total: 1600 bytes
Left: 100 bytes
```

---

## 25.23 show lldp local

Use the **show lldp local** Privileged EXEC mode command to display the LLDP information that is advertised from a specific port.

### Syntax

**show lldp local** *interface-id*

### Parameters

**Interface-id**—Specifies a port ID.

### Default Configuration

If no port ID is entered, the command displays information for all ports.

**Command Mode**

Privileged EXEC mode

**Example**

The following examples display LLDP information that is advertised from gi1/0/11 and 2.

---

```
Switch# show lldp local gi1/0/11
Device ID: 0060.704C.73FF
Port ID: gi1/0/11
Capabilities: Bridge
System Name: ts-7800-1
System description:
Port description:
Management address: 172.16.1.8
802.3 MAC/PHY Configuration/Status
Auto-negotiation support: Supported
Auto-negotiation status: Enabled
Auto-negotiation Advertised Capabilities: 100BASE-TX full duplex, 1000BASE-T
full duplex
Operational MAU type: 1000BaseTFD
802.3 Link Aggregation
Aggregation capability: Capable of being aggregated
Aggregation status: Not currently in aggregation
Aggregation port ID: 1
802.3 Maximum Frame Size: 1522
802.3 EEE
Local Tx: 30 usec
Local Rx: 25 usec
Remote Tx Echo: 30 usec
Remote Rx Echo: 25 usec
802.1 PVID: 1
802.1 PPVID: 2 supported, enabled
802.1 VLAN: 2 (VLAN2)
802.1 Protocol: 88 8E 01
LLDP-MED capabilities: Network Policy, Location Identification
LLDP-MED Device type: Network Connectivity
LLDP-MED Network policy
Application type: Voice
Flags: Tagged VLAN
VLAN ID: 2
Layer 2 priority: 0
DSCP: 0
LLDP-MED Power over Ethernet
Device Type: Power Sourcing Entity
Power source: Primary Power Source
Power priority: High
Power value: 9.6 Watts
LLDP-MED Location
```



```

Coordinates: 54:53:c1:f7:51:57:50:ba:5b:97:27:80:00:00:67:01
Hardware Revision: B1
Firmware Revision: A1
Software Revision: 3.8
Serial number: 7978399
Manufacturer name: Manufacturer
Model name: Model 1
Asset ID: Asset 123
Switch# show lldp local gi1/0/12
LLDP is disabled.

```

## 25.24 show lldp neighbors

Use the **show lldp neighbors** Privileged EXEC mode command to display information about neighboring devices discovered using LLDP. The information can be displayed for all ports or for a specific port.

### Syntax

**show lldp neighbors** [*interface-id*]

### Parameters

**interface-id**—Specifies a port ID.

### Default Configuration

If no port ID is entered, the command displays information for all ports.

### Command Mode

Privileged EXEC mode

### User Guidelines

A TLV value that cannot be displayed as an ASCII string is displayed as a hexadecimal string.

### Examples

**Example 1** - The following example displays information about neighboring devices discovered using LLDP on all ports on which LLDP is enabled and who are up.

Location information, if it exists, is also displayed.

```

Switch# show lldp neighbors
Port  Device ID          Port ID  System Name  Capabilities  TTL
-----
gi1/0/11 00:00:00:11:11:11   gi1/0/11   ts-7800-2    B              90
gi1/0/11 00:00:00:11:11:11 D gi1/0/11   ts-7800-2    B              90
gi1/0/12 00:00:26:08:13:24   gi1/0/13   ts-7900-1    B, R          90
gi1/0/13 00:00:26:08:13:24   gi1/0/12   ts-7900-2    W              90

```

**Example 2** - The following example displays information about neighboring devices discovered using LLDP on port 1.

```

Switch# show lldp neighbors gi1/0/11
Device ID: 00:00:00:11:11:11

```

```
Port ID: gi1/0/11
System Name: ts-7800-2
Capabilities: B
System description:
Port description:
Management address: 172.16.1.1
Time To Live: 90 seconds
802.3 MAC/PHY Configuration/Status
Auto-negotiation support: Supported.
Auto-negotiation status: Enabled.
Auto-negotiation Advertised Capabilities: 100BASE-TX full duplex, 1000BASE-T
full duplex.
Operational MAU type: 1000BaseTFD
802.3 Power via MDI
MDI Power support Port Class: PD
PSE MDI Power Support: Not Supported
PSE MDI Power State: Not Enabled
PSE power pair control ability: Not supported.
PSE Power Pair: Signal
PSE Power class: 1
802.3 Link Aggregation
Aggregation capability: Capable of being aggregated
Aggregation status: Not currently in aggregation
Aggregation port ID: 1
802.3 Maximum Frame Size: 1522
802.3 EEE
Remote Tx: 25 usec
Remote Rx: 30 usec
Local Tx Echo: 30 usec
Local Rx Echo: 25 usec
802.1 PVID: 1
802.1 PPVID: 2 supported, enabled
802.1 VLAN: 2(VLAN2)
802.1 Protocol: 88 8E 01
LLDP-MED capabilities: Network Policy.
LLDP-MED Device type: Endpoint class 2.
LLDP-MED Network policy
Application type: Voice
Flags: Unknown policy
VLAN ID: 0
Layer 2 priority: 0
DSCP: 0
LLDP-MED Power over Ethernet
Device Type: Power Device
Power source: Primary power
Power priority: High
Power value: 9.6 Watts
Hardware revision: 2.1
Firmware revision: 2.3
```

Software revision: 2.7.1  
 Serial number: LM759846587  
 Manufacturer name: VP  
 Model name: TR12  
 Asset ID: 9  
 LLDP-MED Location  
 Coordinates: 54:53:c1:f7:51:57:50:ba:5b:97:27:80:00:00:67:01

The following table describes significant LLDP fields shown in the display:

Field	Description
<b>Port</b>	The port number.
<b>Device ID</b>	The neighbor device's configured ID (name) or MAC address.
<b>Port ID</b>	The neighbor device's port ID.
<b>System name</b>	The neighbor device's administratively assigned name.
<b>Capabilities</b>	The capabilities discovered on the neighbor device. Possible values are: B - Bridge R - Router W - WLAN Access Point T - Telephone D - DOCSIS cable device H - Host r - Repeater O - Other
<b>System description</b>	The neighbor device's system description.
<b>Port description</b>	The neighbor device's port description.
<b>Management address</b>	The neighbor device's management address.
<b>Auto-negotiation support</b>	The auto-negotiation support status on the port. (supported or not supported)
<b>Auto-negotiation status</b>	The active status of auto-negotiation on the port. (enabled or disabled)
<b>Auto-negotiation Advertised Capabilities</b>	The port speed/duplex/flow-control capabilities advertised by the auto-negotiation.
<b>Operational MAU type</b>	The port MAU type.
<b>LLDP MED</b>	
<b>Capabilities</b>	The sender's LLDP-MED capabilities.
<b>Device type</b>	The device type. Indicates whether the sender is a Network Connectivity Device or Endpoint Device, and if an Endpoint, to which Endpoint Class it belongs.
<b>LLDP MED - Network Policy</b>	
<b>Application type</b>	The primary function of the application defined for this network policy.
<b>Flags</b>	Flags. The possible values are: Unknown policy: Policy is required by the device, but is currently unknown. Tagged VLAN: The specified application type is using a tagged VLAN. Untagged VLAN: The specified application type is using an Untagged VLAN.
<b>VLAN ID</b>	The VLAN identifier for the application.
<b>Layer 2 priority</b>	The Layer 2 priority used for the specified application.
<b>DSCP</b>	The DSCP value used for the specified application.

Field	Description
<b>LLDP MED - Power Over Ethernet</b>	
<b>Power type</b>	The device power type. The possible values are: Power Sourcing Entity (PSE) or Power Device (PD).
<b>Power Source</b>	The power source utilized by a PSE or PD device. A PSE device advertises its power capability. The possible values are: Primary power source and Backup power source. A PD device advertises its power source. The possible values are: Primary power, Local power, Primary and Local power.
<b>Power priority</b>	The PD device priority. A PSE device advertises the power priority configured for the port. A PD device advertises the power priority configured for the device. The possible values are: Critical, High and Low.
<b>Power value</b>	The total power in watts required by a PD device from a PSE device, or the total power a PSE device is capable of sourcing over a maximum length cable based on its current configuration.
<b>LLDP MED - Location</b>	
<b>Coordinates, Civic address, ECS ELIN.</b>	The location information raw data.

## 25.25 show lldp statistics

Use the `show lldp statistics` EXEC mode command to display LLDP statistics on all ports or a specific port.

### Syntax

`show lldp statistics [interface-id | detailed]`

### Parameters

- **interface-id**—Specifies the port ID.
- **detailed**—Displays information for non-present ports in addition to present ports.

### Default Configuration

If no port ID is entered, the command displays information for all ports. If `detailed` is not used, only present ports are displayed.

### Command Mode

EXEC mode

### Example

```
Switch# show lldp statistics
console(config-if)# do show lldp statistics
Tables Last Change Time: 14-Oct-2010 32:08:18
Tables Inserts: 26
Tables Deletes: 2
Tables Dropped: 0
Tables Ageouts: 1
```

Port	TX Frames		RX Frame		RX TLVs		RX Ageouts
	Total	Total	Discarded	Errors	Discarded	Unrecognized	Total
gi1/0/11	730	850	0	0	0	0	0
gi1/0/12	0	0	0	0	0	0	0
gi1/0/13	730	0	0	0	0	0	0
gi1/0/14	0	0	0	0	0	0	0
gi1/0/15	0	0	0	0	0	0	0
gi1/0/16	8	7	0	0	0	0	1
gi1/0/17	0	0	0	0	0	0	0
gi1/0/18	0	0	0	0	0	0	0
gi1/0/19	730	0	0	0	0	0	0
gi1/0/110	0	0	0	0	0	0	0



---

## 26.1 spanning-tree

Use the **spanning-tree** Global Configuration mode command to enable spanning-tree functionality. Use the **no** form of this command to disable the spanning-tree functionality.

### Syntax

**spanning-tree**

**no spanning-tree**

### Parameters

N/A

### Default Configuration

Spanning-tree is enabled.

### Command Mode

Global Configuration mode

### Example

The following example enables spanning-tree functionality.

---

```
switchxxxxxx(config)# spanning-tree
```

---

## 26.2 spanning-tree mode

Use the **spanning-tree mode** Global Configuration mode command to select which Spanning Tree Protocol (STP) protocol to run. Use the **no** form of this command to restore the default configuration.

### Syntax

**spanning-tree mode** {*stp* | *rstp* | *mst*}

**no spanning-tree mode**

### Parameters

- **stp**—Specifies that STP is enabled.
- **rstp**—Specifies that the Rapid STP is enabled.
- **mst**—Specifies that the Multiple STP is enabled.

### Default Configuration

The default is RSTP.

**Command Mode**

Global Configuration mode

**User Guidelines**

In RSTP mode, the device uses STP when the neighbor device uses STP.

In MSTP mode, the device uses RSTP when the neighbor device uses RSTP, and uses STP when the neighbor device uses STP.

**Example**

The following example enables MSTP.

---

```
switchxxxxxx(config)# spanning-tree mode mstp
```

---

## 26.3 spanning-tree forward-time

Use the **spanning-tree forward-time** Global Configuration mode command to configure the spanning-tree bridge forward time, which is the amount of time a port remains in the listening and learning states before entering the forwarding state. Use the **no** form of this command to restore the default configuration.

**Syntax**

**spanning-tree forward-time** *seconds*

**no spanning-tree forward-time**

**Parameters**

**seconds**—Specifies the spanning-tree forward time in seconds. (Range: 4–30)

**Default Configuration**

15 seconds.

**Command Mode**

Global Configuration mode

**User Guidelines**

When configuring the forwarding time, the following relationship should be maintained:

$$2 * (\text{Forward-Time} - 1) \geq \text{Max-Age}$$

**Example**

The following example configures the spanning tree bridge forwarding time to 25 seconds.

---

```
switchxxxxxx(config)# spanning-tree forward-time 25
```



---

## 26.4 spanning-tree hello-time

Use the **spanning-tree hello-time** Global Configuration mode command to configure how often the device broadcasts Hello messages to other devices. Use the **no** form of this command to restore the default configuration.

### Syntax

**spanning-tree hello-time** *seconds*

**no spanning-tree hello-time**

### Parameters

**seconds**—Specifies the spanning-tree Hello time in seconds. (Range: 1–10)

### Default Configuration

2 seconds.

### Command Mode

Global Configuration mode

### User Guidelines

When configuring the Hello time, the following relationship should be maintained:

$$\text{Max-Age} \geq 2 * (\text{Hello-Time} + 1)$$

### Example

The following example configures the spanning-tree bridge hello time to 5 seconds.

---

```
switchxxxxxx(config)# spanning-tree hello-time 5
```

---

## 26.5 spanning-tree max-age

Use the **spanning-tree max-age** Global Configuration mode command to configure the STP maximum age. Use the **no** form of this command to restore the default configuration.

### Syntax

**spanning-tree max-age** *seconds*

**no spanning-tree max-age**

### Parameters

**seconds**—Specifies the spanning-tree bridge maximum age in seconds. (Range: 6–40)

### Default Configuration

The default maximum age is 20 seconds.

### Command Mode

Global Configuration mode

### User Guidelines

When configuring the maximum age, the following relationships should be maintained:

$$2 * (\text{Forward-Time} - 1) \geq \text{Max-Age}$$

Max-Age  $\geq 2 * (\text{Hello-Time} + 1)$

### Example

The following example configures the spanning-tree bridge maximum age to 10 seconds.

---

```
switchxxxxxx(config)# spanning-tree max-age 10
```

---

## 26.6 spanning-tree priority

Use the **spanning-tree priority** Global Configuration mode command to configure the device STP priority, which is used to determine which bridge is selected as the root bridge. Use the **no** form of this command to restore the default device spanning-tree priority.

### Syntax

**spanning-tree priority** *priority*

**no spanning-tree priority**

### Parameters

**priority**—Specifies the bridge priority. (Range: 0–61440)

### Default Configuration

Default priority = 32768.

### Command Mode

Global Configuration mode

### User Guidelines

The priority value must be a multiple of 4096.

The switch with the lowest priority is the root of the spanning tree. When more than one switch has the lowest priority, the switch with the lowest MAC address is selected as the root.

### Example

The following example configures the spanning-tree priority to 12288.

---

```
switchxxxxxx(config)# spanning-tree priority 12288
```

---

## 26.7 spanning-tree disable

Use the **spanning-tree disable** Interface Configuration (Ethernet, port-channel) mode command to disable the spanning tree on a specific port. Use the **no** form of this command to enable the spanning tree on a port.

### Syntax

**spanning-tree disable**

**no spanning-tree disable**

### Parameters

N/A

**Default Configuration**

Spanning tree is enabled on all ports.

**Command Mode**

Interface Configuration (Ethernet, port-channel) mode

**Example**

The following example disables the spanning tree on `gi1/0/15`

---

```
switchxxxxxx(config)# interface gi1/0/15
switchxxxxxx(config-if)# spanning-tree disable
```

---

**26.8 spanning-tree cost**

Use the **spanning-tree cost** Interface Configuration (Ethernet, port-channel) mode command to configure the spanning-tree path cost for a port. Use the **no** form of this command to restore the default configuration.

**Syntax**

**spanning-tree cost** *cost*

**no spanning-tree cost**

**Parameters**

**cost**—Specifies the port path cost. (Range: 1–200000000)

**Default Configuration**

Default path cost is determined by port speed and path cost method (long or short) as shown below:

Interface	Long	Short
Port-channel	20,000	4
TenGigabit Ethernet (10000 Mbps)	2000	2
Gigabit Ethernet (1000 Mbps)	20,000	4
Ethernet (10 Mbps)	2,000,000	100

**Command Mode**

Interface Configuration (Ethernet, port-channel) mode

**Example**

The following example configures the spanning-tree cost on `gi1/0/115` to 35000.

---

```
switchxxxxxx(config)# interface gi1/0/115
switchxxxxxx(config-if)# spanning-tree cost 35000
```

---

---

## 26.9 spanning-tree port-priority

Use the **spanning-tree port-priority** Interface Configuration (Ethernet, port-channel) mode command to configure the port priority. Use the **no** form of this command to restore the default configuration.

### Syntax

**spanning-tree port-priority** *priority*

**no spanning-tree port-priority**

### Parameters

**priority**—Specifies the port priority. (Range: 0–240)

### Default Configuration

The default port priority is 128.

### Command Mode

Interface Configuration (Ethernet, port-channel) mode

### User Guidelines

The priority value must be a multiple of 16.

### Example

The following example configures the spanning priority on `gi1/0/115` to 96

---

```
switchxxxxxx(config)# interface gi1/0/115
switchxxxxxx(config-if)# spanning-tree port-priority 96
```

---

## 26.10 spanning-tree portfast

Use the **spanning-tree portfast** Interface Configuration (Ethernet, port-channel) mode command to enable the PortFast mode. In PortFast mode, the interface is immediately put into the forwarding state upon linkup, without waiting for the standard forward time delay. Use the **no** form of this command to disable the PortFast mode.

### Syntax

**spanning-tree portfast** [*auto*]

**no spanning-tree portfast**

### Parameters

**auto**—Specifies that the software waits for 3 seconds (with no Bridge Protocol Data Units (BPDUs) received on the interface) before putting the interface into the PortFast mode.

### Default Configuration

PortFast mode is disabled.

### Command Mode

Interface Configuration (Ethernet, port-channel) mode

**Example**

The following example enables the PortFast mode on `gi1/0/115`.

---

```
switchxxxxxx(config)# interface gi1/0/115
switchxxxxxx(config-if)# spanning-tree portfast
```

---

**26.11 spanning-tree link-type**

Use the **spanning-tree link-type** Interface Configuration (Ethernet, port-channel) mode command to override the default link-type setting determined by the port duplex mode, and enable RSTP transitions to the Forwarding state. Use the **no** form of this command to restore the default configuration.

**Syntax**

**spanning-tree link-type** {*point-to-point* | *shared*}

**no spanning-tree spanning-tree link-type**

**Parameters**

- **point-to-point**—Specifies that the port link type is point-to-point.
- **shared**—Specifies that the port link type is shared.

**Default Configuration**

The device derives the port link type from the duplex mode. A full-duplex port is considered a point-to-point link and a half-duplex port is considered a shared link.

**Command Mode**

Interface Configuration (Ethernet, port-channel) mode

**Example**

The following example enables shared spanning-tree on `gi1/0/115`.

---

```
switchxxxxxx(config)# interface gi1/0/115
switchxxxxxx(config-if)# spanning-tree link-type shared
```

---

**26.12 spanning-tree pathcost method**

Use the **spanning-tree pathcost method** Global Configuration mode command to set the default path cost method. Use the **no** form of this command to return to the default configuration.

**Syntax**

**spanning-tree pathcost method** {*long* | *short*}

**no spanning-tree pathcost method**

**Parameters**

- **long**—Specifies that the default port path costs are within the range: 1–200,000,000.
- **short**—Specifies that the default port path costs are within the range: 1–65,535.

**Default Configuration**

Long path cost method.

**Command Mode**

Global Configuration mode

**User Guidelines**

This command applies to all the spanning tree instances on the switch.

- If the short method is selected, the switch calculates cost in the range 1 through 65,535.
- If the long method is selected, the switch calculates cost in the range 1 through 200,000,000.

**Example**

The following example sets the default path cost method to Long.

---

```
switchxxxxxx(config)# spanning-tree pathcost method long
```

---

## 26.13 spanning-tree bpdud (Global)

Use the **spanning-tree bpdud** Global Configuration mode command to define Bridge Protocol Data Unit (BPDU) handling when the spanning tree is disabled globally or on a single interface. Use the **no** form of this command to restore the default configuration.

**Syntax**

```
spanning-tree bpdud {filtering | flooding}
```

```
no spanning-tree bpdud
```

**Parameters**

- **filtering**—Specifies that BPDU packets are filtered when the spanning tree is disabled on an interface.
- **flooding**—Specifies that untagged BPDU packets are flooded unconditionally (without applying VLAN rules) to all ports with the spanning tree disabled and BPDU handling mode of flooding. Tagged BPDU packets are filtered.

**Default Configuration**

The default setting is **flooding**.

**Command Mode**

Global Configuration mode

**User Guidelines**

The **filtering** and **flooding** modes are relevant when the spanning tree is disabled globally or on a single interface.

**Example**

The following example defines the BPDU packet handling mode as **flooding** when the spanning tree is disabled on an interface.

---

```
switchxxxxxx(config)# spanning-tree bpdud flooding
```

---

---

## 26.14 spanning-tree bpdud (Interface)

Use the **spanning-tree bpdud** Interface Configuration (Ethernet, Port-channel) mode command to define BPDU handling when the spanning tree is disabled on a single interface. Use the **no** form of this command to restore the default configuration.

### Syntax

**spanning-tree bpdud** {*filtering* | *flooding*}

**no spanning-tree bpdud**

### Parameters

- **filtering**—Specifies that BPDU packets are filtered when the spanning tree is disabled on an interface.
- **flooding**—Specifies that untagged BPDU packets are flooded unconditionally (without applying VLAN rules) to ports with the spanning tree disabled and BPDU handling mode of flooding. Tagged BPDU packets are filtered.

### Default Configuration

The **spanning-tree bpdud (Global)** command determines the default configuration.

### Command Mode

Interface Configuration (Ethernet, Port-channel) mode

### Example

The following example defines the BPDU packet as **flooding** when the spanning tree is disabled on gi1/0/13.

---

```
switchxxxxxx(config)# interface gi1/0/13
switchxxxxxx(config-if)# spanning-tree bpdud flooding
```

---

## 26.15 spanning-tree guard root

use the **spanning-tree guard root** Interface Configuration (Ethernet, Port-channel) mode command to enable Root Guard on all spanning-tree instances on the interface. Root guard prevents the interface from becoming the root port of the device. Use the **no** form of this command to disable the root guard on the interface.

### Syntax

**spanning-tree guard root**

**no spanning-tree guard root**

### Default Configuration

Root guard is disabled.

### Command Mode

Interface Configuration (Ethernet, Port-channel) mode

### User Guidelines

Root Guard can be enabled when the device operates in any mode (STP, RSTP and MSTP).

When Root Guard is enabled, the port changes to the alternate state if the spanning-tree calculations select the port as the root port.

**Example**

The following example prevents `gi1/0/11` from being the root port of the device.

---

```
switchxxxxxx(config)# interface gi1/0/11
switchxxxxxx(config-if)# spanning-tree guard root
```

---

## 26.16 spanning-tree bpduguard

Use the **spanning-tree bpduguard** Interface Configuration (Ethernet, port-channel) mode command to shut down an interface when it receives a Bridge Protocol Data Unit (BPDU). Use the **no** form of this command to restore the default configuration.

**Syntax**

**spanning-tree bpduguard** {*enable* | *disable*}

**no spanning-tree bpduguard**

**Parameters**

**bpduguard enable**—Enables BPDU Guard.

**bpduguard disable**—Disables BPDU Guard.

**Default Configuration**

BPDU Guard is disabled.

**Command Mode**

Interface Configuration (Ethernet, Port-channel) mode

**User Guidelines**

The command can be enabled when the spanning tree is enabled (useful when the port is in the PortFast mode) or disabled.

**Example**

The following example shuts down `gi1/0/15` when it receives a BPDU.

---

```
switchxxxxxx(config)# interface gi1/0/15
switchxxxxxx(config-if)# spanning-tree bpduguard enable
```

---

## 26.17 clear spanning-tree detected-protocols

Use the **clear spanning-tree detected-protocols** Privileged EXEC command to restart the STP migration process (force renegotiation with neighboring switches) on all interfaces or on the specified interface

**Syntax**

**clear spanning-tree detected-protocols** [*interface interface-id*]

**Parameters**

**interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

**Default Configuration**

All interfaces.



**Command Mode**

Privileged EXEC mode

**User Guidelines**

This feature can only be used when working in RSTP or MSTP mode.

**Example**

This restarts the STP migration process on all interfaces.

---

```
switchxxxxxx# clear spanning-tree detected-protocols
```

---

## 26.18 spanning-tree mst priority

Use the **spanning-tree mst priority** Global Configuration mode command to configure the device priority for the specified spanning-tree instance. Use the **no** form of this command to restore the default configuration.

**Syntax**

**spanning-tree mst** *instance-id* **priority** *priority*

**no spanning-tree mst** *instance-id* **priority**

**Parameters**

- **instance-id**—Specifies the spanning-tree instance ID. (Range:1–16)
- **priority**—Specifies the device priority for the specified spanning-tree instance. This setting determines the likelihood that the switch is selected as the root switch. A lower value increases the probability that the switch is selected as the root switch. (Range: 0–61440)

**Default Configuration**

The default priority is 32768.

**Command Mode**

Global Configuration mode

**User Guidelines**

The priority value must be a multiple of 4096.

The switch with the lowest priority is the root of the spanning tree.

**Example**

The following example configures the spanning tree priority of instance 1 to 4096.

---

```
switchxxxxxx(config)# spanning-tree mst 1 priority 4096
```

---

## 26.19 spanning-tree mst max-hops

Use the **spanning-tree mst max-hops** Global Configuration mode command to configure the number of hops in an MST region before the BPDU is discarded and the port information is aged out. Use the **no** form of this command to restore the default configuration.

**Syntax**

**spanning-tree mst max-hops** *hop-count*

**no spanning-tree mst max-hops**

**Parameters**

**max-hops** *hop-count*—Specifies the number of hops in an MST region before the BPDU is discarded. (Range: 1–40)

**Default Configuration**

The default number of hops is 20.

**Command Mode**

Global Configuration mode

**Example**

The following example configures the maximum number of hops that a packet travels in an MST region before it is discarded to 10.

---

```
switchxxxxxx(config)# spanning-tree mst max-hops 10
```

---

## 26.20 spanning-tree mst port-priority

Use the **spanning-tree mst port-priority** Interface Configuration (Ethernet, port-channel) mode command to configure the priority of a port. Use the **no** form of this command to restore the default configuration.

**Syntax**

**spanning-tree mst** *instance-id* **port-priority** *priority*

**no spanning-tree mst** *instance-id* **port-priority**

**Parameters**

- **instance-id**—Specifies the spanning tree instance ID. (Range: 1–15)
- **priority**—Specifies the port priority. (Range: 0–240 in multiples of 16)

**Default Configuration**

The default port priority is 128.

**Command Mode**

Interface Configuration (Ethernet, port-channel) mode

**User Guidelines**

The priority value must be a multiple of 16.

**Example**

The following example configures the port priority of gi1/0/11 to 144.

---

```
switchxxxxxx(config)# interface gi1/0/11  
switchxxxxxx(config-if)# spanning-tree mst 1 port-priority 144
```

---

## 26.21 spanning-tree mst cost

Use the **spanning-tree mst cost** Interface Configuration (Ethernet, Port-channel) mode command to configure the path cost for MST calculations. If a loop occurs, the spanning tree considers path cost when selecting an interface to put in the Forwarding state. Use the **no** form of this command to restore the default configuration.

### Syntax

**spanning-tree mst** *instance-id* **cost** *cost*

**no spanning-tree mst** *instance-id* **cost**

### Default Configuration

N/A

### Parameters

- **instance-id**—Specifies the spanning-tree instance ID. (Range: 1–15)
- **cost**—Specifies the port path cost. (Range: 1–200000000)

### Default Configuration

Default path cost is determined by the port speed and path cost method (long or short) as shown below:

Interface	Long	Short
Port-channel	20,000	4
TenGigabit Ethernet (10000 Mbps)	2000	2
Gigabit Ethernet (1000 Mbps)	20,000	4
Ethernet (10 Mbps)	2,000,000	100

### Command Mode

Interface Configuration (Ethernet, port-channel) mode

### Example

The following example configures the MSTP instance 1 path cost for gigabitethernet port 9 to 4.

```
switchxxxxxx(config)# interface gi1/0/19
switchxxxxxx(config-if)# spanning-tree mst 1 cost 4
```

## 26.22 spanning-tree mst configuration

Use the **spanning-tree mst configuration** Global Configuration mode command to enable configuring an MST region by entering the MST mode.

### Syntax

**spanning-tree mst configuration**

### Command Mode

Global Configuration mode

**User Guidelines**

For two or more switches to be in the same MST region, they must contain the same VLAN mapping, the same configuration revision number, and the same name.

**Example**

The following example configures an MST region.

---

```
switchxxxxxx(config)# spanning-tree mst configuration
switchxxxxxx(config-mst)# instance 1 vlan 10-20
switchxxxxxx(config-mst)# name region1
switchxxxxxx(config-mst)# revision 1
```

---

**26.23 instance (MST)**

Use **instance** MST Configuration mode command to map VLANs to an MST instance. Use the **no** form of this command to restore the default mapping.

**Syntax**

**instance** *instance-id* **vlan** *vlan-range*

**no instance** *instance-id* **vlan** *vlan-range*

**Parameters**

- **instance-id**—MST instance (Range: 1–16)
- **vlan-range**—The specified range of VLANs is added to the existing ones. To specify a range, use a hyphen. To specify a series, use a comma. (Range: 1–4094)

**Default Configuration**

All VLANs are mapped to the common and internal spanning tree (CIST) instance (instance 0).

**Command Mode**

MST Configuration mode

**User Guidelines**

All VLANs that are not explicitly mapped to an MST instance are mapped to the common and internal spanning tree (CIST) instance (instance 0) and cannot be unmapped from the CIST.

For two or more devices to be in the same MST region, they must have the same VLAN mapping, the same configuration revision number, and the same name.

**Example**

The following example maps VLANs 10-20 to MST instance 1.

---

```
switchxxxxxx(config)# spanning-tree mst configuration
switchxxxxxx(config-mst)# instance 1 vlan 10-20
```

---

---

## 26.24 name (MST)

Use the **name** MST Configuration mode command to define the MST instance name. Use the **no** form of this command to restore the default setting.

### Syntax

**name** *string*

**no name**

### Parameters

**string**—Specifies the MST instance name. (Length: 1–32 characters)

### Default Configuration

The default name is the bridge MAC address.

### Command Mode

MST Configuration mode

### Example

The following example defines the instance name as Region1.

---

```
switchxxxxxx(config)# spanning-tree mst configuration
switchxxxxxx(config-mst)# name region1
```

---

## 26.25 revision (MST)

Use the **revision** MST Configuration mode command to define the MST configuration revision number. Use the **no** form of this command to restore the default configuration.

### Syntax

**revision** *value*

**no revision**

### Parameters

**value**—Specifies the MST configuration revision number. (Range: 0–65535)

### Default Configuration

The default configuration revision number is 0.

### Command Mode

MST Configuration mode

### Example

The following example sets the configuration revision to 1.

---

```
switchxxxxxx(config) # spanning-tree mst configuration
switchxxxxxx(config-mst) # revision 1
```

---

## 26.26 show (MST)

Use the **show** MST Configuration mode command to display the current or pending MST region configuration.

### Syntax

**show** {*current* | *pending*}

### Parameters

- **current**—Displays the current MST region configuration.
- **pending**—Displays the pending MST region configuration.

### Default Configuration

N/A

### Command Mode

MST Configuration mode

### Example

The following example displays a pending MST region configuration

```
switchxxxxxx(config-mst)# show pending
Gathering information .....
Current MST configuration
Name: Region1
Revision: 1
Instance  VLANs Mapped          State
-----  -
0         1-4094                      Disabled
switchxxxxxx(config-mst)#
```

---

## 26.27 exit (MST)

Use the **exit** MST Configuration mode command to exit the MST region Configuration mode and apply all configuration changes.

### Syntax

**exit**

### Parameters

N/A

### Default Configuration

N/A

### Command Mode

MST Configuration mode

**Example**

The following example exits the MST Configuration mode and saves changes.

---

```
switchxxxxxx(config)# spanning-tree mst configuration
switchxxxxxx(config-mst)# exit
switchxxxxxx(config)#
```

---

**26.28 abort (MST)**

Use the **abort** MST Configuration mode command to exit the MST Configuration mode without applying the configuration changes.

**Syntax**

**abort**

**Parameters**

N/A

**Default Configuration**

N/A

**Command Mode**

MST Configuration mode

**Example**

The following example exits the MST Configuration mode without saving changes.

---

```
switchxxxxxx(config)# spanning-tree mst configuration
switchxxxxxx(config-mst)# abort
```

---

**26.29 show spanning-tree**

Use the **show spanning-tree** Privileged EXEC mode command to display the spanning-tree configuration.

**Syntax**

**show spanning-tree** [*interface-id*] [*instance instance-id*]

**show spanning-tree** [*detail*] [*active* | *blockedports*] [*instance instance-id*]

**show spanning-tree** *mst-configuration*

**Parameters**

- **instance** *instance-id*—Specifies the spanning tree instance ID. (Range: 1–16)
- **detail**—Displays detailed information.
- **active**—Displays active ports only.
- **blockedports**—Displays blocked ports only.
- **mst-configuration**—Displays the MST configuration identifier.
- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

**Default Configuration**

If no interface is specified, the default is all interfaces.

**Command Mode**

Privileged EXEC mode

**User Guidelines**

This command only works when MST is enabled.

**Example**

The following examples display spanning-tree information in various configurations:

---

```
switchxxxxx# show spanning-tree
Spanning tree enabled mode RSTP
Default port cost method: long
Loopback guard: Disabled

Root ID    Priority          32768
Address    00:01:42:97:e0:00
Cost       20000
Port       gil/0/11

Hello Time 2 sec           Max Age 20 sec Forward Delay 15 sec

Bridge ID  Priority          36864
Address    00:02:4b:29:7a:00

Hello Time 2 sec           Max Age 20 sec Forward Delay 15 sec

Interfaces

Name       State   Prio. No   Cost   Sts   Role   PortFastType
-----
gil/0/11   Enabled 128.1     20000  FWD   Root   No       P2p (RSTP)
gil/0/12   Enabled 128.2     20000  FWD   Desg   No       Shared (STP)
gil/0/13   Disabled 128.3     20000  -     -     -        -
gil/0/14   Enabled 128.4     20000  BLK   Altn   No       Shared (STP)
gil/0/15   Enabled 128.5     20000  DIS   -     -        -
```

---

```
switchxxxxx# show spanning-tree
Spanning tree enabled mode RSTP
Default port cost method: long

Root ID    Priority          36864
Address    00:02:4b:29:7a:00

This switch is the Root.

Hello Time 2 sec           Max Age 20 sec Forward Delay 15 sec

Interfaces
```



Name	State	Prio.Nbr	Cost	Sts	Role	PortFastType
gil/0/11	Enabled	128.1	20000	FWD	Desg	- P2p (RSTP)
gil/0/12	Enabled	128.2	20000	FWD	Desg	No Shared (STP)
gil/0/13	Disabled	128.3	20000	-	-	No -
gil/0/14	Enabled	128.4	20000	FWD	Desg	- Shared (STP)
gil/0/15	Enabled	128.5	20000	DIS	-	No -

---

```
switchxxxxxx# show spanning-tree
```

```
Spanning tree disabled (BPDU filtering) mode RSTP
Default port cost method: long
```

```
Root ID      Priority      N/A
Address      N/A
Path Cost    N/A
Root Port    N/A
Hello Time   N/A      Max Age N/A      Forward Delay N/A
```

```
Bridge ID    Priority      36864
Address      00:02:4b:29:7a:00
Hello Time 2 sec      Max Age 20 sec Forward Delay 15 sec
```

```
Interfaces
```

Name	State	Prio.Nb	Cost	Sts	Role	PortFastType
gil/0/11	Enabled	128.1	20000	-	-	- -
gil/0/12	Enabled	128.2	20000	-	-	- -
gil/0/13	Disabled	128.3	20000	-	-	- -
gil/0/14	Enabled	128.4	20000	-	-	- -
gil/0/15	Enabled	128.5	20000	-	-	- -

---

```
switchxxxxxx# show spanning-tree active
```

```
Spanning tree enabled mode RSTP
Default port cost method: long
```

```
Root ID      Priority      32768
Address      00:01:42:97:e0:00
Path Cost    20000
Root Port    gil/0/11
Hello Time 2 sec      Max Age 20 sec Forward Delay 15 sec
```

```
Bridge ID    Priority      36864
Address      00:02:4b:29:7a:00
Hello Time 2 sec      Max Age 20 sec Forward Delay 15 sec
```

```
Interfaces
```

Name	State	Prio.Nbr	Cost	Sts	Role	PortFastType
-----	-----	-----	-----	---	----	-----
gi1/0/11	Enabled	128.1	20000	FWD	Root	- P2p (RSTP)
gi1/0/12	Enabled	128.2	20000	FWD	Desg	No Shared (STP)
gi1/0/14	Enabled	128.4	20000	BLK	Altn	No Shared (STP)
						No

---

switchxxxxxx# **show spanning-tree blockedports**

Spanning tree enabled mode RSTP  
 Default port cost method: long

Root ID      Priority                    32768  
             Address                    00:01:42:97:e0:00  
             Path Cost                20000  
             Root Port                gi1/0/11  
             Hello Time 2 sec                    Max Age 20 sec Forward Delay 15 sec

Bridge ID    Priority                    36864  
             Address                    00:02:4b:29:7a:00  
             Hello Time 2 sec                    Max Age 20 sec Forward Delay 15 sec

Interfaces

Name	State	Prio.Nbr	Cost	Sts	Role	PortFastType
-----	-----	-----	-----	---	----	-----
gi1/0/14	Enabled	128.4	19	BLK	Altn	No Shared (STP)

---

switchxxxxxx# **show spanning-tree detail**

Spanning tree enabled mode RSTP  
 Default port cost method: long

Root ID      Priority                    32768  
             Address                    00:01:42:97:e0:00  
             Path Cost                20000  
             Root Port                gi1/0/11  
             Hello Time 2 sec                    Max Age 20 sec Forward Delay 15 sec

Bridge ID    Priority                    36864  
             Address                    00:02:4b:29:7a:00  
             Hello Time 2 sec                    Max Age 20 sec Forward Delay 15 sec

Number of topology changes 2 last change occurred 2d18h ago

Times:      hold 1, topology change 35, notification 2  
             hello 2, max age 20, forward delay 15

```

Port 1 (gi1/0/11) enabled
State: Forwarding                               Role: Root
Port id: 128.1                                  Port cost: 20000
Type: P2p (configured: auto) RSTP               Port Fast: No (configured:no)
Designated bridge Priority: 32768               Address: 00:01:42:97:e0:00
Designated port id: 128.25                      Designated path cost: 0
Guard root: Disabled                            BPDU guard: Disabled

Number of transitions to forwarding state: 1
BPDU: sent 2, received 120638

Port 2 (gi1/0/12) enabled
State: Forwarding                               Role: Designated
Port id: 128.2                                  Port cost: 20000
Type: Shared (configured: auto) STP            Port Fast: No (configured:no)
Designated bridge Priority: 32768               Address: 00:02:4b:29:7a:00
Designated port id: 128.2                      Designated path cost: 20000
Guard root: Disabled                            BPDU guard: Disabled

Number of transitions to forwarding state: 1
BPDU: sent 2, received 170638

Port 3 (gi1/0/13) disabled
State: N/A                                       Role: N/A
Port id: 128.3                                  Port cost: 20000
Type: N/A (configured: auto)                   Port Fast: N/A (configured:no)
Designated bridge Priority: N/A                 Address: N/A
Designated port id: N/A                        Designated path cost: N/A
Guard root: Disabled                            BPDU guard: Disabled

Number of transitions to forwarding state: N/A
BPDU: sent N/A, received N/A

Port 4 (gi1/0/14) enabled
State: Blocking                                 Role: Alternate
Port id: 128.4                                  Port cost: 20000
Type: Shared (configured:auto) STP             Port Fast: No (configured:no)
Designated bridge Priority: 28672               Address: 00:30:94:41:62:c8
Designated port id: 128.25                      Designated path cost: 20000
Guard root: Disabled                            BPDU guard: Disabled

Number of transitions to forwarding state: 1
BPDU: sent 2, received 120638

Port 5 (gi1/0/15) enabled
State: Disabled                                 Role: N/A
Port id: 128.5                                  Port cost: 20000
Type: N/A (configured: auto)                   Port Fast: N/A (configured:no)
Designated bridge Priority: N/A                 Address: N/A
Designated port id: N/A                        Designated path cost: N/A
Guard root: Disabled                            BPDU guard: Disabled

Number of transitions to forwarding state: N/A
BPDU: sent N/A, received N/A

```

---

```
switchxxxxxx# show spanning-tree ethernet gil/0/11
Port 1 (gil/0/11) enabled
State: Forwarding                               Role: Root
Port id: 128.1                                   Port cost: 20000
Type: P2p (configured: auto) RSTP               Port Fast: No (configured:no)
Designated bridge Priority: 32768               Address: 00:01:42:97:e0:00
Designated port id: 128.25                      Designated path cost: 0
Guard root: Disabled                           BPDU guard: Disabled

Number of transitions to forwarding state: 1
BPDU: sent 2, received 120638
```

---

```
switchxxxxxx# show spanning-tree mst-configuration
Name: Region1
Revision: 1
```

Instance	Vlans mapped	State
0	1-9, 21-4094	Enabled
1	10-20	Enabled

---

```
switchxxxxxx# show spanning-tree
Spanning tree enabled mode MSTP
Default port cost method: long
##### MST 0 Vlans Mapped: 1-9

CST Root ID      Priority    32768
                 Address     00:01:42:97:e0:00
                 Path Cost  20000
                 Root Port  gil/0/11
                 Hello Time 2 sec   Max Age 20 sec Forward Delay 15 sec

IST Master ID    Priority    32768
                 Address     00:02:4b:29:7a:00
                 This switch is the IST master.
                 Hello Time 2 sec   Max Age 20 sec Forward Delay 15 sec
                 Max hops 20
```

Interfaces

Name	State	Prio.Nbr	Cost	Sts	Role	PortFast	Type
gil/0/11	Enabled	128.1	20000	FWD	Root	No	P2p Bound
gil/0/12	Enabled	128.2	20000	FWD	Desg	No	(RSTP)
gil/0/13	Enabled	128.3	20000	FWD	Desg	No	Shared Bound
gil/0/14	Enabled	128.4	20000	FWD	Desg	No	(STP)
							P2p
							P2p

```
##### MST 1 Vlans Mapped: 10-20
```

```
Root ID          Priority    24576
                Address     00:02:4b:29:89:76
                Path Cost  20000
                Root Port  gil1/0/14
                Rem hops  19
```

```
Bridge ID       Priority    32768
                Address     00:02:4b:29:7a:00
```

#### Interfaces

Name	State	Prio.Nbr	Cost	Sts	Role	PortFast	Type
gil/0/11	Enabled	128.1	20000	FWD	Boun	No	P2p Bound
gil/0/12	Enabled	128.2	20000	FWD	Boun	No	(RSTP)
gil/0/13	Enabled	128.3	20000	BLK	Altn	No	Shared Bound
gil/0/14	Enabled	128.4	20000	FWD	Root	No	(STP)

P2p  
P2p

```
switchxxxxxx# show spanning-tree detail
```

```
Spanning tree enabled mode MSTP
```

```
Default port cost method: long
```

```
##### MST 0 Vlans Mapped: 1-9
```

```
CST Root ID      Priority    32768
                Address     00:01:42:97:e0:00
                Path Cost  20000
                Root Port  gil1/0/11
                Hello Time 2 sec   Max Age 20 sec Forward Delay 15 sec
```

```
IST Master ID    Priority    32768
                Address     00:02:4b:29:7a:00
                This switch is the IST master.
                Hello Time 2 sec   Max Age 20 sec Forward Delay 15 sec
                Max hops 20
                Number of topology changes 2 last change occurred 2d18h
                ago
                Times: hold 1, topology change 35, notification 2
                hello 2, max age 20, forward delay 15
```

```
Port 1 (gil/0/11) enabled
```

```
State: Forwarding
```

```
Port id: 128.1
```

```
Type: P2p (configured: auto) Boundary RSTP
```

```
Designated bridge Priority: 32768
```

```
Designated port id: 128.25
```

```
Number of transitions to forwarding state: 1
```

```
BPDU: sent 2, received 120638
```

```
Role: Root
```

```
Port cost: 20000
```

```
Port Fast: No (configured:no)
```

```
Address: 00:01:42:97:e0:00
```

```
Designated path cost: 0
```

```

Port 2 (gi1/0/12) enabled
State: Forwarding                               Role: Designated
Port id: 128.2                                   Port cost: 20000
Type: Shared (configured: auto) Boundary STP    Port Fast: No (configured:no)
Designated bridge Priority: 32768              Address: 00:02:4b:29:7a:00
Designated port id: 128.2                     Designated path cost: 20000
Number of transitions to forwarding state: 1
BPDU: sent 2, received 170638

```

```

Port 3 (gi1/0/13) enabled
State: Forwarding                               Role: Designated
Port id: 128.3                                   Port cost: 20000
Type: Shared (configured: auto) Internal       Port Fast: No (configured:no)
Designated bridge Priority: 32768              Address: 00:02:4b:29:7a:00
Designated port id: 128.3                     Designated path cost: 20000
Number of transitions to forwarding state: 1
BPDU: sent 2, received 170638

```

```

Port 4 (gi1/0/14) enabled
State: Forwarding                               Role: Designated
Port id: 128.4                                   Port cost: 20000
Type: Shared (configured: auto) Internal       Port Fast: No (configured:no)
Designated bridge Priority: 32768              Address: 00:02:4b:29:7a:00
Designated port id: 128.2                     Designated path cost: 20000
Number of transitions to forwarding state: 1
BPDU: sent 2, received 170638

```

```
##### MST 1 Vlans Mapped: 10-20
```

```

Root ID      Priority    24576
             Address     00:02:4b:29:89:76
             Path Cost  20000
             Root Port  gi1/0/14
             Rem hops  19

```

```

Bridge ID    Priority    32768
             Address     00:02:4b:29:7a:00
             Number of topology changes 2 last change occurred 1d9h
             ago
             Times: hold 1, topology change 2, notification 2
             hello 2, max age 20, forward delay 15

```

```

Port 1 (gi1/0/11) enabled
State: Forwarding                               Role: Boundary
Port id: 128.1                                   Port cost: 20000
Type: P2p (configured: auto) Boundary RSTP    Port Fast: No (configured:no)
Designated bridge Priority: 32768              Address: 00:02:4b:29:7a:00
Designated port id: 128.1                     Designated path cost: 20000
Number of transitions to forwarding state: 1
BPDU: sent 2, received 120638

```

```

Port 2 (gi1/0/12) enabled
State: Forwarding                               Role: Designated
Port id: 128.2                                  Port cost: 20000
Type: Shared (configured: auto) Boundary STP    Port Fast: No (configured:no)
Designated bridge Priority: 32768               Address: 00:02:4b:29:7a:00
Designated port id: 128.2                       Designated path cost: 20000
Number of transitions to forwarding state: 1
BPDU: sent 2, received 170638

```

```

Port 3 (gi1/0/13) disabled
State: Blocking                                 Role: Alternate
Port id: 128.3                                  Port cost: 20000
Type: Shared (configured: auto) Internal        Port Fast: No (configured:no)
Designated bridge Priority: 32768               Address: 00:02:4b:29:1a:19
Designated port id: 128.78                      Designated path cost: 20000
Number of transitions to forwarding state: 1
BPDU: sent 2, received 170638

```

```

Port 4 (gi1/0/14) enabled
State: Forwarding                               Role: Designated
Port id: 128.4                                  Port cost: 20000
Type: Shared (configured: auto) Internal        Port Fast: No (configured:no)
Designated bridge Priority: 32768               Address: 00:02:4b:29:7a:00
Designated port id: 128.2                       Designated path cost: 20000
Number of transitions to forwarding state: 1
BPDU: sent 2, received 170638

```

---

```

switchxxxxxx# show spanning-tree

```

```

Spanning tree enabled mode MSTP
Default port cost method: long
##### MST 0 Vlans Mapped: 1-9

```

```

CST Root ID      Priority    32768
                  Address     00:01:42:97:e0:00
                  Path Cost  20000
                  Root Port   gi1/0/11
                  Hello Time 2 sec   Max Age 20 sec Forward Delay 15 sec

```

```

IST Master ID    Priority    32768
                  Address     00:02:4b:19:7a:00
                  Path Cost  10000
                  Rem hops   19

```

```

Bridge ID        Priority    32768
                  Address     00:02:4b:29:7a:00
                  Hello Time 2 sec   Max Age 20 sec Forward Delay 15 sec
                  Max hops   20

```

---

```

switchxxxxxx# show spanning-tree
Spanning tree enabled mode MSTP
Default port cost method: long

##### MST 0 Vlans Mapped: 1-9
CST Root ID      Priority    32768
                 Address    00:01:42:97:e0:00

                 This switch is root for CST and IST master.
                 Root Port   gi1/0/11
                 Hello Time 2 sec   Max Age 20 sec Forward Delay 15 sec
                 Max hops 20

```

---

## 26.30 show spanning-tree bpdud

Use the **show spanning-tree bpdud** EXEC mode command to display the BPDUD handling when spanning-tree is disabled.

### Syntax

**show spanning-tree bpdud** [*interface-id* | *detailed*]

### Parameters

- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.
- **detailed**—Displays information for non-present ports in addition to present ports.

### Default Configuration

Show information for all interfaces. If detailed is not used, only present ports are displayed.

### Command Mode

EXEC mode

### Example

The following examples display spanning-tree BPDUD information:

```

switchxxxxxx# show spanning-tree bpdud

```

The following is the output if the global BPDUD handling command is not supported.

Interface	Admin Mode	Oper Mode
-----	-----	-----
gi1/0/11	Filtering	Filtering
gi1/0/12	Filtering	Filtering
gi1/0/13	Filtering	Guard

The following is the output if both the global BPDUD handling command and the per-interface BPDUD handling command are supported.



Global: Flooding

Interface	Admin Mode	Oper Mode
-----	-----	-----
gi1/0/11	Global	Flooding
gi1/0/12	Global	STP
gi1/0/13	Flooding	STP

---

## 26.31 spanning-tree loopback-guard

Use the **spanning-tree loopback-guard global configuration** command to shut down an interface if it receives a loopback BPDU. Use the **no** form of this command to return the default setting.

### Syntax

**spanning-tree loopback-guard**

**no spanning-tree loopback-guard**

### Parameters

N/A

### Default Configuration

N/A

### Command Mode

Global

### User Guidelines

This enables shutting down all interfaces if a loopback BPDU is received on it.

### Example

---

```
switchxxxxxx(config)# spanning-tree loopback-guard
```

---



# Virtual Local Area Network (VLAN) Commands

---

## 27.1 vlan database

Use the **vlan database** Global Configuration mode command to enter the VLAN Configuration mode. This mode is used to create VLAN(s) and define the default VLAN.

Use the **exit** command to return to Global Configuration mode.

### Syntax

**vlan database**

### Parameters

N/A

### Default Configuration

VLAN 1 exists by default.

### Command Mode

Global Configuration mode

### Example

The following example enters the VLAN Configuration mode, creates VLAN 1972 and exits VLAN Configuration mode.

---

```
switchxxxxxx(config)# vlan database
switchxxxxxx(config-vlan)# vlan 1972
switchxxxxxx(config-vlan)# exit
switchxxxxxx(config)#
```

---

## 27.2 vlan

Use the **vlan** VLAN Configuration mode or Global Configuration mode command to create a VLAN and assign it a name (if only a single VLAN is being created). Use the **no** form of this command to delete the VLAN(s).

### Syntax

**vlan** *vlan-range*

**no vlan** *vlan-range*

### Parameters

- **vlan-range**—Specifies a list of VLAN IDs to add. Separate nonconsecutive VLAN IDs with a comma and no spaces. Use a hyphen to designate a range of IDs. (Range: 2-4094)

**Default Configuration**

VLAN 1 exists by default.

**Command Mode**

Global Configuration mode

VLAN Configuration mode

**Example**

The following example creates VLAN number 1972.

---

```
switchxxxxxx(config)#vlan database
switchxxxxxx(config-vlan)#vlan 1972
switchxxxxxx(config-vlan)#
```

---

## 27.3 show vlan

Use the **show vlan** Privileged EXEC mode command to display the following VLAN information for all VLANs or for a specific VLAN:

- VLAN ID
- VLAN name
- Ports on the VLAN
- Whether the VLAN was is dynamic or permanent
- Whether authorization is required on the VLAN

**Syntax**

```
show vlan [tag vlan-id | name vlan-name]
```

**Parameters**

- **tag** *vlan-id*—Specifies a VLAN ID.
- **name** *vlan-name*—Specifies a VLAN name string (length: 1–32 characters)

**Default Configuration**

All VLANs are displayed.

**Command Mode**

Privileged EXEC mode

**Examples:**

**Example 1** - The following example displays information for all VLANs:

---

```
switchxxxxxx# show vlan
```

VLAN	Name	Ports	Type	Authorization
1	default	gi1/0/11-2	Default	Required
10	Marketing	gi1/0/13-14	Static	Required
11	VLAN0011	gi1/0/15-16	Static	Required
20	VLAN0020	gi1/0/17-18	Static	Required
21	VLAN0021		Static	Required
30	VLAN0030		Static	Required
31	VLAN0031		Static	Required
91	VLAN0091	gi1/0/12	Dynamic	Not Required
3978	Guest	gi1/0/17	Static	Guest
	VLAN			

---

**Example 2** - The following example displays information for the default VLAN (VLAN 1):

---

```
switchxxxxxx# show vlan tag default
```

VLAN	Name	Ports	Type	Authorization
1	default	gi1/0/11-2	Default	Required

---

**Example 3** - The following example displays information for the VLAN named Marketing:

---

```
switchxxxxxx# show vlan name Marketing
```

VLAN	Name	Ports	Type	Authorization
1	Marketing	gi1/0/13-14	static	Required

---

## 27.4 interface vlan

Use the **interface vlan** Global Configuration mode command to enter the Interface Configuration (VLAN) mode for a specific VLAN. After this command is entered, all commands configure this VLAN. To configure a range of VLANs, use [interface range vlan](#).

**Syntax**

```
interface vlan vlan-id
```

**Parameters**

**vlan *vlan-id***—Specifies the VLAN to be configured.

**Default Configuration**

N/A

**Command Mode**

Global Configuration mode

**User Guidelines**

If the VLAN does not exist (ghost VLAN), some commands are not available under the interface VLAN context.

The commands that are supported for VLANs but do not exist for ghost VLANs are:

- IGMP snooping control commands
- Bridge Multicast configuration commands

**Example**

The following example configures VLAN 1 with IP address 131.108.1.27 and subnet mask 255.255.255.0.

---

```
switchxxxxxx (config)# interface vlan 1
switchxxxxxx (config-if)# ip address 131.108.1.27 255.255.255.0
```

---

## 27.5 interface range vlan

Use the **interface range vlan** Global Configuration mode command to configure multiple VLANs simultaneously.

**Syntax**

**interface range vlan** *vlan-range*

**Parameters**

**vlan** *vlan-range*—Specifies a list of VLANs. Separate nonconsecutive VLANs with a comma and no spaces. Use a hyphen to designate a range of VLANs.

**Default Configuration**

N/A

**Command Mode**

Global Configuration mode

**User Guidelines**

Commands under the interface VLAN range context are executed independently on each VLAN in the range. If the command returns an error on one of the VLANs, an error message is displayed, and the system attempts to configure the remaining VLANs.

If a VLAN does not exist (ghost VLAN), some commands are not available under the interface VLAN context. These are:

- IGMP snooping control commands
- Bridge Multicast configuration commands

**Example**

The following example groups VLANs 221 through 228 and 889 to receive the same command(s).

---

```
switchxxxxxx(config)# interface range vlan 221-228, vlan 889  
switchxxxxxx(config-if)#
```

---

## 27.6 name

Use the **name** Interface Configuration (VLAN) mode command to name a VLAN. Use the **no** form of this command to remove the VLAN name.

**Syntax**

**name** *string*

**no name**

**Parameters**

**string**—Specifies a unique name associated with this VLAN. (Length: 1–32 characters)

**Default Configuration**

No name is defined.

**Command Mode**

Interface Configuration (VLAN) mode. It cannot be configured for a range of interfaces (range context).

**User Guidelines**

The VLAN name must be unique.

**Example**

The following example assigns VLAN 19 the name Marketing.

---

```
switchxxxxxx(config)# interface vlan 19  
switchxxxxxx(config-if)# name Marketing
```

---

## 27.7 switchport

Use the **switchport** Interface Configuration mode command to put an interface that is in Layer 3 mode into Layer 2 mode. Use the **no** form of this command to put an interface in Layer 3 mode.

**Syntax**

**switchport**

**no switchport**

**Parameters**

N/A

**Default Configuration**

Layer 2 mode

**Command Mode**

Interface Configuration (Ethernet, port-channel) mode

**Examples:**

**Example 1** - The following example puts the port gi1 into Layer 2 mode.

---

```
switchxxxxxx(config)# interface gi1
switchxxxxxx(config-if)#switchport
```

---

**Example 2** - The following example puts the port gi1 into Layer 3 mode.

---

```
switchxxxxxx(config)# interface gi1
switchxxxxxx(config-if)#no switchport
```

---

## 27.8 switchport mode

Use the **switchport mode** Interface Configuration (Ethernet, port-channel) mode command to configure the VLAN membership mode (access, trunk, general or customer) of a port. Use the **no** form of this command to restore the default configuration.

**Syntax**

**switchport mode** {*access* | *trunk* | *general* | *customer*}

**no switchport mode**

**Parameters**

- **access**—Specifies an untagged layer 2 VLAN port.
- **trunk**—Specifies a trunking layer 2 VLAN port.
- **general**—Specifies a full 802-1q-supported VLAN port.
- **customer**—Specifies that the port is connected to customer equipment. Used when the switch is in a provider network.

**Default Configuration**

Access mode.

**Command Mode**

Interface Configuration (Ethernet, port-channel) mode

**User Guidelines**

- When the port's mode is changed, it receives the configuration corresponding to the mode.
- If the port mode is changed to access and the access VLAN does not exist, then the port does not belong to any VLAN.
- Trunk and general mode ports can be changed to access mode only if all VLANs (except for an untagged PVID) are first removed.



### Example

The following example configures `gi1/0/11` as an access port (untagged layer 2) VLAN port.

---

```
switchxxxxxx(config)# interface gi1/0/11
switchxxxxxx(config-if)# switchport mode access
switchxxxxxx(config-if)# switchport access vlan 2
```

---

## 27.9 switchport access vlan

A port in access mode can be an untagged member of at most a single VLAN. The **switchport access vlan** Interface Configuration command reassigns an interface to a different VLAN than it currently belongs or assigns it to *none*, in which case it is not a member of any VLAN.

The **no** form of this command to restore the default configuration.

### Syntax

**switchport access vlan** {*vlan-id* | *none*}

**no switchport access vlan**

### Parameters

**vlan** *vlan-id*—Specifies the VLAN to which the port is configured.

**vlan** *none*—Specifies that the access port cannot belong to any VLAN.

### Default Configuration

The interface belongs to the default VLAN.

### Command Mode

Interface Configuration (Ethernet, port-channel) mode

### User Guidelines

When the port is assigned to a different VLAN, it is automatically removed from its previous VLAN and added to the new VLAN. If the port is assigned to *none*, it is removed from the previous VLAN and not assigned to any other VLAN.

If the VLAN specified by the *vlan-id* argument does not exist it is created by the switch automatically.

### Example

The following example assigns access port `gi1` to VLAN `2` (and removes it from its previous VLAN).

---

```
switchxxxxxx(config)# interface gi1/0/12
switchxxxxxx(config-if)# switchport mode access
switchxxxxxx(config-if)# switchport access vlan 2
```

---

## 27.10 switchport trunk allowed vlan

A trunk interface is an untagged member of a single VLAN, and, in addition, it may be an tagged member of one or more VLANs. Use the **switchport trunk allowed vlan** Interface Configuration mode command to add/remove VLAN(s) to/from a trunk port.

### Syntax

**switchport trunk allowed vlan** {*all* | *none* | *add vlan-list* | *remove vlan-list* | *except vlan-list*}

### Parameters

**all**—Specifies all VLANs from 1 to 4094. At any time, the port belongs to all VLANs existing at the time. (Range: 1–4094)

**none**—Specifies an empty VLAN list The port does not belong to any VLAN.

**add *vlan-list***—List of VLAN IDs to add to the port. Separate nonconsecutive VLAN IDs with a comma and no spaces. Use a hyphen to designate a range of IDs.

**remove *vlan-list***—List of VLAN IDs to remove from a port. Separate nonconsecutive VLAN IDs with a comma and no spaces. Use a hyphen to designate a range of IDs.

**except *vlan-list***—List of VLAN IDs is calculated by inverting the defined list of VLANs (the calculated list will include all VLANs from 1 - 4094 except VLANs from the this list).

### Default Configuration

By default, trunk ports belongs to all created VLANs.

### Command Mode

Interface Configuration (Ethernet, port-channel) mode

### User Guidelines

Inside **except *except-vlan-list*** is saved as **add ~ *vlan-list***, where **~ *vlan-list*** is a list of all VLANs from 1 to 4094 minus the VLANs from **except-vlan-list**. The **show running/startup** command always uses the latter format.

The port must be in trunk mode before the command can take effect.

### Example

To add VLANs 2,3 and 100 to trunk ports 1 to 13

```
switchxxxxxx(config)# interface range gi1/0/11-13
switchxxxxxx(config-if)# switchport mode trunk
switchxxxxxx(config-if)# switchport trunk allowed vlan add 2-3,100
switchxxxxxx(config-if)#
```

## 27.11 switchport trunk native vlan

If an untagged packet arrives on a trunk port, it is directed to the port's native VLAN. Use the **switchport trunk native vlan** Interface Configuration (Ethernet, port-channel) mode command to define the native VLAN for a trunk interface. Use the **no** form of this command to restore the default native VLAN.

### Syntax

**switchport trunk native vlan** {*vlan-id* | *none*}

**no switchport trunk native vlan**

**Parameters**

- **vlan-id**—Specifies the native VLAN ID.
- **none**—Specifies the access port cannot belong to any VLAN.

**Default Configuration**

If the default VLAN is enabled, the default native VLAN is 1. Otherwise, the default native VLAN is 4095.

**Command Mode**

Interface Configuration (Ethernet, port-channel) mode

**User Guidelines**

The command adds the port as a member of the VLAN. If the port is already a member of the VLAN (not a native), it must first be removed from the VLAN.

**Examples:**

**Example 1** - The following example:

- Defines VLAN 2 as native VLAN for port 1
- Removes VLAN 2 from port 1 and then sets it as the native VLAN

---

```
switchxxxxxx(config)# interface gi1/0/11
switchxxxxxx(config-if)# switchport trunk native vlan 2
Port 1: Port is Trunk in VLAN 2.
switchxxxxxx(config-if)# switchport trunk allowed vlan remove 2
switchxxxxxx(config-if)# switchport trunk native vlan 2
switchxxxxxx(config-if)#
```

---

**Example 2** - The following example sets packets on port as untagged on ingress and untagged on egress:

---

```
switchxxxxxx(config)# interface gi1/0/11
switchxxxxxx(config-if)# switchport mode trunk
switchxxxxxx(config-if)# switchport trunk native vlan 2
switchxxxxxx(config-if)#
```

---

**Example 3** - The following example sets packets on port are tagged on ingress and tagged on egress:

---

```
switchxxxxxx(config)# interface gi1/0/11
switchxxxxxx(config-if)# switchport mode trunk
switchxxxxxx(config-if)# switchport trunk allowed vlan add 2
switchxxxxxx(config-if)#
```

---

## 27.12 switchport general allowed vlan

General ports can receive tagged or untagged packets. Use the **switchport general allowed vlan** Interface Configuration mode command to add/remove VLANs to/from a general port and configure whether packets on the egress are tagged or untagged. Use the **no** form of this command to reset to the default.

### Syntax

**switchport general allowed vlan** {add | remove} *vlan-list* [**tagged** | **untagged**]

**no switchport general allowed vlan**

### Parameters

- **add** *vlan-list*—List of VLAN IDs to add. Separate nonconsecutive VLAN IDs with a comma and no spaces. Use a hyphen to designate a range of IDs. (Range: 1–4094)
- **remove** *vlan-list*—List of VLAN IDs to remove. Separate nonconsecutive VLAN IDs with a comma and no spaces. Use a hyphen to designate a range of IDs.
- **tagged**—Specify that packets are transmitted tagged for the configured VLANs
- **untagged**—Specify that packets are transmitted untagged for the configured VLANs (this is the default)

### Default Configuration

The port is not a member of any VLAN.

Packets are transmitted untagged.

### Command Mode

Interface Configuration mode

### Example

Sets port 1 to general mode and adds VLAN 2 and 3 to it. Packets are tagged on the egress.

```
switchxxxxxx(config)# interface gi1/0/11
switchxxxxxx(config-if)# switchport mode general
switchxxxxxx(config-if)# switchport general allowed vlan add 2-3 tagged
```

## 27.13 switchport general pvid

The port VLAN ID (PVID) is the VLAN to which incoming untagged and priority-tagged frames are classified on a general port. Use the **switchport general pvid** Interface Configuration (Ethernet, Port-channel) mode command to configure the Port VLAN ID (PVID) of an interface when it is in general mode. Use the **no** form of this command to restore the default configuration.

### Syntax

**switchport general pvid** *vlan-id*

**no switchport general pvid**

### Parameters

**pvid** *vlan-id*—Specifies the Port VLAN ID (PVID).

### Default Configuration

The default VLAN is the PVID.

**Command Mode**

Interface Configuration (Ethernet, Port-channel) mode

**Example****Example 1** - The following example configures port 2 as a general port and sets its PVID to 234.

---

```
switchxxxxxx(config)# interface gi1/0/12
switchxxxxxx(config-if)# switchport mode general
switchxxxxxx(config-if)# switchport general pvid 234
```

---

**Example 2** - Performs the following:

- Adds VLANs 2&3 as tagged, and VLAN 100 as untagged to general mode port 14
  - Defines VID 100 as the PVID
  - Reverts to the default PVID (VID=1)
- 

```
switchxxxxxx(config)# interface gi1/0/114
switchxxxxxx(config-if)# switchport mode general
switchxxxxxx(config-if)# switchport general allowed vlan add 2-3 tagged
switchxxxxxx(config-if)# switchport general allowed vlan add 100 untagged
switchxxxxxx(config-if)# switchport general pvid 100
switchxxxxxx(config-if)# no switchport general pvid
switchxxxxxx(config-if)#
```

---

**Example 3** - Configures VLAN on port 14 as untagged on input and untagged on output:

---

```
switchxxxxxx(config)# interface gi1/0/114
switchxxxxxx(config-if)# switchport mode general
switchxxxxxx(config-if)# switchport general pvid 2
switchxxxxxx(config-if)# switchport general allowed vlan add 2 untagged
switchxxxxxx(config-if)#
```

---

**Example 4** - Configures VLAN on port 21 as untagged on input and tagged on output:

---

```
switchxxxxxx(config)# interface gi1/0/121
switchxxxxxx(config-if)# switchport mode general
switchxxxxxx(config-if)# switchport general pvid 2
switchxxxxxx(config-if)# switchport general allowed vlan add 2 tagged
switchxxxxxx(config-if)#
```

---

**Example 5** - Configures VLAN on port 14 as tagged on input and tagged on output:

---

```
switchxxxxxx(config)# interface gi1/0/114
switchxxxxxx(config-if)# switchport mode general
switchxxxxxx(config-if)# switchport general allowed vlan add 2 tagged
```

---

```
switchxxxxxx(config-if)#
```

---

**Example 6** - Configures VLAN on port 23 as tagged on input and untagged on output:

---

```
switchxxxxxx(config)# interface gi1/0/123
switchxxxxxx(config-if)# switchport mode general
switchxxxxxx(config-if)# switchport general allowed vlan add 2 tagged
switchxxxxxx(config-if)#
```

---

## 27.14 switchport general ingress-filtering disable

Use the **switchport general ingress-filtering disable** Interface Configuration (Ethernet, Port-channel) mode command to disable port ingress filtering (no packets are discarded at the ingress) on a general port. Use the **no** form of this command to restore the default configuration.

### Syntax

**switchport general ingress-filtering disable**

**no switchport general ingress-filtering disable**

### Parameters

N/A

### Default Configuration

Ingress filtering is enabled.

### Command Mode

Interface Configuration (Ethernet, port-channel) mode

### Example

The following example disables port ingress filtering on `gi1/0/11`.

---

```
switchxxxxxx(config)# interface gi1/0/11
switchxxxxxx(config-if)# switchport mode general
switchxxxxxx(config-if)# switchport general ingress-filtering disable
```

---

## 27.15 switchport general acceptable-frame-type

The **switchport general acceptable-frame-type** Interface Configuration mode command configures the types of packets (tagged/untagged) that are filtered (discarded) on the interface. Use the **no** form of this command to return ingress filtering to the default.

### Syntax

**switchport general acceptable-frame-type** {*tagged-only* | *untagged-only* | *all*}

**no switchport general acceptable-frame-type**

### Parameters

- **tagged-only**—Ignore (discard) untagged packets and priority-tagged packets.
- **untagged-only**—Ignore (discard) VLAN-tagged packets (not including priority-tagged packets)
- **all**—Do not discard packets untagged or priority-tagged packets.

**Default Configuration**

All frame types are accepted at ingress (**all**).

**Command Mode**

Interface Configuration (Ethernet, port-channel) mode

**Example**

The following example configures port `gi1/0/13` to be in general mode and to discard untagged frames at ingress.

---

```
switchxxxxxx(config)# interface gi1/0/13
switchxxxxxx(config-if)# switchport mode general
switchxxxxxx(config-if)# switchport general acceptable-frame-type tagged-only
```

---

## 27.16 map protocol protocols-group

Forwarding of packets based on their protocol requires setting up groups of protocols and then mapping these groups to VLANs. Use the **map protocol protocols-group** VLAN Configuration mode command to map a protocol to a group of protocols. This protocol group can then be used in [switchport general map protocols-group vlan](#). Use the **no** form of this command to delete a protocol from a group.

**Syntax**

**map protocol** *protocol* [*encapsulation-value*] **protocols-group** *group*

**no map protocol** *protocol* [*encapsulation*]

**Parameters**

- **protocol**—Specifies a 16-bit protocol number or one of the reserved names listed in the User Guidelines. (Range: 0x0600–0xFFFF)
- **encapsulation-value**—Specifies one of the following values: Ethernet, rfc1042, llcOther.
- **protocols-group group**—Specifies the group number of the group of protocols (Range: 1–2147483647).

**Default Configuration**

The default encapsulation value is Ethernet.

**Command Mode**

VLAN Configuration mode

**User Guidelines**

The value 0x8100 is not valid as the protocol number for Ethernet encapsulation.

The following protocol names are reserved for Ethernet Encapsulation:

- ip
- arp
- ipv6
- ipx

**Example**

The following example maps the IP protocol to protocol group number 213.

---

```
switchxxxxxx(config)# vlan database  
switchxxxxxx(config-vlan)# map protocol ip protocols-group 213
```

---

## 27.17 switchport general map protocols-group vlan

Use the **switchport general map protocols-group vlan** Interface Configuration (Ethernet, Port-channel) mode command to forward packets based on their protocol, otherwise known as setting up a classifying rule. This command forwards packets arriving on an interface containing a specific protocol to a specific VLAN.

Use the no form of this command to stop forwarding packets based on their protocol.

**Syntax**

**switchport general map protocols-group** *group* **vlan** *vlan-id*

**no switchport general map protocols-group** *group*

**Parameters**

- **group**—Specifies the group number as defined in [map protocol protocols-group](#) (Range: 1–65535).
- **vlan** *vlan-id*—Defines the VLAN ID in the classifying rule.

**Default Configuration**

N/A

**Command Mode**

Interface Configuration (Ethernet, port-channel) mode

**User Guidelines**

The VLAN classification rule priorities are:

4. MAC-based VLAN (best match among the rules)
5. Subnet-based VLAN (best match among the rules)
6. Protocol-based VLAN
7. PVID

**Example**

The following example forwards packets with protocols belong to protocol-group 1 to VLAN 8.

---

```
switchxxxxxx(config-if)# switchport general map protocols-group 1 vlan 8
```

---

## 27.18 show vlan protocols-groups

Use the **show vlan protocols-groups** EXEC mode command to display the protocols that belong to the defined protocols-groups.

**Syntax**

**show vlan protocols-groups**

**Parameters**

N/A



**Default Configuration**

N/A

**Command Mode**

EXEC mode

**Example**

The following example displays protocols-groups information.

---

```
switchxxxxxx# show vlan protocols-groups
```

Encapsulation	Protocol	Group ID
-----	-----	-----
Ethernet	0x800 (IP)	1
Ethernet	0x806 (ARP)	1
Ethernet	0x86dd (IPv6)	2
Ethernet	0x8898	3

---

## 27.19 map mac macs-group

Forwarding of packets based on their MAC address requires setting up groups of MAC addresses and then mapping these groups to VLANs.

Use the **map mac macs-group** VLAN Configuration mode command to map a MAC address or range of MAC addresses to a group of MAC addresses, which is then used in [switchport general map macs-group vlan](#). Use the **no** form of this command to delete the mapping.

**Syntax**

```
map mac mac-address {prefix-mask | host} macs-group group
```

```
no map mac mac-address {prefix-mask | host}
```

**Parameters**

- **mac mac-address**—Specifies the MAC address to be mapped to the group of MAC addresses.
- **prefix-mask**—Specifies the number of ones in the mask.
- **host**—Specifies that the mask is comprised of all 1s.
- **macs-group group**—Specifies the group number (Range: 1–2147483647)

**Default Configuration**

N/A

**Command Mode**

VLAN Configuration mode

**Example**

The following example creates two groups of MAC addresses, sets a port to general mode and maps the groups of MAC addresses to specific VLANs.

---

```
switchxxxxxx(config)# vlan database
switchxxxxxx(config-vlan)# map mac 0000.1111.0000 32 macs-group 1
switchxxxxxx(config-vlan)# map mac 0000.0000.2222 host macs-group 2
switchxxxxxx(config-vlan)# exit
```

```
switchxxxxxx(config)# interface gi1/0/111
switchxxxxxx(config-if)# switchport mode general
switchxxxxxx(config-if)# switchport general map macs-group 1 vlan 2
switchxxxxxx(config-if)# switchport general map macs-group 2 vlan 3
```

---

## 27.20 switchport general map macs-group vlan

After groups of MAC addresses have been created (see [map mac macs-group](#)), they can be mapped to specific VLANs.

Use the **switchport general map macs-group vlan** Interface Configuration (Ethernet, Port-channel) mode command to set a MAC-based classification rule. Use the no form of this command to delete a classification rule.

### Syntax

**switchport general map macs-group** *group* **vlan** *vlan-id*

**no switchport general map macs-group** *group*

### Parameters

- **macs-group** *group*—Specifies the group number (Range: 1–2147483647)
- **vlan** *vlan-id*—Defines the VLAN ID associated with the rule.

### Default Configuration

N/A

### Command Mode

Interface Configuration (Ethernet, port-channel) mode

### User Guidelines

MAC-based VLAN rules cannot contain overlapping ranges on the same interface.

The VLAN classification rule priorities are:

1. MAC-based VLAN (Best match among the rules).
2. Subnet-based VLAN (Best match among the rules).
3. Protocol-based VLAN.
4. PVID.

### Example

The following example creates two groups of MAC addresses, sets a port to general mode and maps the groups of MAC addresses to specific VLANs.

---

```
switchxxxxxx(config)# vlan database
switchxxxxxx(config-vlan)# map mac 0000.1111.0000 32 macs-group 1
switchxxxxxx(config-vlan)# map mac 0000.0000.2222 host macs-group 2
switchxxxxxx(config-vlan)# exit
switchxxxxxx(config)# interface gi1/0/111
switchxxxxxx(config-if)# switchport mode general
switchxxxxxx(config-if)# switchport general map macs-group 1 vlan 2
switchxxxxxx(config-if)# switchport general map macs-group 2 vlan 3
```

## 27.21 show vlan macs-groups

Use the **show vlan macs-groups** EXEC mode command to display the MAC addresses that belong to the defined MACs-groups.

### Syntax

**show vlan macs-groups**

### Parameters

N/A

### Default Configuration

N/A

### Command Mode

EXEC mode

### Example

The following example displays macs-groups information.

```
switchxxxxxx# show vlan macs-groups
```

MAC Address	Mask	Group ID
00:12:34:56:78:90	20	22
00:60:70:4c:73:ff	40	1

## 27.22 map subnet subnets-group

Forwarding of packets based on their IP subnet requires setting up groups of IP subnets and then mapping these groups to VLANs. Use the **map subnet subnets-group** VLAN Configuration mode command to map an IP subnet to a group of IP subnets. Use the **no** form of this command to delete the map.

### Syntax

**map subnet** *ip-address prefix-mask* **subnets-group** *group*

**no map subnet** *ip-address prefix-mask*

### Parameters

- **ip-address**—Specifies the IP address prefix of the subnet to be mapped to the group.
- **prefix-mask**—Specifies the number of 1s in the mask.
- **subnets-group** *group*—Specifies the group number. (Range: 1–2147483647)

### Default Configuration

N/A

### Command Mode

VLAN Configuration mode

**Example**

The following example maps an IP subnet to the group of IP subnets 4. It then maps this group of IP subnets to VLAN 8

---

```
switchxxxxxx(config)#vlan database
switchxxxxxx(config-vlan)# map subnet 172.16.1.1 24 subnets-group 4
switchxxxxxx(config-if)# switchport general map subnets-group 4 vlan 8
```

---

**27.23 switchport general map subnets-group vlan**

Use the **switchport general map subnets-group vlan** Interface Configuration (Ethernet, Port-channel) mode command to set a subnet-based classification rule. Use the **no** form of this command to delete a subnet-based classification rule.

**Syntax**

**switchport general map subnets-group** *group* **vlan** *vlan-id*

**no switchport general map subnets-group** *group*

**Parameters**

- **group**—Specifies the group number. (Range: 1–2147483647)
- **vlan-id**—Defines the VLAN ID associated with the rule.

**Default Configuration**

N/A

**Command Mode**

Interface Configuration (Ethernet, Port-channel) mode

**User Guidelines**

The VLAN classification rule priorities are:

1. MAC-based VLAN (Best match among the rules)
2. Subnet-based VLAN (Best match among the rules)
3. Protocol-based VLAN
4. PVID

**Example**

The following example maps an IP subnet to the group of IP subnets 4. It then maps this group of IP subnets to VLAN 8

---

```
switchxxxxxx(config)#vlan database
switchxxxxxx(config-vlan)# map subnet 172.16.1.1 24 subnets-group 4
switchxxxxxx(config-if)# switchport general map subnets-group 4 vlan 8
```

---

**27.24 show vlan subnets-groups**

Use the **show vlan subnets-groups** EXEC mode command to display subnets-groups information.

**Syntax**

**show vlan subnets-groups**

**Parameters**

N/A

**Default Configuration**

N/A

**Command Mode**

EXEC mode

**Example**

The following example displays subnets-groups information.

---

```
switchxxxxxx# show vlan subnets-groups
```

IP Subnet Address	Mask	Group ID
-----	-----	-----
1.1.1.1	32	1
172.16.2.0	24	2

---

## 27.25 switchport forbidden default-vlan

Use the **switchport forbidden default-vlan** Interface Configuration command to forbid a port from being added to the default VLAN. Use the no form of this command to revert to default.

**Syntax****switchport forbidden default-vlan****no switchport forbidden default-vlan****Parameters**

N/A

**Default Configuration**

Membership in the default VLAN is allowed.

**Command Mode**

Interface and Interface range configuration (Ethernet, port-channel)

**User Guidelines**

The command may be used at any time regardless of whether the port belongs to the default VLAN.

The **no** command does not add the port to the default VLAN, it only defines an interface as permitted to be a member of the default VLAN, and the port will be added only when conditions are met.

**Example**

The following example forbids the port gi1 from being added to the default VLAN.

---

```
switchxxxxxx(config)#interface gi1
switchxxxxxx(config-if)# switchport forbidden default-vlan
```

---

## 27.26 switchport forbidden vlan

The **switchport forbidden vlan** Interface Configuration (Ethernet, Port-channel) mode command forbids adding or removing specific VLANs to or from a port. To restore the default configuration, use the **no** form of this command.

### Syntax

**switchport forbidden vlan** {**add** *vlan-list* | **remove** *vlan-list*}

**no switchport forbidden vlan** {**add** *vlan-list* | **remove** *vlan-list*}

### Parameters

- **add** *vlan-list* — Specifies a list of VLAN IDs to add. Separate nonconsecutive VLAN IDs with a comma and no spaces; use a hyphen designate a range of IDs.
- **remove** *vlan-list* — Specifies a list of VLAN IDs to remove. Separate nonconsecutive VLAN IDs with a comma and no spaces; use a hyphen designate a range of IDs.

### Default Configuration

All VLANs are allowed.

### Command Mode

Interface Configuration (Ethernet, Port-channel) mode

### Example

The following example forbids adding VLAN IDs 234 to 256 to *gi1/0/17*.

---

```
switchxxxxxx(config)# interface gi1/0/17
switchxxxxxx(config-if)# switchport mode trunk
switchxxxxxx(config-if)# switchport forbidden vlan add 234-256
```

---

## 27.27 switchport default-vlan tagged

Use the **switchport default-vlan tagged** Interface Configuration command to configure the port as a tagged port in the default VLAN. Use the **no** form of the command to return the port to an untagged port.

### Syntax

**switchport default-vlan tagged**

**no switchport default-vlan tagged**

### Parameters

N/A

### Default Configuration

If the port is a member in the default VLAN, by default, it is a member as an untagged port.

### Command Mode

Interface configuration (Ethernet, port-channel)

### User Guidelines

The command adds a port to the default VLAN as a tagged port.

The command is available only if the port mode is trunk or general.

When a trunk port is a member in the default VLAN as a tagged port then:

- The native VLAN cannot be the default VLAN
- The default of the native VLAN is 4095

Note: If the native VLAN of a port is the default VLAN when the port is added to the default VLAN as tagged, the native VLAN is set by the system to 4095.

When a general port is a member in the default VLAN as a tagged port then:

- The PVID can be the default VLAN.
- The default PVID is the default VLAN.

Note: The PVID is not changed when the port is added to the default VLAN as a tagged.

When executing the **switchport default-vlan tagged** command, the port is added (automatically by the system) to the default VLAN when the following conditions no longer exist:

- The port is a member in a LAG.
- The port is 802.1X unauthorized.
- An IP address is defined on the port.
- The port is a destination port of port mirroring.
- An IP address is defined on the default VLAN and the port is a PVE protected port.

The **no switchport default-vlan tagged** command removes the port from the default VLAN, and returns the default VLAN mode to untagged.

Note:

- If the native VLAN of a trunk port is 4095 when the port is removed from the default VLAN (as a tagged), the native VLAN is set by the system to the default VLAN.
- The PVID of a general port is not changed when the port is removed from the default VLAN (as a tagged). If the PVID is the default VLAN, the port is added by the system to the default VLAN as an untagged.

### Example

The following example configures the port gi1/0/11 as a tagged port in the default VLAN.

```
switchxxxxxx(config)#interface gi1
switchxxxxxx(config-if)# switchport mode trunk
switchxxxxxx(config-if)#switchport default-vlan tagged
```

## 27.28 show interfaces switchport

Use the **show interfaces switchport** Privileged EXEC command to display the administrative and operational status of all interfaces or a specific interface.

### Syntax

**show interfaces switchport** [*interface-id*]

### Parameters

**interface-id**—Specify an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel

### Default Configuration

Displays information for all interfaces.

**Command Mode**

EXEC mode

**Examples:****Example 1** - The following example displays the the command output for a trunk port:

---

```

switchxxxxxx# show interfaces switchport gil/0/11
Port gil/0/11:
Port Mode: Trunk
Gvrp Status: disabled
Ingress Filtering: true
Acceptable Frame Type: admitAll
Ingress UnTagged VLAN ( NATIVE ): 2

Port gil/0/11 is member in:
  VLAN   Name           Egress Rule  Type
  ----   -
  1      default        untagged     System
  8      VLAN008        tagged       Dynamic
  11     VLAN0011       tagged       Static
  19     IPv6VLAN       untagged     Static
  72     VLAN0072       untagged     Static

Forbidden VLANS:
  VLAN   Name
  ----   -
  73     Out

Classification rules:
Mac based VLANs:
  Group ID  Vlan ID

```

## 27.29 ip internal-usage-vlan

The system assigns a VLAN to every IP address. In rare cases, this might conflict with a user requirement for that VLAN. In this case, use the **ip internal-usage-vlan** Interface Configuration (Ethernet, Port-channel) mode command to reserve a different VLAN as the internal usage VLAN of an interface. Use the **no** form of this command to restore the default configuration.

**Syntax****ip internal-usage-vlan** *vlan-id***no ip internal-usage-vlan****Parameters****vlan-id**—Specifies the internal usage VLAN ID.**Default Configuration**

No VLAN is reserved as an internal usage VLAN by default (using this command).



### Command Mode

Interface Configuration (Ethernet, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

### User Guidelines

An internal usage VLAN is assigned by the system when an IP interface is defined on an Ethernet port or port-channel.

If an internal usage VLAN is not defined for a port, the software selects one of the unused VLANs.

If a VLAN was chosen by the software for internal usage, but you want to use that VLAN for a static or dynamic VLAN, do one of the following:

- Remove the IP address from the interface (this releases the internal usage VLAN).
- Recreate the VLAN on the required interface (now it will be assigned to the interface and not be used as an internal usage VLAN)
- Recreate the IP interface (another internal usage VLAN is assigned to this IP interface) or use this command to explicitly define the internal usage VLAN.

### Example

The following example reserves unused VLAN 200 as the internal usage VLAN of gi1/0/13.

---

```
switchxxxxxx(config)# interface gi1/0/13
switchxxxxxx(config-if)# ip internal-usage-vlan 200
```



---

## 28.1 ip igmp snooping (Global)

Use the **ip igmp snooping** Global Configuration mode command to enable Internet Group Management Protocol (IGMP) snooping. Use the **no** form of this command to disable IGMP snooping.

### Syntax

**ip igmp snooping**

**no ip igmp snooping**

### Default Configuration

Disabled.

### Command Mode

Global Configuration mode

### Example

The following example enables IGMP snooping.

---

```
switchxxxxxx(config)# ip igmp snooping
```

---

## 28.2 ip igmp snooping vlan

Use the **ip igmp snooping vlan** Global Configuration mode command to enable IGMP snooping on a specific VLAN. Use the **no** form of this command to disable IGMP snooping on a VLAN interface.

### Syntax

**ip igmp snooping vlan** *vlan-id*

**no ip igmp snooping vlan** *vlan-id*

### Parameters

**vlan** *vlan-id*—Specifies the VLAN.

### Default Configuration

Disabled

### Command Mode

Global Configuration mode

### User Guidelines

IGMP snooping can be enabled only on static VLANs.

IGMPv1, IGMPv2 and IGMPv3 are supported.

To activate IGMP snooping, the [bridge multicast filtering](#) should be enabled.

The user guidelines of the [bridge multicast mode](#) Interface VLAN Configuration command describes the configuration that is written into the FDB as a function of the FDB mode and the IGMP version that is used in the network.

### Example

---

```
switchxxxxxx(config)# ip igmp snooping vlan 2
```

---

## 28.3 ip igmp snooping vlan mrouter

Use the **ip igmp snooping vlan mrouter** Global Configuration mode command to enable automatic learning of Multicast router ports on a VLAN. Use the **no** form of this command to remove the configuration.

### Syntax

**ip igmp snooping vlan *vlan-id* mrouter learn pim-dvmrp**

**no ip igmp snooping vlan *vlan-id* mrouter learn pim-dvmrp**

### Parameters

**vlan *vlan-id***—Specifies the VLAN.

### Default Configuration

Learning **pim-dvmrp** is enabled.

### Command Mode

Global Configuration mode

### User Guidelines

Multicast router ports are learned according to:

- Queries received on the port
- PIM/PIMv2 received on the port
- DVMRP received on the port
- MRDISC received on the port
- MOSPF received on the port

You can execute the command before the VLAN is created.

### Example

---

```
switchxxxxxx(config)# ip igmp snooping vlan 1 mrouter learn pim-dvmrp
```

---

## 28.4 ip igmp snooping vlan mrouter interface

Use the **ip igmp snooping mrouter interface** Global Configuration mode command to define a port that is connected to a Multicast router port. Use the **no** form of this command to remove the configuration.

### Syntax

**ip igmp snooping vlan** *vlan-id* **mrouter interface** *interface-list*

**no ip igmp snooping vlan** *vlan-id* **mrouter interface** *interface-list*

### Parameters

- **vlan** *vlan-id*—Specifies the VLAN.
- **interface** *interface-list*—Specifies the list of interfaces. The interfaces can be one of the following types: Ethernet port or Port-channel.

### Default Configuration

No ports defined

### Command Mode

Global Configuration mode

### User Guidelines

A port that is defined as a Multicast router port receives all IGMP packets (reports and queries) as well as all Multicast data.

You can execute the command before the VLAN is created.

### Example

---

```
switchxxxxxx(config)# ip igmp snooping vlan 1 mrouter interface gi1/0/11
```

---

---

## 28.5 ip igmp snooping vlan forbidden mrouter

Use the **ip igmp snooping vlan forbidden mrouter** Global Configuration mode command to forbid a port from being defined as a Multicast router port by static configuration or by automatic learning. Use the **no** form of this command to remove the configuration.

### Syntax

**ip igmp snooping vlan** *vlan-id* **forbidden mrouter interface** *interface-list*

**no ip igmp snooping vlan** *vlan-id* **forbidden mrouter interface** *interface-list*

### Parameters

- **vlan** *vlan-id*—Specifies the VLAN.
- **interface** *interface-list*—Specifies a list of interfaces. The interfaces can be from one of the following types: Ethernet port or Port-channel.

### Default Configuration

No ports defined.

### Command Mode

Global Configuration mode

**User Guidelines**

A port that is a forbidden mrouter port cannot be a Multicast router port (i.e. cannot be learned dynamically or assigned statically).

You can execute the command before the VLAN is created.

**Example**


---

```
switchxxxxxx(config)# ip igmp snooping vlan 1 forbidden mrouter interface
                        gil/0/11
```

---

**28.6 ip igmp snooping vlan static**

Use the **ip igmp snooping vlan static** Global Configuration mode command to register an IP-layer Multicast address to the bridge table, and to add static ports to the group defined by this address. Use the **no** form of this command to remove ports specified as members of a static Multicast group.

**Syntax**

**ip igmp snooping vlan** *vlan-id* **static** *ip-address* [**interface** *interface-list*]

**no ip igmp snooping vlan** *vlan-id* **static** *ip-address* [**interface** *interface-list*]

**Parameter**

- **vlan** *vlan-id*—Specifies the VLAN.
- **static** *ip-address*—Specifies the IP Multicast address.
- **interface** *interface-list*—Specifies a list of interfaces. The interfaces can be from one of the following types: Ethernet port or Port-channel.

**Default Configuration**

No Multicast addresses are defined.

**Command Mode**

Global Configuration mode

**User Guidelines**

Static Multicast addresses can only be defined on static VLANs.

You can execute the command before the VLAN is created.

You can register an entry without specifying an interface.

Using the **no** command without a port-list removes the entry.

**Example**


---

```
switchxxxxxx(config)# ip igmp snooping vlan 1 static 239.2.2.2 interface
                        gil/0/11
```

---

---

## 28.7 ip igmp snooping vlan querier

Use the **ip igmp snooping vlan querier** Global Configuration mode command to enable the Internet Group Management Protocol (IGMP) querier on a specific VLAN. Use the **no** form of this command to disable the IGMP querier on a VLAN interface.

### Syntax

**ip igmp snooping vlan** *vlan-id* **querier**

**no ip igmp snooping vlan** *vlan-id* **querier**

### Parameters

**vlan** *vlan-id*—Specifies the VLAN

### Default Configuration

Disabled

### Command Mode

Global Configuration mode

### User Guidelines

The IGMP snooping querier can be enabled on a VLAN only if IGMP snooping is enabled for that VLAN.

At most one switch can be configured as an IGMP Querier for a VLAN.

When the IGMP snooping querier is enabled, it starts after a host-time-out/2 with no IGMP traffic being detected from a Multicast router.

The IGMP Snooping Querier disables itself if it detects IGMP traffic from a Multicast router. It restarts automatically after host-time-out/2.

### Example

---

```
switchxxxxxx(config)# ip igmp snooping vlan 1 querier
```

---

## 28.8 ip igmp snooping vlan querier address

Use the **ip igmp snooping vlan querier address** Global Configuration mode command to define the source IP address that the IGMP snooping querier uses. Use the **no** form of this command to return to default.

### Syntax

**ip igmp snooping vlan** *vlan-id* **querier address** *ip-address*

**no ip igmp snooping vlan** *vlan-id* **querier address**

### Parameters

- **vlan** *vlan-id*—Specifies the VLAN.
- **querier address** *ip-address*—Source IP address.

### Default Configuration

If an IP address is configured for the VLAN, it is used as the source address of the IGMP snooping querier. If there are multiple IP addresses, the minimum IP address defined on the VLAN is used.

### Command Mode

Global Configuration mode

### User Guidelines

If an IP address is not configured by this command, and no IP address is configured for the querier's VLAN, the querier is disabled.

### Example

```
switchxxxxxx(config)# ip igmp snooping vlan 1 querier address 10.5.234.205
```

---

## 28.9 ip igmp snooping vlan querier version

Use the **ip igmp snooping vlan querier version** Global Configuration mode command to configure the IGMP version of an IGMP querier on a specific VLAN. Use the **no** form of this command to return to the default version.

### Syntax

**ip igmp snooping vlan** *vlan-id* **querier version** {2 | 3}

**no ip igmp snooping vlan** *vlan-id* **querier version**

### Parameters

- **vlan** *vlan-id*—Specifies the VLAN.
- **querier version 2**—Specifies that the IGMP version would be IGMPv2.
- **querier version 3**—Specifies that the IGMP version would be IGMPv3.

### Default Configuration

IGMPv2.

### Command Mode

Global Configuration mode

### Example

```
switchxxxxxx(config)# ip igmp snooping vlan 1 querier version 3
```

---

## 28.10 ip igmp robustness

Use the **ip igmp robustness** Interface Configuration (VLAN) mode command to set the IGMP robustness variable on a VLAN. Use the **no** format of the command to return to default.

### Syntax

**ip igmp robustness** *count*

**no ip igmp robustness**

### Parameters

*count*—The number of expected packet loss on a link. Parameter range. (Range: 1–7)

### Default Configuration

2

### Command Mode

Interface Configuration (VLAN) mode



### User Guidelines

You can execute the command before the VLAN is created, but you must enter the command in Interface VLAN mode.

### Example

---

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ip igmp robustness 3
```

---

## 28.11 ip igmp query-interval

Use the **ip igmp query-interval** Interface Configuration (VLAN) mode command to configure the Query interval on a VLAN. Use the **no** format of the command to return to default.

### Syntax

**ip igmp query-interval** *seconds*

**no ip igmp query-interval**

### Parameters

**seconds**—Frequency, in seconds, at which IGMP query messages are sent on the interface. (Range: 30–18000)

### Default Configuration

125

### Command Mode

Interface Configuration (VLAN) mode

### User Guidelines

You can execute the command before the VLAN is created.

### Example

---

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ip igmp query-interval 200
```

---

## 28.12 ip igmp query-max-response-time

Use the **ip igmp query-max-response-time** Interface Configuration (VLAN) mode command to configure the Query Maximum Response time on a VLAN. Use the **no** format of the command to return to default.

### Syntax

**ip igmp query-max-response-time** *seconds*

**no ip igmp query-max-response-time**

### Parameters

**seconds**—Maximum response time, in seconds, advertised in IGMP queries. (Range: 5–20)

### Default Configuration

10

**Command Mode**

Interface Configuration (VLAN) mode

**User Guidelines**

You can execute the command before the VLAN is created.

**Example**

---

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ip igmp query-max-response-time 20
```

---

## 28.13 ip igmp last-member-query-count

Use the **ip igmp last-member-query-count** Interface Configuration (VLAN) mode command to configure the Last Member Query Counter on a VLAN. Use the **no** format of the command to return to default.

**Syntax**

**ip igmp last-member-query-count** *count*

**no ip igmp last-member-query-count**

**Parameter**

**count**—The number of times that group- or group-source-specific queries are sent upon receipt of a message indicating a leave. (Range: 1–7)

**Default Configuration**

A value of Robustness variable

**Command Mode**

Interface Configuration (VLAN) mode

**User Guidelines**

You can execute the command before the VLAN is created.

**Example**

---

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ip igmp last-member-query-count 7
```

---

## 28.14 ip igmp last-member-query-interval

Use the **ip igmp last-member-query-interval** Interface Configuration (VLAN) mode command to configure the Last Member Query interval on a VLAN. Use the **no** format of the command to return to default.

**Syntax**

**ip igmp last-member-query-interval** *milliseconds*

**no ip igmp last-member-query-interval**

**Parameters**

**milliseconds**—Interval, in milliseconds, at which IGMP group-specific host query messages are sent on the interface. (Range: 100–25500)

**Default Configuration**

1000

**Command Mode**

Interface Configuration (VLAN) mode

**User Guidelines**

You can execute the command before the VLAN is created.

**Example**


---

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ip igmp last-member-query-interval 2000
```

---

**28.15 ip igmp snooping vlan immediate-leave**

Use the **ip igmp snooping vlan immediate-leave** Global Configuration mode command to enable the IGMP Snooping Immediate-Leave processing on a VLAN. Use the **no** format of the command to disable IGMP Snooping Immediate-Leave processing.

**Syntax****ip igmp snooping vlan** *vlan-id* **immediate-leave****no ip igmp snooping vlan** *vlan-id* **immediate-leave****Parameters****vlan** *vlan-id*—Specifies the VLAN ID value. (Range: 1–4094)**Default Configuration**

Disabled

**Command Mode**

Global Configuration mode

**User Guidelines**

You can execute the command before the VLAN is created.

**Example**

The following example enables IGMP snooping immediate-leave feature on VLAN 1.

---

```
switchxxxxxx(config)# ip igmp snooping vlan 1 immediate-leave
```

---

**28.16 show ip igmp snooping mrouter**

The **show ip igmp snooping mrouter** EXEC mode command displays information on dynamically learned Multicast router interfaces for all VLANs or for a specific VLAN.

**Syntax****show ip igmp snooping mrouter** [**interface** *vlan-id*]

**Parameters**

**interface** *vlan-id*—Specifies the VLAN ID.

**Command Mode**

EXEC mode

**Example**

The following example displays information on dynamically learned Multicast router interfaces for VLAN 1000.

---

```
switchxxxxxx# show ip igmp snooping mrouter interface
1000
```

VLAN	Dynamic	Static	Forbidden
----	-----	-----	-----
1000	gi1/0/11	gi1/0/12	gi1/0/13-23

**28.17 show ip igmp snooping interface**

The **show ip igmp snooping interface** EXEC mode command displays the IGMP snooping configuration for a specific VLAN.

**Syntax**

**show ip igmp snooping interface** *vlan-id*

**Parameters**

**interface** *vlan-id*—Specifies the VLAN ID.

**Command Mode**

EXEC mode

**Example**

The following example displays the IGMP snooping configuration for VLAN 1000

---

```
switchxxxxxx# show ip igmp snooping interface 1000
IGMP Snooping is globally enabled
IGMP Snooping admin: Enabled
IGMP Snooping oper: Enabled
Routers IGMP version: 3
Groups that are in IGMP version 2 compatibility mode:
231.2.2.3, 231.2.2.3
Groups that are in IGMP version 1 compatibility mode:
IGMP snooping querier admin: Enabled
IGMP snooping querier oper: Enabled
IGMP snooping querier address admin:
IGMP snooping querier address oper: 172.16.1.1
IGMP snooping querier version admin: 3
IGMP snooping robustness: admin 2 oper 2
IGMP snooping query interval: admin 125 sec oper 125 sec
IGMP snooping query maximum response: admin 10 sec oper 10 sec
```

```

IGMP snooping last member query counter: admin 2 oper 2
IGMP snooping last member query interval: admin 1000 msec oper 500 msec
IGMP snooping last immediate leave: enable
Automatic learning of Multicast router ports is enabled

```

## 28.18 show ip igmp snooping groups

The **show ip igmp snooping groups** EXEC mode command displays the Multicast groups learned by the IGMP snooping.

### Syntax

```
show ip igmp snooping groups [vlan vlan-id] [address ip-multicast-address] [source ip-address]
```

### Parameters

**vlan** *vlan-id*—Specifies the VLAN ID.

**address** *ip-multicast-address*—Specifies the IP multicast address.

**source** *ip-address*—Specifies the IP source address.

### Command Mode

EXEC mode

### User Guidelines

To see all Multicast groups learned by IGMP snooping, use the **show ip igmp snooping groups** command without parameters.

Use the **show ip igmp snooping groups** command with parameters to see a needed subset of all Multicast groups learned by IGMP snooping.

To see the full Multicast address table (including static addresses), use the **show bridge multicast address-table** command.

### Example

The following example shows sample output for IGMP version 2.

```

switchxxxxxx# show ip igmp snooping groups

```

Vlan	Group Address	Source Address	Include Ports	Exclude Ports	Comp-Mode
1	239.255.255.250	*	gi1		v3



---

## 29.1 ipv6 mld snooping (Global)

The **ipv6 mld snooping** Global Configuration mode command enables IPv6 Multicast Listener Discovery (MLD) snooping. To disable IPv6 MLD snooping, use the **no** form of this command.

### Syntax

**ipv6 mld snooping**

**no ipv6 mld snooping**

### Parameters

N/A

### Default Configuration

IPv6 MLD snooping is disabled.

### Command Mode

Global Configuration mode

### Example

The following example enables IPv6 MLD snooping.

---

```
switchxxxxxx(config)# ipv6 mld snooping
```

---

## 29.2 ipv6 mld snooping vlan

Use the **ipv6 mld snooping vlan** Global Configuration mode command to enable MLD snooping on a specific VLAN. Use the **no** form of this command to disable MLD snooping on a VLAN interface.

### Syntax

**ipv6 mld snooping vlan** *vlan-id*

**no ipv6 mld snooping vlan** *vlan-id*

### Parameters

**vlan-id**—Specifies the VLAN.

### Default Configuration

Disabled

### Command Mode

Global Configuration mode

### User Guidelines

MLD snooping can only be enabled on static VLANs.

MLDv1 and MLDv2 are supported.

To activate MLD snooping, the Bridge Multicast Filtering command must be enabled.

The user guidelines of the [bridge multicast ipv6 mode](#) Interface VLAN Configuration command describe the configuration that can be written into the FDB as a function of the FDB mode, and the MLD version that is used in the network.

### Example

```
switchxxxxxx(config)# ipv6 mld snooping vlan 2
```

---

## 29.3 ipv6 mld robustness

Use the **ipv6 mld robustness** interface Configuration mode command to change a value of MLD robustness. Use the **no** format of the command to return to default.

### Syntax

**ipv6 mld robustness** *count*

**no ipv6 mld robustness**

### Parameters

**count** - The number of expected packet losses on a link. (Range: 1–7)

### Default Configuration

2

### Command Mode

Interface Configuration (VLAN) mode

### User Guidelines

You can execute the command before the VLAN is created.

### Example

```
switchxxxxxx(config)# interface vlan 1  
switchxxxxxx(config-if)# ipv6 mld robustness 3
```

---

## 29.4 ipv6 mld snooping vlan mrouter

Use the **ipv6 mld snooping vlan mrouter** Global Configuration mode command to enable automatic learning of Multicast router ports. Use the **no** form of this command to remove the configuration.

### Syntax

**ipv6 mld snooping vlan** *vlan-id* **mrouter learn** *pim-dvmrp*

**no ipv6 mld snooping vlan** *vlan-id* **mrouter learn** *pim-dvmrp*

### Parameters

- **vlan-id**—Specifies the VLAN.
- **pim-dvmrp**—Learn Multicast router port by PIM, DVMRP and MLD messages.



## Default Configuration

Learning `pim-dvmrp` is enabled.

## Command Mode

Global Configuration mode

## User Guidelines

Multicast router ports can be configured statically with the `bridge multicast forward-all` command.

You can execute the command before the VLAN is created.

## Example

```
switchxxxxxx(config)# ipv6 mld snooping vlan 1 mrouter learn pim-dvmrp
```

## 29.5 ipv6 mld snooping vlan mrouter

Use the `ipv6 mld snooping vlan mrouter` Interface Configuration mode command to define a port that is connected to a Multicast router port. Use the `no` form of this command to remove the configuration.

### Syntax

```
ipv6 mld snooping vlan vlan-id mrouter interface interface-list
```

```
no ipv6 mld snooping vlan vlan-id mrouter interface interface-list
```

### Parameters

- **vlan-id**—Specifies the VLAN.
- **interface-list**—Specifies a list of interfaces. The interfaces can be from one of the following types: port or port-channel.

### Default Configuration

No ports defined

### Command Mode

Interface Configuration mode

### User Guidelines

This command may be used in conjunction with the `bridge multicast forward-all` command, which is used in older versions to statically configure a port as a Multicast router.

A port that is defined as a Multicast router port receives all MLD packets (reports and queries) as well as all Multicast data.

You can execute the command before the VLAN is created and for a range of ports as shown in the example.

## Example

```
switchxxxxxx(config)interface gi1/0/11/1/1
switchxxxxxx(config-if)# ipv6 mld snooping vlan 1 mrouter interface
    gi1/0/11/1/1 - 10
```

## 29.6 ipv6 mld snooping vlan forbidden mrouter

Use the **ipv6 mld snooping vlan forbidden mrouter** Global Configuration mode command to forbid a port from being defined as a Multicast router port by static configuration or by automatic learning. Use the **no** form of this command to remove the configuration.

### Syntax

**ipv6 mld snooping vlan** *vlan-id* **forbidden mrouter** *interface* *interface-list*

**no ipv6 mld snooping vlan** *vlan-id* **forbidden mrouter** *interface* *interface-list*

### Parameters

- **vlan-id**—Specifies the VLAN.
- **interface-list**—Specifies list of interfaces. The interfaces can be from one of the following types: Ethernet port or Port-channel.

### Default Configuration

No forbidden ports by default

### Command Mode

Global Configuration mode

### User Guidelines

A port that is forbidden to be defined as a Multicast router port (mrouter port) cannot be learned dynamically or assigned statically.

The [bridge multicast forbidden forward-all](#) command was used in older versions to forbid dynamic learning of Multicast router ports.

You can execute the command before the VLAN is created.

### Example

```
switchxxxxxx(config)# ipv6 mld snooping vlan 1 forbidden mrouter interface
                        gil/0/11
```

## 29.7 ipv6 mld snooping vlan static

Use the **ipv6 mld snooping vlan static** Global Configuration mode command to register a IPv6-layer Multicast address to the bridge table, and to add statically ports to the group. Use the **no** form of this command to remove ports specified as members of a static Multicast group.

### Syntax

**ipv6 mld snooping vlan** *vlan-id* **static** *ipv6-address* *interface* [*interface-list*]

**no ipv6 mld snooping vlan** *vlan-id* **static** *ipv6-address* *interface* [*interface-list*]

### Parameters

- **vlan-id**—Specifies the VLAN.
- **ipv6-address**—Specifies the IP multicast address
- **interface-list**—Specifies list of interfaces. The interfaces can be from one of the following types: Ethernet port or Port-channel.

### Default Configuration

No Multicast addresses are defined.

### Command Mode

Global configuration mode

### User Guidelines

Static multicast addresses can only be defined on static VLANs.

You can execute the command before the VLAN is created.

You can register an entry without specifying an interface.

Using the **no** command without a port-list removes the entry.

### Example

---

```
switchxxxxxx(config)# ipv6 mld snooping vlan 1 static 239.2.2.2 gi1/0/11
```

---

## 29.8 ipv6 mld query-interval

Use the **ipv6 mld query-interval** Interface Configuration mode command to configure the Query interval. Use the **no** format of the command to return to default.

### Syntax

**ipv6 mld query-interval** *seconds*

**ipv6 mld query-interval**

### Parameters

**seconds**—Frequency, in seconds, at which MLD query messages are sent on the interface. (Range: 30–18000)

### Default Configuration

125

### Command Mode

Interface Configuration (VLAN) mode

### User Guidelines

This command provides the frequency value if this value is not received in [MLD general query messages](#). A field for this value is present in [MLDv2 general query messages](#), but this field may be blank. There is no field for this value in [MLDv1 general query messages](#).

### Example

---

```
switchxxxxxx(config)# interface vlan 1  
switchxxxxxx(config-if)# ipv6 mld query-interval 3000
```

---

---

## 29.9 ipv6 mld query-max-response-time

Use the **ipv6 mld query-max-response-time** Interface Configuration mode command to configure the Query Maximum Response time. Use the **no** format of the command to return to default.

### Syntax

**ipv6 mld query-max-response-time** *seconds*

**no ipv6 mld query-max-response-time**

### Parameter

**seconds**—Maximum response time, in seconds, advertised in MLD queries. (Range: 5–20)

### Default Configuration

10

### Command Mode

Interface Configuration (VLAN) mode

### User Guidelines

This command provides the maximum response time value if this value is not received in [MLD general query messages](#). A field for this value is present in [MLDv2 general query messages](#), but this field may be blank. There is no field for this value in [MLDv1 general query messages](#).

### Example

---

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ipv6 mld query-max-response-time 5
```

---

## 29.10 ipv6 mld last-member-query-count

Use the **ipv6 mld last-member-query-count** Interface Configuration mode command to configure the Last Member Query Count. This is the number of Multicast address specific queries sent before the router assumes there are no local listeners. The Last Listener Query Count is also the number of Multicast Address and Source Specific Queries sent before the router assumes there are no listeners for a particular source.

Use the **no** format of the command to return to default.

### Syntax

**ipv6 mld last-member-query-count** *count*

**no ipv6 mld last-member-query-count**

### Parameters

**count**—The number of times that group- or group-source-specific queries are sent upon receipt of a Leave message. (Range: 1–7)

### Default Configuration

The value of the Robustness variable.

### Command Mode

Interface Configuration (VLAN) mode

### User Guidelines

This command provides this value if it is not received in [MLD general query messages](#). A field for this value is present in [MLDv2 general query messages](#), but this field may be blank. There is no field for this value in [MLDv1 general query messages](#).

### Example

---

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ipv6 mld last-member-query-count 3
```

---

## 29.11 ipv6 mld last-member-query-interval

Use the `ipv6 mld last-member-query-interval` interface configuration command to configure the Last Member Query Interval. Use the `no` format of the command to return to default.

### Syntax

`ipv6 mld last-member-query-interval milliseconds`

`no ipv6 mld last-member-query-interval`

### Parameter

**milliseconds**—Interval, in milliseconds, at which MLD group-specific host query messages are sent on the interface. (Range: 100–64512).

### Default Configuration

1000

### Command Mode

Interface Configuration (VLAN) mode

### User Guidelines

This command provides this value if it is not received in [MLD general query messages](#). A field for this value is present in [MLDv2 general query messages](#), but this field may be blank. There is no field for this value in [MLDv1 general query messages](#).

### Example

---

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ipv6 mld last-member-query-interval 2000
```

---

## 29.12 ipv6 mld snooping vlan immediate-leave

Use the `ipv6 mld snooping vlan immediate-leave` Global Configuration mode command to enable MLD Snooping Immediate-Leave processing on a VLAN. When an MLD Leave Group message is received from a host, the system removes the host port from the table entry. After it relays the MLD queries from the Multicast router, it deletes entries periodically if it does not receive any MLD membership reports from the Multicast clients.

MLD snooping Immediate-Leave processing allows the switch to remove an interface that sends a leave message from the forwarding table without first sending out MAC-based general queries to the interface.

Use the `no` format of the command to return to disable MLD Snooping Immediate-Leave processing.

**Syntax****ipv6 mld snooping vlan *vlan-id* immediate-leave****no ipv6 mld snooping vlan *vlan-id* immediate-leave****Parameters****vlan-id**—Specifies the VLAN ID value. (Range: 1–4094)**Default Configuration**

Disabled

**Command Mode**

Global Configuration mode

**User Guidelines**

You can execute the command before the VLAN is created.

**Example**


---

```
switchxxxxxx(config)# ipv6 mld snooping vlan 1 immediate-leave
```

---

**29.13 show ipv6 mld snooping mrouter**The **show ipv6 mld snooping mrouter** EXEC mode command displays information on dynamically learned Multicast router interfaces for all VLANs or for a specific VLAN.**Syntax****show ipv6 mld snooping mrouter [*interface vlan-id*]****Parameters****interface *vlan-id***—Specifies the VLAN ID.**Default Configuration**

Display information for all VLANs.

**Command Mode**

EXEC mode

**Example**

The following example displays information on dynamically learned Multicast router interfaces for VLAN 1000

---

```
switchxxxxxx# show ipv6 mld snooping mrouter interface 1000
```

VLAN	Static	Dynamic	Forbidden
-----	-----	-----	-----
1000	gi1/0/11	gi1/0/12	gi1/0/13-23

## 29.14 show ipv6 mld snooping interface

The **show ipv6 mld snooping interface** EXEC mode command displays the IPv6 MLD snooping configuration for a specific VLAN.

### Syntax

**show ipv6 mld snooping interface** *vlan-id*

### Parameters

**vlan-id**—Specifies the VLAN ID.

### Default Configuration

Display information for all VLANs.

### Command Mode

EXEC mode

### Example

The following example displays the MLD snooping configuration for VLAN 1000.

```
switchxxxxxx# show ipv6 mld snooping interface 1000
MLD Snooping is globally enabled
MLD Snooping admin: Enabled
MLD snooping oper mode: Enabled
Routers MLD version: 2
Groups that are in MLD version 1 compatibility mode:
FF12::3, FF12::8
MLD snooping robustness:admin 2 oper 2
MLD snooping query interval: admin 125 sec oper 125 sec
MLD snooping query maximum response: admin 10 sec oper 10 sec
MLD snooping last member query counter: admin 2 oper 2
MLD snooping last member query interval: admin 1000 msec oper 600 msec
MLD snooping last immediate leave: enable
Automatic learning of multicast router ports is enabled
```

## 29.15 show ipv6 mld snooping groups

The **show ipv6 mld snooping groups** EXEC mode command displays the multicast groups learned by the MLD snooping.

### Syntax

**show ipv6 mld snooping groups** [*vlan vlan-id*] [*address ipv6-multicast-address*] [*source ipv6-address*]

### Parameters

- **vlan vlan-id**—Specifies the VLAN ID.
- **address ipv6-multicast-address**—Specifies the IPv6 multicast address.
- **source ipv6-address**—Specifies the IPv6 source address.

## Command Mode

EXEC mode

## Default Configuration

Display information for all VLANs and addresses defined on them.

## User Guidelines

To see the full multicast address table (including static addresses), use the **show bridge multicast address-table** command.

The Include list contains the ports which are in a forwarding state for this group according to the snooping database. In general, the Exclude list contains the ports which have issued an explicit Exclude for that specific source in a multicast group.

The Reporters That Are Forbidden Statically list contains the list of ports which have asked to receive a multicast flow but were defined as forbidden for that multicast group in a multicast bridge.

Note: Under certain circumstances, the Exclude list may not contain accurate information; for example, in the case when two Exclude reports were received on the same port for the same group but for different sources, the port will not be in the Exclude list but rather in the Include list

## Example

The following example shows the output for show ipv6 mld snooping groups.

```
switchxxxxxx# show ipv6 mld snooping groups
```

VLAN	Group Address	Source Address	Include Ports	Exclude Ports	Compatibility Mode
1	-----	FE80::201:C9FF:FE40:8	-----	-----	-----
1	FF12::3	001	gi1/0/11		1
19	FF12::3	FE80::201:C9FF:FE40:8	gi1/0/12		1
19	FF12::8	002	gi1/0/19		2
19	FF12::8	FE80::201:C9FF:FE40:8	gi1/0/11	gi1/0/12	2
	FF12::8	003	gi1/0/110	gi1/0/13	2
		FE80::201:C9FF:FE40:8	-11		
		004			
		FE80::201:C9FF:FE40:8			
		005			

MLD Reporters that are forbidden statically:

VLAN	Group Address	Source Address	Ports
1	-----	FE80::201:C9FF:FE40:8	gi1/0/18
19	FF12::3	001	gi1/0/19
	FF12::8	FE80::201:C9FF:FE40:8	001



# Link Aggregation Control Protocol (LACP) Commands

---

## 30.1 lacp system-priority

Use the **lacp system-priority** Global Configuration mode command to set the system priority. Use the **no** form of this command to restore the default configuration.

### Syntax

**lacp system-priority** *value*

**no lacp system-priority**

### Parameters

**value**—Specifies the system priority value. (Range: 1–65535)

### Default Configuration

The default system priority is 1.

### Command Mode

Global Configuration mode

### Example

The following example sets the system priority to 120.

---

```
switchxxxxxx(config)# lacp system-priority 120
```

---

## 30.2 lacp port-priority

Use the **lacp port-priority** Interface Configuration (Ethernet) mode command to set the physical port priority. Use the **no** form of this command to restore the default configuration.

### Syntax

**lacp port-priority** *value*

**no lacp port-priority**

### Parameters

**value**—Specifies the port priority. (Range: 1use the **no** form of this command65535)

### Default Configuration

The default port priority is 1.

### Command Mode

Interface Configuration (Ethernet) mode

**Example**

The following example sets the priority of gi1/0/16.

---

```
switchxxxxxx(config)# interface gi1/0/16
switchxxxxxx(config-if)# lacp port-priority 247
```

---

## 30.3 lacp timeout

Use the **lacp timeout** Interface Configuration (Ethernet) mode command to assign an administrative LACP timeout to an interface. Use the **no** form of this command to restore the default configuration.

**Syntax**

**lacp timeout** {*long* | *short*}

**no lacp timeout**

**Parameters**

- **long**—Specifies the long timeout value.
- **short**—Specifies the short timeout value.

**Default Configuration**

The default port timeout value is Long.

**Command Mode**

Interface Configuration (Ethernet) mode

**Example**

The following example assigns a long administrative LACP timeout to gi1/0/16.

---

```
switchxxxxxx(config)# interface gi1/0/16
switchxxxxxx(config-if)# lacp timeout long
```

---

## 30.4 show lacp

Use the **show lacp** EXEC mode command to display LACP information for all Ethernet ports or for a specific Ethernet port.

**Syntax**

**show lacp** *interface-id* [*parameters* | *statistics* | *protocol-state*]

**Parameters**

- **interface-id** —Specify an interface ID. The interface ID must be an Ethernet port
- **parameters**—Displays parameters only.
- **statistics**—Displays statistics only.
- **protocol-state**—Displays protocol state only.

**Command Mode**

EXEC mode

**Example**

The following example displays LACP information for gi1/0/11.

```

switchxxxxxx# show lacp ethernet gi1/0/11
Port gi1/0/11 LACP parameters:
    Actor
        system priority:          1
        system mac addr:         00:00:12:34:56:78
        port Admin key:          30
        port Oper key:           30
        port Oper number:        21
        port Admin priority:     1
        port Oper priority:      1
        port Admin timeout:      LONG
        port Oper timeout:       LONG
        LACP Activity:           ACTIVE
        Aggregation:             AGGREGATABLE
        synchronization:         FALSE
        collecting:               FALSE
        distributing:             FALSE
        expired:                  FALSE
    Partner
        system priority:          0
        system mac addr:         00:00:00:00:00:00
        port Admin key:          0
        port Oper key:           0
        port Oper number:        0
        port Admin priority:     0
        port Oper priority:      0
        port Admin timeout:      LONG
        port Oper timeout:       LONG
        LACP Activity:           PASSIVE
        Aggregation:             AGGREGATABLE
        synchronization:         FALSE
        collecting:               FALSE
        distributing:             FALSE
        expired:                  FALSE
Port gi1/0/11 LACP Statistics:
LACP PDUs sent:                2
LACP PDUs received:           2
Port gi1/0/11 LACP Protocol State:
    LACP State Machines:
        Receive FSM:            Port Disabled State
        Mux FSM:                 Detached State
    Control Variables:

```

```

BEGIN:                               FALSE
LACP_Enabled:                         TRUE
Ready_N:                              FALSE
Selected:                             UNSELECTED
Port_moved:                           FALSE
NNT:                                   FALSE
Port_enabled:                         FALSE

Timer counters:

periodic tx timer:                    0
current while timer:                  0
wait while timer:                     0

```

---

## 30.5 show lacp port-channel

Use the **show lacp port-channel** EXEC mode command to display LACP information for a port-channel.

### Syntax

**show lacp port-channel** [*port\_channel\_number*]

### Parameters

**port\_channel\_number**—Specifies the port-channel number.

### Command Mode

EXEC mode

### Example

The following example displays LACP information about port-channel 1.

---

```

switchxxxxxx# show lacp port-channel 1

Port-Channel 1:Port Type 1000 Ethernet

Actor

System          1
Priority:        000285:0E1C00
MAC Address:    29
Admin Key:      29
Oper Key:

Partner

System          0
Priority:        00:00:00:00:00:00
MAC Address:    14
Oper Key:

```

# GARP VLAN Registration Protocol (GVRP) Commands

---

## 31.1 gvrp enable (Global)

Use the **gvrp enable** Global Configuration mode command to enable the Generic Attribute Registration Protocol (GARP) VLAN Registration Protocol (GVRP) globally. Use the **no** form of this command to disable GVRP on the device.

### Syntax

**gvrp enable**

**no gvrp enable**

### Parameters

N/A

### Default Configuration

GVRP is globally disabled.

### Command Mode

Global Configuration mode

### Example

The following example enables GVRP globally on the device.

---

```
switchxxxxxx(config)# gvrp enable
```

---

## 31.2 gvrp enable (Interface)

Use the **gvrp enable** Interface Configuration (Ethernet, Port-channel) mode command to enable GVRP on an interface. Use the **no** form of this command to disable GVRP on an interface.

### Syntax

**gvrp enable**

**no gvrp enable**

### Default Configuration

GVRP is disabled on all interfaces.

### Command Mode

Interface Configuration (Ethernet, Port-channel) mode

**User Guidelines**

An access port does not dynamically join a VLAN because it is always a member of a single VLAN only. Membership in an untagged VLAN is propagated in the same way as in a tagged VLAN. That is, the PVID must be manually defined as the untagged VLAN ID.

**Example**

The following example enables GVRP on gi1/0/16.

---

```
switchxxxxxx(config)# interface gi1/0/16
switchxxxxxx(config-if)# gvrp enable
```

---

**31.3 garp timer**

Use the **garp timer** Interface Configuration mode command to adjust the values of the join, leave and leaveall timers of GARP applications, such as GVRP. Use the **no** form of this command to restore the default configuration.

**Syntax**

**garp timer** *{join | leave | leaveall}* *timer-value*

**no garp timer**

**Parameters**

- The following specify the type of timer. The possible values are:
  - **join**—Specifies the GARP join timer. The timer value for this type of timer specifies the time interval between the two join messages sent by the GARP application.
  - **leave**—Specifies the GARP leave timer. The timer value for this type of timer specifies the time interval for a GARP application to wait for a join message after receiving a leave message for a GARP attribute, before it de-registers the GARP attribute.
  - **leaveall**—Specifies the GARP leaveall timer. The timer value for this type of timer specifies the time interval between leaveall messages for a GARP entity, which prompt other GARP entities to re-register all attribute information on this entity.
- **timer-value**—Specifies the timer value in milliseconds in multiples of 10. (Range: 10–2147483640)

**Default Configuration**

The following are the default timer values:

- **Join timer**—200 milliseconds
- **Leave timer**—600 milliseconds
- **Leaveall timer**—10000 milliseconds

**Command Mode**

Interface Configuration (Ethernet, Port-channel) mode

**User Guidelines**

The **timer-value** must be a multiple of 10.

The following relationship must be maintained between the timers:

- The leave timer value must be greater than or equal to three times the join timer.
- The leave-all timer value must be greater than the leave timer.

Set the same GARP timer values on all Layer 2-connected devices to ensure proper operation of the GARP application.

**Example**

The following example sets the leave timer for `gi1/0/16` to 900 milliseconds.

---

```
switchxxxxxx(config)# interface gi1/0/16
switchxxxxxx(config-if)# garp timer leave 900
```

---

## 31.4 gvrp vlan-creation-forbid

Use the **gvrp vlan-creation-forbid** Interface Configuration mode command to disable dynamic VLAN creation or modification. Use the **no** form of this command to enable dynamic VLAN creation or modification.

**Syntax**

**gvrp vlan-creation-forbid**

**no gvrp vlan-creation-forbid**

**Default Configuration**

Enabled.

**Command Mode**

Interface Configuration (Ethernet, Port-channel) mode

**Example**

The following example disables dynamic VLAN creation on `gi1/0/13`.

---

```
switchxxxxxx(config)# interface gi1/0/13
switchxxxxxx(config-if)# gvrp vlan-creation-forbid
```

---

## 31.5 gvrp registration-forbid

Use the **gvrp registration-forbid** Interface Configuration mode command to deregister all dynamic VLANs on a port and prevent VLAN creation or registration on the port. Use the **no** form of this command to allow dynamic registration of VLANs on a port.

**Syntax**

**gvrp registration-forbid**

**no gvrp registration-forbid**

**Default Configuration**

Dynamic registration of VLANs on the port is allowed.

**Command Mode**

Interface Configuration (Ethernet, Port-channel) mode

**Example**

The following example forbids dynamic registration of VLANs on `gi1/0/12`.

---

```
switchxxxxxx(config)# interface gi1/0/12
switchxxxxxx(config-if)# gvrp registration-forbid
```

---

---

## 31.6 clear gvrp statistics

Use the **clear gvrp statistics** Privileged EXEC mode command to clear GVRP statistical information for all interfaces or for a specific interface.

### Syntax

**clear gvrp statistics** [*interface-id*]

### Parameters

**Interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

### Default Configuration

All GVRP statistics are cleared.

### Command Mode

Privileged EXEC mode

### Example

The following example clears all GVRP statistical information on `gi1/0/15`.

---

```
switchxxxxxx# clear gvrp statistics gi1/0/15
```

---

---

## 31.7 show gvrp configuration

Use the **show gvrp configuration** EXEC mode command to display GVRP configuration information, including timer values, whether GVRP and dynamic VLAN creation are enabled, and which ports are running GVRP.

### Syntax

**show gvrp configuration** [*interface-id* | **detailed**]

### Parameters

- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or port-channel.
- **detailed**—Displays information for non-present ports in addition to present ports.

### Default Configuration

All GVRP statistics are displayed for all interfaces. If **detailed** is not used, only present ports are displayed.

### Command Mode

EXEC mode

### Example

The following example displays GVRP configuration.

---

```
switchxxxxxx# show gvrp configuration
GVRP Feature is currently Enabled on the device.
Maximum VLANs: 4094
```

---



Port(s)	GVRP-Status	Regist- ration	Dynamic VLAN Creation	Timers (ms)		
				Join	Leave	Leave All
gi1/0/11	Enabled	Forbidden	Disabled	600	200	10000
gi1/0/12	Enabled	Normal	Enabled	1200	400	20000

## 31.8 show gvrp statistics

Use the **show gvrp statistics** EXEC mode command to display GVRP statistics for all interfaces or for a specific interface.

### Syntax

**show gvrp statistics** [*interface-id*]

### Parameters

**interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

### Default Configuration

All GVRP statistics are displayed.

### Command Mode

EXEC mode

### Example

The following example displays GVRP statistical information.

```
switchxxxxxx# show gvrp statistics
```

```
GVRP statistics:
```

```
-----
```

```
Legend:
```

```
rJE :   Join Empty Received      rJIn: Join In Received
rEmp:   Empty Received           rLIn: Leave In Received
rLE :   Leave Empty Received     rLA : Leave All Received
sJE :   Join Empty Sent          sJIn: Join In Sent
sEmp:   Empty Sent               sLIn: Leave In Sent
sLE :   Leave Empty Sent         sLA : Leave All Sent
```

Port	rJE	rJIn	rEmp	rLIn	rLE	rLA	sJE	sJIn	sEmp	sLIn	sLE	sLA
gi1/0/11	0	0	0	0	0	0	0	0	0	0	0	0
gi1/0/12	0	0	0	0	0	0	0	0	0	0	0	0
gi1/0/13	0	0	0	0	0	0	0	0	0	0	0	0
gi1/0/14	0	0	0	0	0	0	0	0	0	0	0	0
gi1/0/15	0	0	0	0	0	0	0	0	0	0	0	0
gi1/0/16	0	0	0	0	0	0	0	0	0	0	0	0
gi1/0/17	0	0	0	0	0	0	0	0	0	0	0	0
gi1/0/18	0	0	0	0	0	0	0	0	0	0	0	0

## 31.9 show gvrp error-statistics

Use the **show gvrp error-statistics** EXEC mode command to display GVRP error statistics for all interfaces or for a specific interface.

### Syntax

**show gvrp error-statistics** [*interface-id*]

### Parameters

**interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

### Default Configuration

All GVRP error statistics are displayed.

### Command Mode

EXEC mode

### Example

The following example displays GVRP error statistics.

---

```
switchxxxxxx# show gvrp error-statistics
GVRP Error Statistics:
-----
Legend:
  INVPROT  : Invalid Protocol Id
  INVATYP  : Invalid Attribute Type  INVALEN  : Invalid Attribute Length
  INVAVAL  : Invalid Attribute Value INVEVENT: Invalid Event
  Port    INVPROT INVATYP INVAVAL INVALEN INVEVENT
-----
gi1/0/11      0      0      0      0      0
gi1/0/12      0      0      0      0      0
gi1/0/13      0      0      0      0      0
gi1/0/14      0      0      0      0      0
gi1/0/15      0      0      0      0      0
gi1/0/16      0      0      0      0      0
gi1/0/17      0      0      0      0      0
gi1/0/18      0      0      0      0      0
```

---

## 32.1 ip dhcp snooping

Use the **ip dhcp snooping** Global Configuration mode command to enable Dynamic Host Configuration Protocol (DHCP) Snooping globally. Use the **no** form of this command to restore the default configuration.

### Syntax

**ip dhcp snooping**

**no ip dhcp snooping**

### Parameters

N/A

### Default Configuration

DHCP snooping is disabled.

### Command Mode

Global Configuration mode

### User Guidelines

For any DHCP Snooping configuration to take effect, DHCP Snooping must be enabled globally. DHCP Snooping on a VLAN is not active until DHCP Snooping on a VLAN is enabled by using the **ip dhcp snooping vlan** Global Configuration mode command.

### Example

The following example enables DHCP Snooping on the device.

---

```
Console(config)# ip dhcp snooping
```

---

## 32.2 ip dhcp snooping vlan

Use the **ip dhcp snooping vlan** Global Configuration mode command to enable DHCP Snooping on a VLAN. Use the **no** form of this command to disable DHCP Snooping on a VLAN.

### Syntax

**ip dhcp snooping vlan** *vlan-id*

**no ip dhcp snooping** *vlan-id*

### Parameters

**vlan-id**—Specifies the VLAN ID.

**Default Configuration**

DHCP Snooping on a VLAN is disabled.

**Command Mode**

Global Configuration mode

**User Guidelines**

DHCP Snooping must be enabled globally before enabling DHCP Snooping on a VLAN.

**Example**

The following example enables DHCP Snooping on VLAN 21.

---

```
Console(config)# ip dhcp snooping vlan 21
```

---

## 32.3 ip dhcp snooping trust

Use the **ip dhcp snooping trust** Interface Configuration (Ethernet, Port-channel) mode command to configure a port as trusted for DHCP snooping purposes. Use the **no** form of this command to restore the default configuration.

**Syntax**

**ip dhcp snooping trust**

**no ip dhcp snooping trust**

**Parameters**

N/A

**Default Configuration**

The interface is untrusted.

**Command Mode**

Interface Configuration (Ethernet, Port-channel) mode

**User Guidelines**

Configure as trusted the ports that are connected to a DHCP server or to other switches or routers. Configure the ports that are connected to DHCP clients as untrusted.

**Example**

The following example configures `gi1/0/15` as trusted for DHCP Snooping.

---

```
Console(config)# interface gi1/0/15
Console(config-if)# ip dhcp snooping trust
```

---

---

## 32.4 ip dhcp snooping information option allowed-untrusted

Use the **ip dhcp snooping information option allowed-untrusted** Global Configuration mode command to allow a device to accept DHCP packets with option-82 information from an untrusted port. Use the **no** form of this command to drop these packets from an untrusted port.

### Syntax

**ip dhcp snooping information option allowed-untrusted**

**no ip dhcp snooping information option allowed-untrusted**

### Parameters

N/A

### Default Configuration

DHCP packets with option-82 information from an untrusted port are discarded.

### Command Mode

Global Configuration mode

### Example

The following example allows a device to accept DHCP packets with option-82 information from an untrusted port.

---

```
Console(config)# ip dhcp snooping information option allowed-untrusted
```

---

## 32.5 ip dhcp snooping verify

Use the **ip dhcp snooping verify** Global Configuration mode command to configure a device to verify that the source MAC address in a DHCP packet received on an untrusted port matches the client hardware address. Use the **no** form of this command to disable MAC address verification in a DHCP packet received on an untrusted port.

### Syntax

**ip dhcp snooping verify**

**no ip dhcp snooping verify**

### Default Configuration

The switch verifies that the source MAC address in a DHCP packet received on an untrusted port matches the client hardware address in the packet.

### Command Mode

Global Configuration mode

### Example

The following example configures a device to verify that the source MAC address in a DHCP packet received on an untrusted port matches the client hardware address.

---

```
Console(config)# ip dhcp snooping verify
```

---

## 32.6 ip dhcp snooping database

Use the **ip dhcp snooping database** Global Configuration mode command to enable the DHCP Snooping binding database file. Use the **no** form of this command to delete the DHCP Snooping binding database file.

### Syntax

**ip dhcp snooping database**

**no ip dhcp snooping database**

### Parameters

N/A

### Default Configuration

The DHCP Snooping binding database file is not defined.

### Command Mode

Global Configuration mode

### User Guidelines

The DHCP Snooping binding database file resides on Flash.

To ensure that the lease time in the database is accurate, the Simple Network Time Protocol (SNTP) must be enabled and configured.

The device writes binding changes to the binding database file only if the device system clock is synchronized with SNTP.

### Example

The following example enables the DHCP Snooping binding database file.

---

```
Console(config)# ip dhcp snooping database
```

---

---

## 32.7 ip dhcp snooping database update-freq

Use the **ip dhcp snooping database update-freq** Global Configuration mode command to set the update frequency of the DHCP Snooping binding database file. Use the **no** form of this command to restore the default configuration.

### Syntax

**ip dhcp snooping database update-freq** *seconds*

**no ip dhcp snooping database update-freq**

### Parameters

**seconds**—Specifies the update frequency in seconds. (Range: 600–86400)

### Default Configuration

The default update frequency value is 1200 seconds.

### Command Mode

Global Configuration mode

**Example**

The following example sets the DHCP Snooping binding database file update frequency to 1 hour.

---

```
Console(config)# ip dhcp snooping database update-freq 3600
```

---

**32.8 ip dhcp snooping binding**

Use the **ip dhcp snooping binding** Privileged EXEC mode command to configure the DHCP Snooping binding database and add binding entries to the database. Use the **no** form of this command to delete entries from the binding database.

**Syntax**

**ip dhcp snooping binding** *mac-address* *vlan-id* *ip-address* *interface-id* **expiry** {*seconds* | *infinite*}

**no ip dhcp snooping binding** *mac-address* *vlan-id*

**Parameters**

- **mac-address**— Specifies a MAC address.
- **vlan-id**— Specifies a VLAN number.
- **ip-address**— Specifies an IP address.
- **interface-id**— Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.
- **expiry**
  - *seconds*— Specifies the time interval, in seconds, after which the binding entry is no longer valid. (Range: 10–4294967295)
  - *infinite*— Specifies infinite lease time.

**Default Configuration**

No static binding exists.

**Command Mode**

Privileged EXEC mode

**User Guidelines**

After entering this command, an entry is added to the DHCP Snooping database. If the DHCP Snooping binding file exists, the entry is also added to that file.

The entry is displayed in the show commands as a DHCP Snooping entry.

The user cannot delete dynamic temporary entries for which the IP address is 0.0.0.0.

The user can add static entry to the DHCP Snooping database by using the command **ip source-guard binding**.

**Example**

The following example adds a binding entry to the DHCP Snooping binding database.

---

```
Console# ip dhcp snooping binding 0060.704C.73FF 23 176.10.1.1 gi1/0/15 expiry
900
```

---

---

## 32.9 clear ip dhcp snooping database

Use the **clear ip dhcp snooping database** Privileged EXEC mode command to clear the DHCP Snooping binding database.

### Syntax

**clear ip dhcp snooping database**

### Parameters

N/A

### Command Mode

Privileged EXEC mode

### Example

The following example clears the DHCP Snooping binding database.

---

```
Console# clear ip dhcp snooping database
```

---

## 32.10 show ip dhcp snooping

Use the **show ip dhcp snooping** EXEC mode command to display the DHCP snooping configuration for all interfaces or for a specific interface.

### Syntax

**show ip dhcp snooping** [*interface-id*]

### Parameters

**interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

### Command Mode

EXEC mode

### Example

The following example displays the DHCP snooping configuration.

---

```
console# show ip dhcp snooping
DHCP snooping is Enabled
DHCP snooping is configured on following VLANs: 21
DHCP snooping database is Enabled
Relay agent Information option 82 is Enabled
Option 82 on untrusted port is allowed
Verification of hwaddr field is Enabled
DHCP snooping file update frequency is configured to: 6666 seconds

  Interface    Trusted
  -----
gi1/0/11      Yes
```



gi1/0/12                      Yes

## 32.11 show ip dhcp snooping binding

Use the **show ip dhcp snooping binding** User EXEC mode command to display the DHCP Snooping binding database and configuration information for all interfaces or for a specific interface.

### Syntax

**show ip dhcp snooping binding** [*mac-address mac-address*] [*ip-address ip-address*] [*vlan vlan-id*] [*interface-id*]

### Parameters

- **mac-address mac-address**—Specifies a MAC address.
- **ip-address ip-address**—Specifies an IP address.
- **vlan vlan-id**—Specifies a VLAN ID.
- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

### Command Mode

User EXEC mode

### Example

The following examples displays the DHCP snooping binding database and configuration information for all interfaces on a device.-

```

Console# show ip dhcp snooping binding

Update frequency: 1200
Total number of binding: 2

Mac Address          IP Address          Lease (sec)         Type                VLAN  Interface
-----
0060.704C.73FF      10.1.8.1            7983                snooping            3     gi1/0/121
0060.704C.7BC1      10.1.8.2            92332               snooping            3     gi1/0/122
                                     (s)

```

## 32.12 ip arp inspection

Use the **ip arp inspection** Global Configuration mode command globally to enable Address Resolution Protocol (ARP) inspection. Use the **no** form of this command to disable ARP inspection.

### Syntax

**ip arp inspection**

**no ip arp inspection**

### Parameters

N/A

### Default Configuration

ARP inspection is disabled.

**Command Mode**

Global Configuration mode

**User Guidelines**

Note that if a port is configured as an untrusted port, then it should also be configured as an untrusted port for DHCP Snooping, or the IP-address-MAC-address binding for this port should be configured statically. Otherwise, hosts that are attached to this port cannot respond to ARPs.

**Example**

The following example enables ARP inspection on the device.

---

```
Console(config)# ip arp inspection
```

---

## 32.13 ip arp inspection vlan

Use the **ip arp inspection vlan** Global Configuration mode command to enable ARP inspection on a VLAN, based on the DHCP Snooping database. Use the **no** form of this command to disable ARP inspection on a VLAN.

**Syntax**

```
ip arp inspection vlan vlan-id
```

```
no ip arp inspection vlan vlan-id
```

**Parameters**

**vlan-id**—Specifies the VLAN ID.

**Default Configuration**

DHCP Snooping based ARP inspection on a VLAN is disabled.

**Command Mode**

Global Configuration mode

**User Guidelines**

This command enables ARP inspection on a VLAN based on the DHCP snooping database. Use the **ip arp inspection list assign** Global Configuration mode command to enable static ARP inspection.

**Example**

The following example enables DHCP Snooping based ARP inspection on VLAN 23.

---

```
Console(config)# ip arp inspection vlan 23
```

---

## 32.14 ip arp inspection trust

Use the **ip arp inspection trust** Interface Configuration (Ethernet, Port-channel) mode command to configure an interface trust state that determines if incoming Address Resolution Protocol (ARP) packets are inspected. Use the **no** form of this command to restore the default configuration.

**Syntax**

```
ip arp inspection trust
```

```
no ip arp inspection trust
```

**Parameters**

N/A

**Default Configuration**

The interface is untrusted.

**Command Mode**

Interface Configuration (Ethernet, Port-channel) mode

**User Guidelines**

The device does not check ARP packets that are received on the trusted interface; it only forwards the packets.

For untrusted interfaces, the device intercepts all ARP requests and responses. It verifies that the intercepted packets have valid IP-to-MAC address bindings before updating the local cache and before forwarding the packet to the appropriate destination. The device drops invalid packets and logs them in the log buffer according to the logging configuration specified with the **ip arp inspection log-buffer vlan** Global Configuration mode command.

**Example**

The following example configures `gi1/0/13` as a trusted interface.

---

```
Console(config)# interface gi1/0/13
Console(config-if)# ip arp inspection trust
```

---

**32.15 ip arp inspection validate**

Use the **ip arp inspection validate** Global Configuration mode command to perform specific checks for dynamic Address Resolution Protocol (ARP) inspection. Use the **no** form of this command to restore the default configuration.

**Syntax****ip arp inspection validate****no ip arp inspection validate****Parameters**

N/A

**Default Configuration**

ARP inspection validation is disabled.

**Command Mode**

Global Configuration mode

**User Guidelines**

The following checks are performed:

- **Source MAC address:** Compares the source MAC address in the Ethernet header against the sender MAC address in the ARP body. This check is performed on both ARP requests and responses.
- **Destination MAC address:** Compares the destination MAC address in the Ethernet header against the target MAC address in the ARP body. This check is performed for ARP responses.
- **IP addresses:** Compares the ARP body for invalid and unexpected IP addresses. Addresses include 0.0.0.0, 255.255.255.255, and all IP multicast addresses.

**Example**

The following example executes ARP inspection validation.

---

```
Console(config)# ip arp inspection validate
```

---

## 32.16 ip arp inspection list create

Use the **ip arp inspection list create** Global Configuration mode command to create a static ARP binding list and enters the ARP list configuration mode. Use the **no** form of this command to delete the list.

**Syntax**

**ip arp inspection list create** *name*

**no ip arp inspection list create** *name*

**Parameters**

**name**—Specifies the static ARP binding list name. (Length: 1–32 characters)

**Default Configuration**

No static ARP binding list exists.

**Command Mode**

Global Configuration mode

**User Guidelines**

Use the **ip arp inspection list assign** command to assign the list to a VLAN.

**Example**

The following example creates the static ARP binding list 'servers' and enters the ARP list configuration mode.

---

```
Console(config)# ip arp inspection list create servers
Console(config-ARP-list)#
```

---

## 32.17 ip mac

Use the **ip mac** ARP-list Configuration mode command to create a static ARP binding. Use the **no** form of this command to delete a static ARP binding.

**Syntax**

**ip** *ip-address* **mac** *mac-address*

**no ip** *ip-address* **mac** *mac-address*

**Parameters**

- **ip-address**—Specifies the IP address to be entered to the list.
- **mac-address**—Specifies the MAC address associated with the IP address.

**Default Configuration**

No static ARP binding is defined.

**Command Mode**

ARP-list Configuration mode

**Example**

The following example creates a static ARP binding.

---

```
Console(config)# ip arp inspection list create servers
Console(config-ARP-list)# ip 172.16.1.1 mac 0060.704C.7321
Console(config-ARP-list)# ip 172.16.1.2 mac 0060.704C.7322
```

---

**32.18 ip arp inspection list assign**

Use the **ip arp inspection list assign** Global Configuration mode command to assign a static ARP binding list to a VLAN. Use the **no** form of this command to delete the assignment.

**Syntax**

**ip arp inspection list assign** *vlan-id name*

**no ip arp inspection list assign** *vlan-id*

**Parameters**

- **vlan-id**—Specifies the VLAN ID.
- **name**—Specifies the static ARP binding list name.

**Default Configuration**

No static ARP binding list assignment exists.

**Command Mode**

Global Configuration mode

**Example**

The following example assigns the static ARP binding list Servers to VLAN 37.

---

```
Console(config)# ip arp inspection list assign 37 servers
```

---

**32.19 ip arp inspection logging interval**

Use the **ip arp inspection logging interval** Global Configuration mode command to set the minimum time interval between successive ARP SYSLOG messages. Use the **no** form of this command to restore the default configuration.

**Syntax**

**ip arp inspection logging interval** {*seconds* | *infinite*}

**no ip arp inspection logging interval**

**Parameters**

- **seconds**—Specifies the minimum time interval between successive ARP SYSLOG messages. A 0 value means that a system message is immediately generated. (Range: 0–86400)
- **infinite**—Specifies that SYSLOG messages are not generated.

### Default Configuration

The default minimum ARP SYSLOG message logging time interval is 5 seconds.

### Command Mode

Global Configuration mode

### Example

The following example sets the minimum ARP SYSLOG message logging time interval to 60 seconds.

---

```
Console(config)# ip arp inspection logging interval 60
```

---

## 32.20 show ip arp inspection

Use the **show ip arp inspection** EXEC mode command to display the ARP inspection configuration for all interfaces or for a specific interface.

### Syntax

**show ip arp inspection** [*interface-id*]

### Parameters

**interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

### Command Mode

EXEC mode

### Example

The following example displays the ARP inspection configuration.

---

```
console# show ip arp inspection
IP ARP inspection is Enabled
IP ARP inspection is configured on following VLANs: 1
Verification of packet header is Enabled
IP ARP inspection logging interval is: 222 seconds
  Interface    Trusted
  -----
  gi1/0/11     Yes
  gi1/0/12     Yes
```

---

## 32.21 show ip arp inspection list

Use the **show ip arp inspection list** Privileged EXEC mode command to display the static ARP binding list.

### Syntax

**show ip arp inspection list**

### Parameters

N/A

**Command Mode**

Privileged EXEC mode

**Example**

The following example displays the static ARP binding list.

---

```

Console# show ip arp inspection list
List name: servers
Assigned to VLANs: 1,2

IP             ARP
-----
172.16.1.1     0060.704C.7322
172.16.1.2     0060.704C.7322

```

**32.22 show ip arp inspection statistics**Use the **show ip arp inspection statistics** EXEC command to display Statistics For The Following Types Of Packets That Have Been Processed By This Feature: Forwarded, Dropped, IP/MAC Validation Failure.**Syntax****show ip arp inspection statistics** [*vlan vlan-id*]**Parameters****vlan-id**—Specifies VLAN ID.**Command Mode**

EXEC mode

**User Guidelines**To clear ARP Inspection counters use the **clear ip arp inspection statistics** CLI command. Counters values are kept when disabling the ARP Inspection feature.**Example**


---

```

console# show ip arp inspection statistics
Vlan    Forwarded Packets    Dropped Packets    IP/MAC Failures
----    -
2       1500                 100                80

```

**32.23 clear ip arp inspection statistics**Use the **clear ip arp inspection statistics** Privileged EXEC mode command to clear statistics ARP Inspection statistics globally.**Syntax****clear ip arp inspection statistics** [*vlan vlan-id*]**Parameters****vlan-id**—Specifies VLAN ID

### Command Mode

Privileged EXEC mode

### Example

---

```
console# clear ip arp inspection statistics
```



## 33.1 ip address

Use the **ip address** Interface Configuration (Ethernet, VLAN, Port-channel) mode command to define an IP address for an interface. Use the **no** form of this command to remove an IP address definition.

### Syntax

**ip address** *ip-address* {*mask* | /*prefix-length*}

**no ip address** [*ip-address*]

### Parameters

- **ip-address**—Specifies the IP address.
- **mask**—Specifies the network mask of the IP address.
- **prefix-length**—Specifies the number of bits that comprise the IP address prefix. The prefix length must be preceded by a forward slash (/). (Range: 8–30)
- **default-gateway ip-address**—Specifies the default gateway IP address.

### Default Configuration

No IP address is defined for interfaces.

### Command Mode

Interface Configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

### User Guidelines

Assigning an IP address to an interface does not disable L2 protocols, such as STP. In addition, if this interface is a member of a VLAN, it remains a member after receiving the IP address.

Defining a static IP address on an interface implicitly removes the DHCP client configuration on the interface.

- The product supports up to 64 IP addresses.
- The IP addresses must be from different IP subnets. When adding an IP address from a subnet that already exists in the list, the new IP address replaces the existing IP address from that subnet.

If the IP address is configured in Interface context, the IP address is bound to the interface in that context.

If a static IP address is already defined, the user must do **no IP address** in the relevant interface context before changing the IP address.

If a dynamic IP address is already defined, the user must do **no ip address** in the relevant interface context before configuring another dynamic IP address.

The Interface context may be a port, LAG or VLAN, depending on support that is defined for the product.

**Example**

The following example configures VLAN 1 with IP address 131.108.1.27 and subnet mask 255.255.255.0.

---

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ip address 131.108.1.27 255.255.255.0
```

---

## 33.2 ip address dhcp

Use the **ip address dhcp** Interface Configuration (Ethernet, VLAN, Port-channel) mode command to acquire an IP address for an Ethernet interface from the Dynamic Host Configuration Protocol (DHCP) server. Use the **no** form of this command to release an acquired IP address.

**Syntax**

**ip address dhcp**

**no ip address dhcp**

**Parameters**

N/A

**Command Mode**

Interface Configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

**User Guidelines**

This command enables any interface to dynamically learn its IP address by using the DHCP protocol.

DHCP client configuration on an interface implicitly removes the static IP address configuration on the interface.

If the device is configured to obtain its IP address from a DHCP server, it sends a DHCPDISCOVER message to provide information about itself to the DHCP server on the network.

The **no ip address dhcp** command releases any IP address that was acquired, and sends a DHCPRELEASE message.

**Example**

The following example acquires an IP address for `gi1/0/116` from DHCP.

---

```
switchxxxxxx(config)# interface gi1/0/116
switchxxxxxx(config-if)# ip address dhcp
```

---

## 33.3 renew dhcp

Use the **renew dhcp** Privileged EXEC mode command to renew an IP address that was acquired from a DHCP server for a specific interface.

**Syntax**

**renew dhcp** *{interface-id}* [*force-autoconfig*]

**Parameters**

- **interface-id**—Specifies an interface ID (Ethernet port, Port-channel or VLAN).
- **force-autoconfig** - If the DHCP server holds a DHCP option 67 record for the assigned IP address, the record overwrites the existing device configuration.

**Command Mode**

Privileged EXEC mode

**User Guidelines**

Note the following:

- This command does not enable DHCP on an interface. If DHCP is not enabled on the requested interface, the command returns an error message.
- If DHCP is enabled on the interface and an IP address was already acquired, the command tries to renew that IP address.
- If DHCP is enabled on the interface and an IP address has not yet been acquired, the command initiates a DHCP request.

**Example**

The following example renews an IP address that was acquired from a DHCP server for VLAN 19.

---

```
switchxxxxxx# renew dhcp vlan 19
```

---

## 33.4 ip default-gateway

The **ip default-gateway** Global Configuration mode command defines a default gateway (device). Use the **no** form of this command to restore the default configuration.

**Syntax**

**ip default-gateway** *ip-address*

**no ip default-gateway**

**Parameters**

**ip-address**—Specifies the default gateway IP address.

**Command Mode**

Global Configuration mode

**Default Configuration**

No default gateway is defined.

**Example**

The following example defines default gateway 192.168.1.1.

---

```
switchxxxxxx(config)# ip default-gateway 192.168.1.1
```

## 33.5 show ip interface

Use the **show ip interface** EXEC mode command to display the usability status of configured IP interfaces.

### Syntax

**show ip interface** *[interface-id]*

### Parameters

**interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port, Port-channel or VLAN.

### Default Configuration

All IP addresses.

### Command Mode

EXEC mode

### Example

The following example displays the configured IP interfaces and their types when the device is in Switch mode.

```
switchxxxxxx# show ip interface
Gateway IP Address      Activity status      Type
-----
10.5.234.254           Active              static
IP Address      I/F      Type      Status
-----
10.5.234.207/24  vlan 1   Static    Valid
```

## 33.6 arp

Use the **arp** Global Configuration mode command to add a permanent entry to the Address Resolution Protocol (ARP) cache. Use the **no** form of this command to remove an entry from the ARP cache.

### Syntax

**arp** *ip-address mac-address [interface-id]*

**no arp** *ip-address*

### Parameters

- **ip-address**—IP address or IP alias to map to the specified MAC address.
- **mac-address**—MAC address to map to the specified IP address or IP alias.
- **interface-id**—Address pair is added for specified interface that can be Ethernet port, Port-channel or VLAN.

### Command Mode

Global Configuration mode

### Default Configuration

No permanent entry is defined.

If no interface ID is entered, address pair is relevant to all interfaces.

### User Guidelines

The software uses ARP cache entries to translate 32-bit IP addresses into 48-bit hardware (MAC) addresses. Because most hosts support dynamic address resolution, static ARP cache entries generally do not need to be specified.

### Example

The following example adds IP address 198.133.219.232 and MAC address 00:00:0c:40:0f:bc to the ARP table.

---

```
switchxxxxxx(config)# arp 198.133.219.232 00:00:0c:40:0f:bc gi1/0/16
```

---

## 33.7 arp timeout (Global)

Use the **arp timeout** Global Configuration mode command to set the time interval during which an entry remains in the ARP cache. Use the **no** form of this command to restore the default configuration.

### Syntax

**arp timeout** *seconds*

**no arp timeout**

### Parameters

**seconds**—Specifies the time interval (in seconds) during which an entry remains in the ARP cache. (Range: 1–40000000)

### Default Configuration

The default ARP timeout is 60000 seconds.

### Command Mode

Global Configuration mode

### Example

The following example configures the ARP timeout to 12000 seconds.

---

```
switchxxxxxx(config)# arp timeout 12000
```

---

## 33.8 arp timeout (Interface)

Use the **arp timeout** in Terface Configuration command to configure how long an entry remains in the ARP cache for specific interface. Use the **no** form of this command restore the default value.

### Syntax

**arp timeout** *seconds*

**no arp timeout**

### Parameters

**seconds**—Time (in seconds) that an entry remains in the ARP cache. It is recommended not to set it to less than 3600. (Range: 1–40000000)

### Default

Defined by the **arp timeout** Global Configuration command

**Command Mode**

Interface Configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

**User Guidelines**

This configuration can be applied only if at least one IP address is defined on specific interface.

**Example**

---

```
switchxxxxxx (config)# interface vlan 1
switchxxxxxx(config-if)# arp timeout 12000
```

---

## 33.9 ip arp proxy disable

Use the **ip arp proxy disable** Global Configuration mode command to globally disable proxy Address Resolution Protocol (ARP). Use the **no** form of this command reenable proxy ARP.

**Syntax**

**ip arp proxy disable**

**no ip arp proxy disable**

**Parameters**

N/A

**Default**

Enabled by default.

**Command Mode**

Global Configuration mode

**User Guidelines**

This command overrides any proxy ARP interface configuration.

**Example**

The following example globally disables ARP proxy.

---

```
switchxxxxxx(config)# ip arp proxy disable
```

---

## 33.10 ip proxy-arp

Use the **ip proxy-arp** Interface Configuration mode command to enable an ARP proxy on specific interfaces. Use the **no** form of this command disable it.

**Syntax**

**ip proxy-arp**

**no ip proxy-arp**

**Default Configuration**

ARP Proxy is disabled.

**Command Mode**

Interface Configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

**User Guidelines**

This configuration can be applied only if at least one IP address is defined on a specific interface.

**Example**

The following example enables ARP proxy.

---

```
switchxxxxxx(config-if)# ip proxy-arp
```

---

## 33.11 clear arp-cache

Use the **clear arp-cache** Privileged EXEC mode command to delete all dynamic entries from the ARP cache.

**Syntax**

**clear arp-cache**

**Command Mode**

Privileged EXEC mode

**Example**

The following example deletes all dynamic entries from the ARP cache.

---

```
switchxxxxxx# clear arp-cache
```

---

## 33.12 show arp

Use the **show arp** Privileged EXEC mode command to display entries in the ARP table.

**Syntax**

**show arp** [*ip-address ip-address*] [*mac-address mac-address*] [*interface-id*]

**Parameters**

- **ip-address** *ip-address*—Specifies the IP address.
- **mac-address** *mac-address*—Specifies the MAC address.
- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

**Command Mode**

Privileged EXEC mode

**User Guidelines**

Since the associated interface of a MAC address can be aged out from the FDB table, the Interface field can be empty.

If an ARP entry is associated with an IP interface that is defined on a port or port-channel, the VLAN field is empty.

**Example**

The following example displays entries in the ARP table.

---

```
switchxxxxxx# show arp
ARP timeout: 80000 Seconds

VLAN      Interface  IP Address  HW Address      Status
-----
VLAN 1    gi1/0/11   10.7.1.102  00:10:B5:04:DB:4B  Dynamic
VLAN 1    gi1/0/12   10.7.1.135  00:50:22:00:2A:A4  Static
```

---

**33.13 show arp configuration**

Use the **show arp configuration** privileged EXEC command to display the global and interface configuration of the ARP protocol.

**Syntax**

**show arp configuration**

**Parameters**

This command has no arguments or key words.

**Command Mode**

Privileged EXEC mode

**Example**


---

```
switchxxxxxx# show arp configuration
Global configuration:
  ARP Proxy: enabled
  ARP timeout: 80000 Seconds
Interface configuration:
g2:
  ARP Proxy: disabled
  ARP timeout:60000 Seconds
VLAN 1:
  ARP Proxy: enabled
  ARP timeout:70000 Seconds
VLAN 2:
  ARP Proxy: enabled
  ARP timeout:80000 Second (Global)
```

---

**33.14 directed-broadcast**

Use the **directed-broadcast** IP Interface Configuration mode command to enable the translation of a directed broadcast to physical broadcasts. Use the **no** form of this command to disable this function.

**Syntax**

**directed-broadcast**

**no directed-broadcast**



### Default Configuration

Translation of a directed broadcast to physical broadcasts is disabled. All IP directed broadcasts are dropped.

### Command Mode

IP Interface Configuration mode

### Example

The following example enables the translation of a directed broadcast to physical broadcasts.

---

```
switchxxxxxx(config)# interface ip 192.168.1.1
switchxxxxxx(config-ip)# directed-broadcast
```

---

## 33.15 broadcast-address

Use the **broadcast-address** IP Interface Configuration mode command to define a broadcast address for an interface. Use the **no** form of this command to restore the default IP broadcast address.

### Syntax

**broadcast-address** {255.255.255.255 | 0.0.0.0}

**no broadcast-address**

### Parameters

- **255.255.255.255**—Specifies 255.255.255.255 as the broadcast address.
- **0.0.0.0**—Specifies 0.0.0.0 as the broadcast address.

### Default Configuration

The default broadcast address is 255.255.255.255.

### Command Mode

IP Interface Configuration mode

### Example

The following example enables the translation of a directed broadcast to physical broadcasts.

---

```
switchxxxxxx(config)# interface ip 192.168.1.1
switchxxxxxx(config-ip)# broadcast-address 255.255.255.255
```

---

## 33.16 ip helper-address

Use the **ip helper-address** Global Configuration mode command to enable the forwarding of UDP Broadcast packets received on an interface to a specific (helper) address. Use the **no** form of this command to disable the forwarding of broadcast packets to a specific (helper) address.

### Syntax

**ip helper-address** {ip-interface | all} address [udp-port-list]

**no ip helper-address** {ip-interface | all} address

**Parameters**

- **ip-interface**—Specifies the IP interface.
- **all**—Specifies all IP interfaces.
- **address**—Specifies the destination broadcast or host address to which to forward UDP broadcast packets. A value of 0.0.0.0 specifies that UDP broadcast packets are not forwarded to any host.
- **udp-port-list**—Specifies the destination UDP port number to which to forward Broadcast packets. (Range: 1–65535). This can be a list of port numbers separated by spaces.

**Default Configuration**

Forwarding of UDP Broadcast packets received on an interface to a specific (helper) address is disabled.

If **udp-port-list** is not specified, packets for the default services are forwarded to the helper address.

**Command Mode**

Global Configuration mode

**User Guidelines**

This command forwards specific UDP Broadcast packets from one interface to another, by specifying a UDP port number to which UDP broadcast packets with that destination port number are forwarded. By default, if no UDP port number is specified, the device forwards UDP broadcast packets for the following six services:

- IEN-116 Name Service (port 42)
- DNS (port 53)
- NetBIOS Name Server (port 137)
- NetBIOS Datagram Server (port 138)
- TACACS Server (port 49)
- Time Service (port 37)

Many helper addresses may be defined. However, the total number of address-port pairs is limited to 128 for the device.

The setting of a helper address for a specific interface has precedence over the setting of a helper address for all the interfaces.

Forwarding of BOOTP/DHCP (ports 67, 68) cannot be enabled with this command. Use the DHCP relay commands to relay BOOTP/DHCP packets.

**Example**

The following example enables the forwarding of UDP Broadcast packets received on all interfaces to the UDP ports of a destination IP address and UDP port 1 and 2.

---

```
switchxxxxxx(config)# ip helper-address all 172.16.9.9 49 53 1 2
```

---

**33.17 show ip helper-address**

Use the **show ip helper-address** Privileged EXEC mode command to display the IP helper addresses configuration on the system.

**Syntax**

**show ip helper-address**

**Parameters**

This command has no arguments or key words.

**Command Mode**

Privileged EXEC mode

**Example**

The following example displays the IP helper addresses configuration on the system.

---

```
switchxxxxxx# show ip helper-address
```

Interface	Helper Address	UDP Ports
-----	-----	-----
192.168.1.1	172.16.8.8	37, 42, 49, 53, 137, 138
192.168.2.1	172.16.9.9	37, 49

---

## 33.18 source-precedence

Use the **source-precedence** IP Interface Configuration mode command to define a preference for an IP address as a source IP address for DHCP relayed messages on an interface. Use the **no** form of this command to restore the default configuration.

**Syntax****source-precedence****no source-precedence****Default Configuration**

Source precedence is not defined for the address.

**Command Mode**

IP Interface Configuration mode

**User Guidelines**

For relayed DHCP messages, the source IP address selected is:

1. The lowest of the IP addresses defined as source-precedence IP addresses.
2. The lowest of the IP addresses if there are no source-precedence IP addresses.

**Example**

The following example defines a preference for an IP address as a source IP address for DHCP relayed messages on an interface.

---

```
switchxxxxxx(config-ip)# source-precedence
```

---

## 33.19 ip domain lookup

Use the **ip domain lookup** Global Configuration mode command to enable the IP Domain Name System (DNS)-based host name-to-address translation. Use the **no** form of this command to disable DNS-based host name-to-address translation.

**Syntax****ip domain lookup****no ip domain lookup**

### Default Configuration

Enabled.

### Command Mode

Global Configuration mode

### Example

The following example enables DNS-based host name-to-address translation.

---

```
switchxxxxxx(config)# ip domain lookup
```

---

## 33.20 ip domain name

Use the **ip domain name** Global Configuration mode command to define a default domain name used by the software to complete unqualified host names (names without a dotted-decimal domain name). Use the **no** form of this command to remove the default domain name.

### Syntax

**ip domain name** *name*

**no ip domain name**

### Parameters

**name**—Specifies the default domain name used to complete unqualified host names. Do not include the initial period that separates an unqualified name from the domain name. (Length: 1–158 characters. Maximum label length of each domain level is 63 characters)

### Default Configuration

A default domain name is not defined.

### Command Mode

Global Configuration mode

### User Guidelines

Domain names and host names are restricted to the ASCII letters A through Z (case-insensitive), the digits 0 through 9, the underscore and the hyphen. A period (.) is used to separate labels.

The maximum size of each domain level is 63 characters. The maximum name size is 158 bytes.

### Example

The following example defines the default domain name as 'www.website.com'.

---

```
switchxxxxxx(config)# ip domain name www.website.com
```

---

## 33.21 ip name-server

Use the **ip name-server** Global Configuration mode command to define the available name servers. Use the **no** form of this command to remove a name server.

### Syntax

**ip name-server** {*server1-ip-address*} [*server-address2* ... *server-address8*]

**no ip name-server** [*server-address* ... *server-address8*]

**Parameters**

**server-address**—IP addresses of the name server. Up to 8 servers can be defined in one command or by using multiple commands. The IP address can be an IPv4 address, IPv6 or IPv6z address. See [IPv6z Address Conventions](#).

**Default Configuration**

No name server IP addresses are defined.

**Command Mode**

Global Configuration mode

**User Guidelines**

The preference of the servers is determined by the order in which they were entered.

Up to 8 servers can be defined using one command or using multiple commands.

**Example**

The following example defines the available name server.

---

```
switchxxxxxx(config)# ip name-server 176.16.1.18
```

---

## 33.22 ip host

Use the **ip host** Global Configuration mode command to define the static host name-to-address mapping in the host cache. Use the **no** form of this command to remove the static host name-to-address mapping.

**Syntax**

**ip host** *name* *address* [*address2* *address3* *address4*]

**no ip host** *name*

**Parameters**

- **name**—Specifies the host name. (Length: 1–158 characters. Maximum label length of each domain level is 63 characters)
- **address**—Specifies the associated IP address. Up to 4 addresses can be defined separated by blanks.

**Default Configuration**

No host is defined.

**Command Mode**

Global Configuration mode

**User Guidelines**

Host names are restricted to the ASCII letters A through Z (case-insensitive), the digits 0 through 9, the underscore and the hyphen. A period (.) is used to separate labels.

**Example**

The following example defines a static host name-to-address mapping in the host cache.

---

```
switchxxxxxx(config)# ip host accounting.website.com 176.10.23.1
```

---

---

## 33.23 clear host

Use the **clear host** Privileged EXEC mode command to delete entries from the host name-to-address cache.

### Syntax

```
clear host {name | *}
```

### Parameters

- **name**—Specifies the host entry to remove. (Length: 1–158 characters. Maximum label length: of each domain level is 63 characters)
- **\***—Removes all entries.

### Command Mode

Privileged EXEC mode

### Example

The following example deletes all entries from the host name-to-address cache.

---

```
switchxxxxxx# clear host *
```

---

## 33.24 clear host dhcp

Use the **clear host dhcp** Privileged EXEC mode command to delete entries from the host name-to-address mapping received from the Dynamic Host Configuration Protocol (DHCP) server.

### Syntax

```
clear host dhcp {name | *}
```

### Parameters

- **name** —Specifies the host entry to remove. (Length: 1–158 characters. Maximum label length of each domain level is 63 characters)
- **\***—Removes all entries.

### Command Mode

Privileged EXEC mode

### User Guidelines

This command deletes the host name-to-address mapping temporarily until the next refresh of the IP addresses.

### Example

The following example deletes all entries from the host name-to-address mapping received from DHCP.

---

```
switchxxxxxx# clear host dhcp *
```

## 33.25 show hosts

Use the **show hosts** EXEC mode command to display the default domain name, the list of name server hosts, the static and the cached list of host names and addresses.

### Syntax

**show hosts** *[name]*

### Parameters

**name**—Specifies the host name. (Length: 1–158 characters. Maximum label length of each domain level is 63 characters)

### Command Mode

EXEC mode

### Example

The following example displays host information.

---

```
switchxxxxxx# show hosts
System name: Device
Default domain is gm.com, sales.gm.com, usa.sales.gm.com(DHCP)
Name/address lookup is enabled
Name servers (Preference order): 176.16.1.18 176.16.1.19
Configured host name-to-address mapping:

Host                                IP Addresses
-----
accounting.gm.com                    176.16.8.8 176.16.8.9 (DHCP)
                                      2002:0:130F::0A0:1504:0BB4

Cache: TTL (Hours)

Host            Total  Elapsed  Type  IP Addresses
-----
www.stanford.edu 72     3        IP    171.64.14.203
```





---

## 34.1 ipv6 enable

Use the **ipv6 enable** Interface Configuration (Ethernet, VLAN, Port-channel) mode command to enable the IPv6 addressing mode on an interface. Use the **no** form of this command to disable the IPv6 addressing mode on an interface.

### Syntax

**ipv6 enable** [*no-autoconfig*]

**no ipv6 enable**

### Parameters

**no-autoconfig**—Enables processing of IPv6 on an interface without the stateless address autoconfiguration procedure. This procedure assigns link-local addresses.

### Default Configuration

IPv6 addressing is disabled.

Unless you are using the **no-autoconfig** parameter, when the interface is enabled, stateless address autoconfiguration procedure is enabled.

### Command Mode

Interface Configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

### User Guidelines

This command automatically configures an IPv6 link-local Unicast address on the interface, while also enabling the interface for IPv6 processing. The **no ipv6 enable** command removes the entire IPv6 interface configuration.

To enable stateless address autoconfiguration on an enabled IPv6 interface, use the [ipv6 address autoconfig](#) command.

### Example

The following example enables VLAN 1 for the IPv6 addressing.

---

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ipv6 enable
```

---

## 34.2 ipv6 address autoconfig

Use the **ipv6 address autoconfig** Interface Configuration mode command to enable automatic configuration of IPv6 addresses, using stateless autoconfiguration on an interface. Addresses are configured depending on the prefixes received in Router Advertisement messages. Use the **no** form of this command to disable address autoconfiguration on the interface.

### Syntax

**ipv6 address autoconfig**

**no ipv6 address autoconfig**

### Parameters

N/A

### Default Configuration

Address autoconfiguration is enabled on the interface, no addresses are assigned by default.

### Command Mode

Interface Configuration (Ethernet, VLAN, Port-channel) mode.

### User Guidelines

When **address autoconfig** is enabled, the router solicitation ND procedure is initiated to discover a router and assign IP addresses to the interface, based on the advertised on-link prefixes.

When disabling address autoconfig, automatically generated addresses that were assigned to the interface are removed.

The default state of the address autoconfig is **enabled**. Use the **ipv6 enable no-autoconfig** command to enable an IPv6 interface without address autoconfig.

### Example

---

```
switchxxxxxx(config)# interface vlan 1  
switchxxxxxx(config-if)# ipv6 address autoconfig
```

---

## 34.3 ipv6 icmp error-interval

Use the **ipv6 icmp error-interval** Global Configuration mode command to configure the rate limit interval and bucket size parameters for IPv6 Internet Control Message Protocol (ICMP) error messages. Use the **no** form of this command to return the interval to its default setting.

### Syntax

**ipv6 icmp error-interval** *milliseconds* [*bucketsize*]

**no ipv6 icmp error-interval**

### Parameters

- **milliseconds**—The time interval between tokens being placed in the bucket. Each token represents a single ICMP error message. The acceptable range is from 0–2147483647 with a default of 100 milliseconds. Setting milliseconds to 0 disables rate limiting. (Range: 0–2147483647)
- **bucketsize**—(Optional) The maximum number of tokens stored in the bucket. The acceptable range is from 1–200 with a default of 10 tokens.

**Default Configuration**

The default interval is 100ms and the default bucket size is 10 i.e. 100 ICMP error messages per second.

**Command Mode**

Global Configuration mode

**User Guidelines**

To set the average ICMP error rate limit, calculate the interval with the following formula:

Average Packets Per Second = (1/ interval) \* bucket size

**Example**


---

```
switchxxxxxx(config)# ipv6 icmp error-interval 123 45
```

---

**34.4 show ipv6 icmp error-interval**

Use the **show ipv6 error-interval** command in the EXEC mode to display the IPv6 ICMP error interval.

**Syntax**

**show ipv6 icmp error-interval**

**Parameters**

N/A

**Default Configuration**

N/A

**Command Mode**

EXEC mode

**Example**


---

```
switchxxxxxx# show ipv6 icmp error-interval
Rate limit interval: 100 ms
Bucket size: 10 tokens
```

---

**34.5 ipv6 address**

Use the **ipv6 address** Interface Configuration mode command to configure an IPv6 address for an interface. Use the **no** form of this command to remove the address from the interface.

**Syntax**

**ipv6 address** *ipv6-address/prefix-length* [**eui-64**] [**anycast**]

**no ipv6 address** [*ipv6-address/prefix-length*] [**link-local**] [**eui-64**]

**Parameters**

- **ipv6-address**—Specifies the IPv6 network assigned to the interface. This argument must be in the form documented in RFC 2373 where the address is specified in hexadecimal using 16-bit values between colons.

- **prefix-length**—Specifies the length of the IPv6 prefix. A decimal value that indicates how many of the high-order contiguous bits of the address comprise the prefix (the network portion of the address). A slash mark (/) must precede the decimal.
- **eui-64**—(Optional) Builds an interface ID in the low order 64 bits of the IPv6 address based on the interface MAC address.
- **anycast**—(Optional) Indicates that this address is an anycast address.
- **prefix-length**—3–128(64 when the **eui-64** parameter is used).
- **link-local**—Use the link-local address.

### Default Configuration

No IP address is defined for the interface.

### Command Mode

Interface configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

### User Guidelines

If the value specified for the /prefix-length argument is greater than 64 bits, the prefix bits have precedence over the interface ID.

Using the **no IPv6 address** command without arguments removes all manually configured IPv6 addresses from an interface, including link-local manually-configured addresses.

### Example

---

```
switchxxxxxxx(config)# interface vlan 1
switchxxxxxxx(config-if)# ipv6 address 3000::123/64 eui-64 anycast
```

---

## 34.6 ipv6 address link-local

Use the **ipv6 address link-local** command to configure an IPv6 link-local address for an interface. Use the **no** form of this command to return to the default link-local address on the interface.

### Syntax

```
ipv6 address ipv6-address /prefix-length link-local
no ipv6 address [ipv6-address /prefix-length link-local]
```

### Parameters

- **ipv6-address**—Specifies the IPv6 network assigned to the interface. This argument must be in the format documented in RFC 2373, where the address is specified in hexadecimals using 16-bit values between colons.
- **prefix-length**—Specifies the length of the IPv6 prefix. A decimal value indicates how many of the high-order contiguous bits of the address comprise the prefix (the network portion of the address). A slash mark (/) must precede the decimal. Only 64-bit length is supported, according to IPv6 over Ethernet's well-known practice

### Default Configuration

IPv6 is enabled on the interface, the link-local address of the interface is FE80::EUI64 (interface MAC address).

### Command Mode

Interface Configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

### User Guidelines

Using the **no ipv6 link-local address** command removes the manually configured link-local IPv6 address from an interface. Multiple IPv6 addresses can be configured per interface, but only one link-local address. When the **no ipv6 link-local address** command is used, the interface is reconfigured with the standard link-local address (the same IPv6 link-local address that is set automatically when the **enable ipv6** command is used). The system automatically generates a link-local address for an interface when IPv6 processing is enabled on the interface. To manually specify a link-local address to be used by an interface, use the **ipv6 link-local address** command. The system supports only 64 bits prefix length for link-local addresses.

### Example

---

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ipv6 address fe80::123/64 link-local
```

---

## 34.7 ipv6 unreachable

Use the **ipv6 unreachable** Interface Configuration mode command to enable the generation of Internet Control Message Protocol for IPv6 (ICMPv6) unreachable messages for any packets arriving on a specified interface. Use the **no** form of this command To prevent the generation of unreachable messages.

### Syntax

**ipv6 unreachable**

**no ipv6 unreachable**

### Parameters

N/A

### Default Configuration

ICMP unreachable messages are sent by default.

### Command Mode

Interface Configuration (Ethernet, VLAN, Port-channel) mode.

### User Guidelines

When ICMP unreachable messages are enabled, when receiving a packet addressed to one of the interface's IP address with TCP/UDP port not assigned, the device sends ICMP unreachable messages.

### Example

---

```
switchxxxxxx(config)# interface gi1/0/11
switchxxxxxx(config-if)# ipv6 unreachable
```

---

## 34.8 ipv6 default-gateway

Use the **ipv6 default-gateway** Global Configuration mode command to define an IPv6 default gateway. Use the **no** form of this command To remove the default gateway.

### Syntax

**ipv6 default-gateway** *ipv6-address*

**no ipv6 default-gateway**

**Parameters**

**ipv6-address**—Specifies the IPv6 address of the next hop that can be used to reach the required network. When the IPv6 address is a link-local address (IPv6Z address), See [IPv6z Address Conventions](#).

**Default Configuration**

No default gateway is defined.

**Command Mode**

Global Configuration mode

**User Guidelines**

Configuring a new default GW without deleting the previous configured information overwrites the previous configuration.

A configured default GW has a higher precedence over an automatically advertised (via router advertisement message).

Precedence takes effect after the configured default GW is reachable.

Reachability state is not verified automatically by the neighbor discovery protocol. Router reachability can be confirmed by either receiving a Router Advertisement message containing the router's MAC address or by manually configuring this using the [ipv6 neighbor](#) command. Another option to force reachability confirmation is to ping the router link-local address (this will initiate the neighbor discovery process).

If the egress interface is not specified, the default interface is selected. Specifying interface zone=0 is equal to not defining an egress interface.

**Example**

---

```
switchxxxxxx(config)# ipv6 default-gateway fe80::abcd
```

---

## 34.9 show ipv6 interface

Use the **show ipv6 interface** EXEC command mode to display the usability status of interfaces configured for IPv6.

**Syntax**

**show ipv6 interface** *[interface-id]*

**Parameters**

**interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port, Port-channel or VLAN.

**Default Configuration**

Displays all IPv6 interfaces.

**Command Mode**

EXEC mode

**User Guidelines**

Use the **show ipv6 neighbors** command in the privileged EXEC mode to display an IPv6 neighbor's discovery cache information.

**Examples****Example 1-** Show all IPv6 interfaces.

```
switchxxxxxx# show ipv6 interface
```

Interface	IP addresses	Type
VLAN 1	4004::55/64 [ANY]	manual
VLAN 1	fe80::200:b0ff:fe00:0	linklayer
VLAN 1	ff02::1	linklayer
VLAN 1	ff02::77	manual
VLAN 1	ff02::1:ff00:0	manual
VLAN 1	ff02::1:ff00:1	manual
VLAN 1	ff02::1:ff00:55	manual

  

Default Gateway IP address	Type	Interface	State
fe80::77	Static	VLAN 1	unreachable
fe80::200:cff:fe4a:dfa8	Dynamic	VLAN 1	stale

**Example 2 -** Show IPv6 interfaces on VLAN 15 where IPv6 is not enabled.

```
switchxxxxxx# show ipv6 interface Vlan 15
IPv6 is disabled
```

**Example 3 -** Show IPv6 interfaces on VLAN 15 where it is enabled.

```
switchxxxxxx# show ipv6 interface Vlan 1
Number of ND DAD attempts: 1
MTU size: 1500
Stateless Address Autoconfiguration state: enabled
ICMP unreachable message state: enabled
MLD version: 2
```

IP addresses	Type	DAD State
4004::55/64 [ANY]	manual	Active
fe80::200:b0ff:fe00:0	linklayer	Active
ff02::1	linklayer	-----
ff02::77	manual	-----
ff02::1:ff00:0	manual	-----
ff02::1:ff00:1	manual	-----
ff02::1:ff00:55	manual	-----

**34.10 show IPv6 route**Use the **show ipv6 route** Exec mode command to display the current state of the IPv6 routing table.**Syntax****show ipv6 route**

**Parameters**

N/A

**Default Configuration**

N/A

**Command Mode**

EXEC mode

**Example**


---

```
switchxxxxxx# show ipv6 route
Codes: L - Local, S - Static, I - ICMP, ND - Router Advertisement
The number in the brackets is the metric.
S  ::/0 via fe80::77 [0] VLAN 1 Lifetime Infinite
ND ::/0 via fe80::200:cff:fe4a:dfa8 [0] VLAN 1 Lifetime 1784 sec
L  2001::/64 is directly connected, g2 Lifetime Infinite
L  2002:1:1:1::/64 is directly connected, VLAN 1 Lifetime 2147467 sec
L  3001::/64 is directly connected, VLAN 1 Lifetime Infinite
L  4004::/64 is directly connected, VLAN 1 Lifetime Infinite
L  6001::/64 is directly connected, g2 Lifetime Infinite
```

---

## 34.11 ipv6 nd dad attempts

Use the **ipv6 nd dad attempts** Interface Configuration (Ethernet, VLAN, Port-channel) mode command to configure the number of consecutive neighbor solicitation messages that are sent on an interface while Duplicate Address Detection (DAD) is performed on the unicast IPv6 addresses of the interface. Use the **no** form of this command to restore the number of messages to the default value.

**Syntax****ipv6 nd dad attempts** *attempts***Parameters**

**attempts**—Specifies the number of neighbor solicitation messages. A value of 0 disables DAD processing on the specified interface. A value of 1 configures a single transmission without follow-up transmissions. (Range: 0–600)

**Default Configuration**

DAD on Unicast IPv6 addresses with the sending of one neighbor solicitation message is enabled.

**Command Mode**

Interface Configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

**User Guidelines**

DAD verifies the uniqueness of new Unicast IPv6 addresses before the addresses are assigned to interfaces (the new addresses remain in a tentative state while DAD is performed). DAD uses neighbor solicitation messages to verify the uniqueness of unicast IPv6 addresses.

An interface returning to the administrative Up state restarts DAD for all Unicast IPv6 addresses on the interface. While DAD is performed on the link-local address of an interface, the state of the other IPv6



addresses is still set to TENTATIVE. When DAD is completed on the link-local address, DAD is performed on the remaining IPv6 addresses.

When DAD identifies a duplicate address, the address state is set to DUPLICATE and the address is not used. If the duplicate address is the link-local address of the interface, the processing of IPv6 packets is disabled on the interface and an error message is displayed.

All configuration commands associated with the duplicate address remain as configured, while the address state is set to DUPLICATE.

If the link-local address for an interface changes, DAD is performed on the new link-local address and all of the other IPv6 address associated with the interface are regenerated (DAD is performed only on the new link-local address).

Configuring a value of 0 with this command disables duplicate address detection processing on the specified interface. A value of 1 configures a single transmission without follow-up transmissions. The default is 1 message.

Until the DAD process is completed, an IPv6 address is in the tentative state and cannot be used for data transfer. It is recommended to limit the configured value.

### Example

The following example configures the number of consecutive neighbor solicitation messages sent during DAD processing to 2 on `gi1/0/19`.

---

```
switchxxxxxx (config)# interface gi1/0/19
switchxxxxxx (config-if)# ipv6 nd dad attempts 2
```

---

## 34.12 ipv6 host

Use the **ipv6 host** Global Configuration mode command to define a static host name-to-address mapping in the host name cache. Use the **no** form of this command to remove the host name-to-address mapping.

### Syntax

**ipv6 host** *name* *ipv6-address1* [*ipv6-address2...ipv6-address4*]

**no ipv6 host** *name*

### Parameters

**host name** - Name of the host. (Range: 1–158 characters)

- **ipv6-address1**—Associated IPv6 address. This argument must be in the form documented in RFC 2373 where the address is specified in hexadecimal using 16-bit values between colons. When the IPv6 address is a link-local address (IPv6Z address), the outgoing interface name must be specified. See [IPv6z Address Conventions](#).
- **ipv6-address2-4**—(Optional) Additional IPv6 addresses that may be associated with the host's name

### Default Configuration

No host is defined.

### Command Mode

Global Configuration mode

### Example

---

```
switchxxxxxx(config)# ipv6 host server 3000::a31b
```

## 34.13 ipv6 neighbor

Use the **ipv6 neighbor** command to configure a static entry in the IPv6 neighbor discovery cache. Use the **no** form of this command to remove a static IPv6 entry from the IPv6 neighbor discovery cache.

### Syntax

**ipv6 neighbor** *ipv6\_addr interface-id hw\_addr*

**no ipv6 neighbor** *ipv6\_addr interface-id*

### Parameters

- **ipv6\_addr**—Specifies the IPv6 address to map to the specified MAC address.
- **interface-id**—Specifies the interface that is associated with the IPv6 address
- **hw\_addr**—Specifies the MAC address to map to the specified IPv6 address.

### Command Mode

Global Configuration mode

### User Guidelines

The **IPv6 neighbor** command is similar to the [arp](#) command.

If an entry for the specified IPv6 address already exists in the neighbor discovery cache—learned through the IPv6 neighbor discovery process—the entry is automatically converted to a static entry.

A new static neighbor entry with a global address can be configured only if a manually configured subnet already exists in the device.

Use the [show ipv6 neighbors](#) command to view static entries in the IPv6 neighbor discovery cache.

### Example

```
switchxxxxxx(config)# ipv6 neighbor 3000::a31b vlan 1 001b.3f9c.84ea
```

## 34.14 ipv6 set mtu

Use the **ipv6 mtu** Privileged EXEC mode command to set the maximum transmission unit (MTU) size of IPv6 packets sent on an interface. Use the default parameter to restore the default MTU size.

### Syntax

**ipv6 set mtu** *{interface-id} {bytes | default}*

### Parameters

- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.
- **bytes**—Specifies the MTU in bytes. Range is 1280-65535.
- **default**—Sets the default MTU size 1500 bytes. Minimum is 1280 bytes

### Default Configuration

1500 bytes

### Command Mode

Privileged EXEC mode

### User Guidelines

This command is intended for debugging and testing purposes and should be used only by technical support personnel.

### Example

---

```
switchxxxxxx# ipv6 set mtu gi1/0/11 default
```

---

## 34.15 ipv6 mld version

Use the **ipv6 mld version** Interface Configuration mode command to change the version of the Multicast Listener Discovery Protocol (MLD). Use the **no** form of this command to change to the default version.

### Syntax

```
ipv6 mld version {1 | 2}
```

```
no ipv6 mld version
```

### Parameters

- 1—Specifies MLD version 1.
- 2—Specifies MLD version 2.

### Default Configuration

MLD version 1.

### Command Mode

Interface Configuration (Ethernet, VLAN, Port-channel) mode

---

```
switchxxxxxx(config)# interface vlan 1  
switchxxxxxx(config-if)# ipv6 mld version 2
```

---

## 34.16 ipv6 mld join-group

Use the **ipv6 mld join-group** Interface Configuration mode command to configure MLD reporting for a specified group. Use the **no** form of this command to cancel reporting and leave the group.

### Syntax

```
ipv6 mld join-group group-address
```

```
no ipv6 mld join-group group-address
```

### Parameters

**group-address**—Specifies the IPv6 address of the Multicast group.

### Default Configuration

N/A

### Command Mode

Interface Configuration (Ethernet, VLAN, Port-channel) mode

**User Guidelines**

This command configures MLD reporting for a specified group. The packets that are addressed to a specified group address that will be passed to the client process in the device.

**Example**

The following example configures MLD reporting for specific groups:

---

```
switchxxxxxx(conf) #interface gi1
switchxxxxxx(conf-if) #ipv6 mld join-group ff02::10
```

---

**34.17 show ipv6 neighbors**

Use the **show ipv6 neighbors** Privileged EXEC mode command to display IPv6 neighbor discovery cache information.

**Syntax**

```
show ipv6 neighbors {static | dynamic} [ipv6-address ipv6-address] [mac-address mac-address]
[interface-id]
```

**Parameters**

- **static**—Shows static neighbor discovery cache entries.
- **dynamic**—Shows dynamic neighbor discovery cache entries.
- **ipv6-address**—Shows the neighbor discovery cache information entry of a specific IPv6 address.
- **mac-address**—Shows the neighbor discovery cache information entry of a specific MAC address.
- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port, Port-channel or VLAN.

**Command Mode**

Privileged EXEC mode

**User Guidelines**

Since the associated interface of a MAC address can be aged out from the FDB table, the Interface field can be empty.

When an ARP entry is associated with an IP interface that is defined on a port or port-channel, the VLAN field is empty.

The possible neighbor cache states are:

- **INCMP (Incomplete)**—Address resolution is being performed on the entry. Specifically, a Neighbor Solicitation has been sent to the solicited-node multicast address of the target, but the corresponding Neighbor Advertisement has not yet been received.
- **REACH (Reachable)**—Positive confirmation was received within the last ReachableTime milliseconds that the forward path to the neighbor was functioning properly. While REACHABLE, no special action takes place as packets are sent.
- **STALE**—More than ReachableTime milliseconds have elapsed since the last positive confirmation was received that the forward path was functioning properly. While stale, no action takes place until a packet is sent.
- **DELAY**—More than ReachableTime milliseconds have elapsed since the last positive confirmation was received that the forward path was functioning properly, and a packet was sent within the last DELAY\_FIRST\_PROBE\_TIME seconds. If no reachability confirmation is received within DELAY\_FIRST\_PROBE\_TIME seconds of entering the DELAY state, send a Neighbor Solicitation and change the state to PROBE.
- **PROBE**—A reachability confirmation is actively sought by retransmitting Neighbor Solicitations every RetransTimer milliseconds until a reachability confirmation is received.

**Example**


---

```
switchxxxxxx# show ipv6 neighbors dynamic
```

Interface	IPv6 Address	HW Address	State*	Router
VLAN 1	fe80::200:cff:fe4a:dfa8	00:00:0c:4a:df:a8	stale	yes
VLAN 1	fe80::2d0:b7ff:feal:264d	00:d0:b7:a1:26:4d	stale	no

\*See State values above.

---

**34.18 clear ipv6 neighbors**

Use the **clear ipv6 neighbors** Privileged EXEC mode command to delete all entries in the IPv6 neighbor discovery cache, except for static entries.

**Syntax**

**clear ipv6 neighbors**

**Parameters**

This command has no keywords or arguments.

**Command Mode**

Privileged EXEC mode

**Example**


---

```
switchxxxxxx# clear ipv6 neighbors
```



---

## 35.1 interface tunnel

Use the **interface tunnel** Global Configuration mode command to enter the Interface Configuration (Tunnel) mode.

### Syntax

**interface tunnel** *number*

### Parameters

**number**—Specifies the tunnel index.

### Default Configuration

N/A

### Command Mode

Global Configuration mode

### Example

The following example enters the Interface Configuration (Tunnel) mode.

---

```
switchxxxxxx(config)# interface tunnel 1
switchxxxxxx(config-tunnel)#
```

---

## 35.2 tunnel mode ipv6ip

Use the **tunnel mode ipv6ip** Interface Configuration (Tunnel) mode command to configure an IPv6 transition-mechanism global support mode. Use the **no** form of this command to remove an IPv6 transition mechanism.

### Syntax

**tunnel mode ipv6ip** *{isatap}*

**no tunnel mode ipv6ip**

### Parameters

**isatap**—Enables an automatic IPv6 over IPv4 ISATAP tunnel.

### Default Configuration

Disabled.

### Command Mode

Interface Configuration (Tunnel) mode

### User Guidelines

The system can be enabled to support ISATAP tunnels. When enabled, an automatic tunnel interface is created on each interface that is assigned an IPv4 address.

Note that on a specific interface (for example, port or VLAN), both native IPv6 and transition-mechanisms can coexist. The host implementation chooses the egress interface according to the scope of the destination IP address (such as ISATAP or native IPv6).

### Example

The following example configures an ISATAP tunnel mechanism.

---

```
switchxxxxxx(config)# interface tunnel 1
switchxxxxxx(config-tunnel)# tunnel mode ipv6ip isatap
```

---

## 35.3 tunnel isatap router

Use the **tunnel isatap router** Interface Configuration (Tunnel) mode command to configure a global string that represents a specific automatic tunnel router domain name. Use the **no** form of this command to remove this router name and restore the default configuration.

### Syntax

**tunnel isatap router** *router-name*

**no tunnel isatap router**

### Parameters

**router-name**—Specifies the router's domain name.

### Default Configuration

The automatic tunnel router's default domain name is ISATAP.

### Command Mode

Interface Configuration (Tunnel) mode

### User Guidelines

This command determines the string that the host uses for automatic tunnel router lookup in the IPv4 DNS procedure. By default, the string ISATAP is used for the corresponding automatic tunnel types.

Only one string can represent the automatic tunnel router name per tunnel. Using this command, therefore, overwrites the existing entry.

### Example

The following example configures the global string ISATAP2 as the automatic tunnel router domain name.

---

```
switchxxxxxx(config)# tunnel 1
switchxxxxxx(config-tunnel)# tunnel isatap router ISATAP2
```

---



---

## 35.4 tunnel source

Use the **tunnel source** Interface Configuration (Tunnel) mode command to set the local (source) IPv4 address of a tunnel interface. The **no** form deletes the tunnel local address.

### Syntax

**tunnel source** {*auto* | **ipv4-address** *ipv4-address*}

**no tunnel source**

### Parameters

- **auto**—The system minimum IPv4 address is used as the source address for packets sent on the tunnel interface. If the IPv4 address is changed, then the local address of the tunnel interface is changed too.
- **ipv4-address**—Specifies the IPv4 address to use as the source address for packets sent on the tunnel interface. The local address of the tunnel interface is not changed when the IPv4 address is moved to another interface.

### Default

No source address is defined.

### Command Mode

Interface Configuration (Tunnel) mode

### User Guidelines

The configured source IPv4 address is used for forming the tunnel interface identifier. The interface identifier is set to the 8 least significant bytes of the SIP field of the encapsulated IPv6 tunneled packets.

### Example

---

```
switchxxxxxx(config)# interface tunnel 1
switchxxxxxx(config-tunnel)# tunnel source auto
```

---

## 35.5 tunnel isatap query-interval

Use the **tunnel isatap query-interval** Global Configuration mode command to set the time interval between DNS queries (before the ISATAP router IP address is known) for the automatic tunnel router domain name. Use the **no** form of this command to restore the default configuration.

### Syntax

**tunnel isatap query-interval** *seconds*

**no tunnel isatap query-interval**

### Parameters

**seconds**—Specifies the time interval in seconds between DNS queries. (Range: 10–3600)

### Default Configuration

The default time interval between DNS queries is 10 seconds.

### Command Mode

Global Configuration mode

### User Guidelines

This command determines the time interval between DNS queries before the ISATAP router IP address is known. If the IP address is known, the robustness level that is set by the [tunnel isatap robustness](#) Global Configuration mode command determines the refresh rate.

### Example

The following example sets the time interval between DNS queries to 30 seconds.

---

```
switchxxxxxx(config)# tunnel isatap query-interval 30
```

---

## 35.6 tunnel isatap solicitation-interval

Use the **tunnel isatap solicitation-interval** Global Configuration mode command to set the time interval between ISATAP router solicitation messages. Use the **no** form of this command to restore the default configuration.

### Syntax

**tunnel isatap solicitation-interval** *seconds*

**no tunnel isatap solicitation-interval**

### Parameters

**seconds**—Specifies the time interval in seconds between ISATAP router solicitation messages. (Range: 10–3600)

### Default Configuration

The default time interval between ISATAP router solicitation messages is 10 seconds.

### Command Mode

Global Configuration mode

### User Guidelines

This command determines the interval between router solicitation messages when there is no active ISATAP router. If there is an active ISATAP router, the robustness level set by the **tunnel isatap robustness** Global Configuration mode command determines the refresh rate.

### Example

The following example sets the time interval between ISATAP router solicitation messages to 30 seconds.

---

```
switchxxxxxx(config)# tunnel isatap solicitation-interval 30
```

---

## 35.7 tunnel isatap robustness

Use the **tunnel isatap robustness** Global Configuration mode command to configure the number of DNS query/router solicitation refresh messages that the device sends. Use the **no** form of this command to restore the default configuration.

### Syntax

**tunnel isatap robustness** *number*

**no tunnel isatap robustness**

**Parameters**

**number**—Specifies the number of DNS query/router solicitation refresh messages that the device sends. (Range: 1–20)

**Default Configuration**

The default number of DNS query/router solicitation refresh messages that the device sends is 3.

**Command Mode**

Global Configuration mode

**User Guidelines**

The DNS query interval (after the ISATAP router IP address is known) is the Time-To-Live (TTL) that is received from the DNS, divided by (Robustness + 1).

The router solicitation interval (when there is an active ISATAP router) is the minimum-router-lifetime that is received from the ISATAP router, divided by (Robustness + 1).

**Example**

The following example sets the number of DNS query/router solicitation refresh messages that the device sends to 5.

---

```
switchxxxxxx(config)# tunnel isatap robustness 5
```

---

## 35.8 show ipv6 tunnel

Use the **show ipv6 tunnel** EXEC mode command to display information on the ISATAP tunnel.

**Syntax**

**show ipv6 tunnel**

**Command Mode**

EXEC mode

**Example**

The following example displays information on the ISATAP tunnel.

---

```
switchxxxxxx# show ipv6 tunnel
Tunnel 1
-----
Tunnel status                : DOWN
Tunnel protocol              : NONE
Tunnel Local address type    : auto
Tunnel Local IPv4 address    : 0.0.0.0
Router DNS name              : ISATAP
Router IPv4 address          : 0.0.0.0
DNS Query interval          : 300 seconds
Min DNS Query interval      : 0 seconds
Router Solicitation interval : 10 seconds
Min Router Solicitation interval : 0 seconds
Robustness                   : 2
```



---

## 36.1 ip dhcp information option

Use the **ip dhcp information option** Global Configuration command to enable DHCP option-82 data insertion. Use the **no** form of this command to disable DHCP option-82 data insertion.

### Syntax

**ip dhcp information option**

**no ip dhcp information option**

### Parameters

N/A

### Default Configuration

DHCP option-82 data insertion is disabled.

### Command Mode

Global Configuration mode

### User Guidelines

DHCP option 82 would be enabled only if DHCP snooping or DHCP relay are enabled.

### Example

---

```
switchxxxxxx(config)# ip dhcp information option
```

---

## 36.2 show ip dhcp information option

The **show ip dhcp information option** EXEC mode command displays the DHCP Option 82 configuration.

### Syntax

**show ip dhcp information option**

### Parameters

N/A

### Default Configuration

N/A

### Command Mode

EXEC mode

**Example**

The following example displays the DHCP Option 82 configuration.

---

```
switchxxxxx# show ip dhcp information option
Relay agent Information option is Enabled
```

## 37.1 ip route

Use the **ip route** Global Configuration mode command to configure static routes. Use the **no** form of this command to remove static routes.

### Syntax

```
ip route prefix {mask | prefix-length} {{ip-address [metric distance]} | reject-route}
```

```
no ip route prefix {mask | prefix-length} [ip-address]
```

### Parameters

- **prefix**—Specifies the IP address that is the IP route prefix for the destination IP.
- **mask**—Specifies the network subnet mask of the IP address prefix.
- **prefix-length**—Specifies the number of bits that comprise the IP address prefix. The prefix length must be preceded by a forward slash (/). (Range: 0–32)
- **ip-address**—Specifies the IP address or IP alias of the next hop that can be used to reach the network.
- **metric distance**—Specifies an administrative distance. (Range: 1–255).
- **reject-route**—Stops routing to the destination network via all gateways.

### Default Configuration

The default administrative distance is 1.

### Command Mode

Global Configuration mode

### User Guidelines

Use the **no ip route** command with the *ip-address* parameter to remove a single static route to the given subnet via the given next hop.

Use the **no ip route** command without the *ip-address* parameter to remove all static routes to the given subnet.

### Examples

**Example 1** - The following example shows how to route packets for network 172.31.0.0 to a router at 172.31.6.6 using mask:

---

```
switchxxxxxx(conf)#ip route 172.31.0.0 255.255.0.0 172.31.6.6 metric 2
```

---

**Example 2** - The following example shows how to route packets for network 172.31.0.0 to a router at 172.31.6.6 using prefix length:

---

```
switchxxxxxx(conf)#ip route 172.31.0.0 /16 172.31.6.6 metric 2
```

---

**Example 3** - The following example shows how to reject packets for network 194.1.1.0:

---

```
switchxxxxxx(conf)#ip route 194.1.1.0 255.255.255.0 reject-route
```

---

**Example 4** - The following example shows how to remove all static routes to network 194.1.1.0/24:

---

```
switchxxxxxx(conf)#no ip route 194.1.1.0 /24
```

---

**Example 5** - The following example shows how to remove one static route to network 194.1.1.0/24 via 1.1.1.1:

---

```
switchxxxxxx(conf)#no ip route 194.1.1.0 /24 1.1.1.1
```

---

## 37.2 ip routing

Use the **ip routing** Global Configuration mode command to enable IPv4 Routing. Use the **no** format of the command to disable IPv4 Routing.

### Syntax

**ip routing**

**no ip routing**

### Parameters

N/A

### Default Configuration

Enabled.

### Command Mode

Global Configuration mode

**Example.** The following example enables ipv4 routing.

---

```
switchxxxxxx# ip routing
```

---

## 37.3 show ip route

Use the **show ip route** EXEC mode command to display the current routing table state.

### Syntax

**show ip route** [*connected* | *static* | {**address** *address* [*mask* | *prefix-length*] [*longer-prefixes*]}]

### Parameters

- **connected**—Displays connected routing entries only.
- **static**—Displays static routing entries only.
- **address address**—Specifies the address for which routing information is displayed.
- **mask**—Specifies the network subnet mask of the IP address.
- **prefix-length**—Specifies the number of bits that comprise the IP address prefix. The prefix length must be preceded by a forward slash (/). (Range: 1–32)



- **longer-prefixes**—Specifies that the **address** and **mask** pair becomes a prefix and any routes that match that prefix are displayed.

### Command Mode

EXEC mode

### Example

The following example displays the current routing table state.

---

```
switchxxxxxx# show ip route
switchxxxxxx# show ip route
Maximum Parallel Paths: 1 (1 after reset)
IP Forwarding:          enabled
Codes: C - connected, S - static, D - DHCP
S  0.0.0.0/0            [gi1/0/11] via 10.5.234.254 119:9:27  vlan 1
C  10.5.234.0/24       is directly connected                vlan 1
```

---

```
switchxxxxxx#show ip route
Maximum Parallel Paths: 1 (1 after reset)
IP Forwarding:          enabled
Codes: C - connected, S - static, D - DHCP, R - RIP
S  0.0.0.0/0            [1/1] via 10.5.229.1 3:19:29          vlan 1
C  10.5.229.0/27       is directly connected                vlan 1
```

---

```
s
switchxxxxxx#show ip route address 10.5.229.12
Maximum Parallel Paths: 1 (1 after reset)
IP Forwarding:          enabled
Codes: C - connected, S - static, D - DHCP, R - RIP
C  10.5.229.0/27       is directly connected                vlan 1
```

---

The following table describes the significant fields shown in the display:

Field	Description
<b>O</b>	The protocol that derived the route.
<b>10.8.1.0/24</b>	The remote network address.
<b>[30/2000]</b>	The first number in the brackets is the administrative distance of the information source; the second number is the metric for the route.
<b>via 10.0.1.2</b>	The address of the next router to the remote network.
<b>00:39:08</b>	The last time the route was updated in hours:minutes:seconds.
<b>gi1/0/11</b>	The interface through which the specified network can be reached.



---

## 38.1 ip access-list (IP extended)

Use the **ip access-list extended** Global Configuration mode command to name an IPv4 access list (ACL) and to place the device in IPv4 Access List Configuration mode. All commands after this command refer to this ACL. The rules (ACEs) for this ACL are defined in the [permit \(IP\)](#) and [deny \(IP\)](#) commands. The [service-acl input](#) command is used to attach this ACL to an interface.

Use the **no** form of this command to remove the access list.

### Syntax

**ip access-list extended** *acl-name*

**no ip access-list extended** *acl-name*

### Parameters

- **acl-name**—Name of the IPv4 access list. (Range 1-32 characters)

### Default Configuration

No IPv4 access list is defined.

### Command Mode

Global Configuration mode

### User Guidelines

An IPv4 ACL is defined by a unique name. IPv4 ACL, IPv6 ACL, MAC ACL or policy maps cannot have the same name.

### Example

---

```
switchxxxxxx(config)# ip access-list extended server
switchxxxxxx(config-ip-al)#
```

---

## 38.2 permit (IP)

Use the **permit** IP Access-list Configuration mode command to set permit conditions for an IPv4 access list (ACL). Permit conditions are also known as access control entries (ACEs).

### Syntax

**permit** *protocol* [*any* | *source source-wildcard*] [*any* | *destination destination-wildcard*] [*dscp number* | *precedence number*]

**permit** *icmp* [*any* | *source source-wildcard*] [*any* | *destination destination-wildcard*] [*any* | *icmp-type*] [*any* | *icmp-code*] [*dscp number* | *precedence number*]

**permit igmp** {*any* | *source source-wildcard*} {*any* | *destination destination-wildcard*}[*igmp-type*] [*dscp number* | *precedence number*]

**permit tcp** {*any* | *source source-wildcard*} {*any*|*source-port/port-range*}{*any* | *destination destination-wildcard*} {*any*|*destination-port/port-range*} [*dscp number* | *precedence number*] [*match-all list-of-flags*]

**permit udp** {*any* | *source source-wildcard*} {*any*|*source-port/port-range*} {*any* | *destination destination-wildcard*} {*any*|*destination-port/port-range*} [*dscp number* | *precedence number*]

## Parameters

- **permit protocol**—The name or the number of an IP protocol. Available protocol names are: icmp, igmp, ip, tcp, egp, igp, udp, hmp, rdp, idpr, ipv6, ipv6:rout, ipv6:frag, idrp, rsvp, gre, esp, ah, ipv6:icmp, eigrp, ospf, ipinip, pim, l2tp, isis. To match any protocol, use the **ip** keyword.(Range: 0–255)
- **source**—Source IP address of the packet.
- **source-wildcard**—Wildcard bits to be applied to the source IP address. Use ones in the bit position that you want to be ignored.
- **destination**—Destination IP address of the packet.
- **destination-wildcard**—Wildcard bits to be applied to the destination IP address. Use ones in the bit position that you want to be ignored.
- **dscp number**—Specifies the DSCP value.
- **precedence number**—Specifies the IP precedence value.
- **icmp-type**—Specifies an ICMP message type for filtering ICMP packets. Enter a number or one of the following values: echo-reply, destination-unreachable, source-quench, redirect, alternate-host-address, echo-request, router-advertisement, router-solicitation, time-exceeded, parameter-problem, timestamp, timestamp-reply, information-request, information-reply, address-mask-request, address-mask-reply, traceroute, datagram-conversion-error, mobile-host-redirect, mobile-registration-request, mobile-registration-reply, domain-name-request, domain-name-reply, skip, photuris. (Range: 0–255)
- **icmp-code**—Specifies an ICMP message code for filtering ICMP packets. (Range: 0–255)
- **igmp-type**—IGMP packets can be filtered by IGMP message type. Enter a number or one of the following values: host-query, host-report, dvmrp, pim, cisco-trace, host-report-v2, host-leave-v2, host-report-v3. (Range: 0–255)
- **destination-port**—Specifies the UDP/TCP destination port. You can enter range of ports by using hyphen. E.g. 20 - 21. For TCP enter a number or one of the following values: bgp (179), chargen (19), daytime (13), discard (9), domain (53), drip (3949), echo (7), finger (79), ftp (21), ftp-data (20), gopher (70), hostname (42), irc (194), klogin (543), kshell (544), lpd (515), nntp (119), pop2 (109), pop3 (110), smtp (25), sunrpc (1110), syslog (514), tacacs-ds (49), talk (517), telnet (23), time (37), uucp (117), whois (43), www (80). For UDP enter a number or one of the following values: biff (512), bootpc (68), bootps (67), discard (9), dnsix (90), domain (53), echo (7), mobile-ip (434), nameserver (42), netbios-dgm (138), netbios-ns (137), on500-isakmp (4500), ntp (123), rip (520), snmp (161), snmptrap (162), sunrpc (111), syslog (514), tacacs-ds (49), talk (517), tftp (69), time (37), who (513), xdmcp (177). (Range: 0–65535)
- **source-port**—Specifies the UDP/TCP source port. Predefined port names are defined in the destination-port parameter. (Range: 0–65535)
- **match-all list-of-flags**—List of TCP flags that should occur. If a flag should be set, it is prefixed by "+". If a flag should be unset, it is prefixed by "-". Available options are +urg, +ack, +psh, +rst, +syn, +fin, -urg, -ack, -psh, -rst, -syn and -fin. The flags are concatenated to a one string. For example: +fin-ack.

## Default Configuration

No IPv4 access list is defined.

## Command Mode

IP Access-list Configuration mode

## User Guidelines

After an ACE is added to an access control list, an implicit **deny any** condition exists at the end of the list. That is, if there are no matches, the packets are denied. However, before the first ACE is added, the list permits all packets up to #ASIC-specific ranges for TCP and up to #ASIC-specific ranges for UDP. If a range

of ports is used for source port in an ACE, it is not counted again, if it is also used for a source port in another ACE. If a range of ports is used for the destination port in an ACE, it is not counted again if it is also used for destination port in another ACE.

If a range of ports is used for source port it is counted again if it is also used for destination port.

## Example

```
switchxxxxxx(config)# ip access-list extended server
switchxxxxxx(config-ip-af)# permit ip 176.212.0.0 00.255.255
```

## 38.3 deny (IP)

Use the **deny** IP Access-list Configuration mode command to set deny conditions for IPv4 access list. Deny conditions are also known as access control entries (ACEs).

### Syntax

**deny protocol** {**any** | source source-wildcard} {**any** | destination destination-wildcard} [**dscp number** | **precedence number**]

**deny icmp** {**any** | source source-wildcard} {**any** | destination destination-wildcard} [**any** | icmp-type] [**any** | icmp-code]] [**dscp number** | **precedence number**]

**deny igmp** {**any** | source source-wildcard} {**any** | destination destination-wildcard}[igmp-type] [**dscp number** | **precedence number**]

**deny tcp** {**any** | source source-wildcard} {**any**|source-port/port-range}{**any** | destination destination-wildcard} {**any**|destination-port/port-range} [**dscp number** | **precedence number**] [**match-all list-of-flags**]

**deny udp** {**any** | source source-wildcard} {**any**|source-port/port-range} {**any** | destination destination-wildcard} {**any**|destination-port/port-range} [**dscp number** | **precedence number**]

### Parameters

- **protocol**—The name or the number of an IP protocol. Available protocol names: icmp, igmp, ip, tcp, egp, igp, udp, hmp, rdp, idpr, ipv6, ipv6:rout, ipv6:frag, idrp, rsvp, gre, esp, ah, ipv6:icmp, eigrp, ospf, ipinip, pim, l2tp, isis. To match any protocol, use the Ip keyword. (Range: 0–255)
- **source**—Source IP address of the packet.
- **source-wildcard**—Wildcard bits to be applied to the source IP address. Use 1s in the bit position that you want to be ignored.
- **destination**—Destination IP address of the packet.
- **destination-wildcard**—Wildcard bits to be applied to the destination IP address. Use 1s in the bit position that you want to be ignored.
- **dscp number**—Specifies the DSCP value.
- **precedence number**—Specifies the IP precedence value.
- **icmp-type**—Specifies an ICMP message type for filtering ICMP packets. Enter a number or one of the following values: echo-reply, destination-unreachable, source-quench, redirect, alternate-host-address, echo-request, router-advertisement, router-solicitation, time-exceeded, parameter-problem, timestamp, timestamp-reply, information-request, information-reply, address-mask-request, address-mask-reply, traceroute, datagram-conversion-error, mobile-host-redirect, mobile-registration-request, mobile-registration-reply, domain-name-request, domain-name-reply, skip, photuris. (Range: 0–255)
- **icmp-code**—Specifies an ICMP message code for filtering ICMP packets. (Range: 0–255)
- **igmp-type**—IGMP packets can be filtered by IGMP message type. Enter a number or one of the following values: host-query, host-report, dvmrp, pim, cisco-trace, host-report-v2, host-leave-v2, host-report-v3. (Range: 0–255)
- **destination-port**—Specifies the UDP/TCP destination port. You can enter range of ports by using hyphen. E.g. 20 - 21. For TCP enter a number or one of the following values: bgp (179), chargen (19), daytime (13), discard (9), domain (53), drip (3949), echo (7), finger (79), ftp (21), ftp-data (20), gopher (70), hostname (42), irc (194), klogin (543), kshell (544), lpd (515), nntp (119), pop2 (109), pop3 (110),

smtp (25), sunrpc (1110), syslog (514), tacacs-ds (49), talk (517), telnet (23), time (37), uucp (117), whois (43), www (80). For UDP enter a number or one of the following values: biff (512), bootpc (68), bootps (67), discard (9), dnsix (90), domain (53), echo (7), mobile-ip (434), nameserver (42), netbios-dgm (138), netbios-ns (137), non500-isakmp (4500), ntp (123), rip (520), snmp 161), snmptrap (162), sunrpc (111), syslog (514), tacacs-ds (49), talk (517), tftp (69), time (37), who (513), xdmcp (177). (Range: 0–65535)

- **source-port**—Specifies the UDP/TCP source port. Predefined port names are defined in the destination-port parameter. (Range: 0–65535)
- **match-all list-of-flags**—List of TCP flags that should occur. If a flag should be set it is prefixed by "+". If a flag should be unset it is prefixed by "-". Available options are +urg, +ack, +psh, +rst, +syn, +fin, -urg, -ack, -psh, -rst, -syn and -fin. The flags are concatenated to a one string. For example: +fin-ack.
- **disable-port**—The Ethernet interface is disabled if the condition is matched.
- **log-input**—Specifies sending an informational syslog message about the packet that matches the entry. Because forwarding is done in hardware and logging is done in software, if a large number of packets match a deny ACE containing a log-input keyword, the software might not be able to match the hardware processing rate, and not all packets will be logged.

### Default Configuration

No IPv4 access list is defined.

### Command Mode

IP Access-list Configuration mode

### User Guidelines

After an ACE is added to an access control list, an implicit **deny any any** condition exists at the end of the list. That is, if there are no matches, the packets are denied. However, before the first ACE is added, the list permits all packets.

The number of TCP/UDP ranges that can be defined in ACLs is limited. You can define up to #ASIC-specific ranges for TCP and up to #ASIC-specific ranges for UDP. If a range of ports is used for a source port in ACE it is not counted again if it is also used for source port in another ACE. If a range of ports is used for destination port in ACE it is not counted again if it is also used for destination port in another ACE.

If a range of ports is used for source port, it is counted again if it is also used for destination port.

### Example

```
switchxxxxxx(config)# ip access-list extended server
switchxxxxxx(config-ip-a1)# deny ip 176.212.0.0 00.255.255
```

## 38.4 ipv6 access-list (IPv6 extended)

Use the **ipv6 access-list** Global Configuration mode command to define an IPv6 access list (ACL) and to place the device in IPv6 Access List Configuration mode. All commands after this command refer to this ACL. The rules (ACEs) for this ACL are defined in the [permit \(IPv6\)](#) and [deny \(IPv6\)](#) commands. The [service-acl input](#) command is used to attach this ACL to an interface.

Use the **no** form of this command to remove the access list.

### Syntax

```
ipv6 access-list [acl-name]
no ipv6 access-list [acl-name]
```

### Parameters

**acl-name**—Name of the IPv6 access list. Range 1-32 characters.

## Default Configuration

No IPv6 access list is defined.

## Command Mode

Global Configuration mode

## User Guidelines

IPv6 ACL is defined by a unique name. IPv4 ACL, IPv6 ACL, MAC ACL or policy maps cannot have the same name.

Every IPv6 ACL has an implicit **permit icmp any any nd-ns any**, **permit icmp any any nd-na any**, and **deny ipv6 any any** statements as its last match conditions. (The former two match conditions allow for ICMPv6 neighbor discovery.)

The IPv6 neighbor discovery process uses the IPv6 network layer service, therefore, by default, IPv6 ACLs implicitly allow IPv6 neighbor discovery packets to be sent and received on an interface. In IPv4, the Address Resolution Protocol (ARP), which is equivalent to the IPv6 neighbor discovery process, uses a separate data link layer protocol; therefore, by default, IPv4 ACLs implicitly allow ARP packets to be sent and received on an interface.

## Example

```
Switch (config)# ipv6 access-list acl1
Switch(config-ipv6-acl)# permit tcp 2001:0DB8:0300:0201::/64 any any 80
```

## 38.5 permit (IPv6)

Use the **permit** command in IPv6 Access-list Configuration mode to set permit conditions (ACEs) for IPv6 ACLs.

### Syntax

**permit protocol** *{any | {source-prefix/length}{any | destination- prefix/length} [dscp number | precedence number]}*

**permit icmp** *{any | {source-prefix/length}{any | destination- prefix/length} {any|icmp-type} {any|icmp-code} [dscp number | precedence number]}*

**permit tcp** *{any | {source-prefix/length} {any | source-port/port-range}} {any | destination- prefix/length} {any | destination-port/port-range} [dscp number | precedence number] [match-all list-of-flags]*

**permit udp** *{any | {source-prefix/length}} {any | source-port/port-range}} {any | destination- prefix/length} {any | destination-port/port-range} [dscp number | precedence number]*

### Parameters

- **protocol**—The name or the number of an IP protocol. Available protocol names are: icmp (58), tcp (6) and udp (17). To match any protocol, use the ipv6 keyword. (Range: 0–255)
- **source-prefix/length**—The source IPv6 network or class of networks about which to set permit conditions. This argument must be in the form documented in RFC 3513 where the address is specified in hexadecimal using 16-bit values between colons.
- **destination-prefix/length**—The destination IPv6 network or class of networks about which to set permit conditions. This argument must be in the form documented in RFC 3513 where the address is specified in hexadecimal using 16-bit values between colons.
- **dscp number**—Specifies the DSCP value. (Range: 0–63)
- **precedence number**—Specifies the IP precedence value.
- **icmp-type**—Specifies an ICMP message type for filtering ICMP packets. Enter a number or one of the following values: destination-unreachable (1), packet-too-big (2), time-exceeded (3), parameter-problem (4), echo-request (128), echo-reply (129), mld-query (130), mld-report (131), mldv2-report (143),

- mld-done (132), router-solicitation (133), router-advertisement (134), nd-ns (135), nd-na (136). (Range: 0–255)
- **icmp-code**—Specifies an ICMP message code for filtering ICMP packets. (Range: 0–255)
  - **destination-port**—Specifies the UDP/TCP destination port. You can enter a range of ports by using a hyphen. E.g. 20 - 21. For TCP enter a number or one of the following values: bgp (179), chargen (19), daytime (13), discard (9), domain (53), drip (3949), echo (7), finger (79), ftp (21), ftp-data (20), gopher (70), hostname (42), irc (194), klogin (543), kshell (544), lpd (515), nntp (119), pop2 (109), pop3 (110), smtp (25), sunrpc (1110), syslog (514), tacacs-ds (49), talk (517), telnet (23), time (37), uucp (117), whois (43), www (80). For UDP enter a number or one of the following values: biff (512), bootpc (68), bootps (67), discard (9), dnsix (90), domain (53), echo (7), mobile-ip (434), nameserver (42), netbios-dgm (138), netbios-ns (137), non500-isakmp (4500), ntp (123), rip (520), snmp (161), snmptrap (162), sunrpc (111), syslog (514), tacacs (49), talk (517), tftp (69), time (37), who (513), xdmcp (177). (Range: 0–65535)
  - **source-port**—Specifies the UDP/TCP source port. Predefined port names are defined in the destination-port parameter. (Range: 0–65535)
  - **match-all list-of-flag**—List of TCP flags that should occur. If a flag should be set it is prefixed by "+". If a flag should be unset it is prefixed by "-". Available options are +urg, +ack, +psh, +rst, +syn, +fin, -urg, -ack, -psh, -rst, -syn and -fin. The flags are concatenated to a one string. For example: +fin-ack.

### Default Configuration

No IPv6 access list is defined.

### Command Mode

Ipv6 Access-list Configuration mode

### User Guidelines

The number of TCP/UDP ranges that can be defined in ACLs is limited. You can define up to #ASIC-specific ranges for TCP and up to #ASIC-specific ranges for UDP. If a range of ports is used for a source port in ACE, it is not counted again if it is also used for a source port in another ACE. If a range of ports is used for destination port in ACE it is not counted again if it is also used for destination port in another ACE.

If a range of ports is used for source port it is counted again if it is also used for destination port.

### Example

This example defines an ACL by the name of server and enters a rule (ACE) for tcp packets.

```
switchxxxxxx(config)# ipv6 access-list server
switchxxxxxx(config-ipv6-al)# permit tcp 3001::2/64 any any 80
```

## 38.6 deny (IPv6)

Use the **deny** command in IPv6 Access List Configuration mode to set permit conditions (ACEs) for IPv6 ACLs.

### Syntax

**deny protocol** {any | {source-prefix/length}{any | destination- prefix/length} [dscp number | precedence number] [disable-port | log-input]

**deny icmp** {any | {source-prefix/length}{any | destination- prefix/length} {any|icmp-type} {any|icmp-code} [dscp number | precedence number][disable-port | log-input]

**deny tcp** {any | {source-prefix/length} {any | source-port/port-range}}{any | destination- prefix/length} {any| destination-port/port-range} [dscp number | precedence number] [match-all list-of-flags][disable-port | log-input]

**deny udp** {any | {source-prefix/length}} {any | source-port/port-range}}{any | destination- prefix/length} {any| destination-port/port-range} [dscp number | precedence number] [disable-port | log-input]



## Parameters

- **protocol**—The name or the number of an IP protocol. Available protocol names are: icmp (58), tcp (6) and udp (17). To match any protocol, use the ipv6 keyword. (Range: 0–255)
- **source-prefix/length**—The source IPv6 network or class of networks about which to set permit conditions. This argument must be in the format documented in RFC 3513 where the address is specified in hexadecimal using 16-bit values between colons.
- **destination-prefix/length**—The destination IPv6 network or class of networks about which to set permit conditions. This argument must be in the format documented in RFC 3513 where the address is specified in hexadecimal using 16-bit values between colons.
- **dscp number**—Specifies the DSCP value. (Range: 0–63)
- **precedence number**—Specifies the IP precedence value.
- **icmp-type**—Specifies an ICMP message type for filtering ICMP packets. Enter a number or one of the following values: destination-unreachable (1), packet-too-big (2), time-exceeded (3), parameter-problem (4), echo-request (128), echo-reply (129), mld-query (130), mld-report (131), mldv2-report (143), mld-done (132), router-solicitation (133), router-advertisement (134), nd-ns (135), nd-na (136). (Range: 0–255)
- **icmp-code**—Specifies an ICMP message code for filtering ICMP packets. (Range: 0–255)
- **destination-port**—Specifies the UDP/TCP destination port. You can enter a range of ports by using a hyphen. E.g. 20 - 21. For TCP enter a number or one of the following values: bgp (179), chargen (19), daytime (13), discard (9), domain (53), drip (3949), echo (7), finger (79), ftp (21), ftp-data (20), gopher (70), hostname (42), irc (194), klogin (543), kshell (544), lpd (515), nntp (119), pop2 (109), pop3 (110), smtp (25), sunrpc (1110), syslog (514), tacacs-ds (49), talk (517), telnet (23), time (37), uucp (117), whois (43), www (80). For UDP enter a number or one of the following values: biff (512), bootpc (68), bootps (67), discard (9), dnsix (90), domain (53), echo (7), mobile-ip (434), nameserver (42), netbios-dgm (138), netbios-ns (137), non500-isakmp (4500), ntp (123), rip (520), snmp (161), snmptrap (162), sunrpc (111), syslog (514), tacacs (49), talk (517), tftp (69), time (37), who (513), xdmcp (177). (Range: 0–65535)
- **source-port**—Specifies the UDP/TCP source port. Predefined port names are defined in the destination-port parameter. (Range: 0–65535)
- **match-all list-of-flags**—List of TCP flags that should occur. If a flag should be set it is prefixed by "+". If a flag should be unset it is prefixed by "-". Available options are +urg, +ack, +psh, +rst, +syn, +fin, -urg, -ack, -psh, -rst, -syn and -fin. The flags are concatenated to a one string. For example: +fin-ack.
- **disable-port**—The Ethernet interface is disabled if the condition is matched.
- **log-input**—Specifies to send an informational syslog message about the packet that matches the entry. Because forwarding is done in hardware and logging is done in software, if a large number of packets match a deny ACE containing a log-input keyword, the software might not be able to match the hardware processing rate, and not all packets will be logged.

## Default Configuration

No IPv6 access list is defined.

## Command Mode

IPv6 Access-list Configuration mode

## User Guidelines

The number of TCP/UDP ranges that can be defined in ACLs is limited. You can define up to #ASIC-specific ranges for TCP and up to #ASIC-specific ranges for UDP. If a range of ports is used for source port in ACE it is not counted again if it is also used for source port in another ACE. If a range of ports is used for a destination port in ACE it is not counted again if it is also used for a destination port in another ACE.

If a range of ports is used for source port it is counted again if it is also used for destination port.

## Example

```
switchxxxxxx(config)# ipv6 access-list server
switchxxxxxx(config-ipv6-al)# deny tcp 3001::2/64 any any 80
```

## 38.7 mac access-list

Use the **mac access-list** Global Configuration mode command to define a Layer 2 access list (ACL) based on source MAC address filtering and to place the device in MAC Access List Configuration mode. All commands after this command refer to this ACL. The rules (ACEs) for this ACL are defined in the **permit (MAC)** and **deny (MAC)** commands. The **service-acl input** command is used to attach this ACL to an interface.

Use the **no** form of this command to remove the access list.

### Syntax

**mac access-list extended** *acl-name*

**no mac access-list extended** *acl-name*

### Parameters

**acl-name**—Specifies the name of the MAC ACL (Range: 1–32 characters).

### Default Configuration

No MAC access list is defined.

### Command Mode

Global Configuration mode

### User Guidelines

A MAC ACL is defined by a unique name. IPv4 ACL, IPv6 ACL, MAC ACL or policy maps cannot have the same name.

### Example

```
switchxxxxxx(config)# mac access-list extended server1
switchxxxxxx(config-mac-acl)# permit 00:00:00:00:00:01 00:00:00:00:00:ff any
```

## 38.8 permit (MAC)

Use the **permit** command in MAC Access List Configuration mode to set permit conditions (ACEs) for a MAC ACL.

### Syntax

**permit** {*any* | *source source-wildcard*} {*any* | *destination destination-wildcard*} [*eth-type 0* | *arp* | *amber* | *dec-spanning* | *decnet-iv* | *diagnostic* | *dsm* | *etype-6000*] [*vlan vlan-id*] [*cos cos cos-wildcard*]

### Parameters

- **source**—Source MAC address of the packet.
- **source-wildcard**—Wildcard bits to be applied to the source MAC address. Use 1s in the bit position that you want to be ignored.
- **destination**—Destination MAC address of the packet.
- **destination-wildcard**—Wildcard bits to be applied to the destination MAC address. Use 1s in the bit position that you want to be ignored.
- **eth-type**—The Ethernet type in hexadecimal format of the packet.
- **vlan-id**—The VLAN ID of the packet. (Range: 1–4094)
- **cos**—The Class of Service of the packet. (Range: 0–7)
- **cos-wildcard**—Wildcard bits to be applied to the CoS.

## Default Configuration

No MAC access list is defined.

## Command Mode

MAC Access-list Configuration mode

## User Guidelines

After an access control entry (ACE) is added to an access control list, an implicit **deny any any** condition exists at the end of the list. That is, if there are no matches, the packets are denied. However, before the first ACE is added, the list permits all packets.

## Example

---

```
switchxxxxxx(config)# mac access-list extended server1
switchxxxxxx(config-mac-al)# permit 00:00:00:00:00:01 00:00:00:00:00:ff any
```

---

## 38.9 deny (MAC)

Use the **deny** command in MAC Access List Configuration mode to set deny conditions (ACEs) for a MAC ACL. Use the no form of the command to remove the access control entry.

### Syntax

**deny** {*any* | *source source-wildcard*} {*any* | *destination destination-wildcard*} [{*eth-type 0*} | *aarp* | *amber* | *dec-spanning* | *decnet-iv* | *diagnostic* | *dsm* | *etype-6000*] [*vlan vlan-id*] [*cos cos cos-wildcard*] [*disable-port* | *log-input*]

**no deny** {*any* | *source source-wildcard*} {*any* | *destination destination-wildcard*} [{*eth-type 0*} | *aarp* | *amber* | *dec-spanning* | *decnet-iv* | *diagnostic* | *dsm* | *etype-6000*] [*vlan vlan-id*] [*cos cos cos-wildcard*] [*disable-port* | *log-input*]

### Parameters

- **source**—Source MAC address of the packet.
- **source-wildcard**—Wildcard bits to be applied to the source MAC address. Use ones in the bit position that you want to be ignored.
- **destination**—Destination MAC address of the packet.
- **destination-wildcard**—Wildcard bits to be applied to the destination MAC address. Use 1s in the bit position that you want to be ignored.
- **eth-type**—The Ethernet type in hexadecimal format of the packet.
- **vlan-id**—The VLAN ID of the packet. (Range: 1–4094)
- **cos**—The Class of Service of the packet.(Range: 0–7)
- **cos-wildcard**—Wildcard bits to be applied to the CoS.
- **disable-port**—The Ethernet interface is disabled if the condition is matched.
- **log-input**—Sends an informational syslog message about the packet that matches the entry. Because forwarding is done in hardware and logging is done in software, if a large number of packets match a deny ACE containing a log-input keyword, the software might not be able to match the hardware processing rate, and not all packets will be logged.

## Default Configuration

No MAC access list is defined.

## Command Mode

MAC Access-list Configuration mode

## Example

---

```
switchxxxxxx(config)# mac access-list extended server1
switchxxxxxx(config-mac-al)# deny 00:00:00:00:00:01 00:00:00:00:00:ff any
```

---

## 38.10 service-acl input

Use the **service-acl input** command in interface Configuration mode to bind an access list(s) (ACL) to an interface.

Use the **no** form of this command to remove all ACLs from the interface.

### Syntax

**service-acl input** *acl-name1* [*acl-name2*]

**no service-acl input**

### Parameters

**acl-name**—Specifies an ACL to apply to the interface. See the user guidelines. (Range: 1–32 characters).

### Default Configuration

No ACL is assigned.

### Command Mode

Interface Configuration (Ethernet, Port-Channel) mode.

### User Guidelines

The following rules govern when ACLs can be bound or unbound from an interface:

- IPv4 ACLs and IPv6 ACLs can be bound together to an interface.
- A MAC ACL cannot be bound on an interface which already has an IPv4 ACL or IPv6 ACL bound to it.
- Two ACLs of the same type cannot be bound to a port.
- An ACL cannot be bound to a port that is already bound to an ACL, without first removing the current ACL. Both ACLs must be mentioned at the same time in this command.

## Example

---

```
switchxxxxxx(config)# mac access-list extended server-acl
switchxxxxxx(config-mac-al)# permit 00:00:00:00:00:01 00:00:00:00:00:ff any
switchxxxxxx(config-mac-al)# exit
switchxxxxxx(config)# interface gi1/0/11
switchxxxxxx(config-if)# service-acl input server-acl
```

---

## 38.11 show access-lists

Use the **show access-lists** Privileged EXEC mode command to display access control lists (ACLs) configured on the switch.

### Syntax

**show access-lists** [*name*]

**show access-lists/**

**Parameters**

- **name**—Specifies the name of the ACL.

**Command Mode**

Privileged EXEC mode

**Example**


---

```
switchxxxxxx#show access-lists
Standard IP access list 1
deny any any
Standard IP access list 2
deny 192.168.0.0/24
permit any any
Standard IP access list 3
deny 192.168.0.1 10.0.0.0/8
permit any any
Standard IP access list ACL1
permit 192.168.0.0/16 10.1.1.1
Extended IP access list ACL2
permit 234 172.30.19.1 0.0.0.255 any
permit 234 172.30.23.8 0.0.0.255 any
```

---

**38.12 show interfaces access-lists**

Use the **show interfaces access-lists** Privileged EXEC mode command to display access lists (ACLs) applied on interfaces.

**Syntax**

```
show interfaces access-lists [interface-id]
```

**Parameters**

**interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port, port-channel or VLAN.

**Command Mode**

Privileged EXEC mode

**Example**


---

```
switchxxxxxx# show interfaces access-lists
Interface      Input ACL
-----
gi1/0/11      ACL1
gi1/0/12      ACL3
```

---

## 38.13 clear access-lists counters

Use the **clear access-lists counters** Privileged EXEC mode command to clear access-lists (ACLs) counters.

### Syntax

**clear access-lists counters** *[interface-id]*

### Parameters

**interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or port-channel.

### Command Mode

Privileged EXEC mode

### Example

```
switchxxxxxx# clear access-lists counters gi1/0/11
```

## 38.14 show interfaces access-lists counters

Use the **show interfaces access-lists counters** Privileged EXEC mode command to display Access List (ACLs) counters.

### Syntax

**show interfaces access-lists counters** *[interface-id | port-channel-number]*

### Parameters

**interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or port-channel.

### Command Mode

Privileged EXEC mode

### User Guidelines

The deny ACE hits count includes only ACEs with the log-input keyword.

Because forwarding is done in hardware and counting is done in software, if a large number of packets match a deny ACE containing a log-input keyword, the software might not be able to match the hardware processing rate, and not all packets are counted.

### Example

```
switchxxxxxx# show interfaces access-lists counters
```

Interface	Deny ACE Hits
-----	-----
gi1/0/11	79
gi1/0/12	9
gi1/0/13	0

Number of hits that were counted in global counter (due to lack of resources) =19

---

## 39.1 qos

Use the **qos** Global Configuration mode command to enable QoS on the device and set its mode. Use the **no** form of this command to disable QoS on the device.

### Syntax

**qos** [*basic* | *advanced* [*ports-not-trusted* | *ports-trusted*]]

**no qos**

### Parameters

- **basic**—QoS basic mode. If no option is specified, the QoS mode defaults to the basic mode.
- **advanced**—Specifies the QoS advanced mode, which enables the full range of QoS configuration.
- **ports-not-trusted**—Relevant for advanced mode only. Indicates that packets, which are not classified by policy map rules to a QoS action, are mapped to egress queue 0. This is the default setting in advanced mode.
- **ports-trusted**—Relevant for advanced mode only. Indicates that packets, which are not classified by policy map rules to a QoS action, are mapped to an egress queue based on the packet's fields. Use the [qos advanced-mode trust](#) command to specify the trust mode.

### Default Configuration

If **qos** is entered without any keywords, the QoS **basic** mode is **enabled**.

If **qos advanced** is entered without a keyword, the default is **ports-not-trusted**.

### Command Mode

Global Configuration mode

### Examples

**Example 1-** The following example enables QoS basic mode on the device.

---

```
switchxxxxxx(config)# qos
```

---

**Example 2 -** The following example enables QoS advanced mode on the device with the **ports-not-trusted** option.

---

```
switchxxxxxx(config)# qos advanced
```

---

---

## 39.2 qos advanced-mode trust

Use the **qos advanced-mode trust** Global Configuration command to configure the trust mode in advanced mode. Use the **no** form of this command to return to default.

### Syntax

```
qos advanced-mode trust {cos | dscp | cos-dscp}
```

```
no qos advanced-mode trust
```

### Parameters

- **cos**—Classifies ingress packets with the packet CoS values. For untagged packets, the port default CoS is used.
- **dscp**—Classifies ingress packets with the packet DSCP values.
- **cos-dscp**—Classifies ingress packets with the packet DSCP values for IP packets. For other packet types, use the packet CoS values.

### Default Configuration

cos-dscp

### Command Mode

Global Configuration

### User Guidelines

The configuration is relevant for advanced mode in the following cases:

- **ports-not-trusted mode**: For packets that are classified to the QoS action trust.
- **ports-trusted mode**: For packets that are not classified by to any QoS action or classified to the QoS action trust.

### Example

The following example sets **cos** as the trust mode for QoS on the device.

---

```
switchxxxxxx(config)# qos advanced-mode trust cos
```

---

## 39.3 show qos

Use the **show qos** EXEC mode command to display the QoS information for the device. The trust mode is displayed for the QoS basic mode.

### Syntax

```
show qos
```

### Parameters

N/A

### Default Configuration

Disabled Command Mode

### Command Mode

EXEC mode



### User Guidelines

Trust mode is displayed if QoS is enabled in basic mode.

### Examples

**Example 1** - The following example displays QoS attributes when QoS is enabled in basic mode and the advanced mode is supported.

---

```
switchxxxxxx# show qos
Qos: basic
Basic trust: cos
```

---

## 39.4 class-map

The **class-map** command and its subcommands are used to define packet classification, marking, and aggregate policing as part of a globally-named service policy applied on a per-interface basis.

A class map consists of one or more ACLs (see [ACL Commands](#)). It defines a traffic flow by determining which packets match some or all of the criteria specified in the ACLs.

Use the **class-map** Global Configuration mode command to create or modify a class map and enter the Class-map Configuration mode (only possible when QoS is in the advanced mode).

Use the **no** form of this command to delete a class map.

All class map commands are only available when QoS is in advanced mode.

### Syntax

**class-map** *class-map-name* [*match-all* | *match-any*]

**no class-map** *class-map-name*

### Parameters

- **class-map-name**—Specifies the class map name.
- **match-all**—Performs a logical AND of all the criteria of the ACLs belonging to this class map. All match criteria in this class map must be matched.
- **match-any**—Performs a logical OR of the criteria of the ACLs belonging to this class map. Only a single match criteria in this class map must be matched.

### Default Configuration

If neither **match-all** nor **match-any** is specified, the **match-all** parameter is selected by default.

### Command Mode

Global Configuration mode

### User Guidelines

The **class-map** enters Class-map Configuration mode. In this mode, up to two **match** commands can be entered to configure the criteria for this class. Each **match** specifies an ACL.

When using two **match** commands, each must point to a different type of ACL, such as: one IP ACL and one MAC ACL. The classification is by first match, therefore, the order of the ACLs is important.

Error messages are generated in the following cases:

- There is more than one **match** command in a **match-all** class map
- There is a repetitive classification field in the participating ACLs.

After entering the Class-map Configuration mode, the following configuration commands are available:

- **exit**: Exits the Class-map Configuration mode.
- **match**: Configures classification criteria.
- **no**: Removes a match statement from a class map.

### Example

The following example creates a class map called Class1 and configures it to check that packets match all classification criteria in the ACL specified.

---

```
switchxxxxxx(config)# class-map class1 match-all
switchxxxxxx(config-cmap) #match access-group acl-name
```

---

## 39.5 show class-map

The **show class-map** EXEC mode command displays all class maps when QoS is in advanced mode.

### Syntax

**show class-map** [*class-map-name*]

### Parameters

**class-map-name**—Specifies the name of the class map to be displayed.

### Command Mode

EXEC mode

### Example

The following example displays the class map for Class1.

---

```
switchxxxxxx# show class-map class1
Class Map match-any class1 (id4)
Match IP dscp 11 21
```

---

## 39.6 match

Use the **match** Class-map Configuration mode command to bind the ACLs that belong to the class-map being configured. Use the **no** form of this command to delete the ACLs.

This command is available only when the device is in QoS advanced mode.

### Syntax

**match access-group** *acl-name*

**no match access-group** *acl-name*

### Parameters

**acl-name**—Specifies the MAC or IP ACL name.

### Default Configuration

No match criterion is supported.

**Command Mode**

Class-map Configuration mode.

**Example**

The following example defines a class map called Class1. Class1 contains an ACL called **enterprise**. Only traffic matching all criteria in **enterprise** belong to the class map.

---

```
switchxxxxxx(config)# class-map class1
switchxxxxxx(config-cmap)# match access-group enterprise
```

---

**39.7 policy-map**

A policy map contains one or more class maps and an action that is taken if the packet matches the class map. Policy maps may be bound to ports/port-channels.

Use the **policy-map** Global Configuration mode command to create a policy map and enter the Policy-map Configuration mode. Use the **no** form of this command to delete a policy map.

This command is only available when QoS is in advanced mode.

**Syntax**

**policy-map** *policy-map-name*

**no policy-map** *policy-map-name*

**Parameters**

**policy-map-name**—Specifies the policy map name.

**Default Configuration**

N/A

**Command Mode**

Global Configuration mode

**User Guidelines**

Use the **policy-map** Global Configuration mode command to specify the name of the policy map to be created, added to, or modified before configuring policies for classes whose match criteria are defined in a class map.

Entering the **policy-map** Global Configuration mode command also enables configuring or modifying the class policies for that policy map. Class policies in a policy map can be configured only if the classes have match criteria defined for them.

Policy map is applied on the ingress path.

The match criteria is for a class map. Only one policy map per interface is supported. The same policy map can be applied to multiple interfaces and directions.

The **service-policy** command binds a policy map to a port/port-channel.

**Example**

The following example creates a policy map called Policy1 and enters the Policy-map Configuration mode.

---

```
switchxxxxxx(config)# policy-map policy1
switchxxxxxx(config-pmap)#
```

---

## 39.8 class

Use the **class** Policy-map Configuration mode command after the [policy-map](#) command to attach ACLs to a policy-map.

Use the **no** form of this command to detach a class map from a policy map.

This command is only available when QoS is in advanced mode.

### Syntax

**class** *class-map-name* [**access-group** *acl-name*]

**no class** *class-map-name*

### Parameters

- **class-map-name**—Specifies the name of an existing class map. If the class map does not exist, a new class map is created under the specified name.
- **access-group** *acl-name*—Specifies the name of an IP or MAC Access Control List (ACL).

### Default Configuration

No class map is defined for the policy map.

### Command Mode

Policy-map Configuration mode

### User Guidelines

This is the same as creating a class map and then binding it to the policy map.

You can specify an existing class map in this command, or you can use the **access-group** parameter to create a new class map.

After the policy-map is defined, use the [service-policy](#) command to attach it to a port/port-channel.

### Example

The following example defines a traffic classification (class map) called **class1** containing an ACL called **enterprise**. The class is in a policy map called **policy1**. The policy-map **policy1** now contains the ACL **enterprise**.

```
switchxxxxxx(config)# policy-map policy1
switchxxxxxx(config-pmap)# class class1 access-group enterprise
```

## 39.9 show policy-map

Use the **show policy-map** EXEC mode command to display all policy maps or a specific policy map.

This command is only available when QoS is in advanced mode.

### Syntax

**show policy-map** [*policy-map-name*]

### Parameters

**policy-map-name**—Specifies the policy map name.

### Default Configuration

All policy-maps are displayed.

**Command Mode**

EXEC mode

**Example**

The following example displays all policy maps.

---

```
switchxxxxxx# show policy-map
Policy Map policy1
class class1
set IP dscp 7
Policy Map policy2
class class 2
police 96000 4800 exceed-action drop
class class3
police 124000 96000 exceed-action policed-dscp-transmit
```

---

**39.10 trust**

Use the **trust** Policy-map Class Configuration mode command to configure the trust state. This command is relevant only when QoS is in advanced, ports-not-trusted mode. Trust indicates that traffic is sent to the queue according to the packet's QoS parameters (UP or DSCP).

Use the **no** form of this command to return to the default trust state.

This command is only available when QoS is in advanced mode.

**Syntax****trust****no trust****Parameters**

N/A

**Default Configuration**

The default state is according to the mode selected in the [qos](#) command (advanced mode). The type of trust is determined in [qos advanced-mode trust](#).

**Command Mode**

Policy-map Class Configuration mode

**User Guidelines**

Use this command to distinguish the QoS trust behavior for certain traffic from others. For example, incoming traffic with certain DSCP values can be trusted. A class map can be configured to match and trust the DSCP values in the incoming traffic.

The type of trust is determined in [qos advanced-mode trust](#).

Trust values set with this command supersede trust values set on specific interfaces with the [qos trust \(Interface\)](#) Interface Configuration mode command.

The **trust** and **set** commands are mutually exclusive within the same policy map.

Policy maps, which contain **set** or **trust** commands or that have ACL classification to an egress interface, cannot be attached by using the [service-policy](#) Interface Configuration mode command.

If specifying **trust cos**, QoS maps a packet to a queue, the received or default port CoS value, and the CoS-to-queue map.

### Example

The following example creates an ACL, places it into a class map, places the class map into a policy map and configures the trust state using the DSCP value in the ingress packet.

---

```
switchxxxxxx(config)# ip access-list extended ip1
switchxxxxxx(config-mac-a1)# permit ip any any
switchxxxxxx(config-mac-a1)# exit
switchxxxxxx(config)# class-map c1
switchxxxxxx(config-cmap)# match access-group ip1
switchxxxxxx(config-cmap)# exit
switchxxxxxx(config)# policy-map p1
switchxxxxxx(config-pmap)# class c1
switchxxxxxx(config-pmap-c)# trust
```

---

## 39.11 set

Use the **set** Policy-map Class Configuration mode command to select the value that QoS uses as the DSCP value, the egress queue or to set user priority values.

This command is only available when QoS is in advanced mode.

### Syntax

**set** {*dscp new-dscp* | *queue queue-id* | *cos new-cos*}

**no set**

### Parameters

- **dscp new-dscp**—Specifies the new DSCP value for the classified traffic. (Range: 0–63)
- **queue queue-id**—Specifies the egress queue. (Range: 1-8)
- **cos new-cos**—Specifies the new user priority to be marked in the packet. (Range: 0–16)

### Command Mode

Policy-map Class Configuration mode

### User Guidelines

The **set** and **trust** commands are mutually exclusive within the same policy map.

To return to the Configuration mode, use the **exit** command. To return to the Privileged EXEC mode, use the **end** command.

### Example

The following example creates an ACL, places it into a class map, places the class map into a policy map and sets the DSCP value in the packet to 56 for classes in the policy map called p1.

---

```
switchxxxxxx(config)# ip access-list extended ip1
switchxxxxxx(config-mac-a1)# permit ip any any
switchxxxxxx(config-mac-a1)# exit
switchxxxxxx(config)# class-map c1
switchxxxxxx(config-cmap)# match access-group ip1
```

---

```
switchxxxxxx(config-cmap)# exit
switchxxxxxx(config)# policy-map p1
switchxxxxxx(config-pmap)# class c1
switchxxxxxx(config-pmap-c)# set dscp 56
```

## 39.12 police

Use the **police** Policy-map Class Configuration mode command to define the policer for classified traffic. This defines another group of actions for the policy map (per class map).

This command is used after the [policy-map](#) and [class](#) commands.

Use the **no** form of this command to remove a policer.

This command is only available when QoS is in advanced mode.

### Syntax

**police** *committed-rate-kbps* *committed-burst-byte* [*exceed-action* {*drop* | *policed-dscp-transmit*}]

**no police**

### Parameters

- **committed-rate-kbps**—Specifies the average traffic rate (CIR) in kbits per second (bps). (Range: 3–10000000)
- **committed-burst-byte**—Specifies the normal burst size (CBS) in bytes. (Range: 3000–19173960)
- **exceed-action {drop | policed-dscp-transmit}**—Specifies the action taken when the rate is exceeded. The possible values are:
  - **drop**—Drops the packet.
  - **policed-dscp-transmit**—Remarks the packet DSCP, according to the policed-DSCP map as configured by the **qos map policed-dscp** Global Configuration mode command.

### Default Usage

N/A

### Command Mode

Policy-map Class Configuration mode

### User Guidelines

This command only exists in when the device is in Layer 2 mode.

Policing uses a token bucket algorithm. CIR represents the speed with which the token is added to the bucket. CBS represents the depth of the bucket.

### Example

The following example defines a policer for classified traffic. When the traffic rate exceeds 124,000 kbps and the normal burst size exceeds 9600 bytes, the packet is dropped. The class is called class1 and is in a policy map called policy1.

```
switchxxxxxx(config)# policy-map policy1
switchxxxxxx(config-pmap)# class class1
switchxxxxxx(config-pmap-c)# police 124000 9600 exceed-action drop
```

## 39.13 service-policy

Use the **service-policy** Interface Configuration (Ethernet, Port-channel) mode command to bind a policy map to a port/port-channel. Use the **no** form of this command to detach a policy map from an interface.

This command is only available in QoS advanced mode.

### Syntax

**service-policy input** *policy-map-name*

**no service-policy input**

### Parameters

**policy-map-name**—Specifies the policy map name to apply to the input interface. (Length: 1–32 characters)

### Command Mode

Interface Configuration (Ethernet, Port-channel) mode

### User Guidelines

Only one policy map per interface per direction is supported.

### Example

The following example attaches a policy map called Policy1 to the input interface.

```
switchxxxxxx(config-if)# service-policy input policy1
```

## 39.14 qos aggregate-policer

Use the **qos aggregate-policer** Global Configuration mode command to define the policer parameters that can be applied to multiple traffic classes. Use the **no** form of this command to remove an existing aggregate policer.

This command is only available when QoS is in advanced mode.

### Syntax

**qos aggregate-policer** *aggregate-policer-name* *committed-rate-kbps* *excess-burst-byte* [**exceed-action** {*drop* | *policed-dscp-transmit*}]

**no qos aggregate-policer** *aggregate-policer-name*

### Parameters

- **aggregate-policer-name**—Specifies the aggregate policer name.
- **committed-rate-kbps**—Specifies the average traffic rate (CIR) in kbits per second (kbps). (Range: 3–57982058)
- **excess-burst-byte**—Specifies the normal burst size (CBS) in bytes. (Range: 3000–19173960)
- **exceed-action** {*drop* | *policed-dscp-transmit*}—Specifies the action taken when the rate is exceeded. The possible values are:
  - **drop**—Drops the packet.
  - **policed-dscp-transmit**—Remarks the packet DSCP.

### Default Configuration

No aggregate policer is defined.



**Command Mode**

Global Configuration mode

**User Guidelines**

This command only exists when the device is in Layer 2.

Define an aggregate policer if the policer aggregates traffic from multiple class maps.

Aggregate policers cannot aggregate traffic from multiple devices. If the aggregate policer is applied to more than one device, the traffic on each device is counted separately and is limited per device.

Traffic from two different ports on the same device can be aggregated for policing purposes.

An aggregate policer can be applied to multiple classes in the same policy map.

An aggregate policer cannot be deleted if it is being used in a policy map. The **no police aggregate** Policy-map Class Configuration mode command must first be used to delete the aggregate policer from all policy maps before using the **no mls qos aggregate-policer** command.

Policing uses a token bucket algorithm. CIR represents the speed with which the token is added to the bucket. CBS represents the depth of the bucket.

**Example**

The following example defines the parameters of a policer called Policer1 that can be applied to multiple classes in the same policy map. When the average traffic rate exceeds 124,000 kbps or the normal burst size exceeds 9600 bytes, the packet is dropped.

---

```
switchxxxxxx(config)# qos aggregate-policer policer1 124000 9600 exceed-action
drop
```

---

**39.15 show qos aggregate-policer**

Use the **show qos aggregate-policer** EXEC mode command to display aggregate policers

This command is only available in QoS advanced mode.

**Syntax**

**show qos aggregate-policer** [*aggregate-policer-name*]

**Parameters**

**aggregate-policer-name**—Specifies the aggregate policer name.

**Default Configuration**

All policers are displayed.

**Command Mode**

EXEC mode

**Example**

The following example displays the parameters of the aggregate policer called Policer1.

---

```
switchxxxxxx# show qos aggregate-policer policer1
aggregate-policer policer1 96000 4800 exceed-action drop
not used by any policy map
```

---

## 39.16 police aggregate

Use the **police aggregate** Policy-map Class Configuration mode command to apply an aggregate policer to multiple class maps within the same policy map. Use the **no** form of this command to remove an existing aggregate policer from a policy map.

This command is only available in QoS advanced mode.

### Syntax

**police aggregate** *aggregate-policer-name*

**no police aggregate** *aggregate-policer-name*

### Parameters

**aggregate-policer-name**—Specifies the aggregate policer name.

### Command Mode

Policy-map Class Configuration mode

### User Guidelines

An aggregate policer can be applied to multiple classes in the same policy map. An aggregate policer cannot be applied across multiple policy maps or interfaces.

Use the **exit** command to return to the Configuration mode. Use the **end** command to return to the Privileged EXEC mode.

### Example

The following example applies the aggregate policer called Policer1 to a class called class1 in a policy map called policy1 and class2 in policy map policy2.

```
switchxxxxxx(config)# qos aggregate-policer policer1 124000 9600 exceed-action drop
switchxxxxxx(config)# policy-map policy1
switchxxxxxx(config-pmap)# class class1
switchxxxxxx(config-pmap-c)# police aggregate policer1
switchxxxxxx(config-pmap-c)# exit
switchxxxxxx(config-pmap)# exit
switchxxxxxx(config)# policy-map policy2
switchxxxxxx(config-pmap)# class class2
switchxxxxxx(config-pmap-c)# police aggregate policer1
```

## 39.17 wrr-queue cos-map

Use the **wrr-queue cos-map** Global Configuration mode command to map Class of Service (CoS) values to a specific egress queue. Use the **no** form of this command to restore the default configuration.

### Syntax

**wrr-queue cos-map** *queue-id cos0... cos7*

**no wrr-queue cos-map** [*queue-id*]

### Parameters

- **queue-id**—Specifies the queue number to which the CoS values are mapped.
- **cos0... cos7**—Specifies up to 8 CoS values to map to the specified queue number. (Range: 0–7)

**Default Configuration**

The default CoS value mapping to 8 queues is as follows:

CoS value 0 is mapped to queue 3.

CoS value 1 is mapped to queue 1.

CoS value 2 is mapped to queue 2.

CoS value 3 is mapped to queue 4.

CoS value 4 is mapped to queue 5.

CoS value 5 is mapped to queue 6.

CoS value 6 is mapped to queue 7.

CoS value 7 is mapped to queue 8.

**Command Mode**

Global Configuration mode

**User Guidelines**

Use this command to distribute traffic to different queues.

**Example**

The following example maps CoS value 4 and 6 to queue 2.

---

```
switchxxxxxx(config)# wrr-queue cos-map 2 4 6
```

---

## 39.18 wrr-queue bandwidth

Use the **wrr-queue bandwidth** global Configuration command to assign Weighted Round Robin (WRR) weights to egress queues. The weight ratio determines the frequency at which the packet scheduler removes packets from each queue. Use the **no** form of this command to restore the default configuration.

**Syntax**

**wrr-queue bandwidth** *weight1 weight2... weighting*

**no wrr-queue bandwidth**

**Parameters**

**weight1 weight1... weighting** the ratio of bandwidth assigned by the WRR packet scheduler to the packet queues. See explanation in the User Guidelines. Separate each value by a space. (Range for each weight: 0–255)

**Default Configuration**

wrr is disabled by default. The default wrr weight is '1' for all queues.

**Command Mode**

Global Configuration mode

**User Guidelines**

The ratio for each queue is defined as the queue weight divided by the sum of all queue weights (the normalized weight). This sets the bandwidth allocation of each queue.

A weight of 0 indicates that no bandwidth is allocated for the same queue, and the shared bandwidth is divided among the remaining queues. It is not recommended to set the weight of a queue to a 0 as it might stop transmission of control-protocols packets generated by the device.

All 7 queues participate in the WRR, excluding the expedite queues, whose corresponding weight is not used in the ratio calculation.

An expedite queue is a priority queue, which is serviced until empty before the other queues are serviced. The expedite queues are designated by the `priority-queue out num-of-queues` command.

### Example

The following assigns WRR values to the queues.

---

```
switchxxxxxx(config)# wrr-queue bandwidth 6 6 6 6 6 6 6
```

---

## 39.19 priority-queue out num-of-queues

An expedite queue is a strict priority queue, which is serviced until empty before the other lower priority queues are serviced.

Use the `priority-queue out num-of-queues` Global Configuration mode command to configure the number of expedite queues. Use the `no` form of this command to restore the default configuration.

### Syntax

`priority-queue out num-of-queues number-of-queues`

`no priority-queue out num-of-queues`

### Parameters

- **number-of-queues**—Specifies the number of expedite (strict priority) queues. Expedite queues are assigned to the queues with the higher indexes. (Range: 0–8).  
There must be either 0 wrr queues or more than one.
- If **number-of-queues** = 0, all queues are assured forwarding (according to wrr weights) If the **number-of-queues** = 8, all queues are expedited (strict priority queues).

### Default Configuration

All queues are expedite queues.

### Command Mode

Global Configuration mode

### User Guidelines

the weighted round robin (WRR) weight ratios are affected by the number of expedited queues, because there are fewer queues participating in WRR. This indicates that the corresponding weight in the `wrr-queue bandwidth` Interface Configuration mode command is ignored (not used in the ratio calculation).

### Example

The following example configures the number of expedite queues as 2.

---

```
switchxxxxxx(config)# priority-queue out num-of-queues 2
```

---

## 39.20 traffic-shape

The egress port shaper controls the traffic transmit rate (Tx rate) on a port.

Use the **traffic-shape** Interface Configuration mode command to configure the egress port shaper. Use the **no** form of this command to disable the shaper.

### Syntax

**traffic-shape** *committed-rate* [*committed-burst*]

**no traffic-shape**

### Parameters

- **committed-rate**—Specifies the maximum average traffic rate (CIR) in kbits per second (kbps). (Range: GE: 64kbps–maximum port speed; 10GE: 64Kbps–maximum port speed)
- **committed-burst**—Specifies the maximum permitted excess burst size (CBS) in bytes. (Range: 4096 - 16762902 bytes)

### Default Configuration

The shaper is disabled.

### Command Mode

Interface Configuration (Ethernet, Port-channel) mode

### Example

The following example sets a traffic shaper on `gi1/0/15` on queue 1 when the average traffic rate exceeds 124000 kbps or the normal burst size exceeds 9600 bytes.

```
switchxxxxxx(config)# interface gi1/0/15
switchxxxxxx(config-if)# traffic-shape 1 124000 9600
```

## 39.21 traffic-shape queue

The egress port shaper controls the traffic transmit rate (Tx rate) on a queue on a port.

Use the **traffic-shape queue** Interface Configuration mode command to configure the egress queue shaper. Use the **no** form of this command to disable the shaper.

### Syntax

**traffic-shape queue** *queue-id* *committed-rate* [*committed-burst*]

**no traffic-shape queue** *queue-id*

### Parameters

- **queue-id**—Specifies the queue number to which the shaper is assigned. (Range: 1-4)
- **committed-rate**—Specifies the average traffic rate (CIR) in kbits per second (kbps). (Range: 64 kbps–maximum port speed)
- **committed-burst**—Specifies the excess burst size (CBS) in bytes. (Range: 4096 - 16762902 bytes)

### Default Configuration

The shaper is disabled.

### Command Mode

Interface Configuration (Ethernet, Port-channel) mode

**Example**

The following example sets a shaper on queue 1 on `gi1/0/15` when the average traffic rate exceeds 124000 kbps or the normal burst size exceeds 9600 bytes.

---

```
switchxxxxxx(config)# interface gi1/0/15
switchxxxxxx(config-if)# traffic-shape 1 124000 9600
```

---

**39.22 rate-limit (Ethernet)**

Use the **rate-limit** Interface Configuration mode command to limit the incoming traffic rate on a port. Use the **no** form of this command to disable the rate limit.

**Syntax**

**rate-limit** *committed-rate-kbps* [*burst committed-burst-bytes*]

**no rate-limit**

**Parameters**

- **committed-rate-kbps**—Specifies the maximum number of kilobits per second of ingress traffic on a port. The range is 3500–max port speed.
- **burst committed-burst-bytes**—The burst size in bytes (3000–19173960). If unspecified, defaults to 128K.

**Default Configuration**

Rate limiting is disabled.

Committed-burst-bytes is 128K.

**Command Mode**

Interface Configuration (Ethernet) mode

**User Guidelines**

Storm control and rate-limit (of Unicast packets) cannot be enabled simultaneously on the same port.

**Example**

The following example limits the incoming traffic rate on `gi1/0/15` to 150,000 kbps.

---

```
switchxxxxxx(config)# interface gi1/0/15
switchxxxxxx(config-if)# rate-limit 150000
```

---

**39.23 qos wrr-queue wrtd**

Use the **qos wrr-queue wrtd** Global Configuration mode command to enable Weighted Random Tail Drop (WRTD). Use the **no** form of this command to disable WRTD.

**Syntax**

**qos wrr-queue wrtd**

**no qos wrr-queue wrtd**

**Parameters**

N/A

**Default**

Disabled

**Command Mode**

Global Configuration mode

**User Guidelines**

The command is effective after reset.

**Example**


---

```
switchxxxxxx(conf)#>qos wrr-queue wrtd
This setting will take effect only after copying running configuration to startu
p configuration and resetting the device
switchxxxxxx(config)#
```

---

**39.24 show qos wrr-queue wrtd**

Use the **show qos wrr-queue wrtd** Exec mode command to display the Weighted Random Tail Drop (WRTD) configuration.

**Syntax****show qos wrr-queue wrtd****Parameters**

N/A

**Default Configuration**

N/A

**Command Mode**

Exec mode

**Example**


---

```
switchxxxxxx# show qos wrr-queue wrtd
Weighted Random Tail Drop is disabled
Weighted Random Tail Drop will be enabled after reset
```

---

**39.25 show qos interface**

Use the **show qos interface** EXEC mode command to display Quality of Service (QoS) information on the interface.

**Syntax****show qos interface** [*buffers* | *queueing* | *policers* | *shapers* | *rate-limit*] [*interface-id*]**Parameters**

- **buffers**—Displays the buffer settings for the interface's queues. For GE ports, displays the queue depth for each of the 8 queues.

- **queueing**—Displays the queue's strategy (WRR or EF), the weight for WRR queues, the CoS to queue map and the EF priority.
- **policers**—Displays all the policers configured for this interface, their settings, and the number of policers currently unused (on a VLAN).
- **shapers**—Displays the shaper of the specified interface and the shaper for the queue on the specified interface.
- **rate-limit**—Displays the rate-limit configuration.
- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port, or Port-channel.

### Default Configuration

N/A

### Command Mode

EXEC mode

### User Guidelines

If no parameter is specified with the **show qos interface** command, the port QoS mode (DSCP trusted, CoS trusted, untrusted, and so on), default CoS value, DSCP-to-DSCP- map (if any) attached to the port, and policy map (if any) attached to the interface are displayed. If a specific interface is not specified, the information for all interfaces is displayed.

### Examples

**Example 1** - This is an example of the output from the **show qos interface buffers** command for 8 queues.

---

```
switchxxxxxx#show qos interface buffers gi1/0/11
gi1/0/11
Notify Q depth:
buffers gi1/0/11
Ethernet gi1/0/11
qid  thresh0  thresh1  thresh2
1    100      100      80
2    100      100      80
3    100      100      80
4    100      100      80
5    100      100      80
6    100      100      80
7    100      100      80
8    100      100      80
```



**Example 2** - This is an example of the output from the **show qos interface shapers** command.

```
switchxxxxxx#show qos interface shapers gi1/0/11
gi1/0/11
Port shaper: enable
Committed rate: 192000 bps
Committed burst: 9600 bytes
```

QID	Status	Target Committed Rate [bps]	Target Committed Burst [bytes]
1	Enable	100000	17000
2	Disable	N/A	N/A
3	Enable	200000	19000
4	Disable	N/A	N/A
5	Disable	N/A	N/A
6	Disable	N/A	N/A
7	Enable	178000	8000
8	Enable	23000	1000

**Example - 3** This is an example of the output from the **show qos interface policer** command.

```
switchxxxxxx# show qos interface policer gi1/0/11
Ethernet gi1/0/11
Class map: A
Policer type: aggregate
Committed rate: 192000 bps
Committed burst: 9600 bytes
Exceed-action: policed-dscp-transmit
Class map: B
Policer type: single
Committed rate: 192000 bps
Committed burst: 9600 bytes
Exceed-action: drop
Class map: C
Policer type: none
Committed rate: N/A
Committed burst: N/A
Exceed-action: N/A
```

**Example 4** - This is an example of the output from the **show qos interface rate-limit** command.

```
switchxxxxxx# show qos interface rate-limit gi1/0/11
```

Port	rate-limit [kbps]	Burst [KBytes]
gi1/0/11	1000	512K

## 39.26 qos wrr-queue threshold

Use the **qos wrr-queue threshold** Global Configuration mode command to assign queue thresholds globally. Use the **no** form of this command to restore the default configuration.

This command is only available in QoS advanced mode.

### Syntax

```
qos wrr-queue threshold gigabitethernet tengigabitethernet queue-id threshold-percentage  
no qos wrr-queue threshold gigabitethernet queue-id
```

### Parameters

- **gigabitethernet**—Specifies that the thresholds are to be applied to Gigabit Ethernet ports.
- **tengigabitethernet**—Specifies that the thresholds are to be applied to 10 Gigabit Ethernet ports.
- **queue-id**—Specifies the queue number to which the tail-drop threshold is assigned.
- **threshold-percentage**—Specifies the queue threshold percentage value.

### Default Configuration

The default threshold is 80 percent.

### Command Mode

Global Configuration mode

### User Guidelines

If the threshold is exceeded, packets with the corresponding Drop Precedence (DP) are dropped until the threshold is no longer exceeded.

### Example

The following example assigns a threshold of 80 percent to WRR queue 1.

```
switchxxxxxx(config)# qos wrr-queue threshold gigabitethernet 1 80
```

## 39.27 qos map policed-dscp

Use the **qos map policed-dscp** Global Configuration mode command to configure the policed-DSCP map for remarking purposes. Use the **no** form of this command to restore the default configuration.

This command is only available in QoS advanced mode.

### Syntax

```
qos map policed-dscp dscp-list to dscp-mark-down  
no qos map policed-dscp [dscp-list]
```

### Parameters

- **dscp-list**—Specifies up to 8 DSCP values, separated by spaces. (Range: 0–63)
- **dscp-mark-down**—Specifies the DSCP value to mark down. (Range: 0–63)

### Default Configuration

The default map is the Null map, which means that each incoming DSCP value is mapped to the same DSCP value.

**Command Mode**

Global Configuration mode.

**User Guidelines**

The original DSCP value and policed-DSCP value must be mapped to the same queue in order to prevent reordering.

**Example**

The following example marks incoming DSCP value 3 as DSCP value 5 on the policed-DSCP map.

---

```
switchxxxxxx(config)# qos map policed-dscp 3 to 5
```

---

**39.28 qos map dscp-queue**

Use the **qos map dscp-queue** Global Configuration mode command to configure the DSCP to CoS map. Use the **no** form of this command to restore the default configuration.

**Syntax**

**qos map dscp-queue** *dscp-list* to *queue-id*

**no qos map dscp-queue** [*dscp-list*]

**Parameters**

- **dscp-list**—Specifies up to 8 DSCP values, separated by spaces. (Range: 0–63)
- **queue-id**—Specifies the queue number to which the DSCP values are mapped.

**Default Configuration**

The default map for 8 queues is as follows.

DSCP value	0-7	8-15	16-23	24-31	32-39	40-47	48-56	57-63
Queue-ID	1	2	3	4	5	6	7	8

**Command Mode**

Global Configuration mode

**Example**

The following example maps DSCP values 33, 40 and 41 to queue 1.

---

```
switchxxxxxx(config)# qos map dscp-queue 33 40 41 to 1
```

---

**39.29 qos map dscp-dp**

Use the **qos map dscp-dp** Global Configuration mode command to map the DSCP values to Drop Precedence. Use the **no** form of this command to restore the default configuration.

This command is only available in QoS advanced mode.

**Syntax**

**qos map dscp-dp** *dscp-list* to *dp*

**no qos map dscp-dp** [*dscp-list*]

**Parameters**

- **dscp-list**—Specifies up to 8 DSCP values, with values separated by a space. (Range: 0–63)
- **dp**—Specifies the Drop Precedence value to which the DSCP values are mapped. (values: 0,2) where 2 is the highest Drop Precedence).

**Default Configuration**

All the DSCPs are mapped to Drop Precedence 0.

**Command Mode**

Global Configuration mode.

**Example**

The following example maps DSCP values 25, 27 and 29 to Drop Precedence 2.

---

```
switchxxxxxx(config)# qos map dscp-dp 25 27 29 to 2
```

---

## 39.30 qos trust (Global)

Use the **qos trust** Global Configuration mode command to configure the system to the basic mode and trust state. Use the **no** form of this command to return to the default configuration.

**Syntax**

**qos trust** {*cos* | *dscp*}

**no qos trust**

**Parameters**

- **cos**— Specifies that ingress packets are classified with packet CoS values. Untagged packets are classified with the default port CoS value.
- **dscp**—Specifies that ingress packets are classified with packet DSCP values.

**Default Configuration**

CoS is the default trust mode.

**Command Mode**

Global Configuration mode

**User Guidelines**

This command can be used only in QoS basic mode.

Packets entering a QoS domain are classified at its edge. When the packets are classified at the edge, the switch port within the QoS domain can be configured to one of the trusted states because there is no need to classify the packets at every switch within the domain.

Use this command to specify whether the port is trusted and which fields of the packet to use to classify traffic.

When the system is configured with trust DSCP, the traffic is mapped to the queue by the DSCP-queue map.

When the system is configured with trust CoS, the traffic is mapped to the queue by the CoS-queue map.

For an inter-QoS domain boundary, configure the port to the DSCP-trusted state and apply the DSCP-to-DSCP-mutation map if the DSCP values are different in the QoS domains.

**Example**

The following example configures the system to the DSCP trust state.

---

```
switchxxxxxx(config)# qos trust dscp
```

---

## 39.31 qos trust (Interface)

Use the **qos trust** Interface Configuration (Ethernet, Port-channel) mode command to enable port trust state while the system is in the basic QoS mode. Use the **no** form of this command to disable the trust state on each port.

**Syntax**

**qos trust**

**no qos trust**

**Parameters**

N/A

**Default Configuration**

Each port is enabled while the system is in basic mode.

**Command Mode**

Interface Configuration (Ethernet, Port-channel) mode

**Example**

The following example configures `gi1/0/115` to the default trust state.

---

```
switchxxxxxx(config)# interface gi1/0/15  
switchxxxxxx(config-if)# qos trust
```

---

## 39.32 qos cos

Use the **qos cos** Interface Configuration (Ethernet, Port-channel) mode command to define the default CoS value of a port. Use the **no** form of this command to restore the default configuration.

**Syntax**

**qos cos** *default-cos*

**no qos cos**

**Parameters**

**default-cos**—Specifies the default CoS value (VPT value) of the port. If the port is trusted and the packet is untagged, then the default CoS value become the CoS value. (Range: 0–16)

**Default Configuration**

The default CoS value of a port is 0.

**Command Mode**

Interface Configuration (Ethernet, Port-channel) mode

**User Guidelines**

Use the default CoS value to assign a CoS value to all untagged packets entering the interface.

**Example**

The following example defines the port `gi1/0/15` default CoS value as 3.

---

```
switchxxxxxx(config)# interface gi1/0/15
switchxxxxxx(config-if)# qos cos 3
```

---

**39.33 qos dscp-mutation**

Use the **qos dscp-mutation** Global Configuration mode command to apply the DSCP Mutation map to system DSCP trusted ports. Use the **no** form of this command to restore the trusted port with no DSCP mutation.

**Syntax**

**qos dscp-mutation**

**no qos dscp-mutation**

**Parameters**

N/A

**Default Configuration**

N/A

**Command Mode**

Global Configuration mode.

**User Guidelines**

Apply the DSCP-to-DSCP-mutation map to a port at the boundary of a Quality of Service (QoS) administrative domain. If two QoS domains have different DSCP definitions, use the DSCP-to-DSCP-mutation map to translate a set of DSCP values to match the definition of another domain. Apply the map to ingress and to DSCP-trusted ports only. Applying this map to a port causes IP packets to be rewritten with newly mapped DSCP values at the ingress ports. If applying the DSCP mutation map to an untrusted port, to class of service (CoS), or to an IP-precedence trusted port.

Global trust mode must be DSCP or CoS-DSCP. In advanced CoS mode, ports must be trusted.

**Example**

The following example applies the DSCP Mutation map to system DSCP trusted ports.

---

```
switchxxxxxx(config)# qos dscp-mutation
```

---

**39.34 qos map dscp-mutation**

Use the **qos map dscp-mutation** Global Configuration mode command to configure the DSCP to DSCP Mutation table. Use the **no** form of this command to restore the default configuration.

**Syntax**

**qos map dscp-mutation** *in-dscp* to *out-dscp*

**no qos map dscp-mutation** [*in-dscp*]

**Parameters**

- **in-dscp**—Specifies up to 8 DSCP values to map, separated by spaces. (Range: 0–63)
- **out-dscp**—Specifies up to 8 DSCP mapped values, separated by spaces. (Range: 0–63)

**Default Configuration**

The default map is the Null map, which means that each incoming DSCP value is mapped to the same DSCP value.

**Command Mode**

Global Configuration mode.

**User Guidelines**

This is the only map that is not globally configured. It is possible to have several maps and assign each one to a different port.

**Example**

The following example changes DSCP values 1, 2, 4, 5 and 6 to DSCP Mutation Map value 63.

---

```
switchxxxxxx(config)# qos map dscp-mutation 1 2 4 5 6 to 63
```

---

## 39.35 show qos map

Use the **show qos map** EXEC mode command to display the various types of QoS mapping.

**Syntax**

**show qos map [dscp-queue | dscp-dp | policed-dscp | dscp-mutation]**

**Parameters**

- **dscp-queue**—Displays the DSCP to queue map.
- **dscp-dp**—Displays the DSCP to Drop Precedence map.
- **policed-dscp**—Displays the DSCP to DSCP remark table.
- **dscp-mutation**—Displays the DSCP-DSCP mutation table.

**Default Configuration**

Display all maps.

**Command Mode**

EXEC mode

**Example**

The following example displays the QoS mapping information.

---

```
switchxxxxxx# show qos map dscp-queue
Dscp-queue map:
d1   :   d2  0    1    2    3    4    5    6    7    8    9
--   --   --   --   --   --   --   --   --   --   --   --
0    :           01  01  01  01  01  01  01  01  01  01  01
1    :           01  01  01  01  01  01  01  01  02  02  02
2    :           02  02  02  02  03  03  03  03  03  03  03
3    :           04  04  05  05  05  05  05  05  05  05  05
4    :           06  06  06  06  06  06  06  06  06  07  07
5    :           07  07  07  07  07  07  07  08  08  08  08
6    :           08  08  08  08
```

---

**39.36 clear qos statistics**

Use the **clear qos statistics** EXEC mode command to clear the QoS statistics counters.

**Syntax**

**clear qos statistics**

**Parameters**

N/A

**Default Configuration**

N/A

**Command Mode**

EXEC mode

**Example**

The following example clears the QoS statistics counters.

---

```
switchxxxxxx# clear qos statistics
```

---

**39.37 qos statistics policer**

Use the **qos statistics policer** Interface Configuration (Ethernet, Port-channel) mode command to enable counting in-profile and out-of-profile. Use the **no** form of this command to disable counting.

This command is relevant only when policers are defined.

**Syntax**

**qos statistics policer** *policy-map-name* *class-map-name*

**no qos statistics policer** *policy-map-name* *class-map-name*

**Parameters**

- **policy-map-name**—Specifies the policy map name.
- **class-map-name**—Specifies the class map name.



**Default Configuration**

Counting in-profile and out-of-profile is disabled.

**Command Mode**

Interface Configuration (Ethernet, Port-channel) mode

**Example**

The following example enables counting in-profile and out-of-profile on the interface.

---

```
switchxxxxxx(config-if)# qos statistics policer policy1 class1
```

---

**39.38 qos statistics aggregate-policer**

Use the **qos statistics aggregate-policer** Global Configuration mode command to enable counting in-profile and out-of-profile. Use the **no** form of this command to disable counting.

**Syntax**

**qos statistics aggregate-policer** *aggregate-policer-name*

**no qos statistics aggregate-policer** *aggregate-policer-name*

**Parameters**

**aggregate-policer-name**—Specifies the aggregate policer name.

**Default Configuration**

Counting in-profile and out-of-profile is disabled.

**Command Mode**

Global Configuration mode

**Example**

The following example enables counting in-profile and out-of-profile on the interface.

---

```
switchxxxxxx(config)# qos statistics aggregate-policer policer1
```

---

**39.39 qos statistics queues**

Use the **qos statistics queues** Global Configuration mode command to enable QoS statistics for output queues. Use the **no** form of this command to disable QoS statistics for output queues.

**Syntax**

**qos statistics queues set** *{queue | all}* *{dp | all}* *{interface | all}*

**no qos statistics queues set**

**Parameters**

- **set**—Specifies the counter set number.
- **interface**—Specifies the Ethernet port.
- **queue**—Specifies the output queue number.
- **dp**—Specifies the drop precedence. The available values are: **high**, **low**.

**Default Configuration**

Set 1: All interfaces, all queues, high DP.

Set 2: All interfaces, all queues, low DP.

**Command Mode**

Global Configuration mode

**User Guidelines**

There are no user guidelines for this command.

If the queue parameter is all, traffic in cascading ports is also counted.

**Example**

The following example enables QoS statistics for output queues for counter set 1.

---

```
switchxxxxxx(config)# qos statistics queues 1 all all all
```

---

## 39.40 show qos statistics

Use the **show qos statistics** EXEC mode command to display Quality of Service statistical information.

**Syntax**

**show qos statistics**

**Parameters**

N/A

**Default Configuration**

N/A

**Command Mode**

EXEC mode

**User Guidelines**

Up to 16 sets of counters can be enabled for policers. The counters can be enabled in the creation of the policers.

Use the **qos statistics queues** Global Configuration mode command to enable QoS statistics for output queues.







