



# **ZXR10**

## **Router/Ethernet Switch**

Command Manual (Basic Configuration Volume I)

---

Version 4.8.22

ZTE CORPORATION  
ZTE Plaza, Keji Road South,  
Hi-Tech Industrial Park,  
Nanshan District, Shenzhen,  
P. R. China  
518057  
Tel: (86) 755 26771900  
Fax: (86) 755 26770801  
URL: <http://ensupport.zte.com.cn>  
E-mail: [support@zte.com.cn](mailto:support@zte.com.cn)

## LEGAL INFORMATION

Copyright © 2006 ZTE CORPORATION.

The contents of this document are protected by copyright laws and international treaties. Any reproduction or distribution of this document or any portion of this document, in any form by any means, without the prior written consent of ZTE CORPORATION is prohibited. Additionally, the contents of this document are protected by contractual confidentiality obligations.

All company, brand and product names are trade or service marks, or registered trade or service marks, of ZTE CORPORATION or of their respective owners.

This document is provided "as is", and all express, implied, or statutory warranties, representations or conditions are disclaimed, including without limitation any implied warranty of merchantability, fitness for a particular purpose, title or non-infringement. ZTE CORPORATION and its licensors shall not be liable for damages resulting from the use of or reliance on the information contained herein.

ZTE CORPORATION or its licensors may have current or pending intellectual property rights or applications covering the subject matter of this document. Except as expressly provided in any written license between ZTE CORPORATION and its licensee, the user of this document shall not acquire any license to the subject matter herein.

ZTE CORPORATION reserves the right to upgrade or make technical change to this product without further notice.

Users may visit ZTE technical support website <http://ensupport.zte.com.cn> to inquire related information.

The ultimate right to interpret this product resides in ZTE CORPORATION.

### **Revision History**

<b>Revision No.</b>	<b>Revision Date</b>	<b>Revision Reason</b>
R1.0	Dec. 28, 2008	First Edition

Serial Number: sjzl20086528

<b>About This Manual.....</b>	<b>i</b>
<b>Command Introduction .....</b>	<b>1</b>
Manual Use Guide.....	1
Description of Man-Machine Commands.....	1
Auxiliary Function .....	2
Command Mode .....	3
<b>Basic System Management.....</b>	<b>7</b>
auto-download config.....	8
banner incoming .....	8
boot config-file.....	9
clock set.....	9
clock timezone .....	10
configure terminal .....	10
disable .....	11
enable .....	11
enable secret .....	12
end .....	13
exit .....	13
flah-protect power-off .....	14
hostname .....	14
help message.....	15
more .....	15
multi-user configure.....	16
nvram boot-password .....	17
nvram boot-server.....	17
nvram boot-username.....	18
nvram default-gateway .....	18
nvram imgfile-location.....	19
nvram mng-ip-address .....	20
privilege.....	20
reload .....	21
service password-encryption .....	21
show auto-download-config .....	22
show clock.....	22
show diagnostic information.....	22
show privilege.....	27
show running-config .....	27
show start running-config .....	28

show system-group .....	29
show username .....	29
show users .....	29
show user-group .....	30
show version .....	30
show version hardware.....	30
show version mec.....	31
show version midplane.....	32
show version npc.....	32
show version software.....	32
show version sfc.....	33
show version upc.....	33
username .....	34
user-group .....	34
who .....	35

## **File System Management.....37**

cd .....	37
check dev-using .....	38
copy .....	39
delete .....	39
dir .....	40
format .....	41
mkdir.....	41
pwd .....	42
rename .....	42
rmdir .....	43
show flash-check.....	43
unmount .....	44
update-imgfile.....	44
write.....	45
write flash .....	45
write imgfile .....	46
write nvram .....	47

## **User Interface Management .....49**

answer-manual .....	49
answer-remote.....	50
line console 0.....	50
line console absolute-timeout.....	50
line console idle-timeout.....	51
line telnet absolute-timeout .....	51

line telnet access-class .....	52
line telnet idle-timeout .....	52
login .....	53
login authentication .....	53
logout .....	54
quit .....	54
session .....	54
show console-info .....	54
show history .....	55
show terminal .....	55
telnet.....	56
telnet mng.....	56
terminal length .....	57
user-authentication-type .....	57
user-authorization-type .....	57

## **System Log/Statistics Management .....59**

alarm.....	60
alarm cpuload-interval .....	60
alarm cpuload-on .....	61
alarm cpuload-threshold .....	61
alarm level-change .....	62
check.....	62
clear logging .....	63
clear processor.....	63
cpuload-threshold.....	63
environ .....	64
filter .....	64
logging alarmlog-interval .....	65
logging buffer .....	65
logging cmd ftp .....	66
logging cmdlog-interval .....	66
logging console .....	67
logging filesavetime .....	67
logging filter-map .....	68
logging ftp.....	69
logging level .....	70
logging mode.....	70
logging nat ftp .....	71
logging on .....	71
logging synchronize .....	72

logging timestamps .....	72
logging trap-enable.....	72
memory-threshold .....	73
show alarm-level .....	73
show logfile .....	74
show logging alarm.....	74
show logging configure.....	75
show processor .....	75
show processor details .....	77
show temperature .....	77
syslog-server facility .....	78
syslog-server host .....	79
syslog-server source .....	80
temper-threshold .....	80
write .....	81
write cmdlog.....	82
write logging.....	82
<b>FTP/TFTP Server .....</b>	<b>83</b>
copy(FTP Client) .....	83
copyTFTP Client.....	84
ftp-server enable.....	84
ftp-server tick-user.....	84
ftp-server top-directory .....	85
ip ftp password .....	85
ip ftp username.....	86
show ftp-server.....	86
show ftp-server-user.....	86
<b>IPV4 Basic Protocols .....</b>	<b>89</b>
address.....	90
arp timeout .....	91
clear arp .....	91
clear ip traffic-statistics .....	92
clear tcp connect .....	92
clear tcp line.....	93
clear tcp statistics.....	93
clear tcp tcb.....	93
clear tcp tty .....	93
clear tcp vty .....	94
detect loop-time .....	94
detect option .....	94

detect try-times .....	95
detcet time-out .....	95
detect-group.....	96
detect-list.....	96
ip address .....	97
ip forwarding-mode .....	97
ip load-sharing .....	98
ip local policy route-map .....	99
ip mtu.....	99
ip policy route-map.....	100
ip proxy-arp.....	100
ip redirect.....	101
ip route .....	101
ip source-route .....	102
ip stream cache.....	103
ip stream enable .....	104
ip stream export.....	104
ip tcp finwait-time .....	105
ip tcp queuemax .....	106
ip tcp synwait-tim.....	106
ip tcp window-size .....	107
ip unnumbered.....	107
ip unreachable .....	108
netflow-sample-rate.....	108
ntp authenticate .....	109
ntp authentication-key .....	109
ntp enable .....	110
ntp server .....	110
ntp source .....	111
ntp trusted-key .....	111
ping.....	111
ping mng.....	113
ping mpls .....	113
set arp .....	114
show arp .....	115
show detect-group.....	116
show ip forwarding .....	117
show ip protocol routing .....	117
show ip protocol routing summary .....	118
show ip route.....	118

show ip traffic .....	119
show ntp status.....	120
show tcp .....	120
show tcp brief .....	121
show tcp config .....	121
show tcp line .....	121
show tcp statistics .....	122
show tcp tcb .....	122
show tcp tty.....	123
show tcp vty .....	124
show vlan-forwarding.....	124
trace.....	125
trace mpls .....	125
vlan arp-mode .....	126
vlan-forwarding.....	127



# About This Manual

---

**Purpose** This manual provides procedures and guidelines that support the operation of ZXR10 router and Ethernet switch.

**Intended Audience** This manual is intended for engineers and technicians who perform operation activities on ZXR10 router and Ethernet switch.

**What Is in This Manual** This manual contains the following chapters:

Chapter	Summary
Chapter 1, Command Introduction	This describes the use method of the command manual, command description, format convention, auxiliary function and mode.
Chapter 2 Basic System Management	Describes the basic system management commands, including the configuration and viewing commands
Chapter 3 File System Management	Describes the operation and management commands for the file system
Chapter 4 User Interface Management	Describes the operation and management commands for the user interfaces
Chapter 5 System Log/Statistics Management	Describes the operation and management commands for the system log and statistics
Chapter 6 FTP/TFTP Server	Describes the operation and management commands for the FTP/TFTP server
Chapter 7 IPV4 Basic Protocols	Describes the configuration and view commands of IPV4 basic protocols, including the ARP, IP, TCP, DHCP, NAT and VRRP

**Related Documentation**

The following documentation is related to this manual:

- ZXR10 Router/Ethernet Switch Command Manual (Command Index Volume)
- ZXR10 Router/Ethernet Switch Command Manual (Ethernet Switch Volume)
- ZXR10 Router/Ethernet Switch Command Manual (Basic Configuration Volume II)
- ZXR10 Router/Ethernet Switch Command Manual (Basic Configuration Volume III)
- ZXR10 Router/Ethernet Switch Command Manual (Remote Access Volume)
- ZXR10 Router/Ethernet Switch Command Manual (IPv4 Routing Volume I)

- ZXR10 Router/Ethernet Switch Command Manual (IPv4 Routing Volume II)
- ZXR10 Router/Ethernet Switch Command Manual (MPLS Volume)
- ZXR10 Router/Ethernet Switch Command Manual (QoS Volume)
- ZXR10 Router/Ethernet Switch Command Manual (Security Volume)
- ZXR10 Router/Ethernet Switch Command Manual (Network Management Volume)
- ZXR10 Router/Ethernet Switch Command Manual (Multicast Volume)
- ZXR10 Router/Ethernet Switch Command Manual (IPv6 Volume)
- ZXR10 Router/Ethernet Switch Command Manual (Voice and Video Service Volume)

## Command Introduction

---

### Table of Contents

Manual Use Guide.....	1
Description of Man-Machine Commands.....	1
Auxiliary Function .....	2
Command Mode .....	3

## Manual Use Guide

The commands in other volumes are classified by functional modules, and each functional module corresponds to a chapter and the commands in the chapter are organized in the form of level 2 directory and in the order of a–z.

To search a command, do as follows:

1. Find the desired command by referring to ZXR10 Router/Ethernet Switch Command Manual — Command Index.
2. Find command details by the volume, chapter/section and page of the obtained command.

## Description of Man-Machine Commands

Each MML command is described by the following items:

- Function  
It describes the function implemented by this command.
- Command Mode  
It describes the mode in which this command can be executed.
- Format  
It describes the complete format of this command, including the no format if possible.
- Parameter Description  
It describes parameters in this command in the form and prescribes the range and default value. If different products have

different parameter ranges or default values, an additional form is used for description.

- Default

The default value is available in the case that this command is not set. The default parameter value is not described here for value selection.

Additional description shall be given if different products have different default values.

- Instructions

First describes the platform version information about this command. For example, "The platform version X.X.XX or later supports this command" indicates this command is provided from the beginning of the platform version X.X.XX. This command is provided from the platform version 2.6 by default.

Second describes the use method and precautions of this command.

- Example

It describes the use of this command in an example.

- Related Commands

Lists the command(s) related to this command.

- History Command

It describes history version information related to this command if a command is changed after version upgrade.

Do not describe the history command if this entry does not exist.

## Auxiliary Function

The auxiliary function for ZXR10 devices is as follows.

1. In any command mode, enter a question mark (?) after the DOS prompt of the system, a list of available commands in the command mode will be displayed. With the context-sensitive help function, the keywords and parameter lists of any commands can be obtained.
  - i. In any command mode, enter a question mark "?" after the DOS prompt of the system, and a list of all commands in the mode and the brief description of the commands will be displayed.
  - ii. Input the question mark behind a character or character string to view the list of commands or keywords beginning with this character or character string. Note that there is no space between the character (string) and the question mark.
  - iii. Press **TAB** behind the character string. If the command or keyword beginning with this character string is unique, it shall be completed with a space at the end. Note that there is no space between the character string and the **TAB**.

- iv. Input a question mark after a command, a keyword or a parameter, the next keyword or parameter to be input will be listed, and also a brief explanation will be given. Note that a space must be entered before the question mark.
2. If incorrect command, keyword or parameter is input, the error isolation is offered with ^ in the user interface after you press ENTER. The ^ is below the first character of the input incorrect command, keyword or parameter.
3. ZXR10 router/Ethernet switch allows the command or keyword to be abbreviated into a character or character string that uniquely identifies this command or keyword. For example, the **show** command can be abbreviated to **sh** or **sho**.
4. The user interface supports the function of recording input commands. A maximum of ten history commands can be recorded. The function is very useful in re-invocation of a long or complicated command or ingress.

To re-invoke a command from the record buffer, conduct one of the following operations, as shown below.

Command	Function
Press <b>CTRL-P</b> or the up arrow key	Re-invokes the latest command in the record buffer. Repeat these keys to invoke old commands forwards.
Press <b>CTRL-N</b> or the down arrow key	Rolls the commands downward. When the last command line is reached, one more operation will roll the commands from the begging of the buffer cyclically.

In any mode, execute the **show history** command to list the latest commands input in this mode.

## Command Mode

The command modes in this manual are shown below.

Mode	Prompt	Admission Mode	Entry Command	Functions
Exec mode	ZXR10>		enters directly after logging the system	Views simple information
Privileged mode	ZXR10#	Exec mode	<b>enable</b>	Configures system parameters
Global configuration mode	ZXR10(config)#	Privileged mode	<b>configure terminal</b>	Configures global service parameters

Mode	Prompt	Admission Mode	Entry Command	Functions
Interface configuration mode	ZXR10 (config-if) #	Global configuration mode	<b>interface</b>	Configures port parameters and selects a port type depending on the keyword
Subinterface mode	ZXR10 (config-subif) #	Global configuration mode	<b>interface</b>	Configures subinterface parameters of the NPCI/NPCT
VLAN database configuration mode	ZXR10 (vlan-db) #	Privileged mode	<b>vlan database</b>	Creates or deletes VLANs in batches
VLAN configuration mode	ZXR10 (config-vlan) #	Global configuration mode	<b>vlan</b>	Configures VLAN parameters
MSTP configuration mode	ZXR10 (config-mstp) #	Global configuration mode	<b>spanning-tree mst configuration</b>	Configures MSTP parameters
Basic ACL configuration mode	ZXR10 (config-basic-acl) #	Global configuration mode	<b>acl basic</b>	Defines basic ACL rule
Extended ACL configuration mode	ZXR10 (config-ext-acl) #	Global configuration mode	<b>acl extend</b>	Defines extended ACL rule
Line configuration mode	ZXR10 (config-line) #	Global configuration mode	<b>line console 0</b> <b>line &lt;1~64&gt;(GAR)</b>	Configures parameters related to serial port and telnet connection
Layer 2 ACL configuration mode	ZXR10 (config-link-acl) #	Global configuration mode	<b>acl link</b>	Defines layer 2 ACL rule

Mode	Prompt	Admission Mode	Entry Command	Functions
Hybrid ACL configuration mode	ZXR10 (config-hybd-acl) #	Global configuration mode	<b>acl hybrid</b>	Defines hybrid ACL rule
Router standard ACL mode	ZXR10 (config-std-nacl) #	Global configuration mode	<b>ip access-list</b>	Defines router standard ACL rule
Router extended ACL mode	ZXR10 (config-ext-nacl) #	Global configuration mode	<b>ip access-list</b>	Defines router extended ACL rule
Route configuration mode	ZXR10 (config-router) #	Global configuration mode	<b>router rip</b>	Configures RIP parameters
			<b>router ospf</b>	Configures OSPF parameters
			<b>router isis</b>	Configures IS-IS parameters
			<b>router bgp</b>	Configures BGP parameters
			<b>router pimsm</b>	Configures PIM-SM parameters
			<b>ipv6 router rip</b>	Configures RIPng parameters.
			<b>ipv6 router ospf</b>	Configures OSPFv3 parameters
VRF configuration mode	ZXR10 (config-vrf) #	Global configuration mode	<b>ip vrf</b>	Configures VRF parameters
VFI configuration mode	ZXR10 (config-vfi) #	Global configuration mode	<b>vfi</b>	Configures VPLS related parameters

Mode	Prompt	Admission Mode	Entry Command	Functions
IPv4 address family configuration mode	ZXR10 (config-router-af) #	Route configuration mode (RIP)	<b>address-family ipv4 vrf</b>	Configures RIP VRF parameters
		Route configuration mode (BGP)	<b>address-family vpnv4</b> <b>address-family ipv4 vrf</b>	Configures BGP VPN and VRF parameters
IPv6 unicast address family configuration mode	ZXR10 (config-router-af) #	Route configuration mode (BGP4+)	<b>address-family ipv6</b>	Configures BGP4+ unicast address family
		Route configuration mode (IS-ISv6)	<b>address-family ipv6</b>	Configures IS-ISv6 address family
Route map configuration mode	ZXR10 (config-route-map) #	Global configuration mode	<b>route-map</b>	Configures route map matching item and operation
Channelization configuration mode	ZXR10 (config-control) #	Global configuration mode	<b>control</b>	Configures channelization for ce1, ce3 and cpos3
Dial peer configuration mode	ZXR10 (config-voip100) #	Global configuration mode	<b>dial-peer voice</b>	Configures business related to integrated service
Voice port configuration mode	ZXR10 (config-voice-port) #	Global configuration mode	<b>voice-port</b>	Configures voice service
IPSec configuration mode	ZXR10 (config-ipsec) #	Global configuration mode	<b>ipsec</b>	Configures IPv6 IPSec protection
Diagnosis mode	ZXR10 (diag) #	Privileged mode	<b>diagnose</b>	Tests CPU and memory usage



## Chapter 2

# Basic System Management

---

### Table of Contents

auto-download config.....	8
banner incoming .....	8
boot config-file.....	9
clock set .....	9
clock timezone .....	10
configure terminal .....	10
disable .....	11
enable .....	11
enable secret .....	12
end .....	13
exit .....	13
flah-protect power-off .....	14
hostname .....	14
help message.....	15
more .....	15
multi-user configure .....	16
nvrn boot-password .....	17
nvrn boot-server.....	17
nvrn boot-username.....	18
nvrn default-gateway .....	18
nvrn imgfile-location.....	19
nvrn mng-ip-address .....	20
privilege.....	20
reload .....	21
service password-encryption .....	21
show auto-download-config .....	22
show clock.....	22
show diagnostic information.....	22
show privilege.....	27
show running-config .....	27
show start running-config .....	28
show system-group .....	29
show username.....	29
show users .....	29
show user-group .....	30
show version .....	30
show version hardware.....	30
show version mec.....	31
show version midplane.....	32
show version npc.....	32
show version software.....	32
show version sfc.....	33
show version upc.....	33

username .....	34
user-group .....	34
who .....	35

## auto-download config

<b>Purpose</b>	Use this command to enable downloading the configuration file automatically.
<b>Command Modes</b>	Global Configuration
<b>Syntax</b>	<b>auto-download config</b> <b>no auto-download config</b>
<b>Instructions</b>	This command is to enable downloading configuration file automatically. If the configuration files(startup and config) already exist, delete them and reboot the rack to download them automatically. When this function is disabled, if the downloading is in the process, then it informs the TFTP module about shutting the downloading.
<b>Defaults</b>	It is enabled by default and the configuration is writing into NVRAM. It supports 52a.
<b>Example</b>	This example describes how to enable downloading the configuration file automatically.  ZXR10(config)#auto-download config
<b>Related Commands</b>	<b>boot config-file</b> <b>show auto-download-config</b>

## banner incoming

<b>Function</b>	Use this command to set the greeting for the system startup.				
<b>Command mode</b>	Global configuration				
<b>Format</b>	<b>banner incoming</b> <end-char> <TEXT> <end-char>				
<b>Syntax Description</b>	<table border="1"> <tr> <td>&lt;end-char&gt;</td><td>End character, with one character</td></tr> <tr> <td>&lt;TEXT&gt;</td><td>Greeting: text including spaces and ENTER. It does not exceed 253 characters at most and end with&lt;end-char&gt;</td></tr> </table>	<end-char>	End character, with one character	<TEXT>	Greeting: text including spaces and ENTER. It does not exceed 253 characters at most and end with<end-char>
<end-char>	End character, with one character				
<TEXT>	Greeting: text including spaces and ENTER. It does not exceed 253 characters at most and end with<end-char>				
<b>Default</b>	Default welcome prompt.				
<b>Instructions</b>	<ol style="list-style-type: none"> <li>Set the user-defined &lt;end-char&gt;, with only one character: <b>banner incoming #</b>. After you press ENTER, the system prompts the following information:  Enter TEXT message. End with the character ' #' .</li> </ol>				

2. Enter the formal greeting text, which may include special characters (except?) such as space and ENTER. It ends with '#'.

**Note:**

The special character? is regarded as the help prompt by default. As a result, all the command parameters (text-type) or the password cannot include?.

**Example** This example describes how to set the greeting to welcome.

```
ZXR10(config)#banner incoming #  
Enter TEXT message. End with the character '#' .  
welcome  
#
```

## boot config-file

<b>Purpose</b>	Use this command to set the path for config file.			
<b>Command Modes</b>	Global Configuration			
<b>Syntax</b>	<b>boot config-file</b> <filename>			
<b>Syntax Description</b>	<table border="1"><tr><td>&lt;filename&gt;</td><td>Sets the path for config file.</td></tr></table>		<filename>	Sets the path for config file.
<filename>	Sets the path for config file.			
<b>Instructions</b>	This command is to specify the path for config file. The configuration is writing into NVRAM. It only supports 52a currently.			
<b>Defaults</b>	It is enabled by default and the configuration is writing into NVRAM. It supports 52a.			
<b>Example</b>	This example describes how to set the path for configuration file to cfg/config.dat <pre>ZXR10(config)#boot config-file cfg/config.dat ZXR10(config)#</pre>			
<b>Related Commands</b>	<b>auto-download config</b> <b>show auto-download-config</b>			

## clock set

<b>Purpose</b>	Use this command to configure the system clock in standard time format.
<b>Command Modes</b>	Privileged EXEC
<b>Syntax</b>	<b>clock set</b> <current-time> <month> <day> <year>

**Syntax Description**

<i>&lt;current-time&gt;</i>	The current time in the format: hh:mm:ss.
<i>&lt;month&gt;</i>	Month, jan~dec
<i>&lt;day&gt;</i>	Date, 1~31
<i>&lt;year&gt;</i>	Year, 2001~2098

**Example** This example describes how to set the system time to 12 minutes 1 second past 23 o'clock on Feb. 23, 2001 with the following command.

```
ZXR10#clock set 23:12:01 feb 23 2001
```

**Related Commands**

**show clock**

## clock timezone

**Purpose** Use this command to configure time zone information.

**Command Modes** Privileged EXEC

**Syntax** **clock timezone** *<name-of-time-zone>* *<hours-offset>* [*<minutes-offset>*]

**Syntax Description**

<i>&lt;name-of-time-zone&gt;</i>	Name of time zone
<i>&lt;hours-offset&gt;</i>	Hours offset from UTC
<i>&lt;minutes-offset&gt;</i>	Minutes offset from UTC

**Instructions** The parameter *<minutes-offset>* is added in versions 4.8.21 and above.

**Example** This example describes how to configure time zone as Beijing and the *<hours-offset>* as 8.

```
ZXR10#clock timezone Beijing 8 0
```

**Related Commands**

**show clock**

## configure terminal

**Purpose** Use this command to change from the privileged EXEC to the global configuration mode.

**Command Modes** Privileged EXEC

**Syntax** **configure terminal**

**Example** This example describes how to change from the privileged EXEC to the global configuration mode.

```
ZXR10#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
ZXR10(config)#
```

**Related  
Commands**

**end**  
**exit**

## disable

<b>Function</b>	Use this command to return from the privileged mode to exec mode. Lower the current authority level.		
<b>Command Mode</b>	EXEC, Privileged EXEC		
<b>Syntax</b>	<b>disable</b> <b>disable</b> [<level>]		
<b>Syntax Description</b>	<table border="1"><tr><td>&lt;level&gt;</td><td>Authority level, 0~15, the default value is 1.</td></tr></table>	<level>	Authority level, 0~15, the default value is 1.
<level>	Authority level, 0~15, the default value is 1.		
<b>Instruction</b>	<b>disable</b> [<level>] is only applicable to ZXR10 T64E/T128 T600/T1200.		
<b>Example</b>	This example describes how to return from the privileged mode to EXEC mode and lower the authority level to 1.  ZXR10#disable 1 ZXR10> ZXR10>show privilege Current privilege level is 1 ZXR10>		
<b>Related Commands</b>	<b>enable</b> <b>show privilege</b>		

## enable

<b>Function</b>	Use this command to enter from the EXEC to privilege EXEC mode. Heighten the current authority level.				
<b>Command Mode</b>	EXEC, Privilege EXEC				
<b>Format</b>	<b>enable</b> <b>enable</b> [<level>]				
<b>Parameter Description</b>	<table border="1"><tr><th>Parameter</th><th>Description</th></tr><tr><td>&lt;level&gt;</td><td>Authority level, the default value is 15.</td></tr></table>	Parameter	Description	<level>	Authority level, the default value is 15.
Parameter	Description				
<level>	Authority level, the default value is 15.				
<b>Instructions</b>	<ul style="list-style-type: none"><li>■ Password is required when entering into each authority level. If the passwords have not been configured, then entering into the authority level is not permitted.</li></ul>				

- The command **enable** *<level>* is only applicable to ZXR10 T64E/T128, T600/T1200.

**Note:**

This password is not displayed on the screen while it is entered, and is case sensitive.

**Example** This example describes how to heighten authority level to 2; enter from the EXEC to privilege EXEC mode.

```
ZXR10>enable 2
Password:
ZXR10#
ZXR10#show privilege
Current privilege level is 2
ZXR10#
```

**Related Commands**

**disable**  
**show privilege**

## enable secret

**Function** Use this command to set the password for each mode. Use the **no** command to cancel this set.

**Command Mode** Global configuration

**Syntax** **enable secret** { **0** *<password>* | **5** *<password>* | *<password>* }  
**enable secret** [**level** *<level-number>*] { **0** *<password>* | **5** *<password>* | *<password>* }  
**no enable secret level** *<1~14>*

**Syntax Description**

<b>level</b> <i>&lt; level-number &gt;</i>	Designates authority level, the default value is 15
<b>0</b> <i>&lt;password&gt;</i>	Sets the privileged password with 3–16 characters to enter the privileged mode
<b>5</b> <i>&lt;password&gt;</i>	Sets encrypted privileged password with 3–24 characters
<i>&lt;password&gt;</i>	Sets privileged password with 3–16 characters by default

- Instructions**
- The enable password displayed in show running-config is the encrypted privileged password, while the password that is used for enable to enter the privileged mode is unencrypted privileged password.
  - The command **enable secret** [**level** *<1~15>*] { **0** *<password>* | **5** *<password>* | *<password>* } is only applicable to ZXR10 T64E/T128.

**Note:**

Both commands **enable secret 0** *<password>* and **enable secret** *<password>* are used to enter an unencrypted password. Set the password with the **enable secret 5** *<password>* command. The configured password is not an encrypted privileged password unless the length of *<password>* is 24.

**Example** This example describes how to set the privilege password to ZXR10.

```
ZXR10(config)#enable secret ZXR10
```

**Related Command** **enable**

## end

**Purpose** Use this command to return to the privileged EXEC mode.

**Command Modes** The command is available for all modes other than the EXEC and privileged EXEC mode.

**Syntax** **end**

**Example** This example describes how to return from the global configuration mode to the privileged EXEC mode.

```
ZXR10(config)#end  
ZXR10#
```

**Related Commands**

- configure terminal**
- interface**
- router bgp**
- router ospf**
- router rip**

## exit

**Purpose** Use this command to quit the login router or return to the last mode.

**Command Modes** All modes

**Syntax** **exit**

**Instructions** When it is executed under the EXEC mode or privileged EXEC mode, it means exiting the login router. While in other modes, it means returning to the last mode.

**Example** This example describes how to exit from the global configuration mode to the privileged EXEC mode.

```
ZXR10(config)#exit  
ZXR10#
```

**Related Commands**

**configure terminal**  
**login**  
**logout**

## flash-protect power-off

- Purpose** Use this command to confirm the power-off.
- Command Modes** Privileged EXEC
- Syntax** **flash-protect power-off [ force ]**
- Syntax Description**
- |              |                                |
|--------------|--------------------------------|
| <b>force</b> | Forces the power-off manually. |
|--------------|--------------------------------|
- Instructions** The platform version 4.8.22 supports this command. The command with the parameter **force** means forcing power-off manually and being related to flash-protect. If the command is with the parameter **force**, regardless of whether the Flash is in usage or not, unload the Flash device and power-off manually. Or, if the Flash is in usage, it can not power-off manually.
- Example**
- This example describes how to set force power-off manually.

```

ZXR10# flash-protect power-off force
Are you sure to power off the machine?
If you execute the command successfully,
any other operation is invalid except power-off.
[yes/no]:y
.. OK!You can power off the machine later.
ZXR10#

```
  - This example describes how to set power-off manually.

```

ZXR10# flash-protect power-off
Are you sure to power off the machine?
If you execute the command successfully,
any other operation is invalid except power-off.
[yes/no]:y
.. OK!You can power off the machine later.
ZXR10#

```

## hostname

- Purpose** Use this command to set the network name of the system. cancel the network name with the **no** command.
- Command Modes** Global configuration
- Syntax** **hostname <network-name>**  
**no hostname**
- Syntax Description**
- |                             |                                    |
|-----------------------------|------------------------------------|
| <b>&lt;network-name&gt;</b> | Network name, with 1~32 characters |
|-----------------------------|------------------------------------|
- Defaults** By default, the default system network name is ZXR10.



**Instructions** The modified hostname takes effect immediately.

**Example** This example describes how to set the network name of the router to ZXR10\_router.

```
ZXR10(config)#hostname ZXR10_router
ZXR10_router(config)#
```

## help message

**Function** Use this command to set whether to display all command comments.

**Command Mode** Global configuration mode

**Format** **help message** [**full** | **partial**]

**Syntax Description**

<b>Full</b>	Display all comments
<b>Partial</b>	Omit some comments

**Instruction** By default, the comments are displayed in partial mode.

**Example** This example describes how to set help message to full.

```
ZXR10(config)#help message full
```

## more

**Purpose** Use this command to display the flash ascii text such as log, dead halt.

**Command Modes** Privileged EXEC

**Syntax** **more** <word>[**ascii** | **binary** [**width**]]

**Syntax Description**

<word>	The path for this file
<ascii >	The display mode of the text
<binary >	The binary display mode
<width>	The byte width of the unit

**Instructions** The platform version 4.8.22 supports this command. The command with the parameter **force** means forcing power-off manually and being related to flash-protect. If the command is with the parameter **force**, regardless of whether the Flash is in usage or not, unload the Flash device and power-off manually. Or, if the Flash is in usage, it can not power-off manually.

**Example** ■ This example describes how to set force power-off manually.

```
ZXR10# flash-protect power-off force
Are you sure to power off the machine?
```

```
If you execute the command successfully,
any other operation is invalid except power-off.
[yes/no]:y
.. OK!You can power off the machine later.
ZXR10#
```

- This example describes how to set power-off manually.

```
ZXR10# flash-protect power-off
Are you sure to power off the machine?
If you execute the command successfully,
any other operation is invalid except power-off.
[yes/no]:y
.. OK!You can power off the machine later.
ZXR10#
```

## multi-user configure

<b>Function</b>	Use this command to permit multiple users to enter the configuration mode. Configure the single user configuration mode with the <b>no</b> command.
<b>Command Mode</b>	Global configuration
<b>Format</b>	<b>multi-user configure</b> <b>no multi-user configure</b>
<b>Instructions</b>	By default, only a user can enter the global configuration mode. Use this command to permit other users enter into the global configuration mode. The no command is used to configure the single user to enter into configuration mode. Make sure that other users have exited configuration mode, then use no command.



### Note:

When multiple users are configuring, their configurations should not conflict.

- Example**
- This example describes how to enter the configuration mode and allow multiple user configurations when there is no user in the configuration mode.

```
ZXR10#configure terminal
ZXR10(config)#multi-user configure
%Warning: allow others configure, must avoid conflict.
ZXR10(config)#
```

- This example describes how to enter the single user configuration mode when there is one user in the configuration mode.

```
ZXR10#configure terminal
%Simultaneous configs not allowed. Locked from 168.1.168.168
ZXR10#
```

- This example describes how to do when other users have not exited the configuration mode.

```
ZXR10(config)#no multi-user conf
%Someone has entered the configure mode,
cannot set single-user configure!
ZXR10(config)#
```

**Related Command**    **configure terminal**

# nvram boot-password

<b>Function</b>	Use this command to start the FTP download setting for the mapping file and specify the password of the FTP server for download.			
<b>Command Mode</b>	Global configuration			
<b>Format</b>	<b>nvram boot-password</b> <i>&lt;password&gt;</i>			
<b>Syntax Description</b>	<table border="1"><tr><td><i>&lt;password&gt;</i></td><td>FTP password, with 3~16 characters</td></tr></table>		<i>&lt;password&gt;</i>	FTP password, with 3~16 characters
<i>&lt;password&gt;</i>	FTP password, with 3~16 characters			
<b>Instructions</b>	<ul style="list-style-type: none"><li>Valid characters are as follows: 0123456789abcdefghijklmnopqrstuvwxyz_ABCDEFGHIJKLMNOPQRSTUVWXYZ`*-~!@#\$%^&amp;()_+[]{} ;':./&lt;&gt;\\</li><li>This command works with such commands as <b>nvram boot-server</b>, <b>nvram boot-username</b>, <b>nvram imgfile-location</b> and <b>nvram default-gateway</b>.</li></ul>			
<b>Example</b>	This example describes how to Set the login password for the mapping file download FTP to pass.  ZXR10(config)#nvram boot-password pass			
<b>Related Commands</b>	<b>nvram boot-server</b> <b>nvram boot-username</b> <b>nvram default-gateway</b> <b>nvram imgfile-location</b>			

# nvram boot-server

<b>Function</b>	Use this command to enable the FTP download settings for mapping files and specify the IP address of the FTP server for download.			
<b>Command Mode</b>	Global configuration			
<b>Syntax</b>	<b>nvram boot-server</b> <ip-address>			
<b>Syntax Description</b>	<table border="1"><tr><td>&lt;ip-address&gt;</td><td>IP address in the dotted decimal notation</td></tr></table>		<ip-address>	IP address in the dotted decimal notation
<ip-address>	IP address in the dotted decimal notation			
<b>Instruction</b>	This command works with these commands: nvram boot-password, nvram boot-username, nvram imgfile-location and nvram default-gateway.			
<b>Example</b>	This example describes how to set the IP address for the mapping download FTP to 168.1.1.1.  ZXR10(config)#nvram bootserver 168.1.1.1			
<b>Related Commands</b>	<b>nvram boot-password</b> <b>nvram boot-username</b> <b>nvram default-gateway</b> <b>nvram imgfile-location</b>			

## nvramp boot-username

Function	Use this command to enable the FTP download setting for mapping files and specify the username of the FTP server for download.			
Command Mode	Global configuration			
Syntax	<b>nvramp boot-username</b> <username>			
Syntax Description	<table><tr><td>&lt;username&gt;</td><td>Login user name, with 1~16 characters</td></tr></table>		<username>	Login user name, with 1~16 characters
<username>	Login user name, with 1~16 characters			
Instructions	<ul style="list-style-type: none"><li>The valid characters include the letters, numerals and underline, case insensitive for the letters.</li><li>This command works with these commands: <b>nvramp boot-password</b>, <b>nvramp boot-server</b>, <b>nvramp imgfile-location</b> and <b>nvramp default-gateway</b>.</li></ul>			
Example	This example describes how to set the user name for the mapping file download FTP to ZXR10.  ZXR10(config)#nvramp boot-username ZXR10			
Related Command	<b>nvramp boot-password.</b> <b>nvramp boot-server</b> <b>nvramp default-gateway</b> <b>nvramp imgfile-location</b>			

## nvramp default-gateway

<b>Function</b>	Use this command to set the IP address of the default gateway.		
<b>Command Mode</b>	Global configuration		
<b>Syntax</b>	<b>nvramp default-gateway</b> <i>&lt;ip-address&gt;</i>		
<b>Syntax Description</b>	<table><tr><td><i>&lt;ip-address&gt;</i></td><td>IP address of the gateway in the dotted decimal notation</td></tr></table>	<i>&lt;ip-address&gt;</i>	IP address of the gateway in the dotted decimal notation
<i>&lt;ip-address&gt;</i>	IP address of the gateway in the dotted decimal notation		
<b>Instruction</b>	This command works with these commands: <b>nvramp boot-password</b> , <b>nvramp boot-server</b> , <b>nvramp imgfile-location</b> and <b>nvramp boot-username</b> .		
<b>Example</b>	This example describes how to set the default gateway as 168.1.1.1.  ZXR10(config)#nvramp default-gateway 168.1.1.1		
<b>Related Commands</b>	<b>nvramp boot-password</b> <b>nvramp boot-server</b> <b>nvramp boot-username</b> <b>nvramp imgfile-location</b>		

# nvrn imgfile-location

**Purpose** Use this command to set the location for booting the mapping file.

**Command Modes** Global configuration

**Syntax** **set ethernet-oam link-monitor frame-seconds threshold**  
**<xxx> window <yyy>**  
**nvrn imgfile-location {local {flash | sd}<filename>}| netw**  
**ork <filename>}**

## Syntax Description

<b>local</b>	The mapping file is located locally.
<b>flash</b>	If the version reboots from local, the storage device type is flash.
<b>sd</b>	If the version reboots from local, the storage device type is sd card.
<b>network</b>	The mapping file is located in the network.
<b>&lt;filename&gt;</b>	File name, with 1~80 characters.

## Instructions

- The valid characters for the filename are as follows.  
0123456789abcdefghijklmnopqrstuvwxyz\_ABCDEFGHI-  
JKLMNOPQRSTUVWXYZ/.,-+=\$#~@% () !&[]{}  
If it is specified as network boot, the filename can include the path of the specified FTP directory. For example, the specified FTP directory is sysm and now it is in the nets directory under sysm of the FTP server, and the file name can also include the path under the sysm/nets directory. Note that the path sysm/nets cannot be included repeatedly.
- This command works with these commands: **nvrn boot-p**  
**assword, nvrn boot-server, nvrn boot-username** and  
**nvrn default-gateway.**
- The platform version 4.8.22 supports rebooting from SD card when the version starts from local.

## Example

- This example describes how to reset the card in slot 3.

```
ZXR10#reload slot 3
Proceed with reload? [yes/no]:y
ZXR10#
```

- This example describes how to reset the right sfc.

```
ZXR10#reload sfc 2
Proceed with reload? [yes/no]:y
ZXR10#
```

- This example describes how to reset the slave MP.

```
ZXR10#reload mp slave
Proceed with reload? [yes/no]:y
ZXR10#
```

# nvram mng-ip-address

**Function** Set the IP address of the router MNG (management interface).  
**Command Mode** Global configuration

**Syntax** **nvram mng-ip-address** *<ip-address>* *<net-mask>*  
**Syntax Description**

<i>&lt;ip-address&gt;</i>	IP address of the MNG in the dotted decimal notation
<i>&lt;net-mask&gt;</i>	Subnet mask in the dotted decimal notation

**Instruction** This address can be used to log in to the router from an internal network port.



## Note:

The configured interface address and this address cannot be in the same network segment.

**Example** This example describes how to set the MNG IP address to 168.1.1.1 and the subnet mask to 255.255.0.0.

```
ZXR10(config)#nvram mng-ip-address 168.1.1.1 255.255.0.0
```

# privilege

**Function** Use this command to set command authority level. Use no command to recover default authority level.  
**Command Mode** Global configuration

**Syntax** **privilege** *<logic-mode>* [**all**] **level** *<0~15>* *<command-keywords>* **no privilege** *<logic-mode>* [**all**] **reset** *<command-keywords>*  
**Syntax Description**

<i>&lt;logic-mode&gt;</i>	Logic mode type
<b>all</b>	Supports all the commands that this command key word appears head
<b>level</b> <i>&lt;0~15&gt;</i>	Authority level
<i>&lt;command-keywords&gt;</i>	Command keywords

**Example** This example describes how to set all write appears ahead in privilege exec command authority level to 7.

```
ZXR10(config)#privilege exec all level 7 write
```

**Related Command** **show privilege**

# reload

- Purpose** Use this command to reboot the system or reset the board in a specific slot.
- Command Modes** Privileged EXEC
- Syntax** **reload** [**slot** <slot-number>| **sfc** <slot-number >| **mp slave**]  
**reload** [**mp slave**][**force**]

**Syntax Description**

<slot-number>	Slot number, in the range of 1~8.
<b>sfc</b> <slot-number>	Flag of sfc (1: left sfc; 2 right sfc).
<b>mp slave</b>	Restarts the slave board.
<b>force</b>	Restarts the device or slave board by force.

- Instructions**
- The platform version 4.6.02 and upgrade versions support this command.
  - The command without parameter is used to reboot the whole system.
  - The command with parameter slot is used to reset the board in a specific slot.
  - The command with parameter sfc is used to reset a specific sfc board.
- Example**
- This example describes how to reset the card in slot 3.  

```
ZXR10#reload slot 3  
Proceed with reload? [yes/no]:y  
ZXR10#
```
  - This example describes how to reset the right sfc.  

```
ZXR10#reload sfc 2  
Proceed with reload? [yes/no]:y  
ZXR10#
```
  - This example describes how to reset the slave MP.  

```
ZXR10#reload mp slave  
Proceed with reload? [yes/no]:y  
ZXR10#
```

# service password-encryption

- Function** Use this command to set user password encryption display function.
- Command Mode** Global configuration mode
- Format** **service password-encryption**  
**no service password-encryption**
- Instruction** All user password display in encryption after this command is configured.

**Related command**    **username**

## show auto-download-config

<b>Purpose</b>	Use this command to display the related configuration when starting auto-download-configuration.
<b>Command Modes</b>	Privileged EXEC
<b>Syntax</b>	<b>show auto-download-config</b>
<b>Instructions</b>	This command supports 52a.
<b>Example</b>	<ul style="list-style-type: none"> <li>This example describes how to reset the card in slot 3.</li> </ul> <pre> ZXR10# show auto-download-config Config file           : flash:/config.text auto download config  : yes </pre>
<b>Related Commands</b>	<b>boot config-file</b> <b>auto-download config</b>

## show clock

<b>Purpose</b>	Use this command to display the system clock.
<b>Command Modes</b>	All modes
<b>Syntax</b>	<b>show clock</b>
<b>Instructions</b>	When the time zone is configured with this command, the local time will be displayed.
<b>Related Commands</b>	<b>clock set</b>

## show diagnostic information

<b>Purpose</b>	Use this command to display all the system information, when there is fault in the system or in a functional module. It is used to analyze the fault cause. This command contains <b>show version</b> , <b>show processor</b> , <b>show privilege</b> , <b>show running-config</b> , <b>show logfile</b> and other information.
<b>Command Modes</b>	Privileged EXEC
<b>Syntax</b>	<b>show diagnostic information</b> [{ <b>detail</b> [{ <b>module</b> <module-name> [{ <b>begin</b>   <b>exclude</b>   <b>include</b> }] [{ <b>begin</b>   <b>exclude</b>   <b>include</b> }] }]}] [{ <b>module</b> <module-name> [{ <b>begin</b>   <b>exclude</b>   <b>include</b> }] }]}] [ <b>save</b> ]



**Syntax  
Description**

<b>detail</b>	Displays detailed information of system.
<b>module</b> <module-name>	Displays information of a specified module.
<b>begin</b>	Displays the configuration information starting with the line including the specified character or character string.
<b>exclude</b>	Displays the configuration information exclusive of the line including the specified character or character string.
<b>include</b>	Displays the configuration information inclusive of the line including the specified character or character string.
<b>save</b>	Saves the current system information to flash.

**Defaults** By default, brief system information is displayed in pagination, but not saved.

- Instructions**
- The platform version 4.8.21 and upgrade versions support this command.
  - Display the system information in command mode.
  - Execute this command only on single terminal, otherwise an error occurs.
  - Cannot perform this operation when saving the configuration using Write command, otherwise an error occurs.
  - The **terminal length 0** command needs to be used in privileged mode when contents needs to be displayed in one page.

**Example** This example describes how to use **show diagnostic information**.

```
ZXR10#show diagnostic information
ZXR10 T128 Software, Version V2.08.21, RELEASE SOFTWARE
Copyright (c) 2000-2007 by ZTE Corporation
Compiled Feb 20 2008, 09:38:17
ZXR10 Router Operating System Software,ZTE Corporation
ZXR10 ROS Version V4.08.21
System image files from net
<ftp://192.168.3.111/zxr10.zar>
System uptime is 0 days, 0 hours, 5 minutes

[RPU, Panel 2, master]
Main processor: X86-2 with 512M bytes of memory
ROM: System Bootstrap, Version: Copyright 1984-1996 Wi,
RELEASE SOFTWARE

[MPU2, Panel 2, master]
Main processor: X86-2 with 512M bytes of memory
8K bytes of non-volatile configuration memory
64M bytes of processor board System flash (Read/Write)
ROM: System Bootstrap, Version: Copyright 1984-1996 Wi,
RELEASE SOFTWARE
System serial: 6

[SFC2, Panel 1, master]
Main processor: Power pc-2 with 32M bytes of memory
ROM: System Bootstrap, Version: ZXR10 BOOT V2.6.02-003,
RELEASE SOFTWARE

[SFC, Panel 2, slave]
```

Main processor: Power pc-1 with 64M bytes of memory  
ROM: System Bootstrap, Version: , RELEASE SOFTWARE

[NPCT, Panel 5]  
Main processor: XSCALE with 512M bytes of memory in slot 5  
System with multiple processors (2 Network processors)  
Every network processor with 512M bytes of memory  
ROM(4M): System Bootstrap, Version:ZXR10 T128 BOOT 2.6.02,  
RELEASE SOFTWARE  
FPGA Version(Switch) : V42  
CPLD Version(Np) : V65

CPLD Version(Interface) : V18

[NPCT, Panel 7]  
Main processor: XSCALE with 512M bytes of memory in slot 7  
System with multiple processors (2 Network processors)  
Every network processor with 512M bytes of memory  
ROM(4M): System Bootstrap, Version:ZXR10 T128 BOOT 2.6.02,  
RELEASE SOFTWARE  
FPGA Version(Switch) : V42  
CPLD Version(Np) : V23  
CPLD Version(Interface) : V17  
M: Master processor  
S: Slave processor  
PhyMem: Physical memory (megabyte)

	Panel	CPU(5s)	CPU(1m)	CPU(5m)	PhyMem	Buffer	Memory
SP(M)	1	5%	5%	4%	32	1%	40.637%
RP(M)	2	7%	7%	7%	511	0%	48.950%
MP(M)	2	4%	5%	17%	511	0%	40.383%
SP(S)	2	9%	9%	7%	64	1%	23.153%
NP(M)	5	16%	20%	57%	382	0%	39.983%
NP(M)	7	19%	22%	56%	382	0%	39.981%

Current privilege level is 15

Building configuration...

!\*\*\*\*\*Before interface -- show run on RP start!\*\*\*\*\*

!

!

urpf log off

!

eoam disable

no eoam authentication-key

!

!

protect

protect cpu-protect disable

protect slot 1 token 400

protect slot 2 token 400

protect slot 3 token 400

!

!

interface null1

out\_index 1

!

interface fei\_5/1

physical-layer mode npct

out\_index 3

negotiation auto

protect interface token 25

!

interface gei\_7/1

physical-layer mode npct

out\_index 19

negotiation auto

protect interface token 100

!

!\*\*\*\*\*After interface -- show run on RP start!\*\*\*\*\*

!

ip nat stop

ip nat translation timeout class a 20

ip nat translation timeout class b 60

ip nat translation timeout class c 150

```
ip nat translation timeout class d 300
ip nat translation timeout class e 1200
ip nat translation timeout protocol icmp a
ip nat translation timeout protocol ip d
ip nat translation timeout protocol tcp d
ip nat translation timeout protocol tcp port 80 a
ip nat translation timeout protocol udp c
ip nat translation timeout protocol udp port 4000 d
ip nat translation maximal default 65535
!
!
time-range disable
!
bfd-version 1
!
!
version V4.08.21
!
nvram mng-ip-address 192.168.3.12 255.255.0.0
!
nvram boot-username wby
!

nvram boot-password 123456
!
nvram boot-server 192.168.3.111
!
nvram default-gateway 192.168.3.111
!
nvram imgfile-location network zxr10.zar
!
hostname ZXR10
!
enable secret level 15 5 RcMLuUKvnFZX9kNAV6A/UA==
!
!
user-authentication-type local
user-authorization-type local
!
line console 0
    no login authentication
!
banner incoming @
*****
Welcome to ZXR10 Carrier-Class High-end Router of
*****

*****
ZTE Corporation
*****@
!
!
lfap disable
lfap max-send-fun-size 100
lfap update-interval 60
lfap server-retry-interval 60
lfap message-response-interval 60
lfap ka-interval 60
lfap flow-expired-time 600
!
!
!
snmp-server location No.68 Zijinghua Rd. Yuhuatai District,
Nanjing, China
snmp-server contact +86-25-52870000

snmp-server packetsize 1400
snmp-server engine-id 830900020300010289d64401
snmp-server view AllView internet included
snmp-server view DefaultView system included
!
!
!
protect
tcp synflood-protect disable
```

```

tcp synflood-protect defence 0 waittime 30 num 1
tcp synflood-protect max-connect high 90 low 60
tcp synflood-protect one-minute high 80 low 50
!
no ftp-server enable listen 21
ftp-server top-directory /flash/
!
logging on
logging buffer 200
logging mode fullcycle
logging console notifications
logging level notifications
logging cmdlog-interval 2880
logging timestamps datetime localtime
syslog-server facility local0
!
environ
  alarm cpuload on
  alarm temper on
  alarm fan on
  alarm power on
  check cpuload interval 3
  check temper interval 3
  check fan interval 3
  check power interval 3
  cpuload-threshold high-grade 95 middle-grade 85 low-grade 75
  temper-threshold BIC local lowthreshold -20
first-highthreshold 55 second-high
threshold 70
  temper-threshold UPC master local lowthreshold -20
first-highthreshold 55 seco
nd-highthreshold 70
!

line console idle-timeout 120
line console absolute-timeout 1440
line telnet idle-timeout 120
line telnet absolute-timeout 1440
!
ssh server authentication ispgroup 1
ssh server authentication mode local
ssh server authentication type chap
no ssh server only
ssh server version 2
!
!
radius auto-change off
!
!
tacacs disable
tacacs-server timeout 5
tacacs-server packet 1024
!
!
!
end
con0 19:59:24 01/29/2001 UTC show running-config
con0 19:59:24 01/29/2001 UTC show privilege
con0 19:59:24 01/29/2001 UTC show processor
con0 19:59:19 01/29/2001 UTC show version
con0 19:59:19 01/29/2001 UTC show diag inf
con0 19:58:43 01/29/2001 UTC dir cfg

con0 19:58:32 01/29/2001 UTC dir data
con0 19:58:30 01/29/2001 UTC end
con0 19:58:06 01/29/2001 UTC show run | begin tem
con0 19:57:39 01/29/2001 UTC show run | begin tem
con0 19:57:33 01/29/2001 UTC show temperature
con0 19:57:27 01/29/2001 UTC show temperature

con0 19:57:24 01/29/2001 UTC con t
con0 19:57:22 01/29/2001 UTC en
con0 19:56:12 01/29/2001 UTC

ZXR10#

```

**Related Commands** **show run**

## show privilege

**Purpose** Use this command to display the current terminal authority level and command authority configuration information.

**Command Modes** All modes

**Syntax** **show privilege** [{**cur-mode** | **show-mode**}{**detail** | **level** <level>} | **node** <command-keywords>}]

**Syntax Description**

<b>cur-mode</b>	Displays the current command mode authority information.
<b>show-mode</b>	Displays show command mode authority information.
<b>detail</b>	Displays all commands authority level.
<b>level</b> <level>	Displays specified authority level command.
<command-keywords>	Displays specific command authority level.

**Instructions** The command **show privilege** in EXEC mode is without parameters .

**Example** This example describes how to display all commands that authority level is 6 in privileged mode.

```
ZXR10#show privilege cur-mode level 6
```

**Related Commands** **privilege**

## show running-config

**Function** Use this command to display the current configuration information of the system or a specified interface.

**Command Mode** All modes except exec

**Format** **show running-config** [**interface** <interface-name>| **voice-port** <voice-port>]

**show running-config** [{**begin** | **exclude** | **include**}<line>]

**Syntax Description**

<b>interface</b> <interface-name>	Interface name
<b>voice-port</b> <voice-port>	Voice interface name, only supporting the GAR with the tone board

<b>begin</b>	Displays the configuration information starting with the line including the specified character or character string
<b>exclude</b>	Displays the configuration information exclusive of the line including the specified character or character string
<b>include</b>	Displays the configuration information inclusive of the line including the specified character or character string
<i>&lt;line&gt;</i>	Specifies a character or character string

- Instructions**
- This command displays the active system configuration.
  - For ZXR10 GAR with the tone board, this command can be used to specify the tone interface. The other model routers have no tone interface parameter since they do not support VOIP.

## show start running-config

- Function** Use this command to display the saved system configuration information.
- Command Mode** All modes except exec
- Syntax** **show start running-config** [{**begin** | **exclude** | **include**}<line>]

**Syntax Description**

<b>begin</b>	Displays the configuration information starting with the line including the specified character or character string
<b>exclude</b>	Displays the configuration information exclusive of the line including the specified character or character string
<b>include</b>	Displays the configuration information inclusive of the line including the specified character or character string
<i>&lt;line&gt;</i>	Specifies a character or character string

- Instructions**
- This command shows the saved system configuration information.
  - This command is used with the show running-config command to check whether all the saved contents take effect after system startup.

**Related Command** **show running-config**

# show system-group

<b>Function</b>	Use this command to display the system information.
<b>Command Mode</b>	All
<b>Syntax</b>	<b>show system-group</b>
<b>Example</b>	<p>This example describes how to display the system information of GAR.</p> <pre>ZXR10#show system-group System Description: ZXR10 Router Operating System Software ZTE Corporation ZXROS V4.6.01. ZXR10_GAR V2.6.01. Compiled: System ObjectId: .iso.org.dod.internet.private.enterprises.zte.3.100.6 Started before: 23374 Seconds Contact with: +86-25-52870000 System name: ZXR10 Location: No.68 Zijinghua Rd. Yuhuatai District, Nanjing, China This system primarily offers a set of 78 services ZXR10#</pre>

# show username

<b>Function</b>	Use this command to display the list of the usernames who are authorized for login, the passwords and authority level.
<b>Command Mode</b>	All modes except exec
<b>Syntax</b>	<b>show username</b>
<b>Example</b>	<p>This example describes how to display the list of the usernames, who are authorized for login, the passwords and authority level.</p> <pre>ZXR10#show username Username Password      Privilege user1  abcd                6 user2  cdef                15</pre>
<b>Related Command</b>	<b>username</b>

# show users

<b>Function</b>	Use this command to display the terminal user information.
<b>Command Mode</b>	All
<b>Syntax</b>	<b>show users</b>
<b>Example</b>	<p>This example describes how to display the terminal user information.</p> <pre>ZXR10#show users Line      User  Host(s) Idle      Location * 66 vty 0  who   idle    00:00:00  170.1.1.16 ZXR10#</pre> <p>The descriptions of the result fields are displayed below.</p>

Line	Number of the virtual terminal with the user login Login user name res
User	Login user name
Host	IP address of the login server when this router logs in to another telnet server as a client
Idle	Idle time
Location	Client address

## show user-group

<b>Function</b>	Use this command to display the configured user account information.						
<b>Command Mode</b>	All modes except exec						
<b>Syntax</b>	<b>show user-group</b> [ <b>default</b>   <b>special</b> <i>&lt;usergroup-name&gt;</i> ]						
<b>Syntax Description</b>	<table> <tr> <td><b>default</b></td><td>Specifies to configure the public account group</td></tr> <tr> <td><b>special</b></td><td>Specifies to configure the private account group</td></tr> <tr> <td><i>&lt;usergroup-name&gt;</i></td><td>Name of the private account group, with 1~16 characters</td></tr> </table>	<b>default</b>	Specifies to configure the public account group	<b>special</b>	Specifies to configure the private account group	<i>&lt;usergroup-name&gt;</i>	Name of the private account group, with 1~16 characters
<b>default</b>	Specifies to configure the public account group						
<b>special</b>	Specifies to configure the private account group						
<i>&lt;usergroup-name&gt;</i>	Name of the private account group, with 1~16 characters						
<b>Insturction</b>	It is only applicable to ZXR10 GAR, ZXR10 ZSR.						
<b>Related Commands</b>	<b>show username</b> <b>user-group</b> <b>username</b>						

## show version

<b>Function</b>	Use this command to display the software and hardware versions of the system.
<b>Command Mode</b>	All
<b>Syntax</b>	<b>show version</b>

## show version hardware

<b>Function</b>	Use this command to display the software version of the system.
<b>Command Mode</b>	All modes except exec



**Syntax** **show version hardware**

**Example** This example shows how to display the hardware version of the system.

```
ZXR10#show version hardware

[RPU, Panel 2, master]
Main processor: X86-2 with 512M bytes of memory
ROM: System Bootstrap, Version: Copyright 1984-1996 Wi, RELEASE SOFTWARE
[MPU2, Panel 2, master]
Main processor: X86-2 with 512M bytes of memory
8K bytes of non-volatile configuration memory
64M bytes of processor board System flash (Read/Write)
ROM: System Bootstrap, Version: Copyright 1984-1996 Wi, RELEASE SOFTWARE
System serial: 30000
[SFC2, Panel 2, master]
Main processor: Power pc-2 with 32M bytes of memory
ROM: System Bootstrap, Version: ZXR10 BOOT V2.6.02-003, RELEASE SOFTWARE
[NPCT, Panel 2]
Main processor: XSCALE with 512M bytes of memory in slot 2
System with multiple processors (2 Network processors)
Every network processor with 512M bytes of memory
ROM(4M): System Bootstrap, Version:ZXR10 BOOT 2.6.03-001, RELEASE SOFTWARE
FPGA Version(Switch) : V43
CPLD Version(Np) : V65
CPLD Version(Interface) : V18
[NPCT, Panel 6]
Main processor: XSCALE with 512M bytes of memory in slot 6
System with multiple processors (2 Network processors)
Every network processor with 512M bytes of memory
ROM(4M): System Bootstrap, Version:ZXR10 T128 BOOT 2.6.02, RELEASE SOFTWARE
FPGA Version(Switch) : V43
CPLD Version(Np) : V65
CPLD Version(Interface) : V16
```

## show version mec

**Purpose** Use this command to display hardware version information of MEC board. ZXR10 6900 series rack supports this command.

**Command Modes** Privileged EXEC

**Syntax** **show version mec** <1~2>

**Syntax Description**

1~2	The panel no of UPC board
-----	---------------------------

**Example** This example describes how to show mec version information.

```
ZXR10#show version mec 2
PanelNo 2 MEC (Master) version information:
PCB Version: 040100
FPGA Version: 0x41
CPLD Version: 0x00
Processor version information:
Boot Version: Copyright 1984-1996 Wi
DRAM memory size: 512M Bytes
Flash memory size: 64M Bytes
NVRAM memory size: 8K Bytes
```

**Related Commands** **boot config-file**  
**auto-download config**

## show version midplane

<b>Function</b>	Use this command to display the slot information.
<b>Command Mode</b>	All modes except exec
<b>Syntax</b>	<b>show version midplane</b>
<b>Example</b>	This example shows how to display the slot information.

```
ZXR10#show version midplane
Midplane information:
Midplane WID: 01
PCB Version : 050401
UPC Slot quantity: 2
SFC Slot quantity: 2
NPC Slot quantity: 16
LIC Slot quantity: 16
BIC Slot quantity: 1
```

## show version npc

<b>Function</b>	Use this command to display the hardware version of npc board
<b>Command Mode</b>	All modes except exec
<b>Syntax</b>	<b>show version npc &lt;1~16&gt;</b>
<b>Syntax Description</b>	The panel No. of npc board
<b>Example</b>	This example shows how to display the hardware version of npc board.

```
ZXR10#show version npc 2
PanelNo 2 NPCT main version information:
PCB Version: 040100
FPGA Version: 0x2b
CPLD Version: 0x41
Processor1 (Master NP) version information:
PCB Version: 040100
CPLD Version: 0x13
Boot Version: ZXR10 BOOT 2.6.03-001
SRAM memory size: 32M Bytes
DRAM memory size: 512M Bytes
Processor2 (Slave NP) version information:
PCB Version: 040100
CPLD Version: 0x13
Boot Version: ZXR10 BOOT 2.6.03-001
SRAM memory size: 32M Bytes
DRAM memory size: 512M Bytes
```

## show version software

<b>Function</b>	Use this command to display the software version of the system.
<b>Command Mode</b>	All modes except exec
<b>Syntax</b>	<b>show version software</b>

**Example** This example shows how to display the software version of the system.

```
ZXR10#show version software
ZXR10 T128 Software, Version V2.08.21.B.04, RELEASE SOFTWARE
Copyright (c) 2000-2007 by ZTE Corporation
Compiled Apr 10 2008, 10:04:31
ZXR10 Router Operating System Software, ZTE Corporation
ZXR10 ROS Version V4.08.21
System image files from net: ftp://192.168.3.201/zxr10.zar
```

## show version sfc

**Function** Use this command to display the hardware version of sfc board.

**Command Mode** Use this command to display the hardware version of sfc board.

**Syntax** **show version upc** <1~2>

**Syntax Description** The panel No. of sfc board

**Example** This example shows how to display the hardware version of sfc board.

```
ZXR10#show version sfc 2
PanelNo 2 SFC version information:
  PCB Version: 040100
  FPGA Version: 0x21
  CPLD Version: 0x00
  Boot Version: ZXR10 BOOT V2.6.02-003
  DRAM memory size: 32M Bytes
```

## show version upc

**Function** Use this command to display the hardware version of upc board.

**Command Mode** All modes except exec

**Syntax** **show version upc** <1~2>

**Syntax Description** The panel No. of upc board

**Example** This example shows how to display the hardware version of upc board.

```
ZXR10#show version upc 2
PanelNo 2 UPC (Master) version information:
  PCB Version: 040100
  FPGA Version: 0x41
  CPLD Version: 0x00
Processor1 (MPU) version information:
  Boot Version: Copyright 1984-1996 Wi
  DRAM memory size: 512M Bytes
  Flash memory size: 64M Bytes
  NVRAM memory size: 8K Bytes
Processor2 (RPU) version information:
  Boot Version : Copyright 1984-1996 Wi
  DRAM memory size: 512M Bytes
ESC version information:
  PCB Version: 050403
  Band Type: 1
```

## username

- Function** Use this command to configure the login user name and password. Cancel the user name with the no command.
- Command Mode** Global configuration mode
- Syntax** **username** <username> **password** <password>  
**username** <username> **password** {**encrypted** <encrypted-password>|<password>} [**privilege** <0~15>]

**Syntax Description**

<username>	User name, with 1~16 characters and space not allowed
<encrypted-password>	Encrypted password, with 64 characters and space not allowed
<password>	Password, with 3~32 characters and space not allowed
<b>privilege</b> <0~15>	Authority level that binds with this user ,the default value is 1

- Instructions**
- The valid characters for the parameter <username> are as follows,  
0123456789abcdefghijklmnopqrstuvwxyz\_  
The valid characters for the parameter <password>  
0123456789abcdefghijklmnopqrstuvwxyz\_ABCDEFGHI-JKLMNOPQRSTUVWXYZ`\*-~!@#\$%^&()\_+[[]{}|;':.,/<> \\  
**username** <username> **password** <password> [**privilege** <0~15>] is only applicable to ZXR10 T64E/T128.

- Example** This example describes how to set the login password for the user tom to pass and authority level is 6.

```
ZXR10(config)#username tom password pass privilege 6
```

- Related Command** **show username**

## user-group

- Function** Use this command to configure the user account information. Delete the user account with the no command.
- Command Mode** Global configuration
- Syntax** **user-group** {**default** | **special** <usergroup-name>} <username> <password>  
**no user-group** {**default** | **special** <usergroup-name>} [<username>]

**Syntax  
Description**

<b>default</b>	Specifies to configure the public account group
<b>special</b>	Specifies to configure the private account group
<i>&lt;usergroup-name&gt;</i>	Name of the private account group, with 1~16 characters
<i>&lt;username&gt;</i>	Account name, with 1~16 characters
<i>&lt;password&gt;</i>	Account password, with 3~16 characters

**Instructions**

- The public account group can also be configured with the **user name** command with the same effect.
- Here, account group name and account name is not case-sensitive, but password is case-sensitive.
- This command is only applicable to ZXR10 GARZXR10 ZSR.

**Example**

- This example describes how to configure a public account group,

```
ZXR10(config)#user-group default who who
```

- This example describes how to configure the user account of the private account group zxr10.

```
ZXR10(config)#user-group special zxr10 who who
```

**Related  
Commands**

**show user-group  
username**

# who

**Function  
Command Mode  
Syntax**

Use this command to display the list of the current login users.

Privileged

**who**

**Example**

This example describes how to display the list of the current login users.

```
ZXR10#who
Line      User Host(s)   Idle   Location
* 66 vty 0   who idle    00:00:00 168.1.200.57
67 vty 1    abc  idle    00:00:00 168.1.200.58
```

The descriptions of the result fields are displayed below.

Field	Description
Line	Number of the virtual terminal with the user login
User	Login user name

Field	Description
Host	IP address of the login server when this router logs in to another telnet server as a client
Idle	Idle time
Location	Client address

## Chapter 3

# File System Management

### Table of Contents

cd .....	37
check dev-using .....	38
copy .....	39
delete .....	39
dir .....	40
format .....	41
mkdir.....	41
pwd .....	42
rename .....	42
rmdir .....	43
show flash-check.....	43
unmount .....	44
update-imgfile .....	44
write.....	45
write flash .....	45
write imgfile .....	46
write nvram.....	47

## cd

<b>Function</b>	Use this command to enter a specific file device or the file directory of the current file device.			
<b>Command Mode</b>	Privileged configuration			
<b>Syntax</b>	<b>cd</b> <directory>			
<b>Syntax Description</b>	<table><tr><td>&lt;directory&gt;</td><td>Two types are available: file directory name or file device name, with 1~80 characters</td></tr></table>		<directory>	Two types are available: file directory name or file device name, with 1~80 characters
<directory>	Two types are available: file directory name or file device name, with 1~80 characters			
<b>Instructions</b>	<ul style="list-style-type: none"><li>Types of the device name fixed in the system include flash, usb1, usb2, sd and so on. Note that the file device name must be entered completely when enter into a specified file device.</li><li>To enter the upper-level directory, the "." and ".." directory declarators are supported.</li><li>The file systems of ZXR10 series data products vary with the model. ZXR10 GER file name should be not more than 32 characters. For the file system only supporting other data products in 8.3 format, its file name should be not more than eight characters.</li></ul>			

- Example** ■ This example describes how to enter the flash file device of the system.

```
ZXR10#cd flash:
```

- This example describes how to enter the bin directory of the current file device.

```
ZXR10#cd /bin
```

- This example describes how to enter the upper-level directory. Note that the space between "cd" and "." can not be omitted.

```
ZXR10#cd .
```

**Related  
Commands**

**dir**  
**mkdir**  
**pwd**  
**rmdir**

## check dev-using

- Function** Use this command to check the status of the specified storage device.

**Command Mode** Privileged configuration

**Syntax** **check dev-using {flash | usb1 | usb2 | cf | sd}**

**Syntax  
Description**

flash	Inbuilt Flash storage device
Usb	Peripheral storage device: usb 1
Usb	Peripheral storage device: usb 2
cf	Peripheral storage device: compact device
sd	Peripheral storage device: Secure Disk

**Instruction** Only support USB, CF and SD in racks of specific products

- Example** This example describes how to check the use status of inbuilt FLASH in current rack

```
ZXR10#check dev-using flash
```

**Related  
Commands**

**copy**  
**format**



# copy

**Function** Use this command to copy files from a specified directory of the source file system to a specified directory of the destination file system.

**Command Mode** Privileged configuration

**Syntax** **copy** <source-device> <source-file> <destination-device> <destination-file>

**Syntax Description**

<source-device>	Source device name
<source-file>	Source directory and file name, with 1~80 characters
<destination-device>	Destination device name
<destination-file>	Destination directory and file name, with 1~80 characters

- Instructions**
- The device name is of the fixed type in the system: flash:, tftp: and ftp. Add mng command when copying through network management interface.
  - Since high-end routers such as t12869 support peripheral storage device, flash and other peripheral storage cards such as sd, cf can be used as local storage device.
  - Since high-end routers such as t12869 support peripheral storage device, flash and other peripheral storage cards such as sd, cf can be used as local storage device.
  - The total length of the directory name and file name cannot exceed 80 characters. ZXR10 GER file name should be not more than 32 characters. For the file system only supporting other data products in 8.3 format, its file name should be not more than eight characters.

**Example** This example describes how to copy the sys.dat file under the img directory of the flash device into the root directory of the FTP server with IP address 168.1.1.1, user name test and password pass.

```
ZXR10#copy flash: img/sys.dat ftp: //168.1.1.1/sys.dat@test:pass
```

**Related Command** **delete**

# delete

**Function** Use this command to delete the files in a specified directory of the current file device.

**Command Mode** Privileged configuration

**Syntax** **delete** <filename>

**Syntax Description**

&lt;filename&gt;

Directory name and file name, with 1~80 characters

**Instruction**

- The total length of the directory name and file name cannot exceed 80 characters. The ZXR10 GER file name should be not more than 32 characters. For the file system only supporting other data products in 8.3 format, its file name should be not more than eight characters.
- The "." and ".." directory declarators are supported.

**Example**

This example describes how to delete the sys.dat file in the current directory.

```
ZXR10#delete sys.dat
```

**Related Commands**

**copy**  
**rename**

## dir

**Function**

Use this command to display the files in the root directory of a specified file device. Display the files in a specified directory or the current directory of the current file device.

**Command Mode**

Privileged configuration

**Syntax**

**dir** [<directory>]

**Syntax Description**

&lt;directory&gt;

Directory name or device name, with 1~80 characters

**Instructions**

If the device name is input, it should be of the fixed type in the system:cf, flash, usb1, usb2, sd.

The total length of the directory name and file name cannot exceed 80 characters. The ZXR10 GER file name should be not more than 32 characters. For the file system only supporting other data products in 8.3 format, its file name should be not more than eight characters.

**Example**

This example describes how to show the img directory exists in flash,

```
\ZXR10#cd flash:
ZXR10#cd img
ZXR10#dir
Directory of flash:/img/
  attribute size    date       time      name
1  -rwx  9135845   AUG-01-2002  14:26:02  gar.zar
32007616 bytes total (40509440 bytes free)
```

The displayed field descriptions are shown below.

Field	Description
Attribute	File attributes: d: directory, r: readable, w: writeable, x: executable

Field	Description
Size	File size
Date	File created date
Time	File created time
Name	File name

**Related Commands**

**cd**  
**mkdir**  
**pwd**  
**rmdir**

## format

**Function** Use this command to format the storage device.  
**Command Mode** Privileged configuration  
**Syntax** **format {flash | usb1 | usb2 | cf | sd}**

**Syntax Description**

<b>flash</b>	Inbuilt Flash storage device
<b>usb1</b>	Peripheral storage device: usb 1
<b>usb2</b>	Peripheral storage device: usb 2
<b>cf</b>	Peripheral storage device: compact device
<b>sd</b>	Peripheral storage device: Secure Disk

**Instruction** Only support USB, CF and SD in racks of specific products

**Example** This example describes how to format inbuilt FLASH in current rack.

```
ZXR10#format flash
```

**Related Commands**

**check dev-using**

## mkdir

**Function** Use this command to create a new sub-file directory under the current directory.  
**Command Mode** Privileged configuration  
**Syntax** **mkdir <directory>**

**Syntax Description**

&lt;directory&gt;

Created directory name, with 1~80 characters

**Instruction**

The total length of the directory name and file name cannot exceed 80 characters. ZXR10 GER file name should be not more than 32 characters. For the file system only supporting other data products in 8.3 format, its file name should be not more than eight characters.

**Example**

This example describes how to create a sub-directory named test under the current directory.

```
ZXR10#mkdir test
```

**Related Commands**

**cd**  
**dir**  
**pwd**  
**rmdir**

## pwd

**Function**

Use this command to display the current directory path.

**Command Mode**

Privileged configuration

**Syntax**

**pwd**

**Example**

These examples describe how to display the current directory path.

- The current directory is the root directory in the system.

```
ZXR10#pwd
root:/
```

- The current directory is the root directory of flash file device.

```
ZXR10#pwd
flash:/
```

- The current directory is the cfg directory of flash file device

```
ZXR10#pwd
flash:/cfg
```

**Related Commands**

**cd**  
**drr**  
**mkdir**  
**rmdir**

## rename

**Function**

Use this command to modify the name of a specified file directory.

**Command Mode** Privileged configuration

**Syntax** **rename** <source-filename> <destination-filename>

**Syntax Description**

<source-filename>	Source file name or directory, with 1~80 characters
<destination-filename>	Modified file name, with 1~12 characters

- Instructions**
- The total length of the directory name and file name cannot exceed 80 characters. ZXR10 GER file name should be not more than 32 characters. For the file system only supporting other data products in 8.3 format, its file name should be not more than eight characters.
  - The source file name can include the path, but the second parameter only includes the modified name for the file name in the directory specified in the first parameter.

**Example** This example describes how to rename the sys.da file in config directory into back.dat.

```
ZXR10#rename config/sys.dat back.dat
```

**Related Commands**

**copy**  
**delete**  
**rmdir**

## rmdir

**Function** Use this command to delete the specified file directory.

**Command Mode** Privileged configuration

**Syntax** **rmdir** <directory>

**Syntax Description**

<directory>	Directory name, with 1~80 characters
-------------	--------------------------------------

**Related Commands**

**cd**  
**copy**  
**dir**  
**mkdir**  
**pwd**

## show flash-check

**Purpose** Use this command to check whether Flash space is matching or not.

<b>Command Modes</b>	Privileged EXEC
<b>Syntax</b>	<b>show flash-check</b>
<b>Instructions</b>	The platform version 4.8.22 and the upgrade versions support this command. Check whether Flash is matching or not. If the sum of free space and usage space in Flash is greater than Flash space, then it will display that Flash memory check result is too large. Or, it will display that Flash memory check result is too small.
<b>Example</b>	This example describes how to check whether Flash space is full or not.  <pre>ZXR10#show flash-check Master MP flash is loaded. Master MP flash checked OK. Slave MP flash is loaded. Slave MP flash checked OK. ZXR10#</pre>

## unmount

<b>Purpose</b>	Use this command to uninstall a memory device.				
<b>Command Modes</b>	Privileged EXEC				
<b>Syntax</b>	<b>unmount sd [ slave ]</b>				
<b>Syntax Description</b>	<table border="1"> <tr> <td><b>sd</b></td><td>Uninstalls sd card.</td></tr> <tr> <td><b>slave</b></td><td>Only uninstalls memory device on slave control.</td></tr> </table>	<b>sd</b>	Uninstalls sd card.	<b>slave</b>	Only uninstalls memory device on slave control.
<b>sd</b>	Uninstalls sd card.				
<b>slave</b>	Only uninstalls memory device on slave control.				
<b>Instructions</b>	The platform version 4.8.22 and the upgrade versions support this command. It is used on ZXR10 6900 and ZXR10 8900. Only supports SD card currently. Other memory devices need to be extended by adding command parameter.				
<b>Example</b>	This example describes how to uninstall sd card.  <pre>ZXR10# unmount sd SD device will be removed.Continue to unmount? [yes/no]: y Starting unmount SD about several minutes, please wait... ... Unmount SD device successfully! ZXR10#</pre>				

## update-imgfile

<b>Function</b>	Use this command to replace the version files in /system/ with files in /flash/img in current directory.
<b>Command Mode</b>	Privileged configuration
<b>Syntax</b>	<b>update-imgfile</b>
<b>Example</b>	Use this command to replace the version files in /system/ with files in /flash/img in current directory.

```
ZXR10#update-imgfile
Updating the imgfile in system: ...
[ok]
```

## write

**Purpose** Use this command to write configuration information of the current router into the flash, or write the current router-related system parameters into the nvram.

**Command Modes** Privileged EXEC

**Syntax** **write**

**write** [{**master**|**slave**}][**sd**]

**Syntax Description**

<b>master</b>	Master device
<b>slave</b>	Slave device
<b>sd</b>	Uninstalls sd card

**Instructions** It is equivalent to the execution of both write flash and write nvram commands.

The platform version 4.8.22 and the upgrade versions support writing configuration to SD card.

**Example** ■ This example describes how to save the current router information.

```
ZXR10#write
Building configuration...
[ok]
```

■ This example describes how to save the current router information to SD card on master and slave devices.

```
ZXR10#write sd
Building configuration...
.....Write config result on the sd:
      UPC      Status
master  Successfully
```

**Related commands**

**write flash**

**write nvram**

## write flash

**Function** Use this command to write the configuration information of the current router into the flash.

**Command Mode** Privileged configuration

**Syntax** **write flash**

**Instruction** When the equipment is started the next time, the configuration in the flash will take effect automatically.

**Example** This example describes how to write the configuration information of the current router into the flash.

```
ZXR10#write flash
Building configuration FLASH: ...
[ok]
```

**Related Commands** **write**  
**write nvram**

## write imgfile

**Purpose** Use this command to write the current running version into the flash.

**Command Modes** Privileged EXEC

**Syntax** **write imgfile** [{**master** | **slave**}][**sd**]

**Syntax Description**

<b>master</b>	Writes version file to master board.
<b>slave</b>	Writes version file to slave board.
<b>sd</b>	Writes version file to sd card.

**Instructions** When using the command **write imgfile** takes a long time, save the configuration to the master and slave boards respectively by adding parameters (master, slave) in environments supporting master/slave racks(69, t128). In this way to execute **write imgfile** will not take a long time.

The platform version 4.8.22 and the upgrade versions support writing configuration to SD card.

**Example** ■ This example describes how to save the current router information.

```
ZXR10#write
Building configuration...
[ok]
```

■ This example describes how to save the current router information to SD card on master and slave devices.

```
ZXR10#write sd
Building configuration...
.....Write config result on the sd:
      UPC      Status
master  Successfully
```

**Related commands** **write flash**  
**write nvram**



# write nvram

**Function** Use this command to write the current router-related system parameters into the nvram.

**Command Mode** Privileged configuration

**Syntax** **write nvram**

**Example** This example describes how to write the current router-related system parameters into the nvram.

```
ZXR10#write nvram
Building configuration...
[ok]
```

**Related Commands** **write**  
**write flash**

This page is intentionally blank.

## Chapter 4

# User Interface Management

---

### Table of Contents

answer-manual .....	49
answer-remote.....	50
line console 0.....	50
line console absolute-timeout.....	50
line console idle-timeout.....	51
line telnet absolute-timeout .....	51
line telnet access-class.....	52
line telnet idle-timeout .....	52
login .....	53
login authentication .....	53
logout.....	54
quit .....	54
session .....	54
show console-info.....	54
show history .....	55
show terminal .....	55
telnet.....	56
telnet mng .....	56
terminal length .....	57
user-authentication-type .....	57
user-authorization-type .....	57

## answer-manual

<b>Function</b>	When remote access is configured as manual answer in the router, this command is input to allow the user to log in remotely and manage the router.
<b>Command Mode</b>	Privileged configuration
<b>Syntax</b>	<b>answer-manual</b>
<b>Instruction</b>	It is only applicable to ZXR10 GER, ZXR10 GAR and ZXR10 ZSR.

**Related Commands**    answer-remote

## answer-remote

**Function**    Use this command to configure the remote access mode as automatic answer or manual answer with the answer-manual command in the router.

**Command Mode**    Global configuration

**Syntax**    **answer-remote** {**manual** | **auto**}

**Syntax Description**

<b>manual</b>	Manual answer
<b>auto</b>	Automatic answer

**Instruction**    It is only applicable to ZXR10 GER, ZXR10 GAR and ZXR10 ZSR.

**Related command**    **answer-manual**

## line console 0

**Function**    Use this command to enter into LINE configuration mode

**Command Mode**    Global configuration

**Syntax**    **line console 0**

**Example**    This example describes how to enter LINE configuration mode.

```
ZXR10(config)#line console 0
ZXR10(config-line)#
```

**Related Command**    **login authentication**

## line console absolute-timeout

**Function**    Use this command to configure the total using time of the login serial interface terminal. After this command is executed, the total using time of the console terminal is specified. After this specified time, the serial interface terminal session will be closed. Cancel the restriction with the no command

**Command Mode**    Global configuration

**Syntax**    **line console absolute-timeout** <absolute-timeout> **no line console absolute-timeout**

**Syntax Description**

&lt;absolute-timeout&gt;

Total use time of the terminal (unit: minute), in the range of 1~10000. The default value is one day.

**Instruction**

It can work with the **line console idle-timeout** command to close the serial interface terminal session after a specified period.

**Example**

This example describes how to set the total use time of the serial interface terminal to 30 minutes.

```
ZXR10(config)#line console absolute-timeout 30
```

**Related Command****line console idle-timeout**

## line console idle-timeout

**Function**

Use this command to configure the idle time of the login serial interface terminal. After this command is executed, if there is no keyboard input in the specified period, the serial interface terminal session will be closed. Cancel the restriction with the no command.

**Command Mode**

Global configuration

**Syntax****line console idle-timeout** <idle-timeout>**no line console idle-timeout****Syntax Description**

&lt;idle-timeout&gt;

Idle time of the terminal (unit: minute), in the range of 1~1000. The default value is 2 hours.

**Instruction**

It can work with the line console absolute-timeout command to close the serial interface terminal session after a specified period.

**Example**

This example describes how to set the idle time of the serial interface terminal to 30 minutes.

```
ZXR10(config)#line console idle-timeout 30
```

**Related Command****line console absolute-timeout**

## line telnet absolute-timeout

**Function**

Use this command to configure the total using time of the Telnet terminal. After this command is executed, the total using time of the Telnet terminal is specified. After this specified time, the Telnet terminal session will be closed and the connection will be disconnected. Cancel the restriction with the no command.

**Command Mode**

Global configuration

**Syntax****line telnet absolute-timeout** <absolute-timeout>**no line telnet absolute-timeout**

**Syntax Description**

&lt;absolute-timeout&gt;

Total use time of the terminal (unit: minute), in the range of 1~10000. The default value is one day.

**Instruction**

It can work with the line telnet idle-timeout command to close the Telnet terminal session after a specified period.

**Example**

This example describes how to set the total use time of the Telnet terminal as 30 minutes.

```
ZXR10(config)#line telnet absolute-timeout 30
```

**Related Command****line telnet idle-timeout**

## line telnet access-class

**Function**

Use this command to set the login IP restriction of the Telnet terminal. This command is used to allow or refuse the login from some IP addresses. Cancel the restriction with the no command.

**Command Mode**

Global configuration

**Syntax****line telnet access-class** <access-list-number>**no line telnet access-class****Syntax Description**

&lt;access-list-number&gt;

Access address list, in the range of 1~199

**Default**

There is no login address restriction.

**Instruction**

It can work with the access-list command to accept or reject the login from some IP addresses.

**Example**

This example describes how to refuse the login from the address 168.1.16.118.

```
ZXR10(config)#access-list 2 deny 168.1.16.118 0.0.0.0
ZXR10(config)#access-list 2 permit any
ZXR10(config)#line telnet access-class 2
```

**Related Command****access-list**

## line telnet idle-timeout

**Function**

Use this command to configure the idle time of the Telnet terminal. After this command is executed, if there is no keyboard input in the specified period, the Telnet terminal session will be closed and the connection is disconnected. Cancel the restriction with the no command.

**Command Mode**

Global configuration

**Syntax****line telnet idle-timeout** <idle-timeout>**no line telnet idle-timeout**

<b>Syntax Description</b>	<table><tr><td><code>&lt;idle-timeout&gt;</code></td><td>Idle time of the terminal (unit: minute), in the range of 1~1000. The default value is 2 hours.</td></tr></table>	<code>&lt;idle-timeout&gt;</code>	Idle time of the terminal (unit: minute), in the range of 1~1000. The default value is 2 hours.
<code>&lt;idle-timeout&gt;</code>	Idle time of the terminal (unit: minute), in the range of 1~1000. The default value is 2 hours.		
<b>Instruction</b>	It can work with the line telnet absolute-timeout command to close the Telnet terminal session after a specified period.		
<b>Example</b>	<p>This example describes how to set the idle time of the Telnet terminal to 30 minutes.</p> <pre>ZXR10(config)#line telnet idle-timeout 30</pre>		
<b>Related Command</b>	line telnet absolute-timeout		

## login

<b>Function</b>	Use this command to enable another username to log in to the router.
<b>Command Mode</b>	Command Mode Exec mode / privileged
<b>Syntax</b>	<b>login</b>
<b>Instruction</b>	Exec mode and privileged mode are returned to the exec mode after this command is executed.
<b>Example</b>	<p>This example describes how to enable to login the router with the user name zxr10.</p> <pre>ZXR10&gt;login Username:zxr10 Password: ZXR10&gt;</pre>
<b>Related Commands</b>	<b>logout</b> <b>quit</b>

## login authentication

<b>Function</b>	Use this command to set to enable serial port authentication. Close authentication with the no command.
<b>Command Mode</b>	Line configuration
<b>Syntax</b>	<b>login authentication</b> <b>login authentication no login authentication</b>
<b>Example</b>	<p>This example describes how to enable serial port authentication.</p> <pre>ZXR10(config)#line console 0 ZXR10(config-line)#login authentication Warning: Please make sure local or remote authentication is correctly configured. Are you sure to configure console authentication?[yes/no]:yes</pre>
<b>Related Commands</b>	<b>logout</b> <b>quit</b>

# logout

<b>Function</b>	Use this command to quit the login router.
<b>Command Mode</b>	Exec mode / privileged
<b>Syntax</b>	<b>logout</b>
<b>Instruction</b>	Disconnect from the router proactively.
<b>Related Commands</b>	<b>login</b> <b>quit</b>

# quit

<b>Function</b>	Use this command to quit the login router.
<b>Command Mode</b>	Exec mode / privileged
<b>Syntax</b>	<b>quit</b>
<b>Instruction</b>	Disconnect the login router proactively.
<b>Related Commands</b>	<b>login</b> <b>logout</b>

# session

<b>Function</b>	Use this command to make members in the stackable system access each other.	
<b>Command Mode</b>	privileged	
<b>Syntax</b>	<b>session</b> <stack-id>	
<b>Syntax Description</b>		
	<stack-id>	Device ID of members in the stackable system, in the range of 1-9
<b>Instruction</b>	Use this command to make members in the stackable system access each other.	
<b>Example</b>	Log in the stackable device 2 from the stackable master device.  ZXR10#session 2 ZXR10(stack-2)#	

# show console-info

<b>Function</b>	Use this command to display configuration condition of AUX interface of the current router.
-----------------	---



<b>Command Mode</b>	All modes except exec
<b>Syntax</b>	<b>show console-info</b>
<b>Instruction</b>	It is only applicable to ZXR10 GER, ZXR10 GAR and ZXR10 ZSR.

## show history

<b>Function</b>	Use this command to display the history records of the input commands. It can be used to view the commands entered before.
<b>Command Mode</b>	All
<b>Syntax</b>	<b>show history</b>
<b>Instruction</b>	This command can be used to view the commands entered recently, 10 at most.
<b>Example</b>	<p>This example describes how to view the commands entered recently.</p> <pre>ZXR10&gt;show history who show ip route en dir</pre>

## show terminal

<b>Function</b>	Use this command to display the status of the current user terminal.
<b>Command Mode</b>	All
<b>Syntax</b>	<b>show terminal</b>
<b>Instruction</b>	This command can be used to view the information of the login terminal, including the terminal number, terminal type, and terminal window size and login restrictions.
<b>Example</b>	<p>This example describes how to view the information of the current login terminal.</p> <pre>ZXR10#show terminal Line 66, Location: "", Type: "vt100" Length: 24 lines, Width: 80 columns Telnet idle-timeout is: 02:00:00 Telnet absolute-timeout is: 1d00h00m Baud rate (TX/RX) is 9600/9600 Capabilities: none Time since activation: 00:07:55 Editing is enabled. History is enabled, history size is 10. Telnet access-class is: 2</pre>

# telnet

**Function** Use this command to open a Telnet connection.  
**Command Mode** All modes

**Syntax** **telnet** <ip-address>[**vrf** <vrf-name>]

**Syntax Description**

<ip-address>	Destination IP address in the dotted decimal notation
<b>source</b> < ip-address >	Source IP address, in the dotted decimal notation
<b>vrf</b> <vrf-name>	VPF name, with 1~16 characters

**Instruction** This command can be used to login into other switches, routers or Telnet servers.

**Example** ■ This example describes how to log in the server with address 168.1.200.77.

```
ZXR10#telnet 168.1.200.77
```

■ This example describes how to log in the server with address 168.1.200.77. The source address is local address 168.1.200.78.

■ This example describes how to log in the server with address 168.1.200.77 in the vpn1 VPN.

```
ZXR10#telnet 168.1.200.77 vrf vpn1
```

# telnet mng

**Function** Use this command to open a Telnet connection starting from the management interface.  
**Command Mode** Exec mode and privileged

**Syntax** **telnet mng** <ip-address>

**Syntax Description**

<ip-address>	Destination IP address in the dotted decimal notation
--------------	---

**Instruction** This command can be used to log in from the management interface to other routers or Telnet servers.

**Example** This example describes how to log in from the management interface to the server with address 168.1.200.77.

```
ZXR10#telnet mng 168.1.200.77
```

## terminal length

<b>Function</b>	Use this command to set the line length of terminal.	
<b>Command Mode</b>	Privileged	
<b>Syntax</b>	<b>terminal length</b> <i>&lt;length&gt;</i>	
<b>Syntax Description</b>	<i>&lt;length&gt;</i>	Line Length of terminal, in the range of 0~512, 24 by default.
<b>Example</b>	This example describes how to set the line length of the terminal is 1.  ZXR10#terminal length 1	

## user-authentication-type

<b>Function</b>	Use this command to specify the user authentication mode for the Telnet login.									
<b>Command mode</b>	Global configuration mode									
<b>Syntax</b>	<b>user-authentication-type</b> { <b>local</b>   <b>radius</b> <i>&lt;group&gt;</i> [{ <b>chap</b>   <b>pap</b> }]  <b>tacacs+</b> }									
<b>Syntax Description</b>	<table><tr><td><b>local</b></td><td>Local authentication</td></tr><tr><td><b>radius</b> <i>&lt;group&gt;</i></td><td>Radius authentication and group number, in the range of 1~10</td></tr><tr><td><b>chap</b>   <b>pap</b></td><td>Pap authentication mode and Chap authentication mode</td></tr><tr><td><b>tacacs+</b></td><td>Perform authentication using AAA authentication list</td></tr></table>		<b>local</b>	Local authentication	<b>radius</b> <i>&lt;group&gt;</i>	Radius authentication and group number, in the range of 1~10	<b>chap</b>   <b>pap</b>	Pap authentication mode and Chap authentication mode	<b>tacacs+</b>	Perform authentication using AAA authentication list
<b>local</b>	Local authentication									
<b>radius</b> <i>&lt;group&gt;</i>	Radius authentication and group number, in the range of 1~10									
<b>chap</b>   <b>pap</b>	Pap authentication mode and Chap authentication mode									
<b>tacacs+</b>	Perform authentication using AAA authentication list									
<b>Default</b>	Local authentication is the default setting.									
<b>Instuction</b>	In order to meet the requirements of service, the range of Radius authentication and group number is 1~2000 in UAS V4.8.01.									
<b>Example</b>	This example describes how to configure the local authentication.  ZXR10 (config) #user-authentication-type local									
<b>Related Commands</b>	<b>radius server</b> <b>telnet</b>									

## user-authorization-type

<b>Function</b>	Use this command to specify the user authorization type for the Telnet login.
-----------------	---

**Command Mode** Global configuration mode

**Syntax** **user-authorization-type** {**local** | **tacacs+**}

**Syntax  
Description**

<b>local</b>	Local authentication
<b>tacacs+</b>	Perform authorization using TACACS+ authorization list

**Default** Local authorization is the default setting..

**Example** This example describes how to configure the TACACS+ authorization.

```
ZXR10(config)#user-authorization-type tacacs+
```

**Related  
Commands** **user-authentication-type**

## Chapter 5

# System Log/Statistics Management

---

### Table of Contents

alarm.....	60
alarm cpuload-interval .....	60
alarm cpuload-on .....	61
alarm cpuload-threshold .....	61
alarm level-change .....	62
check.....	62
clear logging .....	63
clear processor.....	63
cpuload-threshold .....	63
environ .....	64
filter .....	64
logging alarmlog-interval .....	65
logging buffer .....	65
logging cmd ftp .....	66
logging cmdlog-interval .....	66
logging console .....	67
logging filesavetime .....	67
logging filter-map .....	68
logging ftp .....	69
logging level .....	70
logging mode.....	70
logging nat ftp .....	71
logging on .....	71
logging synchronize .....	72
logging timestamps .....	72
logging trap-enable.....	72
memory-threshold .....	73
show alarm-level .....	73
show logfile .....	74
show logging alarm.....	74
show logging configure.....	75
show processor .....	75
show processor details .....	77
show temperature .....	77
syslog-server facility .....	78
syslog-server host .....	79
syslog-server source .....	80
temper-threshold .....	80
write .....	81
write cmdlog .....	82
write logging.....	82

# alarm

<b>Function</b>	Use this command to open environment alarm. Close this alarm with no command.		
<b>Command Mode</b>	Global configuration		
<b>Syntax</b>	<b>alarm &lt;type&gt; on</b>		
<b>Syntax Description</b>	<table border="1"> <tr> <td>&lt;type&gt;</td><td>           Environment alarm types            all all kinds of environment alarm types            cpuload CPU load alarm            fan fan alarm            power power alarm            temperature temperature alarm            memory memory alarm         </td></tr> </table>	<type>	Environment alarm types all all kinds of environment alarm types cpuload CPU load alarm fan fan alarm power power alarm temperature temperature alarm memory memory alarm
<type>	Environment alarm types all all kinds of environment alarm types cpuload CPU load alarm fan fan alarm power power alarm temperature temperature alarm memory memory alarm		
<b>Instruction</b>	For ZXR10 T128, ZXR10 T1200 only CPU load alarm is enabled. Temperature alarm and memory alarm take effect.		
<b>Example</b>	This example describes how to enable CPU load alarm. <pre>ZXR10(config)#environ ZXR10(config-environ)#alarm cpuload on</pre>		

# alarm cpuload-interval

<b>Function</b>	Use this command to set CPU load alarm test time interval. Recover default value with no command.		
<b>Command Mode</b>	Global configuration		
<b>Syntax</b>	<b>alarm cpuload-interval &lt;30~120&gt;</b> <b>no alarm cpuload-interval</b>		
<b>Syntax Description</b>	<table border="1"> <tr> <td>&lt;30~120&gt;</td><td>CPU load alarm test time interval, the range is from 30 to 120 (unit: second).</td></tr> </table>	<30~120>	CPU load alarm test time interval, the range is from 30 to 120 (unit: second).
<30~120>	CPU load alarm test time interval, the range is from 30 to 120 (unit: second).		
<b>Default</b>	CPU load alarm test time interval is 30s by default.		
<b>Instructions</b>	<ul style="list-style-type: none"> <li>Make sure that alarm cpuload-on is used before using this command.</li> <li>In ZXR10 T128, ZXR10 T1200, this command is included in check command in environment configuration mode. See check command in environment configuration mode for more information.</li> </ul>		
<b>Example</b>	This example describes how to set CPU load alarm test time interval to 60s. <pre>ZXR10(config)#alarm cpuload-interval 60</pre>		

## alarm cpuload-on

- Function** Use this command to open/close cpu load alarm. Close this alarm with no command.
- Command Mode** Global configuration
- Syntax** **alarm cpuload-on**  
**no alarm cpuload-on**
- Instructions**
- **alarm cpuload-on** has the effect on the following commands: **alarm cpuload-interval**, **alarm cpuload-threshold**.
  - When run **no alarm cpuload-on** command, the above commands are invalid.
- Example** This example describes how to close CPU load alarm.
- ```
ZXR10(config)#no alarm cpuload-on
```

## alarm cpuload-threshold

- Function** Use this command to set CPU load alarm threshold. Recover default value with no command.
- Command Mode** Global configuration
- Syntax** **alarm cpuload-threshold** {[**low-grade** < *percent*>] [**middle-grade** < *percent*>] [**high-grade** < *percent*>]}  
**no alarm cpuload-threshold**
- Syntax Description**
- |                    |                                                   |
|--------------------|---------------------------------------------------|
| < <i>percent</i> > | Cpu utility, the range is from 0 to 100 (unit :%) |
|--------------------|---------------------------------------------------|
- Default** By default, low-grade is 75%, middle-grade is 85% and high-grade is 95%.
- Instruction**
- Low-grade middle-grade high-grade can be set at the same time also can be set one, the prerequisite is low-grade middle-grade high-grade.
  - Make sure use command **alarm cpuload-on** firstly.
  - In ZXR10 T128, ZXR10 T1200, this command is replaced by **cpuload-threshold**. See **cpuload-threshold** command in environment configuration mode for more information.
- Example** This example describes how to set alarm cpuload-threshold low-grade to 20%.
- ```
ZXR10(config)#alarm cpuload-threshold low-grade 20
```

## alarm level-change

- Function** Use this command to modify the corresponding alarm level of the alarm code.
- Command Mode** Global configuration
- Syntax** **alarm level-change** *<alarm-code>* *<level>*
- Syntax Description**
- |                           |  |
|---------------------------|--|
| <i>&lt;alarm-code&gt;</i> | Alarm code, in the range of 1~65535. It is only allowed to modify the alarm code for levels 4~8. |
| <i>&lt;level&gt;</i>      | Alarm level(4: errors; 5: warnings; 6: notifications; 7: informational; 8: debugging)            |
- Instructions**
- Only the alarm codes for levels 4- 8 can be modified.
  - For the explanations of the alarm codes, see ZXR10 Router/Ethernet Switch Information Manual.
- Example** This example describes how to change the alarm level of alarm code 18720 as 7.
- ```
ZXR10(config)#alarm level-change 18720 informational
```

## check

- Function** Use this command to set environment alarm check interval. Recover default value with no command.
- Command Mode** Environment configuration
- Syntax** **check** *<type>* **interval** *<second>*
- Syntax Description**
- |                       |                                                                                                                                                                                             |
|-----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>&lt;type&gt;</i>   | Environment alarm types<br>all all kinds of environment alarm types<br>cpuload CPU load alarm<br>fan fan alarm<br>power power alarm<br>temperature temperature alarm<br>memory memory alarm |
| <i>&lt;second&gt;</i> | Interval: 10s by default, in the range of 3-20                                                                                                                                              |
- Instruction**
- For ZXR10 T128 and ZXR10 T1200 only cpuload alarm is enabled. Temperature alarm and memory alarm take effect Make sure alarm switch is on before set an alarm check interval.
  - The default value is 3.
- Example** This example describes how to set CPU load check interval to 5s.
- ```
ZXR10(config)#environ
ZXR10(config-environ)#check cpuload interval 5
```



## clear logging

<b>Function</b>	Use this command to clear the contents in the alarm log buffer.
<b>Command Mode</b>	Privileged
<b>Syntax</b>	<b>clear logging</b>
<b>Example</b>	This example describes how to clear the contents in the alarm log buffer.  ZXR10#clear logging

## clear processor

<b>Function</b>	Use this command to clear the CPU maximum utilization in the system resource statistics information.				
<b>Command Mode</b>	Privileged				
<b>Syntax</b>	<b>clear processor</b> [ <i>&lt;cpu-type&gt;</i> <i>&lt;panel-number&gt;</i> ]				
<b>Description Syntax</b>	<table border="1"><tr><td><i>&lt;cpu-type&gt;</i></td><td>CPU type, such as MP, RP, NP and SP.</td></tr><tr><td><i>&lt;panel-number&gt;</i></td><td>Slot No.</td></tr></table>	<i>&lt;cpu-type&gt;</i>	CPU type, such as MP, RP, NP and SP.	<i>&lt;panel-number&gt;</i>	Slot No.
<i>&lt;cpu-type&gt;</i>	CPU type, such as MP, RP, NP and SP.				
<i>&lt;panel-number&gt;</i>	Slot No.				
<b>Instruction</b>	This command is used to clear the CPU utilization peak in the resource statistics information of the specified CPU.				
<b>Example</b>	This example describes how to clear the CPU utilization peak in the resource statistics information of the specified CPU.  ZXR10#clear processor mp 1				

## cpuload-threshold

<b>Function</b>	Use this command to set the CPU alarm threshold. Recover default value with no command.		
<b>Command Mode</b>	Environment configuration		
<b>Syntax</b>	<b>cpuload-threshold</b> {[ <b>low-grade</b> <i>&lt;percent&gt;</i> ][ <b>middle-grade</b> <i>&lt;percent&gt;</i> ][ <b>high-grade</b> <i>&lt;percent&gt;</i> ]} <b>no cpuload-threshold</b>		
<b>Syntax Description</b>	<table border="1"><tr><td><i>&lt;percent&gt;</i></td><td>CPU utilization, in the range of 0~100 (unit:%)</td></tr></table>	<i>&lt;percent&gt;</i>	CPU utilization, in the range of 0~100 (unit:%)
<i>&lt;percent&gt;</i>	CPU utilization, in the range of 0~100 (unit:%)		
<b>Instruction</b>	This command is used to clear the CPU utilization peak in the resource statistics information of the specified CPU.		

**Example** This example describes how to clear the CPU utilization peak in the resource statistics information of the specified CPU.

```
ZXR10#clear processor mp 1
```

## environ

**Function** Use this command to enter environment mode.

**Command Mode** Global configuration

**Syntax** **environ**

**Example** This example describes how to enter the environment configuration mode.

```
ZXR10 (config) #environ
```

## filter

**Function** Use this command to configure the filter-map function which is created. Cancel this configuration with the no command.

**Command Mode** Alarm-filter configuration

**Syntax** **filter** {**disable-all** | **enable-all** | (**disable-all** <alarmtype>) | (**enable-all** <alarmtype>)} [**except** <range>]

**no filter** {**disable-all** | **enable-all** | (**disable-all** <alarmtype>) | (**enable-all** <alarmtype>)}

**Syntax Description**

<b>disable-all</b>	Disable all alarm filter types
<b>enable-all</b>	Enable all alarm filter types
<alarmtype>	Alarm type
<b>except</b>	The specified alarm code which is not included in this configuration.
<range>	The range of alarm code

**Instruction** Use the logging filter-map command to enter into alarm-filter configuration mode, and then configure the created filter-map.

**Example** This example describes how to enable the alarm function which alarm type is OAM.

```
ZXR10 (config) # logging filter-map zte
ZXR10 (config-alarm-filter) filter enable oam
```

# logging alarmlog-interval

- Purpose** Use this command to set time interval and peripheral equipment of alarm log. Delete the configuration with the **no** command.
- Command Modes** Global Configuration
- Syntax** **logging alarmlog-interval** <minute> {**flash** | **sd**}  
**no logging alarmlog-interval**

**Syntax Description**

<minute>	Time interval(in minutes), 10~65535.
<b>flash</b>	The storage device for alarm log is flash.
<b>sd</b>	The storage device for alarm log is sd.

- Instructions** Only the T128/T1200 support this function. At present T128/T1200 only supports the flash peripheral device. Document way and document name is data/alarm001.log. Document name circulates from alarm001.log to alarm010.log. After each configuration, starts writting from alarm001.log to cover.

After alarm log buffer is full, write alarm log to peripheral device according to log peripheral. The path and file name are the same as this command. No alarm log if this command is not set.

- Example** This example describes how to set writting alarm interval to 100 minutes and write it to flash.

```
ZXR10(config)#logging alarmlog-interval 100 flash
```

# logging buffer

- Function** Use this command to set the size of the alarm log buffer. Cancel the setting and restore default with the no command.
- Command Mode** Global configuration
- Syntax** **logging buffer** <buffer-size>  
**no logging buffer**

**Syntax Description**

<buffer-size>	Size of the alarm buffer (unit: KB), in the range of 100~1000, and 200 KB by default
---------------	--

- Instruction** Run the **logging on** command before this command.

- Example** This example describes how to set the size of the alarm log buffer as 100 K.

```
ZXR10(config)#logging buffer 100
```

## logging cmd ftp

- Function** Use this command to set to send cmd log to remote FTP server. Cancel this setting with the no command.
- Command Mode** Global configuration
- Syntax** **logging cmd ftp** [**vrf** <vrf-name>] <ftp-server> <username> <password> <time> <filename> <interval>]  
**no logging cmd ftp**

**Syntax Description**

<b>Vrf</b> <vrf-name>	VPF name, with 1~16 characters
<ftp-server>	Destination IP address of the FTP server in the dotted decimal notation
<username>	Login username for the FTP server, with 1~31 characters
<password>	Login password for the FTP server, with 1~31 characters Specify time for updating the log file name
<time>	Specify time for updating the log file name
<filename>	File name prefix of storing alarm messages, with 1~31 characters Interval period (in day).
<interval>	In the specified time for updating log file name, generate a new file on the FTP server in the format of configured file name prefix + current date, such as lognat_20050802.log, and send the generated NAT log to a new file.

- Instruction** Run the **logging on** command before this command.

- Example** This example describes how to set to send the cmd log to the 168.1.1.111 FTP server. The login username for FTP server is target, and the password is target. The file name prefix of storing alarm messages is cmdlog. And specify the time for updating the log file name is 2 days. The updating time is 11:11:11.

```
ZXR10(config)# logging cmd ftp 168.1.1.111 target target cmdlog 11:11:11 2
```

## logging cmdlog-interval

- Function** Use this command to set the interval time of writing cmd log. To reset this setting to the default value 2880 use the no command.
- Command Mode** Global configuration
- Syntax** **logging cmdlog-interval** <10~65535>  
**no logging cmdlog-interval**

**Syntax Description**

<i>&lt;minute&gt;</i>	The time interval(in minute), in the range of 10~65535. By default, it is 2880 minutes.
-----------------------	---

**Example** This example describes how to set the interval time of writing cmd log to 100 minutes.

```
ZXR10(config)#logging cmdlog-interval 100
```

## logging console

**Function** Use this command to send the alarm messages to the console COM interface or telnet terminal. Cancel the setting with the no command.

**Command Mode** Global configuration

**Syntax** **logging console** *<level>*  
**no logging console**

**Syntax Description**

<i>&lt;level&gt;</i>	Alarm level (1: emergencies; 2: alerts; 3: critical; 4: errors; 5: warnings; 6: notifications; 7: informational; 8: debugging)
<i>&lt;map-name&gt;</i>	Alarm filter table name

- Instructions**
- After the system initialization, the alarm messages with the level of notifications are sent to the COM interface.
  - Run the logging on command before this command. The no command stops sending the alarm messages to the COM interface. The alarm message output can be opened (closed) with the (no) terminal monitor command on the console COM interface or telnet terminal.
  - filter** *<map-name>* command can be used after this command, which filters a certain alarms. To configure **filter** *<map-name>* use command **logging filter-map**

**Example** This example describes how to send the alarm messages with level 5 and above to the console serial interface,

```
ZXR10(config)#logging console warnings
```

## logging filesavetime

**Function** Use this command to set the time for writing alarm log into file and sending to the FTP server. Cancel the setting with the no command.

**Command Mode** Global configuration

**Syntax** **logging filesavetime interval** *<time>* | **everyday** *<time>* | **week** *<weekday>* *<time>* | **month** *<mothday>* *<time>* [**vrf**

<vrf-name> | **mng**] <ftp-server> <username> <password> [<file name>]

### no logging filesavetime

#### Description

<b>interval</b> <time>	Time interval for saving alarm log file, no less than 1 hour with the accuracy of 1 minute
<b>everyday</b> <time>	Time when the alarm log file is saved everyday
<b>week</b> <weekday> <time>	Date and time for saving alarm log file every week (the range of the weekday is from Monday to Sunday)
<b>month</b> <monthday> <time>	Date and time for saving alarm log file every month, the range of the monthday is from 1~31
<b>vrf</b> <vrf-name>	VPF name, with 1~16 characters
<b>mng</b>	Management interface
<ftp-server>	Saved IP address of the FTP server in the dotted decimal notation
<username>	Login username for the FTP server, with 1~31 characters
<password>	Login password for the FTP server, with 1~31 characters
<filename>	Prefix of the file name saved in the FTP server, being ZXR10AlarmLog by default, and with 1~31 characters

**Instruction** Run the **logging on** command before this command.

**Example** This example describes how to save the alarm log file at 0'clock everyday and send it to the FTP server at 168.1.70.100 FTP, where the login username is target, the password is target and the file prefix is zxrt64log.

```
ZXR10(config)#logging filesavetime everyday 0:0:0 168.1.70.100
target target zxrt64log
```

## logging filter-map

**Function** Use this command to create filter-map to filter alarm type. Delete filter-map with the no command.

**Command Mode** Global configuration

**Syntax** **logging filter-map** <map-name>

**no logging filter-map** <map-name>

#### Syntax Description

<map-name>	Filter-map name, with 1~20 characters
------------	---------------------------------------

**Instruction** Use this command to enter into alarm-filter configuration mode, and configure filter-map.

**Example** This example describes how to create a filter-map, and the name is zte.

```
ZXR10(config)#logging filter-map zte
```

## logging ftp

**Purpose** Use this command to set the alarm level for the alarm messages sent to the FTP server. Cancel the setting with the **no** command.

**Command Modes** Global configuration

**Syntax** **logging ftp** <level>[**vrf** <vrf-name>| **mng**]<ftp-server><username><password>[<filename>]

**no logging ftp**

**Syntax Description**

<level>	Alarm level (1: emergencies; 2: alerts; 3: critical; 4: errors; 5: warnings; 6: notifications; 7: informational; 8: debugging)
<b>vrf</b> <vrf-name>	VPF name, with 1~16 characters
<b>mng</b>	Management interface
<ftp-server>	Destination IP address of the FTP server in the dotted decimal notation
<username>	Login username for the FTP server, with 1~31 characters
<password>	Login password for the FTP server, with 1~31 characters
<filename>	File name of storing alarm messages, with 1~31 characters. The default value is Zxr10Alarm.log.

**Instructions** Run the **logging on** command before this command. In addition, the filename configured in this command must exist in the corresponding FTP server directory and must be writeable (Zxr10Alarm.log by default).

**Example** This example describes how to send the alarm messages above level 6 to the FTP server at 168.1.70.100, where the login username is target, the password is target and the saving file is zxralarm.log.

```
ZXR10(config)#logging ftp notification 168.1.70.100
target target zxralarm.log
```

## logging level

<b>Function</b>	Use this command to set the alarm message level recorded in the alarm log file. Cancel the setting with the no command: notifications.		
<b>Command Mode</b>	Global configuration		
<b>Syntax</b>	<b>logging level</b> <level/> <b>no logging level</b>		
<b>Syntax Description</b>	<table border="1"> <tr> <td>&lt;level/&gt;</td><td>Alarm level (1: emergencies; 2: alerts; 3: critical; 4: errors; 5: warnings; 6: notifications)</td></tr> </table>	<level/>	Alarm level (1: emergencies; 2: alerts; 3: critical; 4: errors; 5: warnings; 6: notifications)
<level/>	Alarm level (1: emergencies; 2: alerts; 3: critical; 4: errors; 5: warnings; 6: notifications)		
<b>Instruction</b>	Run the <b>logging on</b> command before this command.		
<b>Example</b>	This example describes how to record the alarm message in level 4 and above in the alarm log file.  ZXR10(config)#logging level errors		

## logging mode

<b>Function</b>	Use this command to set the clearing mode of the alarm log when it is full. Cancel the setting with the no command:fullcycle.				
<b>Command Mode</b>	Global configuration mode				
<b>Syntax</b>	<b>logging mode</b> <mode>[<interval>] <b>no logging mode</b>				
<b>Syntax Description</b>	<table border="1"> <tr> <td>&lt;mode&gt;</td><td>The clearing mode when the alarm buffer is full. FULLEND: discarded alarm message. FULLCLEAR: Clear all alarm messages in an alarm cache. FULLCYCLE: Clear alarm messages in the first 1/3 part in an alarm cache. The default value is FULLCYCLE.</td></tr> <tr> <td>&lt;interval&gt;</td><td>Time interval for timing storing alarms in log (in minute), in the range of 10~65535</td></tr> </table>	<mode>	The clearing mode when the alarm buffer is full. FULLEND: discarded alarm message. FULLCLEAR: Clear all alarm messages in an alarm cache. FULLCYCLE: Clear alarm messages in the first 1/3 part in an alarm cache. The default value is FULLCYCLE.	<interval>	Time interval for timing storing alarms in log (in minute), in the range of 10~65535
<mode>	The clearing mode when the alarm buffer is full. FULLEND: discarded alarm message. FULLCLEAR: Clear all alarm messages in an alarm cache. FULLCYCLE: Clear alarm messages in the first 1/3 part in an alarm cache. The default value is FULLCYCLE.				
<interval>	Time interval for timing storing alarms in log (in minute), in the range of 10~65535				
<b>Instruction</b>	Run the <b>logging on</b> command before this command.				
<b>Example</b>	This example describes how to select the <b>clear all existing alarm messages</b> when the buffer is full.  ZXR10(config)#logging mode FULLCLEAR				



# logging nat ftp

**Function** Use this command to set to send NAT log to the FTP server. Cancel the setting with the no command.

**Command Mode** Global configuration

**Syntax** **logging nat ftp** [**vrf** <vrf-name>| **mng**]<ftp-server><username><password><time><filename><interval>

**no logging nat ftp**

<b>vrf</b> <vrf-name>	VPF name, with 1~16 characters Management interface
<b>mng</b>	Management interface
<ftp-server>	Destination IP address of the FTP server in the dotted decimal notation
<username>	Login username for the FTP server, with 1~31 characters
<password>	Login password for the FTP server, with 1~31 characters
<time>	Specify time for updating the log file name
<filename>	File name prefix of storing alarm messages, with 1~31 characters
<interval>	Interval period (in day). In the specified time for updating log file name, generate a new file on the FTP server in the format of configured file name prefix + current date, such as lognat_20050802.log, and send the generated NAT log to a new file.

**Instruction** Run the **logging on** command before this command. Moreover, it is necessary to enable NAT log recording function. Refer to the **ip nat logging** command. A lot of NAT will be generated. This command is used to configure interval time (in day) and precise time. Generate a new file according to the current date and configured file name prefix on the FTP server and se

**Example** This example describes how to set to send NAT log to the 168.1.70.100 FTP server. The login user name is target, and the password is target, file name prefix is natlog, time interval is two days, specified time of 08:00:00. Generate a new log file.

```
ZXR10(config)#logging nat ftp 168.1.70.100 target target 08:00:00 natlog 2
```

# logging on

**Function** Use this command to enable the system log function. Disable the function with the no command.

**Command Mode** Global configuration

- Syntax** **logging on**  
**no logging on**
- Default** Enable the system log function.
- Instructions**
- The **logging on** command affects the following commands, logging mode, logging console, logging buffer, logging level, logging ftp, logging trap and logging file savetime.
  - When the **no logging on** command is executed, the above commands cannot be configured, and will not take effect.

## logging synchronize

- Function** Use this command to set the function which execute enter action automatically after use debug information every time. Cancel this configuration with no command.
- Command Mode** Global configuration
- Syntax** **logging synchronize**
- Example** This example describes how to set the function which execute enter action automatically after use debug information every time.
- ```
ZXR10(config)#logging synchronize
```

## logging timestamps

- Function** Use this command to set the time display format of alarm.
- Command Mode** Global configuration
- Syntax** **logging timestamps {localtime | datatime | uptime}**
- Syntax Description**
- |                  |                                                 |
|------------------|-------------------------------------------------|
| <b>datatime</b>  | The time display format is date                 |
| <b>localtime</b> | The time display format is local date           |
| <b>uptime</b>    | The time display format is the time of rack up. |
- Example** This example describes how to set the time display format is local date.
- ```
ZXR10(config)#logging timestamps datetime localtime
```

## logging trap-enable

- Function** Use this command to set the alarm level for the alarm messages sent to the trap server. Cancel the settings with the no command.

**Command Mode** Global configuration mode

**Syntax** **logging trap-enable** <level> [**filter** <map-name>]  
**no logging trap-enable**

**Syntax Description**

<level>	Alarm level (1: emergencies; 2: alerts; 3: critical; 4: errors; 5: warnings; 6: notifications; 7: informational; 8: debugging)
<map-name>	Alarm filter table name

**Instructions**

- Run the **logging on** command before this command.
- This command works with **filter** <map-name> command to filter alarms. To configure **filter** <map-name> command, use **logging filter-map** command

**Example** This example describes how to send the alarm messages above level 6 to the syslog server.

```
ZXR10(config)#logging trap-enable notifications
```

## memory-threshold

**Function** Use this command to set memory alarm threshold. Recover default value with no command.

**Command Mode** Environment configuration

**Syntax** **memory-threshold** <1-100>

**Syntax Description**

<1-100>	threshold, the range 0~100(unit:%)
---------	------------------------------------

**Default** The default value is 60.

**Instruction** Confirm **alarm memory** on before configuring this command. Only support this command.

**Example** This example describes how to set the memory alarm threshold as 70.

```
ZXR10(config-envron)#memory-threshold 70
```

## show alarm-level

**Function** Use this command to show the level of alarm code.

**Command Mode** All modes except exec

**Syntax** **show alarm level** [<alarm-code>]

**Syntax Description**

<i>&lt;alarm-code&gt;</i>	Alarm code, the range 0~65535. Only the alarm codes which belong to alarm level 4-8 are permitted to modify.
---------------------------	--

**Instruction** The command without parameter, that means the information of all alarm codes are displayed.

**Example** This example describes how to show the alarm level which with alarm code 512.

```
ZXR10(config)#show alarm-level 512
```

## show logfile

**Function** Use this command to display the records of the history configuration operation commands stored in the command log buffer.

**Command Mode** All modes except exec

**Syntax** **show logfile** {[**username** *<string>*][**start-time** *<date>**<time>*][**end-time** *<date>**<time>*][**vtyno** *<string>*][**ipaddress** *<ip-address>*]}

**Syntax Description**

<b>username</b> <i>&lt;string&gt;</i>	Login user name, with 1~32 characters
<b>start-time</b> <i>&lt;date&gt;</i> <i>&lt;time&gt;</i>	Start time of configuration command
<b>end-time</b> <i>&lt;date&gt;</i> <i>&lt;time&gt;</i> <i>&lt;date&gt;</i>	End time of configuration command
<b>vtyno</b> <i>&lt;string&gt;</i>	Login vty terminal number
<b>ipaddress</b> <i>&lt;ip-address&gt;</i>	IP address of the host used when login, in the dotted decimal notation. It supports IPv4 and IPv6.

**Default** All the records in the command log buffer are displayed.

**Example** This example describes how to show all command logs.

```
ZXR10#show logfile
```

## show logging alarm

**Function** Use this command to display the alarm information records in the alarm log buffer.

**Command Mode** All modes except exec

**Syntax** **show logging alarm** {[**typeid** *<type>*][**start-date** *<date>*][**end-date** *<date>*][**level** *<level>*]}

**Syntax  
Description**

<b>typeid</b> <type>	Alarm type of the alarm message to be shown
<b>start-date</b> <date>	Alarm message to be shown is created after this date (including this date)
<b>end-date</b> <date>	Alarm message to be shown is created before this date (including this date)
<b>level</b> <level>	Level of alarm messages to be displayed (1: emergencies; 2: alerts; 3: critical; 4: errors; 5: warnings; 6: notifications)

**Instruction** Now, the supported alarm message types are as follows:

ENVIRON, BOARD, PORT, ROS, DATABASE, OAM, SECURITY, OSPF, RIP, BGP,DRP, TCP-UDP, IP, IGMP, TELNET, ARP, ISIS, ICMP, SNMP, RMON, NAT, URPF, VSWITCH, ACL, VRRP, PPP, SCAN, MAC, ALG, LOOPDETECT, SESSION, DHCP, MLD, STP, VLAN, LOCAL-ACCOUNTING, RADIUS, LDP, AMAT, L2VPN, RSVP, ZESR, IGMP-SNOOPING, FR, ATM, SSH, TDM, QOS, TACACS, AAA, IPV6, PIM, MUX and BFD

**Example** This example describes how to display the alarm information that is the IP type from May.22, 2002.

```
ZXR10#show logging alarm typeid ip start-time 5-22-2002
```

## show logging configure

**Function** Use this command to display the configuration information of the statistics alarm functional module.

**Command Mode** All modes except exec

**Syntax** **show logging configure**

**Example** This example describes how to display the configuration information of the statistics alarm functional module.

```
ZXR10#show logging configure
```

## show processor

**Function** Use this command to display the system resource statistics, such as CPU utilization and memory utilization.

**Syntax** **show processor** [(**mp** <1~2>) | (**rp** <1~2>) | (**sp** <1~2>) | (**np** <1~num>)]

**Syntax  
Description**

<b>num</b>	The maximum number of each board, vary with rack type. In order to obtain the number of MP boards, execute show processor mp. The value of num is displayed.
<b>mp</b>	Resource statistics information of mp
<b>&lt;1~2&gt;</b>	mp slot no.
<b>rp</b>	Resource statistics information of rp
<b>&lt;1~2&gt;</b>	rp slot no
<b>sp</b>	Resource statistics information of sp
<b>&lt;1~2&gt;</b>	sp slot no
<b>np</b>	Resource statistics information of np
<b>&lt;1~num&gt;</b>	np slot no.

**Instructions**

- This command display the resource statistics of the specified CPU, such as the CPU utilization (at 5 s, 1 minutes, 5 minutes period), memory size, memory utilization and system buffer utilization.
- This command display the resource statistics of the specified CPU, such as the CPU utilization (at 5 s, 1 minutes, 5 minutes period), memory size, memory utilization and system buffer utilization.

**Example**

This example describes how to display the resource statistics information of mp 1.

```
ZXR10(config)#show process mp 1
M: Master processor
S: Slave processor
PhyMem: Physical memory (megabyte)
```

```

Panel      CPU(5s) CPU(1m) CPU(5m)  PhyMem  Buffer  Memory
MP (M)    1      17%   17%   16%     512    0%   55.585%
```

The displayed information is described below.

Panel	Panel number where the board locates
CPU(5s)	CPU utilization at 5 s period
CPU(1m)	CPU utilization at 1 minute period
CPU(5m)	CPU utilization at 5 minute period
PhyMem	Physical memory size (mb)
Buffer	System buffer utilization
Memory	Memory utilization

# show processor details

**Function** Use this command to display the history CPU utilization rate record.

**Syntax**

**Command Mode** All modes except exec

**Syntax** **show processor details** [**mp** <1~2>| **rp** <1~2>| **sp** <1~2>| **np** <1~num>]

**Syntax Description**

<b>num</b>	The maximum number of each board, vary with rack type. In order to obtain the number of MP boards, execute show processor mp ?. The value of num is displayed.
<b>mp</b>	Display the history CPU utilization rate record of mp
<1~2>	mp slot no.
<b>rp</b>	Display the history CPU utilization rate record of rp
<1~2>	rp slot no
<b>sp</b>	Display the history CPU utilization rate record of sp
<1~2>	sp slot no
<b>np</b>	Display the history CPU utilization rate record of np
<1~2>	np slot no.

**Instruction** This command is used to show the history CPU utilization rate record of the specified single board, or show all of working boards by default.

**Example** This example describes how to display the history CPU utilization rate record.

# show temperature

**Function** Use this command to display local end and remote end temperature of board for ZXR10 T128 series. Use this command to display rack temperature of board for ZXR10 69 series.

**Command Mode** All except exec

**Syntax** For ZXR10 T128 series, **show temperature** [{**bic** | **upc** {**master** | **slave**}} | **sfc** {**master** | **slave**}} | **np** <variable>}]  
For ZXR10 69 series, **show temperature** {**environment** | **mec** {**master** | **slave**}}

**Syntax  
Description**

<b>environment</b>	Display rack temperature
<b>upc</b>	Display upc temperature
<b>sfc</b>	Display sfc temperature
<b>mec</b>	Display mec temperature
<b>np</b>	Display np temperature
<b>master</b>	Display upc, sfc temperature, select master board
<b>slave</b>	Display upc, sfc temperature, select slave board
<b>bic</b>	Display bic temperature
<b>&lt;variable&gt;</b>	slot number of np board

**Instructions**

- The format for ZXR10 T128 series is shown below.

```
Panel  Local (°C/°F) Remote (°C/°F)
BIC      20      68      18      64
UPC 2    21      69      27      80
SFC 2    22      71      36      96
```

- ▶ The first column is board type.
- ▶ Panel: board number.
- ▶ Local (°C/°F): local end temperature (C refers to Celsius, F refers to Fahrenheit).
- ▶ Remote (°C/°F): remote end temperature (C refers to Celsius, F refers to Fahrenheit).

- The format for ZXR10 T6900 series is shown below.

```
Temperature:30C/86F
```

C refers to Celsius F refers to Fahrenheit.

**Example**

This example describes how to display the temperature of SFC master board.

```
ZXR10#show temperature sfc master
```

## syslog-server facility

**Function**

Use this command to set syslog type. Cancel the settings with the no command.

**Command Mode**

Global configuration mode

**Syntax**

**syslog-server facility <facility>**

**no syslog-server facility**



**Syntax Description**

<b>&lt;facility&gt;</b>	Facility type 24 types (0: kern; 1: user; 2: mail; 3: daemon; 4: auth; 5: syslog; 6: lpr; 7: news; 8: uucp; 9: sys9; 10: sys10; 11: sys11; 12: sys12; 13: sys13; 14: sys14; 15: cron; 16: local0; 17: local1; 18: local2; 19: local3; 20: local4; 21: local5; 22: local6; 23: local7.)
-------------------------	--

**Default** The default value is local0

**Example** This example describes how to display set syslog type as news.

```
ZXR10(config)#syslog-server facility news
```

## syslog-server host

**Function** Use this command to set the host address of syslog server. Cancel this setting with the no command.

**Command Mode** Global configuration

**Syntax** **syslog-server host** [**vrf** <vrf-name>] <ip-address> [(**alarmlog level** <level>)] [**cmdlog**] [**debugmsg**] [(**fport** <port number>)] [(**lport** <port number>)]

**no syslog-server host** [**vrf** <vrf-name>] <ip-address> [**alarmlog**] [**cmdlog**] [**debugmsg**]

**Syntax Description**

<b>vrf</b> <vrf-name>	VRF name. with 1-16 characters
<b>&lt;ip-address&gt;</b>	Specify the host IP address
<b>alarmlog</b>	Enable the alarm log send to syslog server
<b>level</b> <level>	Alarm level. 1emergencies2alerts3critical4errors5warnings6notifications7informational8debugging
<b>cmdlog</b>	Enable the cmd log send to syslog server
<b>debugmsg</b>	Enable debug information send to syslog server
<b>fport</b>	The port of server
<b>lport</b>	Local port
<b>&lt;port number&gt;</b>	Port number, 0 ~ 65535

**Instruction** The port number of **fport** and **lport** is 514 by default, and set to send **alarmlog**, **cmdlog**, **debugmsg** to syslog server by default. The alarm level is notifications by default.

**Example** This example describes how to display configure the IP address of 168.1.1.111 syslog server only send alarmlog to syslog server. Alarm level is errors.

```
ZXR10(config)#syslog-server host 168.1.1.111 alarmlog level errors
```

# syslog-server source

- Function** Use this command to set syslog source address. Cancel the settings with the no command.
- Command Mode** Global configuration
- Syntax** **syslog-server source** <ip-address>  
**no syslog-server source**

**Syntax Description**

<ip-address>	Syslog source address in the dotted decimal notation
--------------	--

- Example** This example describes how to display set syslog source address as 10.40.56.19.

```
ZXR10(config)#syslog-server source 10.40.56.19
```

# temper-threshold

- Purpose** Use this command to set board temperature alarm threshold. Recover default value with **no** command.
- Command Modes** Environment configuration
- Syntax** **temper-threshold** {{**bic** | (**upc** {**master** | **slave**}) | (**sfc** {**master** | **slave**}) | (**np** <variable>)}}{**remote** | **local**}{**lowthreshold** <temperature>}[**first-highthreshold** <temperature>][**second-highthreshold** <temperature>] }  
**no temper-threshold** {{**bic** | (**upc** {**master** | **slave**}) | (**sfc** {**master** | **slave**}) | (**np** <variable>)}}{**remote** | **local** }

**Syntax Description**

<temperature>	Temperature range, -65 ~ 127(unit: °C)
<variable>	NP slot number
<b>lowthreshold</b>	lowthreshold value
<b>first-highthreshold</b>	first-highthreshold value
<b>second-highthresh old</b>	second-highthreshold value

**Defaults**

Board type	Local end temperature			Remote end temperature		
	Low threshold	first-high threshold	second-high threshold	Low threshold	first-high threshold	second-high threshold

ENVI- RON_UPC3	-20	55	70	-20	100	120
ENVI- RON_SFC	-20	55	70	-20	70	90
ENVI- RON_SFC2	-20	55	70	-20	100	120
ENVI- RON_SFC3	-20	55	70	-20	100	120
ENVI- RON_BIC	-20	55	70	-20	55	75
ENVI- RON_NPCIX	-20	55	70	-20	85	100
ENVI- RON_NPCH	-20	55	70	-20	65	75
ENVI- RON_NPCT	-20	55	70	-20	65	75

- Instructions**
- Lowthreshold, first-highthreshold second-highthreshold can be set at the same time, also can be set on the prerequisite is **lowthreshold** , **lowthreshold** , **first-highthreshold** lowthreshold
  - The platform version 4.8.22 and the upgrade versions support writing configuration to SD card.
  - first-highthreshold, second-highthreshold are high temperature thresholds. When the temperature is higher than them, the rack occurs alarm.
  - Before configuring this command, make sure **alarm temperature on** already be open.
  - Only ZXR10 T128, ZXR10 T1200 support this command.

**Example** This example describes how to set the lowthreshold on local end of sfc board to -40.

```
ZXR10(config)#environ
ZXR10(config-environ)#temper-threshold sfc master local lowthreshold -40
```

## write

**Function** Use this command to write configuration information of the current router into the flash, or write the current router-related system parameters into the nvram.

**Command Mode** Privileged configuration mode

**Syntax** **write**

**Instruction** Instructions It is equivalent to the execution of both **write flash** and **write nvram** commands.

**Example** This example describes how to save the current router information.

```
ZXR10#write
Building configuration...
[ok]
```

**Related  
Commands**

**write flash**  
**write nvram**

## write cmdlog

- Function** Use this command to save the contents in the alarm log buffer in a file under flash:data/log.dat
- Command mode** Privileged
- Syntax** **write cmdlog**
- Instruction** File name is cmdxxx..log, the range xxx is 001-040. When the value reaches cmd040, it will begin from cmd001.
- Example** This example describes how to write log files.
- ```
ZXR10(config)#write cmdlog
```

## write logging

- Function** Use this command to save the contents in the alarm log buffer in a file under flash:data/log.dat.
- Command Mode** Privileged
- Format** **write logging**
- Instruction** Write alarm messages at the following level in the alarm buffer into a file with this command: 1: emergencies; 2: alerts; 3: critical; 4: errors
- Example** This example describes how to write alarm log files.
- ```
ZXR10(config)#write logging
```

# FTP/TFTP Server

### Table of Contents

copy(FTP Client) .....	83
copyTFTP Client .....	84
ftp-server enable .....	84
ftp-server tick-user .....	84
ftp-server top-directory .....	85
ip ftp password .....	85
ip ftp username .....	86
show ftp-server .....	86
show ftp-server-user .....	86

## copy(FTP Client)

<b>Function</b>	Use this command to copy a specified file in/out of the specified remote host in FTP mode with the specified username and login password. If no username and password are specified, the default username and password will be used. If there are no default user-name and password, error information will be reported.
<b>Command Mode</b>	Privileged mode
<b>Format</b>	<b>copy ftp:</b> [ <b>vrf</b> < <i>vrf-name</i> >  <b>mng</b> ] <b>// remote host address or host name/file path/filename</b> [@username[:password]] <b>root: path/filename</b>  <b>copy flash: path/filename ftp:</b> [ <b>vrf</b> < <i>vrf-name</i> >  <b>mng</b> ] <b>//remote host address or host name/file path/filename</b> [@user name [:password]]
<b>Instructions</b>	<ul style="list-style-type: none"><li>■ In ZXR10 GAR and ZXR10 ZSR, the management interface parameter mng is not supported.</li><li>■ In some devices the local directory might not be flash, such as: it is root in ZXR10 T128.</li></ul>
<b>Examples</b>	<ul style="list-style-type: none"><li>■ This example describes how to copy the file db.dat under the cfg directory of the flash into the working directory of the FTP user zxr10 on the host 168.1.1.1. <pre>ZXR10#copy flash: /cfg/db.dat ftp: //168.1.1.1/db.dat@zxr10:zxr10</pre></li><li>■ This example describes how to copy the file db.dat under the working directory of the FTP user zxr10 on the host 168.1.1.1 into the root directory of the router FLASH. <pre>ZXR10#copy ftp: //168.1.1.1/db.dat@zxr10:zxr10 root db.dat</pre></li></ul>

# copyTFTP Client

<b>Function</b>	Use this command to copy the specified file to or from the specified remote host in the TFTP mode.
<b>Command Mode</b>	Privileged
<b>Syntax</b>	<b>copy tftp:</b> [ <b>vrf &lt;vrf-name&gt; mng</b> ] <b>//remote host address or host name/file path/filename</b> <b>root: path/filename</b> <b>copy flash: path/filename tftp:</b> [ <b>vrf &lt;vrf-name&gt; mng</b> ] <b>//remote host address or host name/file path/filename</b>
<b>Instructions</b>	<ul style="list-style-type: none"> <li>In ZXR10 GAR and ZXR10 ZSR, the management interface parameter mng is not supported.</li> <li>In some devices the local directory might not be flash, such as: it is root in ZXR10 T128.</li> </ul>
<b>Example</b>	<ul style="list-style-type: none"> <li>This example describes how to copy the file db.dat under the cfg directory of the flash into the working directory of the TFTP server on the host 168.1.1.1.  <pre>ZXR10#copy root /cfg/db.dat tftp: //168.1.1.1/db.dat</pre> </li> <li>This example describes how to copy the file db.dat under the working directory of the TFTP server on the host 168.1.1.1 into the root directory of the router FLASH.  <pre>ZXR10#copy tftp: //168.1.1.1/db.dat root db.dat</pre> </li> </ul>

# ftp-server enable

<b>Function</b>	Use this command to enable FTP-SERVER function. Close FTP-SERVER with the no command.		
<b>Command Mode</b>	Global configuration		
<b>Syntax</b>	<b>ftp-server enable [listen &lt;port&gt;]</b> <b>no ftp-server enable</b>		
<b>Syntax Description</b>	<table border="1"> <tr> <td><b>listen &lt; port&gt;</b></td><td>Enable FTP Server to monitor specified port, in the range of 2401-2420</td></tr> </table>	<b>listen &lt; port&gt;</b>	Enable FTP Server to monitor specified port, in the range of 2401-2420
<b>listen &lt; port&gt;</b>	Enable FTP Server to monitor specified port, in the range of 2401-2420		
<b>Instruction</b>	Only the unused port can be monitored, including local port and remote port. Monitor port 21 by default.		
<b>Example</b>	This example describes how to enable FTP SERVER on 2405 port <pre>ZXR10(config)# ftp-server enable listen 2405</pre>		

# ftp-server tick-user

<b>Function</b>	Use this command to disconnect current user.
-----------------	--

<b>Command Mode</b>	Global configuration		
<b>Syntax</b>	<b>ftp-server tick-user</b> <user id>		
<b>Syntax Description</b>	<table border="1"><tr><td>&lt;user id&gt;</td><td>On-line user ID, the valid user is 1</td></tr></table>	<user id>	On-line user ID, the valid user is 1
<user id>	On-line user ID, the valid user is 1		
<b>Instruction</b>	<b>show ftp-server</b> can be used to view whether the user is on-line.		
<b>Example</b>	This example describes how to delete current on-line user <pre>ZXR10(config)# ftp-server tick-user 1</pre>		
<b>Related Commands</b>	<b>show ftp-server</b>		

## ftp-server top-directory

<b>Function</b>	Use this command to set FTP SERVER. Allow user to log in the top directory. Users only can access files in this directory and operate in the directory.		
<b>Command Mode</b>	Global configuration		
<b>Syntax</b>	<b>ftp-server top-directory</b> <directory>		
<b>Syntax Description</b>	<table border="1"><tr><td>&lt;directory&gt;</td><td>The user directory name must a complete path. The directory must exist.</td></tr></table>	<directory>	The user directory name must a complete path. The directory must exist.
<directory>	The user directory name must a complete path. The directory must exist.		
<b>Instruction</b>	<ul style="list-style-type: none"><li>■ The directories in ZXR10 should be /flash/, /cf, /bd, /bd1, /bd2...(number of USB devices vary with routers)</li><li>■ Only directories beginning with /system/ are valid.</li></ul>		
<b>Example</b>	This example describes how to set the top working directory to /flash/cfg/. <pre>ZXR10(config)#ftp-server top-directory /flash/cfg/</pre>		

## ip ftp password

<b>Function</b>	Use this command to set the default login password of the FTP client. Use no command to cancel client default login password.		
<b>Command Mode</b>	Global configuration		
<b>Syntax</b>	<b>ip ftp password</b> <password> <b>no ip ftp password</b>		
<b>Syntax Description</b>	<table border="1"><tr><td>&lt;password&gt;</td><td>Default login password at the FTP client, with 3~16 characters</td></tr></table>	<password>	Default login password at the FTP client, with 3~16 characters
<password>	Default login password at the FTP client, with 3~16 characters		
<b>Instruction</b>	The password is case sensitive.		

**Example** This example describes how to set the FTP login password as zxr10.

```
ZXR10(config)#ip ftp password zxr10
```

**Related Command** ip ftp username

## ip ftp username

**Function** Use this command to set the default login username of the FTP client. Use no command to cancel client default login password.

**Command Mode** Global configuration

**Syntax** **ip ftp username** <username>  
**no ip ftp username**

**Syntax Description**

<username>	Default username at the FTP client, with 1~16 characters
------------	--

**Instruction** The valid characters include the letters, numerals and underline, case insensitive for the letters.

**Example** This example describes how to set the FTP login username as zxr10.

```
ZXR10(config)#ip ftp username zxr10
```

**Related Command** ip ftp password

## show ftp-server

**Function** Use this command to show FTP server-related configuration information.

**Syntax** **show ftp-server**

**Example** This example describes how to show FTP server-related configuration information.

```
ZXR10(config)#show ftp-server
```

**Related Command** **ftp-server top-directory**  
**ftp-server enable**

## show ftp-server-user

**Function** Use this command to show on-line users of FTP server.

**Command Mode** All modes except exec

**Syntax** **show ftp-server-user** <user id>



**Syntax  
Description**

<i>&lt;user id&gt;</i>	On-line user ID, the valid value is 1
------------------------	---------------------------------------

This page is intentionally blank.

## Chapter 7

# IPV4 Basic Protocols

---

### Table of Contents

address.....	90
arp timeout .....	91
clear arp .....	91
clear ip traffic-statistics .....	92
clear tcp connect.....	92
clear tcp line.....	93
clear tcp statistics.....	93
clear tcp tcb .....	93
clear tcp tty.....	93
clear tcp vty .....	94
detect loop-time.....	94
detect option .....	94
detect try-times .....	95
detcet time-out.....	95
detect-group.....	96
detect-list.....	96
ip address .....	97
ip forwarding-mode .....	97
ip load-sharing.....	98
ip local policy route-map .....	99
ip mtu.....	99
ip policy route-map.....	100
ip proxy-arp.....	100
ip redirect .....	101
ip route.....	101
ip source-route .....	102
ip stream cache.....	103
ip stream enable .....	104
ip stream export.....	104
ip tcp finwait-time .....	105
ip tcp queuemax .....	106
ip tcp synwait-tim.....	106
ip tcp window-size .....	107
ip unnumbered.....	107
ip unreachable .....	108
netflow-sample-rate.....	108
ntp authenticate.....	109
ntp authentication-key .....	109
ntp enable .....	110
ntp server .....	110
ntp source .....	111
ntp trusted-key .....	111
ping.....	111
ping mng .....	113
ping mpls .....	113
set arp .....	114

show arp .....	115
show detect-group.....	116
show ip forwarding .....	117
show ip protocol routing .....	117
show ip protocol routing summary .....	118
show ip route.....	118
show ip traffic .....	119
show ntp status.....	120
show tcp .....	120
show tcp brief .....	121
show tcp config .....	121
show tcp line .....	121
show tcp statistics .....	122
show tcp tcb .....	122
show tcp tty .....	123
show tcp vty .....	124
show vlan-forwarding.....	124
trace.....	125
trace mpls .....	125
vlan arp-mode .....	126
vlan-forwarding .....	127

## address

**Function** Use this command to configure the IP address range of subnet segment in multi-net segment pool. Delete IP address range with no command.

**Command Mode** NAT address pool configuration

**Syntax** **address** <start-address> <end-address>  
**no address** <start-address> <end-address>

**Syntax Description**

<start-address>	The start address of subnet segment in NAT multi-net segment pool, in dotted decimal notation.
<end-address>	The end address of subnet segment in NAT multi-net segment pool, in dotted decimal notation.

**Example** This example describes how to configure two subnet segments in NAT multi-net segment pool. The <start-address> and <end-address> of one .sub-network segment are 70.70.70.1, 70.70.70.10 respectively. Those of another subnet segment are 80.80.80.1 and 80.80.80.5.

```
ZXR10(config)#ip nat multipool zte prefix-length 24
ZXR10(config-ipnat-pool)#address 70.70.70.1 70.70.70.10
ZXR10(config-ipnat-pool)#address 80.80.80.1 80.80.80.5
```

**Related Command** **ip nat multipool**

# arp timeout

**Function** Use this command to configure the ARP entry aging time in the ARP buffer. Restore the default ARP entry aging time with the no command.

**Command Mode** Interface configuration mode

**Syntax** **arp timeout** <timeout>  
**no arp timeout**

**Syntax Description**

<timeout>	Aging time of the ARP entry in the ARP buffer in second, ranging 1 ~ 2147483. 300 seconds on switches by default, and 600 seconds on routers by default
-----------	---

**Instruction** This command is ignored on non-Ethernet interfaces. The show **running-config** command shows the ARP aging time configured on the Ethernet interface.

**Example** This example describes how to configure the ARP aging time of interface fei\_1/1 to 1200s.

```
ZXR10(config)#interface fei_1/1  
ZXR10(config-if)#arp timeout 1200
```

# clear arp

**Function** Use this command to delete the ARP entry bound in the ARP cache of the specified Ethernet interface.

**Command Mode** Privileged mode

**Syntax** **clear arp-cache** [**interface** <interface-name>][**dynamic** | **static** | **permanent** | <ip-address>]

**Syntax Description**

<b>interface</b>	Delete ARP entry from specified interface
<b>interface</b> <interface-name>	Specified interface name
<b>dynamic</b>	Deletes dynamic ARP entry
<b>static</b>	Deletes the statically bound ARP entry
<b>permanent</b>	Deletes the permanent bound ARP entry
<ip-address>]	IP address in the dotted decimal notation

**Example** This example describes how to delete the statically bound ARP entry on the fei\_1/1 interface.

```
ZXR10#clear arp in fei_1/1 permanent
```

**Related Commands** **set arp**  
**show arp**

## clear ip traffic-statistics

**Function** Use this command to clear the statistics on IP transmission.

**Command Mode** Privileged

**Syntax** **clear ip traffic-statistics**

**Example** This example describes how to clear the statistics on IP transmission.

```
ZXR10#clear ip traffic-statistics
```

**Related Command** **show ip traffic**

## clear tcp connect

**Function** Use this command to clear TCP connections, including Telnet, FTP and BGP connections.

**Command Mode** Privileged

**Syntax** **clear tcp connect** [**mng** | **vrf** <vrf-name>] <local-host-address> <local-port> <remote-ip-address> <remote-port>

**Syntax Description**

<b>mng</b>	The local IP address is the address of the management port. There is no such parameter in the ZXR10 GAR.
<b>vrf</b> <vrf-name>	VRF of the IP address, 1 ~ 16 characters
<local-host-address>	Local IP address in the dotted decimal notation
<local-port>	Local port number, 1 ~ 65535
<remote-ip-address>	Remote IP address in the dotted decimal notation
<remote-port>	Remote port number, 1 ~ 65535

**Example** This example describes how to clear the Telnet connections.

```
ZXR10#clear tcp connect 168.1.168.168 23 168.1.16.140 1456
```

## clear tcp line

<b>Function</b>	Use this command to clear TCP connection, but only clear Telnet connection.			
<b>Command Mode</b>	Privileged			
<b>Syntax</b>	<b>clear tcp line</b> <i>&lt;line-number&gt;</i>			
<b>Syntax Description</b>	<table><tr><td><i>&lt;line-number&gt;</i></td><td>Ranges 66 ~ 81</td></tr></table>		<i>&lt;line-number&gt;</i>	Ranges 66 ~ 81
<i>&lt;line-number&gt;</i>	Ranges 66 ~ 81			
<b>Example</b>	This example describes how to clear the Telnet connection. ZXR10#clear tcp line 66			

## clear tcp statistics

<b>Function</b>	Use this command to clear TCP statistic information.
<b>Command Mode</b>	Privileged
<b>Syntax</b>	<b>clear tcp statistics</b>
<b>Example</b>	This example describes how to clear TCP statistic information. ZXR10#clear tcp statistics

## clear tcp tcb

<b>Function</b>	Use this command to clear TCP connections, including Telnet, FTP and BGP connections.			
<b>Command Mode</b>	Privileged			
<b>Syntax</b>	<b>clear tcp tcb</b> <tcb-address>			
<b>Syntax Description</b>	<table><tr><td>&lt;tcb-address&gt;</td><td>Ranges 0 ~ 4294967295</td></tr></table>		<tcb-address>	Ranges 0 ~ 4294967295
<tcb-address>	Ranges 0 ~ 4294967295			
<b>Example</b>	This example describes how to clear TCP connections. ZXR10#clear tcp tcb 3261896			

## clear tcp tty

	Use this command to clear the Telnet connection only.
<b>Command Mode</b>	Privileged
<b>Syntax</b>	<b>clear tcp tty</b> <tty-number>

**Syntax Description**

&lt;tty-number&gt;

Ranges 66 ~ 81

**Example** This example describes how to clear the Telnet connection.

```
ZXR10#clear tcp tty 66
```

## clear tcp vty

**Function** Use this command to clear the Telnet connection, but only clear Telnet connection**Command mode** Privileged mode**Syntax** **clear tcp vty** <vty-number>**Syntax Description**

&lt;vty-number&gt;

Ranges 0 ~ 3

**Example** This example describes how to clear the Telnet connection.

```
ZXR10#clear tcp vty 0
```

## detect loop-time

**Function** Use this command to set the automatic detect loop-time. That is to say detect all objects at certain interval.**Command Mode** Detect group configuration**Syntax** **loop-time** <loop-time>**no loop-time****Syntax Description**

&lt;loop-time&gt;

In unit of seconds, in the range of 1-86400.  
By default, it is 15 seconds.**Example** This example describes how to configure the loop time as 10 seconds.

```
ZXR10(config)#detect-group 1
ZXR10(config-detect)#loop-time 10
```

## detect option

**Function** Use this command to set the logic relationship between objects to detect in automatic detect group.**Command Mode** Detect group configuration



**Syntax** **option {and | or}**

**Syntax Description**

<b>and</b>	When the relationship between detect objects is and: if can not PING to one IP, the detect group is unreachable, other IP addresses will not be detected
<b>or</b>	When the relationship is or, if PING one IP address, then the detect group is reachable, other IP addresses will not be detected

**Instruction** The default relationship is and. Recover the relationship between objects to detect to the default value with no command.

**Example** This example describes how to set the relationship between objects to detect to or.

```
ZXR10(config)#detect-group 1 ZXR10(config-detect)#option or
```

## detect try-times

**Function** Use this command to set the maximum retry times in one detect of the detect group.

**Command Mode** Detect group configuration

**Syntax** **try-times <try-times>**  
**no try-times**

**Syntax Description**

<b>&lt;try-times&gt;</b>	Retry times in one detect, in the range of 010
--------------------------	--

**Instruction** The default value is 2. Set the maximum retry times to 2 with no command.

**Example** This example describes how to set the maximum retry times of detect group to 8.

```
ZXR10(config)#detect-group 1
ZXR10(config-detect)#try-times 8
```

## detcet time-out

**Function** Use this command to set the detect time-out limit.

**Command Mode** Detect group configuration

**Syntax** **time-out <time-out>**

**Syntax Description**

<b>time-out</b>	Time-out time(in seconds), in the range of 0-86400. By default, it is 15 seconds.
-----------------	---

**Instruction** The default value is 15s. Set the detect group to default time-out time.

**Example** This example describes how to set the time-out time of detect group to 8 seconds.

```
ZXR10(config)#detect-group 1
ZXR10(config-detect)#time-out 8
```

## detect-group

**Function** Use this command to enter detect group configuration mode. Create detect. Delete configuration related to detect group with no command.

**Command Mode** Detect group configuration

**Syntax** **detect-group** <group-number>  
**no detect-group** <group-number>

**Syntax Description**

<group-number>	Detect number group, in the range of 1~10
----------------	---

**Example** This example describes how to enter the detect group 1.

```
ZXR10(config)#detect-group 1
```

## detect-list

**Function** Use this command to set IP addresses to detect and the detect order.

**Command Mode** Detect group configuration

**Syntax** **detect-list** <list-number> <ip-address> <next-hop-address>  
**no detect-list**

**Syntax Description**

<list-number>	Serial numbers of IP addresses in detect group, the range relates to device
<ip-address>	Automatically detected Ip addresses
<next-hop-address>	Specify an IP address in the next hop automatically detect(the start address of automatic detect)

**Example** This example describes how to configure IP address of serial number 2 in detect group to 1.1.1.1, the next hop address is 2.2.2.2.

```
ZXR10(config)#detect-group 1
ZXR10(config-detect)#detect-list 2 1.1.1.1 2.2.2.2
```

# ip address

**Function** Use this command to configure the interface IP address of the interface. Delete the interface IP address with the no command.

**Command Mode** Interface configuration

**Syntax** **ip address** <ip-address> <net-mask> [<broadcast-address>] [**secondary**]

**no ip address** [<ip-address> <net-mask>]

**Syntax Description**

<ip-address>	IP address in the dotted decimal notation
<net-mask>	IP subnet mask in the dotted decimal notation
<broadcast-address>	Broadcast address correlated with this interface, in dotted decimal notation.
<b>secondary</b>	Secondary address of the interface

**Default** The interface is not configured with any IP address.

- Instructions**
- <broadcast-address> means the interface associated broadcast address that is used for forwarding broadcast datagram directly, and a broadcast route will be added in the routing table. By default, the subnet.ones/32 broadcast route is added in the routing table.
  - <broadcast-address> may be one of 255.255.255.255, subnet.ones, subnet.zeros and 0.0.0.0, and the others are ignored. When it is 255.255.255.255 or subnet.ones, the subnet.ones/32 broadcast route is added into the routing table, which is the same as the default case. When it is subnet.zeros or 0.0.0.0, the subnet.zeros/32 and subnet.ones/32 are regarded as the broadcast routes and added into the routing table.
  - **secondary** is used to indicate that the configured interface address is a secondary address. If the parameter is not attached, the configured interface address is the primary address of the interface. One interface can be configured with only one primary address but with several secondary addresses.
  - In the no command, the parameters are optional. If there is no parameter, all the configured interface addresses of this interface will be deleted.

**Example** This example describes how to set the fei\_1/1 interface IP address to 168.1.10.100 and the subnet mask to 255.255.0.0.

```
ZXR10(config)#interface fei_1/1
ZXR10(config-if)#ip address 168.1.10.100 255.255.0.0
```

# ip forwarding-mode

**Function** Use this command to set the forwarding mode of the interface.

**Command Mode** Interface configuration

**Syntax** **ip forwarding-mode** {**vlan-switch** | **normal** | **mix**}  
**no ip forwarding-mode**

**Syntax Description**

<b>vlan-switch</b>	The IP packets on the interface are forwarded through V_switch The IP packets on the interface are forwarded through IP routing Both modes are supported on the interface
<b>normal</b>	The IP packets on the interface are forwarded through IP routingBoth modes are supported on the interface
<b>mix</b>	

- Instructions**
- In case of the mix mode, packets are forwarded through V\_switch first, and then through IP routing if the forwarding fails.
  - It is applicable only to ZXR10 GER.

**Related Command** **vlan-forwarding ingress**

## ip load-sharing

**Function** Use this command to implement load balancing, also known as load sharing in packet forwarding. Set the policies for load balancing on the interface. Remove the policies with the no command.

**Command Mode** Interface configuration

**Syntax** **ip load-sharing** {**per-destination** | **per-packet**}  
**no ip load-sharing per-packet**

**Syntax Description**

<b>per-destination</b>	Performs load balancing on destination addresses of packets
<b>per-packet</b>	Performs load balancing on the number of datagrams in the packets

- Instructions**
- Load balancing on the destination address of the packets ensures the packets to the same destination use the same path. However, when there are only a limited number of destination addresses, the traffic may concentrate on a few number of paths. Load balancing on the number of datagram can make a full use of bandwidth, but it can not ensure the arrival sequence of the datagram.
  - To implement load balancing on the number of datagram, all interfaces (that can forward the packets to the same destination address) shall be set with ip load-sharing per-packet. Otherwise, load sharing is based on the destination addresses of packets.

- Example** ■ This example describes how to perform load balancing on the number of diagrams on interface fei\_1/1.

```
ZXR10(config)#interface fei_1/1
ZXR10(config-if)# ip load-sharing per-packet
```

- This example describes how to perform load balancing on the destination addresses of packets on interface fei\_1/1.

```
ZXR10(config)#interface fei_1/1
ZXR10(config-if)# ip load-sharing per-destination
```

**Related Command** **ip route**

## ip local policy route-map

**Purpose** Use this command to set local policy route.

After setting local policy route but not route-map, all local PING and TRACE packets will be transmitted by local policy route.

Cancel local policy route with the **no** command.

**Command Modes** Global configuration

**Syntax** **ip local policy route-map** <map-tag>

**no ip local policy route-map**

**Syntax Description**

<map-tag>	route-map name, in length of 1~16 characters
-----------	--

- Instructions** ■ After setting local policy route but not route-map, all local PING and TRACE packets will be transmitted by local policy route.
- Only the platform version 4.8.22 supports this command.

**Example** This example describes how to set ip local policy route-map named rmp1.

```
ZXR10(config)# ip local policy route-map rmp1
ZXR10(config)# no ip local policy route-map
```

**Related Commands** **route-map**

## ip mtu

**Purpose** Use this command to configure the MTU value of the IP packets that the interface can process. Restore the default MTU value with the **no** command.

**Command Modes** Interface configuration

**Syntax** **ip mtu** <bytes>

**ip mtu**

**Syntax Description**

<i>&lt;bytes&gt;</i>	MTU of the interface in byte, ranging 128 ~ 1500, 1500 by default
----------------------	---

**Instructions** Every interface has a default MTU, 1,500 bytes by default. The tunnel interface has a default value of 1,476. The MTU value may vary with the network segment. To avoid fragmentation and improve network performance, the **ip mtu** command can be used to change the MTU value.

**Example** This example describes how to configure the MTU value of the fei\_1/1 interface to 1,000.

```
ZXR10(config)#interface fei_1/1
ZXR10(config-if)#ip mtu 1000
```

## ip policy route-map

**Function** Use this command to configure policy route-based fast forwarding for the incoming packets on the interface. Cancel the policy route-based fast forwarding with the no command.

**Command Mode** Interface configuration

**Syntax** **ip policy route-map** *<map-tag>*

**no ip policy route-map**

**Syntax Description**

<i>&lt;map-tag&gt;</i>	Name of the route map, 1 ~ 16 characters
------------------------	--

**Instruction** The route is mapped to the interface through binding. When the incoming packet is to be forwarded, firstly the route map is matched. And policy route forwarding is performed according to the result of the route map matching. If the route map cannot be matched, normal routing based on the destination address is performed.

**Example** This example describes how to bind the route map named rmp1 to the fei\_1/1 interface.

```
ZXR10(config)#interface fei_1/1
ZXR10(config-if)#ip policy route-map rmp1
```

**Related Command** **route-map**

## ip proxy-arp

**Function** Use this command to enable the ARP proxy on the port. Disable such function with the no command.

**Command Mode** Interface configuration

**Syntax** **ip proxy-arp**

**no ip proxy-arp**

**Defaults** ARP proxy is disabled.

**Instruction** If ARP proxy is enabled on an interface, it is better to configure ARP source address filtering at the same time to filter ARP packets of different network segments. Show running-config can display the setting of the interface. The default setting will not be displayed.

**Example** This example describes how to enable ARP proxy on the fei\_1/1 interface.

```
ZXR10(config)#interface fei_1/1
ZXR10(config-if)#ip proxy-arp
```

**Related Command** **show run**

## ip redirect

**Function** Use this command to enable the router to transmit redirecting packets. Disable the function with the no command.

**Command Mode** Interface configuration

**Syntax** **ip redirect**  
**no ip redirect**

**Defaults** Enabled

**Instruction** The route may not be optimized enough. For example, the router may be forced to forward a packet through the same receiving port. In this case, the router software sends an ICMP redirecting message to the packet sender and tells it to send the packet to another router in the same subnet.

**Example** This example describes how to enable the router to transmit redirecting packets function on the fei\_1/1 interface.

```
ZXR10 (config) # interface feie_6/1
ZXR10(config-if)#ip redirect
```

## ip route

**Function** Use this command to set up a static route. Delete the static route with the no command.

**Command Mode** Global configuration

**Syntax** **ip route** [**mng** | **vrf** <vrf-name>]<prefix><net-mask>{<forwarding-router's-address>|<interface-name>}[<distance-metric>][**tag** <tag>][**global**]  
**no ip route** [**vrf** <vrf-name>]<prefix><net-mask>[<distance-metric>][**tag** <tag>]

**Syntax  
Description**

<b>mng</b>	Configure the static route in management interface
<b>vrf</b> <vrf-name>	Name of the specified VRF where the static route is, 1 ~ 16 characters. The ZXR10 3900/3200 does not provide this parameter
<prefix>	Prefix of IP address in the dotted decimal notation
<net-mask>	Network mask in the dotted decimal notation
<forwarding-router's-address>	Next-hop IP address in the dotted decimal notation
<interface-name>	Name of the interface
<distance-metric>	Administrative distance, 1 ~ 255
<b>tag</b> <tag>	Tag value, used as the match value and to control the route re-allocation, 150 ~ 255, 3 by default
<b>global</b>	Specify global static route

**Instructions**

- <distance-metric> is equivalent to the priority of the routing protocol. The smaller it is, the higher the priority. By default, the priority of static routes is higher than that of dynamic routes. However, it can be configured that the dynamic router has higher priority.
- <tag> corresponds to the tag value in the IP routing table of the routing protocol, 3 by default. Two static routes to the same destination network (with different next hop addresses) cannot have the same tag value.

**Example**

- This example describes how to route the packets sent to the network 131.108.0.0 to the router of 131.108.6.6.

```
ZXR10(config)#ip route 131.108.0.0 255.255.0.0 131.108.6.6
```

- This example describes how to set the administrative distance of static route to 110. In this way, if dynamic route with management distance is less than 110 administrative distance cannot be obtained; the packets sent to the network 10.0.0.0 will be routed to the router 131.108.3.4.

```
ZXR10(config)#ip route 10.0.0.0 255.0.0.0 131.108.3.4 110
```

## ip source-route

**Function**

Use this command to set the router to handle packets with IP source route options. Discard the packets with the IP source route options with the no command.

**Command Mode**

Global configuration

**Syntax**

**ip source-route**



**no ip source-route****Defaults** Enabled

- Instruction**
- The router checks the IP header option of every packet and supports such header options as Strict Source Route, Loose Source Route, and Record Route and Time stamp. If the software finds that one of the options is valid, it will execute the proper operation. If it finds the packet with invalid option, it will send an ICMP parameter problem message to the source of the packet and discard the packet.
  - The IP allows the source host to pre-specify a path through the IP network, which is called source route. If the source route is specified, the software will forward the packet according the specified source path. When it is required to force a packet to go through a specified path, this function can be used. By default, the packets are processed according to the source route.

**Example** This example describes how to enable the processing of the IP packets with the source route header option.

```
ZXR10(config)#ip source-route
```

## ip stream cache

**Function** Use this command to set the ip stream cache parameter, including cache size, flow active and inactive aging time.

**Command Mode** Global configuration

**Syntax** **ip stream cache** {**entries** <size> | **timeout** {**active** <minute> | **in\_active** <10-600>}}

**no ip stream cache** {**entries** | **timeout** {**active** | **in\_active**}}

**Syntax Description**

<b>entries</b>	Configure the size of ip stream cache
<size>	The size of cache, the unit is number of stream records, ranging 1024-65535. 4096 by default
<b>timeout</b>	Set the active time and inactive time of stream records in ip stream cache
<b>active</b> <minute>	Set the active time and inactive time of stream records in ip stream cache, unit is minute, ranging 1-60, 30 by default
<b>in_active</b> <second>	Set the active time and inactive time of stream records in ip stream cache, unit is second, 15 by default

- Instructions**
- This command is only supported by ZXR10 T128 and ZXR10 T1200.
  - After ip stream cache entries are upgraded, it will not take effect immediately. It takes effect after ip stream is enabled. Recover to the default value with no command.

- Example** ■ This example describes how to configure the ip stream cache size to 2048 stream records.

```
ZXR10(config)#ip stream cache entries 2048
```

- This example describes how to configure the active aging time of stream record to 45 minutes.

```
ZXR10(config)#ip stream cache timeout active 45
```

- This example describes how to configure the active aging time of stream record to 60 seconds.

```
ZXR10(config)#ip stream timeout in_active 60
```

## ip stream enable

- Function** Use this command to enable IP stream sampling function.
- Command Mode** Global configuration
- Syntax** **ip stream enable**
- Instruction** This command is only supported by ZXR10 T128 and ZXR10 T1200.
- Example** ■ This example describes how to enable IP stream sampling function.
- ```
ZXR10(config)#ip stream enable
```
- This example describes how to disable IP stream sampling function.
- ```
ZXR10(config)#no ip stream enable
```

## ip stream export

- Function** Use this command to set ip stream export, including collector address and communication port, ip stream version and v9 template output parameter
- Command Mode** Global configuration
- Syntax** **ip stream export** {**destination** <des-ipaddress><udp port number>| **source** <source-ipaddress>| **template** {**refresh-rate** <1-600>| **timeout-rate** <minute>}| **version** <version number>}
- no ip stream export** {**destination** <des-ipaddress>|<source-ip address>| **template** {**refresh-rate** | **timeout-rate**}| **version**}

**Syntax Description**

<b>destination</b>	Configure the collector address and communication port of ip stream
<des-ipaddress>	Configure the collector address and of ip stream
<udp port number>	Configure remote port of collector UDP of ip stream, in the range of <1-65535>

<code>&lt;source-ipaddress&gt;</code>	Configure source address of ip stream
<b>A.B.C.D</b>	Configure source address of ip stream
<b>template</b>	Configure ip stream v9 template output mode
<b>refresh-rate</b> <code>&lt;1-600&gt;</code>	Refresh template by number of sent messages, , in the range of <1-600>, 20 by default
<b>timeout-rate</b> <code>&lt;minute&gt;</code>	Refresh template by interval, unit: minute, in the range of <1-3600>, 30 minutes by default
<b>version</b>	Configure ip stream version
<code>&lt;version number&gt;</code>	If 5 is set, the version is v5, if 9 is set the version is v9. Only these two versions are supported.

**Instructions** ■ This command is only supported by ZXR10 T128 and ZXR10 T1200.

- Two values can be configured in ip stream export destination, distinguished by address. If addresses are same, configure udp port to update the remote communication port.
- Recover the default value for ip stream export template with no command.

**Example** ■ This example describes how to set the collector address of ip stream to 10.60.80.99, the communication port is 2056

```
ZXR10(config)#ip stream export destination 10.60.80.99 2056
```

- This example describes how to set the source address of ip stream to 10.60.45.21.

```
ZXR10(config)#ip stream export source 10.60.45.21
```

- This example describes how to set the template of ip stream to be refreshed every 100 messages.

```
ZXR10(config)#ip stream export template refresh-rate 100
```

- This example describes how to set the template of ip stream to be refreshed every 60 minutes.

```
ZXR10(config)# ip stream export template timeout-rate 60
```

- This example describes how to set the version to be v9

```
ZXR10(config)#ip stream export version 9
```

## ip tcp finwait-time

**Function** Use this command to set the wait time for TCP disconnection. Restore the default with the no command.

**Command Mode** Global configuration

**Syntax** **ip tcp finwait-time** `<seconds>`

**no ip tcp finwait-time**

**Syntax Description**

&lt;seconds&gt;

Time to wait for TCP disconnection in second, 300 ~ 600, 600 seconds by default

**Example**

This example describes how to configure the wait time for TCP disconnection to 400 seconds.

```
ZXR10(config)#ip tcp finwait-time 400
```

## ip tcp queuemax

**Function**

Use this command to configure the maximum length of TCP outgoing queue. This command is ineffective for the Telnet that has been established. Restore the default queue length with the no command.

**Command Mode**

Global configuration

**Syntax**

**ip tcp queuemax** <packets>

**no ip tcp queuemax**

**Syntax Description**

&lt;packets&gt;

Number of packets, 5 ~ 50, 5 by default

**Example**

This example describes how to configure the maximum packets in the queue to 40.

```
ZXR10(config)#ip tcp queuemax 40
```

## ip tcp synwait-tim

**Function**

Use this command to configure the wait time for TCP connection attempt. It is effective for subsequent TCP connections to be established. Restore the default with the no command.

**Command Mode**

Global configuration

**Syntax**

**ip tcp synwait-time** <seconds>

**no ip tcp synwait-time**

**Syntax Description**

&lt;seconds&gt;

Time to wait for the connection in second, 30 ~ 80, 30 by default

**Example**

This example describes how to configure the time to wait for a TCP connection to 50 seconds.

```
ZXR10(config)#ip tcp synwait-time 50
```

## ip tcp window-size

<b>Function</b>	Use this command to configure the maximum length of TCP outgoing queue. This command is ineffective for the Telnet that has been established. Restore the default queue length with the no command			
<b>Command Mode</b>	Global configuration			
<b>Syntax</b>	<b>ip tcp queuemax</b> <packets> <b>no ip tcp queuemax</b>			
<b>Syntax Description</b>	<table><tr><td>&lt;packets&gt;</td><td>Number of packets, 5 ~ 50, 5 by default</td></tr></table>		<packets>	Number of packets, 5 ~ 50, 5 by default
<packets>	Number of packets, 5 ~ 50, 5 by default			
<b>Example</b>	This example describes how to configure the maximum packets in the queue to 40.  ZXR10(config)#ip tcp queuemax 40			

## ip unnumbered

<b>Function</b>	Function Use this command to adopt the specified interface IP address as this interface IP address. Cancel this function with the no command.			
<b>Command Mode</b>	Interface configuration			
<b>Syntax</b>	<b>ip unnumbered</b> <interface-name> <b>no ip unnumbered</b>			
<b>Syntax Description</b>	<table><tr><td>&lt;interface-name&gt;</td><td>Name of the interface</td></tr></table>		<interface-name>	Name of the interface
<interface-name>	Name of the interface			
<b>Defaults</b>	Invalid.			
<b>Instructions</b>	<ul style="list-style-type: none"><li>■ The interface may be POS, E1 or serial port and cannot be configured with an IP address.</li><li>■ To configure the IP address for an interface, the <b>no ip unnumbered</b> command must be executed before the <b>ip address</b> command.</li></ul>			
<b>Example</b>	This example describes how to configure the IP address of the fei_1/1 interface (with configured address 168.1.1.1/24) as the address of the pos_3/1. ZXR10(config)#interface pos_3/1  ZXR10(config-if)#ip unnumbered fei 1/1			

# ip unreachable

- Function** Use this command to enable the router interface to send ICMP unreachable packets. Cancel this function with the no command.
- Command Mode** Command Mode Interface configuration
- Syntax** **ip unreachable**  
**no ip unreachable**
- Defaults** Enable
- Instruction** When the router receives a non-broadcast packet that is sent with an unknown protocol, it will return an ICMP unreachable message to the source address. Similarly, if the router receives a packet that cannot be delivered to the destination (route with unknown destination address), it will return an ICMP host unreachable message to the source address.
- Example** This example describes how to enable the fei\_1/1 interface to send ICMP unreachable packets.
- ```
ZXR10(config)#interface fei_1/1
ZXR10(config-if)#ip unreachable
```

# netflow-sample-rate

- Purpose** Use this command to set ip stream sampling rate.
- Command Modes** Interface configuration
- Syntax** **netflow-sample-rate** {**ingress** | **egress**}{**unicast** | **multicast** | **mpls**| **acl** <word>}<number>  
**no netflow-sample-rate** {**ingress** | **egress**}{**unicast** | **multicast** | **mpls** | **acl** <word>}

## Syntax Description

|                                                 |                                                                                           |
|-------------------------------------------------|-------------------------------------------------------------------------------------------|
| <b>ingress</b>   <b>egress</b>                  | Configures the sampling direction of ip stream.                                           |
| <b>unicast</b>   <b>multicast</b>   <b>mpls</b> | Configures the sampling type of ip stream.                                                |
| <b>acl</b> <word>                               | Samples based on ACL(sample when ACL rules are matching.)ACL can be named ACL or numberd. |
| <i>number</i>                                   | Configures the sampling rate of ip stream, in the range of 1~65535.                       |

- Instructions**
- This command is only supported by ZXR10 T128 and ZXR10 T1200.
  - Ip stream sampling can be set in two directions at the same time. The sampling and service in two directions are independent. Services are sampled randomly according to the set sampling rate.

- Only Ethernet and POS port interfaces support this command.

**Example** This example describes how to set the ingress unicast sampling rate on gei\_7/23 to 2000 and set the egress multicast sampling rate to 1000.

```
ZXR10(config)#interface gei_7/23
ZXR10(config-if)#netflow-sample-rate ingress unicast 2000
ZXR10(config-if)#netflow-sample-rate egress multicast 1000
```

## ntp authenticate

|                         |                                                                                                                                                         |
|-------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Function</b>         | Use this command to enable the NTP authentication function. Disable the authentication with the no command.                                             |
| <b>Command mode</b>     | Global configuration mode                                                                                                                               |
| <b>Syntax</b>           | <b>ntp enable</b><br><b>no ntp enable</b>                                                                                                               |
| <b>Instruction</b>      | This command is like the switch of the NTP authentication function. The NTP packets will not be checked with key unless this authentication is enabled. |
| <b>Related Commands</b> | <b>ntp authentication-key</b> <key number> <b>md5</b> <key word><br><b>ntp trusted-key</b> <key number>                                                 |

## ntp authentication-key

|                           |                                                                                                                                                             |              |                                   |            |          |
|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------|-----------------------------------|------------|----------|
| <b>Function</b>           | Use this command to set the NTP authentication key number and corresponding key word. Cancel the key with the no command.                                   |              |                                   |            |          |
| <b>Command Mode</b>       | Global configuration                                                                                                                                        |              |                                   |            |          |
| <b>Syntax</b>             | <b>ntp authentication-key</b> <key number> <b>md5</b> <key word><br><b>no ntp authentication-key</b> < key number >                                         |              |                                   |            |          |
| <b>Syntax Description</b> | <table border="1"><tr><td>&lt;key number&gt;</td><td>Key number, in the range of 1~255</td></tr><tr><td>&lt;key word&gt;</td><td>Key word</td></tr></table> | <key number> | Key number, in the range of 1~255 | <key word> | Key word |
| <key number>              | Key number, in the range of 1~255                                                                                                                           |              |                                   |            |          |
| <key word>                | Key word                                                                                                                                                    |              |                                   |            |          |
| <b>Instruction</b>        | Instruction Use this command to set key number and the corresponding key word. At most 255 check codes can be set.                                          |              |                                   |            |          |
| <b>Related Commands</b>   | <b>ntp authenticate</b><br><b>ntp trusted-key</b> <key number>                                                                                              |              |                                   |            |          |

# ntp enable

|                         |                                                                                                                                  |
|-------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| <b>Function</b>         | Use this command to enable the NTP function. Disable it with the no command.                                                     |
| <b>Command Mode</b>     | Global configuration                                                                                                             |
| <b>Syntax</b>           | <b>ntp enable</b><br><b>no ntp enable</b>                                                                                        |
| <b>Instruction</b>      | This command is like the switch of the NTP function. The other NTP commands cannot be enabled unless this command is configured. |
| <b>Related Commands</b> | <b>ntp server</b><br><b>show ntp status</b>                                                                                      |

# ntp server

|                           |                                                                                                                                                                                                                                                                                                                                                                                                                                    |              |                                                              |                         |                           |                     |                                         |
|---------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------|--------------------------------------------------------------|-------------------------|---------------------------|---------------------|-----------------------------------------|
| <b>Function</b>           | Use this command to configure the IP address and the NTP version number of the time server that needs to synchronize time. Delete the configured time server with the no command.                                                                                                                                                                                                                                                  |              |                                                              |                         |                           |                     |                                         |
| <b>Command Mode</b>       | Global configuration                                                                                                                                                                                                                                                                                                                                                                                                               |              |                                                              |                         |                           |                     |                                         |
| <b>Syntax</b>             | <b>ntp server</b> <ip-address>[ <b>version</b> <number>][ <b>key</b> <number>]<br><b>no ntp server</b> <ip-address>                                                                                                                                                                                                                                                                                                                |              |                                                              |                         |                           |                     |                                         |
| <b>Syntax Description</b> | <table border="1"> <tr> <td>&lt;ip-address&gt;</td><td>IP address of the time server in the dotted decimal notation</td></tr> <tr> <td><b>version</b> &lt;number&gt;</td><td>NTP version number, 1 ~ 3</td></tr> <tr> <td><b>key</b> &lt;number&gt;</td><td>Valid key number, in the range of 1~255</td></tr> </table>                                                                                                             | <ip-address> | IP address of the time server in the dotted decimal notation | <b>version</b> <number> | NTP version number, 1 ~ 3 | <b>key</b> <number> | Valid key number, in the range of 1~255 |
| <ip-address>              | IP address of the time server in the dotted decimal notation                                                                                                                                                                                                                                                                                                                                                                       |              |                                                              |                         |                           |                     |                                         |
| <b>version</b> <number>   | NTP version number, 1 ~ 3                                                                                                                                                                                                                                                                                                                                                                                                          |              |                                                              |                         |                           |                     |                                         |
| <b>key</b> <number>       | Valid key number, in the range of 1~255                                                                                                                                                                                                                                                                                                                                                                                            |              |                                                              |                         |                           |                     |                                         |
| <b>Instructions</b>       | <ul style="list-style-type: none"> <li>At present, the time can be synchronized from only one time server. If multiple commands are configured, the new command will overwrite the previous one. The last key is valid. If no key is set, the enabled authentication is invalid.</li> <li>After the configuration of this command, configure the ntp enable command to start time synchronization from the time server.</li> </ul> |              |                                                              |                         |                           |                     |                                         |
| <b>Related Commands</b>   | <b>ntp enable</b><br><b>show ntp status</b>                                                                                                                                                                                                                                                                                                                                                                                        |              |                                                              |                         |                           |                     |                                         |



## ntp source

|                    |                                                                                                                                      |              |                                                              |  |
|--------------------|--------------------------------------------------------------------------------------------------------------------------------------|--------------|--------------------------------------------------------------|--|
| Function           | Use this command to set ntp protocol sending message source address. Delete protocol sending message source address with no command. |              |                                                              |  |
| Command Mode       | Global configuration                                                                                                                 |              |                                                              |  |
| Syntax             | <b>ntp source</b> <ip-address><br><b>no ntp source</b> <ip-address>                                                                  |              |                                                              |  |
| Syntax Description | <table><tr><td>&lt;ip-address&gt;</td><td>Source address of NTP packets in the dotted decimal notation</td></tr></table>             | <ip-address> | Source address of NTP packets in the dotted decimal notation |  |
| <ip-address>       | Source address of NTP packets in the dotted decimal notation                                                                         |              |                                                              |  |
| Related Commands   | <b>ntp enable</b><br><b>ntp server</b><br><b>show ntp status</b>                                                                     |              |                                                              |  |

## ntp trusted-key

|                           |                                                                                                                                                                                                               |  |                           |                                   |
|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|---------------------------|-----------------------------------|
| <b>Function</b>           | Use this command to set ntp trusted key. Delete ntp trusted key with no command.                                                                                                                              |  |                           |                                   |
| <b>Command Mode</b>       | Global configuration                                                                                                                                                                                          |  |                           |                                   |
| <b>Syntax</b>             | <b>ntp trusted-key</b> <i>&lt;key number&gt;</i><br><b>no ntp trusted-key</b> <i>&lt;key number&gt;</i>                                                                                                       |  |                           |                                   |
| <b>Syntax Description</b> | <table><tr><td><i>&lt;key number&gt;</i></td><td>Key number, in the range of 1~255</td></tr></table>                                                                                                          |  | <i>&lt;key number&gt;</i> | Key number, in the range of 1~255 |
| <i>&lt;key number&gt;</i> | Key number, in the range of 1~255                                                                                                                                                                             |  |                           |                                   |
| <b>Instruction</b>        | More than one trusted keys can be set. At most 255 trusted keys can be set. Only after set keys, which have been set by <b>ntp authentication-key</b> , to trusted keys, the authentication will not be valid |  |                           |                                   |
| <b>Related Command</b>    | <b>ntp authenticate</b>                                                                                                                                                                                       |  |                           |                                   |

## ping

|                     |                                                                                                                                                                                                                                                                                                                                                                                 |  |
|---------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| <b>Function</b>     | Check the reachability and connectivity of the host.                                                                                                                                                                                                                                                                                                                            |  |
| <b>Command Mode</b> | Exec mode / privileged                                                                                                                                                                                                                                                                                                                                                          |  |
| <b>Syntax</b>       | <b>ping</b> [ <b>vrf</b> <vrf-name>] <ip-addr> [ <b>option</b> { <b>repeat</b> <repeat-count>   <b>size</b> <datagram-size>   <b>timeout</b> <timeout>   <b>source</b> <source-address>   <b>tos</b> <tos>   <b>ttl</b> <tll>   <b>df-bit</b>   <DON'T-FRAG>   <b>limit</b> <limit>   <b>pattern</b> <pad> } } [ <b>extcom</b> { { <b>loose</b>   <b>strict</b> } } { <source-r |  |

*oute-IP-address>}* | **record** *<record-hops>* | **timestamp** *<record-timestamps>* | **none** } }

### Syntax Description

|                                                                |                                                                      |
|----------------------------------------------------------------|----------------------------------------------------------------------|
| <b>&lt;key number&gt;</b>                                      | IP address of the host to be checked, in the dotted decimal notation |
| <b>vrf</b> <i>&lt;vrf-name&gt;</i>                             | VRF of the IP address, 1 ~ 16 characters                             |
| <b>repeat</b> <i>&lt;repeat-count&gt;</i>                      | Times of repeated tests, 1 ~ 4294967295, 5 by default                |
| <b>size</b> <i>&lt;datagram-size&gt;</i>                       | Size of the Ping packet, 36 ~ 8192 bytes, 100 by default             |
| <b>timeout</b> <i>&lt;timeout&gt;</i>                          | Timeout in second, 1 ~ 60                                            |
| <b>source</b> <i>&lt;source-address&gt;</i>                    | Source address in the dotted decimal notation                        |
| <b>tos</b> <i>&lt;tos&gt;</i>                                  | Service type of the packet to be sent, 0 ~ 255, 0 by default         |
| <b>ttl</b> <i>&lt;ttl&gt;</i>                                  | ttl value, 1 ~ 255                                                   |
| <b>df-bit</b> <i>&lt;don't-frag&gt;</i>                        | Fragment tag, 0 or 1. 0 by default, which means no fragment          |
| <b>pattern</b> <i>&lt;pad&gt;</i>                              | The pad field value in message                                       |
| <b>limite</b> <i>&lt;limite-num&gt;</i>                        | Number of packets sent in one second                                 |
| <b>option</b>                                                  | Whether to set IP option, when 1 is set, IP option can be set        |
| <b>none</b>                                                    | No IP option is necessary, and it is the default value               |
| <b>{loose   strict}</b> <i>&lt;source-route-IP-address&gt;</i> | Specified source site routing path, in the dotted decimal notation   |
| <b>record</b> <i>&lt;record-hops&gt;</i>                       | Maximum number of routes to be recorded, 1 ~ 9, 9 by default         |
| <b>timestamp</b> <i>&lt;record-timestamps&gt;</i>              | Maximum timestamps to be recorded, 1 ~ 9                             |

**Instruction** The ping command will send the ICMP Echo packet. If the destination receives an ICMP Echo message, it will send an ICMP Echo Reply message to the source address of the Echo message. As a result, this command is used to diagnose network interconnection.

**Example** This example describes how to check whether 168.1.10.10 is reachable.

```
ZXR10#ping 168.1.10.100
sending 5,100-byte ICMP echos to 168.1.10.100,timeout is 2 seconds.
!!!!!!
Success rate is 100 percent (5/5),round-trip min/avg/max= 0/8/20 ms.
```

## ping mng

|                           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                           |                                                                                       |
|---------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------|---------------------------------------------------------------------------------------|
| <b>Function</b>           | Use this command to check the reachability and interconnection of the system management interface.                                                                                                                                                                                                                                                                                                                                                                                                                   |                           |                                                                                       |
| <b>Command Mode</b>       | Exec mode / privileged                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |                           |                                                                                       |
| <b>Syntax</b>             | For exec mode, <b>ping mng</b> <i>&lt;ip-address&gt;</i><br>For privileged mode, <b>ping mng</b> <i>&lt;ip-address&gt;</i> [ <b>option</b> <i>&lt;repeat-count&gt;</i> <i>&lt;datagram-size&gt;</i> <i>&lt;timeout&gt;</i> ]                                                                                                                                                                                                                                                                                         |                           |                                                                                       |
| <b>Syntax Description</b> | <table border="1"> <tr> <td><i>&lt;ip-address&gt;</i></td><td>IP address of the management interface to be checked, in the dotted decimal notation.</td></tr> </table>                                                                                                                                                                                                                                                                                                                                               | <i>&lt;ip-address&gt;</i> | IP address of the management interface to be checked, in the dotted decimal notation. |
| <i>&lt;ip-address&gt;</i> | IP address of the management interface to be checked, in the dotted decimal notation.                                                                                                                                                                                                                                                                                                                                                                                                                                |                           |                                                                                       |
| <b>Instructions</b>       | <ul style="list-style-type: none"> <li>The ping mng command will send the ICMP Echo packet to the management interface. If the destination receives an ICMP Echo message, it will send an ICMP Echo Reply message to the source address of the Echo message. As a result, this command is used to diagnose the interconnection problems of the router management interface.</li> <li>Since the management interface of ZXR10 GAR participates in the forwarding, ZXR10 GAR does not support this command.</li> </ul> |                           |                                                                                       |
| <b>Example</b>            | <p>This example describes how to check whether the 192.168.0.1 management interface is reachable.</p> <pre>ZXR10#ping mng 192.168.0.1 sending 5,100-byte ICMP echos to 168.1.10.100,timeout is 2 seconds. !!!!!! Success rate is 100 percent (5/5),round-trip min/avg/max= 0/8/20 ms.</pre>                                                                                                                                                                                                                          |                           |                                                                                       |

## ping mpls

|                                           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |                           |                            |                                  |                                           |                      |             |                                 |                |                                           |                                                                 |
|-------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------|----------------------------|----------------------------------|-------------------------------------------|----------------------|-------------|---------------------------------|----------------|-------------------------------------------|-----------------------------------------------------------------|
| <b>Function</b>                           | Use this command to check the connectivity of LDP of IPv4 and LSP of RSVP.                                                                                                                                                                                                                                                                                                                                                                                                                   |                           |                            |                                  |                                           |                      |             |                                 |                |                                           |                                                                 |
| <b>Command Mode</b>                       | Privileged                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |                           |                            |                                  |                                           |                      |             |                                 |                |                                           |                                                                 |
| <b>Syntax</b>                             | <b>ping mpls</b> { <b>ipv4</b> <i>&lt;ip-address&gt;</i> <i>&lt;destination-mask&gt;</i>   <b>pseudowire</b> <i>&lt;ip-address&gt;</i> <i>&lt;vc-id&gt;</i>   <b>traffic-eng</b> <i>&lt;tunnel-interface&gt;</i> } [ <b>repeat</b> <i>&lt;repeat-count&gt;</i> ] [ <b>size</b> <i>&lt;datagram-size&gt;</i> ] [ <b>timeout</b> <i>&lt;timeout&gt;</i> ]                                                                                                                                      |                           |                            |                                  |                                           |                      |             |                                 |                |                                           |                                                                 |
| <b>Syntax Description</b>                 | <table border="1"> <tr> <td><i>&lt;ip-address&gt;</i></td><td>Destination address prefix</td></tr> <tr> <td><i>&lt;destination-masks&gt;</i></td><td>Subnet mask length of destination address</td></tr> <tr> <td><i>&lt;vc-id&gt;</i></td><td>vc-id of VC</td></tr> <tr> <td><i>&lt;tunnel-interface&gt;</i></td><td>MPLS TE tunnel</td></tr> <tr> <td><b>repeat</b> <i>&lt;repeat-count&gt;</i></td><td>Number of repeated tests, in the range of 1~65535, 5 by default</td></tr> </table> | <i>&lt;ip-address&gt;</i> | Destination address prefix | <i>&lt;destination-masks&gt;</i> | Subnet mask length of destination address | <i>&lt;vc-id&gt;</i> | vc-id of VC | <i>&lt;tunnel-interface&gt;</i> | MPLS TE tunnel | <b>repeat</b> <i>&lt;repeat-count&gt;</i> | Number of repeated tests, in the range of 1~65535, 5 by default |
| <i>&lt;ip-address&gt;</i>                 | Destination address prefix                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |                           |                            |                                  |                                           |                      |             |                                 |                |                                           |                                                                 |
| <i>&lt;destination-masks&gt;</i>          | Subnet mask length of destination address                                                                                                                                                                                                                                                                                                                                                                                                                                                    |                           |                            |                                  |                                           |                      |             |                                 |                |                                           |                                                                 |
| <i>&lt;vc-id&gt;</i>                      | vc-id of VC                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |                           |                            |                                  |                                           |                      |             |                                 |                |                                           |                                                                 |
| <i>&lt;tunnel-interface&gt;</i>           | MPLS TE tunnel                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |                           |                            |                                  |                                           |                      |             |                                 |                |                                           |                                                                 |
| <b>repeat</b> <i>&lt;repeat-count&gt;</i> | Number of repeated tests, in the range of 1~65535, 5 by default                                                                                                                                                                                                                                                                                                                                                                                                                              |                           |                            |                                  |                                           |                      |             |                                 |                |                                           |                                                                 |

|                             |                                              |
|-----------------------------|----------------------------------------------|
| <b>size</b> <datagram-size> | Ping mpls packet size                        |
| <b>timeout</b> <timeout>    | Timeout time in second, in the range of 1~60 |

**Example** This example describes how to check whether the specified LDP LSP:173.13.13.8/32 is reachable.

```
ZXR10#ping mpls ipv4 173.13.13.8 32
sending 5,90-byte MPLS echos to 173.13.13.8,timeout is 2 seconds.

Codes: '!' - success,      'Q' - request not transmitted,
        '.' - timeout,     'U' - unreachable,
        'R' - downstream router but not target

!!!!!
Success rate is 100 percent (5/5),round-trip min/avg/max= 0/16/20 ms.
```

## set arp

**Function** Use this command to bind the IP address to the MAC address.

**Command Mode** Interface configuration

**Syntax** **set arp** {**static** | **permanent**}<ip-address><hardware-address><vlanId>

### Syntax Description

|                    |                                                                          |
|--------------------|--------------------------------------------------------------------------|
| <b>static</b>      | Static binding, only valid at present, invalid after switch reset        |
| <b>permanent</b>   | Permanent binding, only valid at present, still valid after switch reset |
| <ip-address>       | IP address in the dotted decimal notation                                |
| <hardware-address> | MAC address in the dotted division format.                               |
| <vlanId>           | VLAN or external VLAN of the configured item                             |
| <internal_vlanId>  | Internal VLAN                                                            |

**Instruction** This command is ignored on non-Ethernet interfaces. The show **running-config** command can show the binding of the IP and MAC address on the Ethernet interface.

**Example** This example describes how to bind IP address 10.1.1.1 to MAC address 000a.010c.e2c6 on the Ethernet interface.

```
ZXR10(config)#interface fei_1/1
ZXR10(config-if)#set arp static 10.1.1.1 000a.010c.e2c6
```

**Related Commands**

**set arp**

**show arp**

# show arp

**Purpose** Use this command to display the ARP table entry on the Ethernet interface.

**Command Modes** All modes

**Syntax** **show arp** [*<ip-addr>* | **dynamic** | **static** | **arp-to-static** | **interface**] *<interface-name>* [*<ip-addr>* | *<mac-addr>*] [**detail**]]]

**Syntax Description**

|                               |                                       |
|-------------------------------|---------------------------------------|
| <b>dynamic</b>                | Displays the dynamic ARP entry        |
| <b>static</b>                 | Displays the static ARP entry         |
| <b>arp-to-static</b>          | Displays the arp-to-static ARP entry  |
| <b>interface</b>              | Displays specified interface          |
| <b>detail</b>                 | Displays ARP entry-related attributes |
| <i>&lt;ip-addr&gt;</i>        | IP address                            |
| <i>&lt;interface-name&gt;</i> | Name of the Ethernet interface        |
| <i>&lt;mac-addr&gt;</i>       | MAC address                           |

**Instructions** The **show arp** command without parameters can show the corresponding relations between the IP address and MAC address in the ARP buffer of the Ethernet interface. If it is attached with the interface name, the ARP table of the specified Ethernet interface will be displayed.

**Example** This example describes how to display the ARP table of the fei\_1/1 interface.

```
ZXR10#show arp interface fei_1/1
Arp protect interface is disabled
The count is 2
IP           Hardware   External  Internal   Sub
Address      Age (min)  Address   Interface  VlanID  VlanID  Interface
-----
192.168.3.99  -          00d0.d0c5.eb80  fei_1/1    N/A     N/A     N/A
192.168.3.192  0          0019.21bf.c956  fei_1/1    N/A     N/A     fei_1/1
```

The displayed field descriptions are shown below.

| Field           | Description                                                                                                                                                                                    |
|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| IP Address      | IP address mapped to the MAC address                                                                                                                                                           |
| Age (min)       | Time interval from the last ARP update message received by the entry to the execution of this command in minute. If it is "-", the address is an interface address and shall be valid forever. |
| hardware add    | The MAC address, in dotted division format                                                                                                                                                     |
| interface       | Name of the Ethernet interface                                                                                                                                                                 |
| External VlanID | External VLAN flag of the ARP                                                                                                                                                                  |

| Field           | Description                   |
|-----------------|-------------------------------|
| Internal VlanID | Internal VLAN flag of the ARP |
| Sub Interface   | Subinterface of the ARP       |

**Related  
Commands**

**clear arp**  
**clear arp-cache**

## show detect-group

|                           |                                                                                                                   |                |                                       |
|---------------------------|-------------------------------------------------------------------------------------------------------------------|----------------|---------------------------------------|
| <b>Function</b>           | Use this command to display the current automatic detect group information.                                       |                |                                       |
| <b>Command Mode</b>       | All                                                                                                               |                |                                       |
| <b>Syntax</b>             | <b>show detect-group</b> <group-number>                                                                           |                |                                       |
| <b>Syntax Description</b> | <table border="1"> <tr> <td>&lt;group-number&gt;</td><td>Detect group No. in the range of 1~10</td></tr> </table> | <group-number> | Detect group No. in the range of 1~10 |
| <group-number>            | Detect group No. in the range of 1~10                                                                             |                |                                       |

**Instruction** The show detect-group command without parameters can show all configuration of automatic detect group. The command with parameters can show the specified detect group configuration.

**Example** This example describes how to view the detect group

```
XR10#show detect-group 1
=====
Information about group 1:
protocol in_use opt retry state loop_time(s) timeout(s)
NOT BIND NO AND 2 UNKNOWN 1 5

Items in this group:
=====
listNo destIP next_hop state
2 1.1.1.1 2.2.2.2 UNKNOWN
```

The displayed field descriptions are shown below.

|                           |                                                                                   |
|---------------------------|-----------------------------------------------------------------------------------|
| Information about group 1 | Information of detect group 1                                                     |
| protocol                  | The bound protocol                                                                |
| in_use                    | Whether it is in use (Yes/No)                                                     |
| opt                       | Relationship between objects in the group (AND/OR) The maximum retry times (1-10) |
| retry                     | The maximum retry times (1-10)                                                    |
| state                     | The detect group state                                                            |
| loop_time(s)              | Periodic check time in second                                                     |
| timeout(s)                | Timeout period in second                                                          |

|                      |                                 |
|----------------------|---------------------------------|
| Items in this group: | Detect object information       |
| listNo               | Detect object No.               |
| destIP               | Detect destination IP addresses |
| next_hop             | The next hop                    |
| state                | State of the detect object      |

## show ip forwarding

**Function** Use this command to show the entries in the unicast forwarding table.

**Command Mode** All

**Syntax** **show ip forwarding** {**hostrt** <ip-address>[<end-ip-address>]|**subnetrt** <ip-address><mask>| **summary**}

**Syntax Description**

|                  |                                                                                                                      |
|------------------|----------------------------------------------------------------------------------------------------------------------|
| <ip-address>     | Network segment address or host address, the initial host address of a segment(255 in total) in case of host routing |
| <end-ip-address> | End host address of a segment(255 in total) in case of host routing (optional)                                       |
| <mask>           | Mask of the host address (optional), or mask of the network segment address                                          |
| <b>summary</b>   | Summary of the unicast forwarding table                                                                              |

- Instructions**
- The unicast forwarding table includes host routes, subnet routes and summary of the forwarding table. This content of the unicast forwarding table will be displayed.
  - To display the host routes, <ip-address>is mandatory, and<end-ip-address>is optional. When<end-ip-address>is not specified, only one entry corresponding to the IP address will be displayed. Otherwise, all entries (no more than 255) within <ip-address> and<end-ip-address> will be displayed.

## show ip protocol routing

**Function** Use this command to display protocol stack route-related information.

**Command Mode** All

**Syntax** **show ip protocol routing** [**network** <ip-address>[**mask** <net-mask>]]

**Syntax Description**

|                             |                                               |
|-----------------------------|-----------------------------------------------|
| <b>network</b> <ip-address> | Network number in the dotted decimal notation |
| <b>mask</b> <net-mask>      | Network mask in the dotted decimal notation   |

**Instruction**

By default all protocol stack routes will be displayed. If the network number parameter is used, the network matched in the routing table will be displayed. If the network number and network mask parameters are used, the protocol routes that match the address/mask will be displayed.

## show ip protocol routing summary

**Function** Use this command to show the quantities of all kinds of protocol routes.

**Command Mode** All

**Syntax** **show ip protocol routing summary**

## show ip route

**Function** Use this command to display the global routing table.

**Command Mode** All

**Syntax** **show ip route** [<ip-address>[<net-mask>]]<protocol>  
**show ip route vpn**  
**show ip route vrf** <vrf-name>[**network** <ip-address>[**mask** <net-mask>]]  
**show ip route vrf-summary** <vrf-name>  
**show ip route other**

**Syntax Description**

|              |                                                                                                         |
|--------------|---------------------------------------------------------------------------------------------------------|
| <vrf-name>   | Name of the VRF where the route entries are, 1 ~ 16 characters                                          |
| <ip-address> | Prefix of the network where the routes are, in the dotted decimal notation                              |
| <net-mask>   | Network mask of the routes, in dotted decimal notation.                                                 |
| <protocol>   | Name of the route protocol or keyword, which may be static, connected, BGP, OSPF, RIP, address or ISIS. |



- Instructions**
- **show ip route** displays all routes.
  - **show ip route <protocol>** displays the routes of the specified protocol or keyword.
  - **show ip route vpn** shows the routes in all VPNs.
  - **show ip route vrf <vrf-name>** shows specific VPN route.
  - **show ip route vrf <vrf-name> network <ip-address> [mask <net-mask>]** displays the specified routes in the specified VPN.
  - **show ip route vrf-summary <vrf-name>** shows the number of routes in the specified VPN.
  - **show ip route other** displays the routes produced after the configuration of NAT, NAT-PT and VRRP.
  - As ZXR10 3900/3200 does not support MPLS VPNs, it does not provide commands **show ip route vpn**, **show ip route vrf**, and **show ip route vrf-summary**

**Example** This example describes how to display the global routing table.

```
ZXR10#show ip route
IPv4 Routing Table:
Dest    Mask      Gw          Interface  Owner    pri  metric
120.1.1.0 255.255.255.0 120.1.1.1  pos3_2/1  direc   0    0
120.1.1.1 255.255.255.255 120.1.1.1  pos3_2/1  addre   0    0
120.2.4.0 255.255.255.0 120.1.1.2  pos3_2/1  stati   1    0
130.1.2.0 255.255.255.0 150.1.1.2  pos48_5/1 ospf    110   2
```

The displayed field descriptions are shown below.

| Field     | Description                                                                                                                                                                                                                                                                                 |
|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Dest      | Address of the destination IP network                                                                                                                                                                                                                                                       |
| Mask      | Network mask                                                                                                                                                                                                                                                                                |
| Gw        | Next-hop IP address.                                                                                                                                                                                                                                                                        |
| Interface | Specified interface                                                                                                                                                                                                                                                                         |
| Owner     | Source of the route, that is, the routing protocol or keyword ospf: routes generated by the ospf rip: routes generated by the RIP bgp: routes generated by the BGP Isis: routes generated by the IS-IS Direc: directly-connected routes Stati: static routes Adder: interface address route |
| pri       | Administrative distance of the information source, that is, the priority                                                                                                                                                                                                                    |
| metric    | Metric of the route                                                                                                                                                                                                                                                                         |

## show ip traffic

- Function** Use this command to display the statistics of IP transmission.
- Command Mode** All
- Syntax** **show ip traffic**

- Instructions**
- Display all the statistics information of all the protocols (including the dynamic routing protocol) on the IP layer.
  - The statistics of the IP layer protocol packets include the following contents:
    - ▶ IP statistics: number of received packets, number of sent packets, fragment statistics, and broadcast packet statistics.
    - ▶ ICMP statistics: packets received, and packet sent.
    - ▶ ARP statistics: Number of received packets and number of sent packets.
    - ▶ TCP statistics: number of packets received, number of packets with checksum errors, and the number of packets sent.
    - ▶ UDP statistics: number of packets received, number of packets with checksum errors, and number of erroneous packets on the receiving port.
    - ▶ URPF statistics: number of packets that are dropped for not passing the URPF check.
  - ZXR10 GAR, ZXR10 ZSR, ZXR10 GER, ZXR10 T128 and ZXR10 T1200 support the display of URPF counter.

**Example** This example describes how to display the statistics on IP transmission.

## show ntp status

- Function** Use this command to display the NTP running status.
- Command Mode** All modes except exec
- Syntax** show ntp status
- Related Commands** **ntp enable**  
**ntp server**

## show tcp

- Function** Use this command to display the relevant parameters of all TCP connections.
- Command Mode** All
- Syntax** **show tcp**
- Example** This example describes how to display the relevant parameters of all the TCP connections.

## show tcp brief

- Function** Use this command to display the brief descriptions of all the TCP connections.
- Command Mode** All
- Syntax** **show tcp brief**
- Example** This example describes how to display the brief descriptions of all the TCP connections.

```
ZXR10#show tcp brief
TCB Local Address Foreign Address (state)
2843616 168.1.200.100.23 168.1.15.168.1037 ESTAB
2843176 168.1.200.100.23 168.1.12.102.1282 ESTAB
2843176 202.119.21.202.23 202.119.21.2.1265 ESTAB
```

## show tcp config

- Function** Use this command to display the TCP configuration parameter information.
- Command Mode** All
- Syntax** **show tcp config**
- Example** This example describes how to display the TCP configuration parameter information.

```
ZXR10#show tcp config TCP SYNWAIT: 50 TCP FINWAIT:
400 TCP QUEUEMAX: 40 TCP WINDOWSIZE: 2000
```

## show tcp line

- Function** Use this command to display the relevant TCP connection parameters of the corresponding connection in the specified row.
- Command Mode** All
- Syntax** **show tcp line <line-number>**

**Syntax Description**

|               |         |
|---------------|---------|
| <line-number> | 66 ~ 81 |
|---------------|---------|

- Example** This example describes how to display the TCP connection parameters in row 66.

```
ZXR10#show tcp line 66
tty 66,virtual tty from host 10.40.53.2
Connection state is ESTAB, I/O status: 1, unread input bytes: 1
Local host: 10.40.88.18, Local port: 23
Foreign host: 10.40.53.2, Foreign port: 1047
Enqueued packets for retransmit: 10, input: 195
mis-ordered: 0 (0 bytes)
```

```
Event Timers (Current time is 0x9ff0268):
Timer Starts Wakeups
```

```

Retrans      84      10
TimeWait     0        0
AckHold      52      18
KeepAlive    0        0
Persist      0        0
SynWait      1        0
FinWait      0        0

iss:2410219336 snduna:2410222919 sndnxt:2410222919 sndwnd:8576
irs: 927547 rcvnxt: 927671 rcvwnd: 2021
SRTT: 1962 ms, RTTO: 751 ms, KRTT: 751 ms
minRTT: 40 ms, maxRTT: 2164 ms, ACK hold: 200 ms
Flags:Passive open,higher precedence,retransmission timeout

Datagrams (max data segment is 536 bytes):
Rcvd:195 (out of order:0),with data:79, total data bytes:123
Sent:100 (retransmit:10),with data:73, total data bytes:3040

```

## show tcp statistics

- Function** Use this command to display the statistic parameters of the TCP layer.
- Command Mode** All
- Syntax** show tcp statistics
- Example** This example describes how to display the statistic parameters of the TCP layer.

```

ZXR10#show tcp statistics Rcvd: 2966 Total,
  0 no port 0 checksum error, 0 bad offset, 0 too short 2955
packets (12107 bytes) in sequence 0 out-of-order packets (0 bytes)
0 packets (0 bytes) with data after window 0 packets after close
0 window probe packets, 2058 window update packets 38 dup ack
packets, 0 ack packets with unsend data 2960 ack packets
(12123 bytes) Sent: 2420 Total, 0 urgent packets 172 control
packets (including 126 retransmitted) 2124 data packets
(70207 bytes) 468 data packets (10748 bytes) retransmitte)
30 ack only packets (0 delayed) 0 window probe packets,
64 window update packets 42 Connections initiated,
  4 connections accepted, 4 connections established,
41 Connections closed , 594 Total rxmt timeout, 0 connections
dropped in rxmt timeout 0 Keepalive timeout, 0 keepalive probe,
0 Connections dropped in keepalive

```

## show tcp tcb

- Function** Use this command to display the relevant parameters of the connection corresponding to the specified TCB.
- Command Mode** All
- Syntax** show tcp tcb <tcb-address>
- Syntax Description**
- |               |                |
|---------------|----------------|
| <tcb-address> | 0 ~ 4294967295 |
|---------------|----------------|
- Example** This example describes how to display the relevant parameters of the connection corresponding to the TCB 3507808.

```

ZXR10#show tcp tcb 3507808
Stand-alone TCP connection from host 168.1.16.140
Connection state is ESTAB, I/O status: 1, unread input bytes: 1
Local host: 168.1.168.168, Local port: 21
Foreign host: 168.1.16.140, Foreign port: 1804
Enqueued packets for retransmit: 0, input: 3
mis-ordered: 0 (0 bytes)

Event Timers (Current time is 0x39f490):
Timer      Starts  Wakeups
Retrans    2      0
TimeWait   0      0
AckHold    0      0
KeepAlive  0      0
Persist    0      0
SynWait    0      0
FinWait    0      0

iss: 911535000 snduna: 911535060 sndnxt: 911535060 sndwnd: 16557
irs: 3109854539 rcvnxt: 3109854540 rcvwnd: 2144
SRTT: 258 ms, RTTO: 1973 ms, KRTT: 1973 ms
minRTT: 0 ms, maxRTT: 20 ms, ACK hold: 200 ms
Flags: Passive open, higher precedence, retransmission timeout

Datagrams (max data segment is 536 bytes):
Rcvd: 3 (out of order: 0), with data: 0, total data bytes: 0
Sent: 2 (retransmit: 0), with data: 1, total data bytes: 59

```

## show tcp tty

**Function** Use this command to display the relevant parameters of the connections whose terminal type is tty.

**Command Mode** All

**Syntax** **show tcp tty** <tty-number>

**Syntax Description**

|              |         |
|--------------|---------|
| <tty-number> | 66 ~ 81 |
|--------------|---------|

**Example** This example describes how to display the related parameters of the connection of tty terminal 67.

```

ZXR10#show tcp tty 67
tty 67,virtual tty from host 168.1.16.140
Connection state is ESTAB, I/O status: 1, unread input bytes: 1
Local host: 168.1.168.168, Local port: 23
Foreign host: 168.1.16.140, Foreign port: 1803
Enqueued packets for retransmit: 5, input: 1664
mis-ordered: 0 (0 bytes)

Event Timers (Current time is 0x616d40):
Timer      Starts  Wakeups
Retrans    1054    5
TimeWait   0      0
AckHold    605    12
KeepAlive  0      0
Persist    0      0
SynWait    0      0
FinWait    0      0

iss:602165000 snduna:602227443 sndnxt:602227443 sndwnd: 16116
irs:2800883239 rcvnxt: 2800884272 rcvwnd: 1112
SRTT: 1580 ms, RTTO: 361 ms, KRTT: 361 ms
minRTT: 0 ms, maxRTT: 1667 ms, ACK hold: 200 ms
Flags:Passive open, higher precedence,retransmission timeout

```

```
Datagrams (max data segment is 536 bytes):
Rcvd:1664 (out of order: 0), with data: 915,total
data bytes: 1035
Sent:1100 (retransmit: 5), with data: 1083,total
data bytes: 62442
```

## show tcp vty

|                           |                                                                                                                                                     |  |                   |                               |
|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|--|-------------------|-------------------------------|
| <b>Function</b>           | Use this command to display the relevant parameters of the connections whose terminal type is vty and display TCP connection information of telnet. |  |                   |                               |
| <b>Command Mode</b>       | All                                                                                                                                                 |  |                   |                               |
| <b>Syntax</b>             | <b>show tcp vty</b> <i>&lt;vty-number&gt;</i>                                                                                                       |  |                   |                               |
| <b>Syntax Description</b> | <table><tr><td><i>vty-number</i></td><td>Quantity of the vtys, 0 ~ 15.</td></tr></table>                                                            |  | <i>vty-number</i> | Quantity of the vtys, 0 ~ 15. |
| <i>vty-number</i>         | Quantity of the vtys, 0 ~ 15.                                                                                                                       |  |                   |                               |

**Example** This example describes how to display the related parameters of the connection of the vty terminal.

```
ZXR10#show tcp vty 1
tty 67,virtual tty from host 168.1.16.140
Connection state is ESTAB, I/O status: 1, unread input bytes: 1
Local host: 168.1.168.168, Local port: 23
Foreign host: 168.1.16.140, Foreign port: 1803
Enqueued packets for retransmit: 7, input: 1734
mis-ordered: 0 (0 bytes)

Event Timers (Current time is 0x631f50):
Timer      Starts    Wakeups
Retrans    1100      7
TimeWait   0         0
AckHold    629      14
KeepAlive  0         0
Persist    0         0
SynWait    0         0
FinWait    0         0

iss:602165000 snduna:602230281 sndnxt:602230295 sndwnd:16592
irs: 2800883239 rcvnxt: 2800884316 rcvwnd: 1068
SRTT: 1462 ms, RTTO: 297 ms, KRTT: 297 ms
minRTT: 0 ms, maxRTT: 1667 ms, ACK hold: 200 ms
Flags: Passive open, higher precedence, retransmission timeout

Datagrams (max data segment is 536 bytes):
Rcvd: 1734 (out of order: 0),with data: 954,
total data bytes: 1079
Sent: 1148 (retransmit: 7), with data: 1128,
total data bytes: 65294
```

## show vlan-forwarding

|                     |                                                               |
|---------------------|---------------------------------------------------------------|
| <b>Function</b>     | Use this command to display the VLAN forwarding table.        |
| <b>Command Mode</b> | All modes except exec                                         |
| <b>Syntax</b>       | <b>show vlan-forwarding</b> [ingress <interface-name>]   all] |

**Syntax Description**

|                                 |                       |
|---------------------------------|-----------------------|
| <b>ingress</b> <interface-name> | Name of the interface |
|---------------------------------|-----------------------|

## trace

**Function** Use this command to trace the path to the destination.

**Command Mode** Exec and Privileged

**Syntax** **trace** [**vrf** <vrf-name>]<ip-address>(**Exec mode**)

**trace** [**vrf** <vrf-name>]<ip-address>[**option** <source-address> <tll>]**Privileged mode**

**Syntax Description**

|                       |                                                       |
|-----------------------|-------------------------------------------------------|
| <ip-address>          | Destination IP address in the dotted decimal notation |
| <b>vrf</b> <vrf-name> | VPF name, with 1~16 characters                        |
| <source-address>      | Source address in the dotted decimal notation         |
| <tll>                 | Set ttl value,the range 1~255                         |

**Instruction** The trace command works on ICMP error message. This occurred on data packet not more than TTL value. If the timer stops before the response arrives, the trace will print a "\*\*".

**Example** This example describes how to trace the path to 168.1.10.100.

```
ZXR10#trace 168.1.10.100
tracing the route to 168.1.10.100
 1  168.1.10.100    2 ms  3 ms  5 ms
[finished]
```

The displayed information descriptions are shown below.

|                      |                                                                                      |
|----------------------|--------------------------------------------------------------------------------------|
| <b>1</b>             | Route sequence number of the router to the destination route.                        |
| <b>168.1.10.100</b>  | IP address of a hop router in the route. The last one is the destination IP address. |
| <b>2ms 3 ms 5 ms</b> | Wrap time of each of the three detections to be sent                                 |

## trace mpls

**Function** Use this command to trace the LSP path to the destination.

**Command Mode** Privileged

**Syntax** **trace mpls** {**ipv4** <ip-address><destination-mask>| **traffic-eng** <tunnel-interface>}[**revision** <revision>][**timeout** <timeout>][**tll** <tll>]

**Syntax Description**

|                                 |                                                                       |
|---------------------------------|-----------------------------------------------------------------------|
| <i>&lt;ip-address&gt;</i>       | Destination IP address in the dotted decimal notation                 |
| <i>&lt;destination-mask&gt;</i> | Length of LDP LSP destination address masks                           |
| <i>&lt;tunnel-interface&gt;</i> | MPLS TE tunnel                                                        |
| <i>&lt;revision&gt;</i>         | revision draft                                                        |
| <i>&lt;timeout&gt;</i>          | Timeout period in second, in range 1~60. By default, it is 2 seconds. |
| <i>&lt;ttl&gt;</i>              | Set ttl value,the range 1~255                                         |

**Instruction**

The **trace mpls** command works on specified FEC forwarding packets and verifies the integrity of LSP (from Ingress LSR to Egress LSR) belonging to this FEC. MPLS traceecho request message contains information of the FEC. MPLS trace packet is encapsulated in UDP packet, containing serial No. and time parameter. When processing MPLS trace request, MPLS adopts the same forwarding policy as FEC packet. When trace mpls is used to check the connectivity, the packet is sent to LSP egress. In the egress LSR control plane checks packets to verify whether the LSP is the real egress of the FEC. If the timer stops before the response arrives, the trace mpls will print a ".".

**Example**

This example describes how to trace the path to 173.13.13.8/32.

```
ZXR10#trace mpls ipv4 173.13.13.8 32
tracing mpls to 173.13.13.8
Codes: '!' - success, 'Q' - request not transmitted,
        '.' - timeout, 'U' - unreachable,
        'R' - downstream router but not target
0  4.15.4.7 MRU 1500 [label 0 ]
! 1  4.15.4.8 1 ms
[finished]
```

The displayed information descriptions are shown below.

|                |                                                                                      |
|----------------|--------------------------------------------------------------------------------------|
| 1              | Route sequence number of the router to the destination route.                        |
| 4.15.4.8       | IP address of a hop router in the route. The last one is the destination IP address. |
| 1 ms 3 ms 5 ms | Wrap time of each of the three detections to be sent                                 |

## vlan arp-mode

**Function**

Use this command to set the transparent transmission mode of ARP packets between VLANs.

**Command Mode**

Interface configuration

**Syntax**

**vlan arp-mode {discard | forwarding}**



**Syntax  
Description**

|                   |                                                  |
|-------------------|--------------------------------------------------|
| <b>discard</b>    | Discards ARP packets between VLANs               |
| <b>forwarding</b> | Transparently forwards ARP packets between VLANs |

**Defaults** ARP packet is discarded.

- Instruction**
- This command can be used when the forwarding mode of the interface is set to vlan-switch with the ip forwarding-mode command.
  - It is applicable only to ZXR10 GER.

**Related Command** **ip forwarding-mode**

## vlan-forwarding

**Function** Use this command to set the VLAN forwarding table.

**Command Mode** Global configuration

**Syntax** **vlan-forwarding ingress** <interface-name><vlan-id> **egress** <interface-name><vlan-id>[**range** <range>][**dual** | **single**]  
**no vlan-forwarding ingress** <interface-name><vlan-id>

**Syntax  
Description**

|                      |                                                       |
|----------------------|-------------------------------------------------------|
| <interface-name>     | Name of the interface                                 |
| <vlan-id>            | VLAN ID, 0 ~ 4095                                     |
| <b>range</b> <range> | VLAN ID range, 0 ~ 4095                               |
| <b>dual</b>          | Dual-direction V_Switch forwarding table, the default |
| <b>single</b>        | Single-direction V_Switch forwarding table            |

**Instruction** It is applicable only to ZXR10 GER.

**Related Command** **ip forwarding-mode**